



SERVICE MANUAL

ENGLISH

AXOR INDUSTRIES[®] MOTORS & DRIVES



Micro B Net Digital Brushless Servo Drive

Release	Notes
ver.1 rel.12/'05	New paging. Insert: Positioning and Homing Procedures Corrections.
ver.1 rel.09/'06	New paging. Update chapters: "General Advices", "Installation", "Interfaces", "Diagnostic", "Appendix". Insert chapter: "Applications". Insert Index. Corrections.
ver.1 rel.01/'07	Update chapter: "5: Diagnostic". A new chapter reserved to Positioner and Homing procedure was created. Update chapter "6: Speeder One". Update chapter "7: Applications": Reset Fault Function, Emergency Function. Corrections.
ver.1 rel.04/'07	Update chapter: "4: Interface". Corrections.
ver.2 rel.09/'07	Manual re-organisation: first base version.
ver.2 rel.02/'08	Figures at page 36 and 37 changed. Corrections.
ver.2 rel.12/'08	Insert note about motor brake connection. Figure pag.25 updated. Corrections.
ver.2 rel.01/'10	Corrections.
ver.2 rel.09/'18	Update chapter: "2: Installation" with RS232 connection.

All rights reserved. Reproduction in whole or in part is prohibited without prior written consent of the copyright owner. All specifications are subject to change without prior notification.
This manual has been carefully checked. However, Axor does not assume liability for errors or inaccuracies.

Print in Italy 09/2018



**THIS MANUAL CONTAINS A DESCRIPTION OF McbNET Digital™
AND A GUIDELINES FOR THE DRIVE'S INSTALLATION;
FOR MORE DETAILS SEE ENCLOSURES ON THE CD PROVIDED WITH THE DRIVE.**

**USING THE DRIVE INCORRECTLY CAN INJURE PEOPLE OR DAMAGE THINGS.
FULLY RESPECT THE TECHNICAL DATA AND INDICATIONS ON CONNECTION
CONDITIONS.**

Summary

1) Description

1.1 Description	6
1.2 General view McbNET Digital	9
1.3 Technical Data	10
1.4 Mechanical Dimension	12
1.5 Product plate and Ordering Code	13

2) Installation

2.1 General Advices	16
2.2 Positioning	19
2.3 Environmental conditions	20
2.4 Cables	21
2.5 Connection to ground and earth	22
2.6 Note about cable shielding	23
2.7 Base installation procedure	24
2.8 Example of base connection	25
2.9 Supply connections	26
2.10 Motor power connection	29
2.11 Relè OK and Back UP supply connections	30
2.12 Regen resistance connection	31
2.13 Digital inputs connection	32
2.14 Digital outputs connections	33
2.15 Analog outputs connections	34
2.16 Analog inputs connections	35
2.17 Emulated encoder outputs connection	36
2.18 Pulse/Dir inputs connections	37
2.19 Feedback signals connections	39
2.20 RS232 connection	41
2.21 Multidrop connection	42
2.22 Canbus connection	43
2.23 Motor Test	44

3) Diagnostic

3.1 Display	48
3.2 Alarms	49

Index	51
--------------	-----------

Conformity	53
-------------------	-----------

Enclosures to the manual

On the CD provided with the drive there are the following enclosures (in pdf):

- Operative Modes Manual
- Additional Features Manual
- Speeder One Interface
- Positioner Manual
- Display and Keypad Manual
- Alarms Manual
- ModBus Manual
- CanOpen Reference Manual
- Cables Manual
- Oscilloscope Manual
- Procedures Manual (*available only on request*)

Chapter 1

Description

1.1 Description	6
1.2 General view McbNET Digital	9
1.3 Technical Data	10
1.4 Mechanical Dimension	12
1.5 Product plate and Ordering Code	13

1.1 Description

The **McbNET Digital™** is a digital drive capable of piloting both rotary AC brushless motors and linear motors, up to **7,5Nm**. It can be supplied by a 3-phase or single phase voltage equal to **110** or **230Vac**.

OPERATIVE MODES		
SPEED CONTROL	It is speed piloting utilising a digital reference or an analogue reference (differential or common mode).	standard
TORQUE CONTROL	It is torque piloting utilising a digital reference or an analogue reference. This function allows you to control the current from the drive.	standard
POSITION CONTROL	The positioner can be managed via hardware (by using the digital inputs) or via RS232 (by using the Axor's <i>Speeder One</i> interface or another ModBus Master). It supports <i>32 programmable position profiles; a single task or a sequence of tasks</i> are permitted. The Homing Procedure is implemented. It uses the signal coming from the <i>homing sensor</i> and eventually the <i>zero signal</i> of the encoder.	standard
ELECTRICAL AXIS (GEARING)	It is possible to pilot the drive with the quadrature signals of an emulated encoder from a Master drive or with the quadrature signals of an incremental encoder from a Master motor (Electrical Axis or Gearing).	standard
PULSE/DIRECTION	It is possible to connect the drive to a stepper-motor controller , piloting it with the +/-Pulse and +/-Dir signals (Pulse/Dir Mode).	standard
MULTIDROP RS232	It can work in Multidrop , where the first drive, connected via RS232 to the Master PC, is piloted with <i>ModBus communication</i> , while the other drives are piloted with the duplication of commands using the <i>CanBus interface</i> .	<i>optional</i>
CANBUS	It can be configured and controlled using CanBus . It supports the following Can Open protocols: <ul style="list-style-type: none"> • part of the DS301-V4.02 • part of the DSP402-V2.0 	<i>optional</i>
Notes: <ul style="list-style-type: none"> • The current controller is vectorial with sampling time of 50µs. The velocity and position loop both work with sampling time of 200µs. • The current commutation is sinusoidal. 		
FEEDBACK		
ENCODER	incremental encoder signals plus hall signals	standard
RESOLVER	2 pole	<i>optional</i>

1.1 Description


DIGITAL INPUTS/OUTPUTS		
9 DIGITAL INPUTS	They are programmable for: the limit switch, the holding brake, the homing and positioning procedures, the emergency stop, the reset alarm, etc.	standard
2 programmable DIGITAL OUTPUTS	They can be used to send messages from pre-programmed functions of the drive.	standard
EMULATED ENCODER OUTPUTS	There are 6 pins dedicated to emulated encoder with different programmed ratios (1/2, 1/4, 1/8, 1/16, 1/32, 1/64, 1/128) between output pulse/rev and encoder/resolver ones.	standard
ANALOG INPUTS/OUTPUTS		
1 ANALOG COMMON MODE INPUT (TPRC)	It is used for controlling the current from the drive.	standard
1 ANALOG DIFFERENTIAL or COMMON MODE INPUTS (+/-Vref)	It is used for piloting the drive with an analogue speed reference from an external controller.	standard
2 programmable ANALOG OUTPUTS	They allow you to visualise by the oscilloscope some of the drive's measurement values (for example: the velocity, the Iq current, etc.)	standard
GENERAL FEATURES		
KEYPAD	Four buttons (UP-DW-MODE-SET) allow the manual insertion of data without using a PC.	standard
DISPLAY	A display with 3 characters visualises: the inserted values, the drive's status, the alarms.	standard
SPEEDER ONE SOFTWARE INTERFACE	It allows you to set and manage all drive's parameters by using a PC connected to the drive. The communication between the drive and PC is done by a RS232 cable using the ModBUS protocol. The software works on the following operating systems: Windows 98, Windows 2000, Windows XP.	standard

1.1 Description

EMI FILTER	The drive is equipped with an integrated EMI anti-disturbance filter at the 3-phase power supply input.	standard
REGEN CIRCUIT		standard
EXPANSION CARDS	There is a slot for expansion card to implement additional features.	<i>optional</i>
SAFETY		
SAFETY	The converter is protected from short circuitry, the Max/Min Voltage, the drive I ² t , the Motor I ² t , etc. When there is an alarm the "Relè OK" contact opens and the motor is stopped, or a message is visualised on the display without compromising the system's functioning.	standard
EQUIPMENT		
a drive serie McbNET Digital™		standard
terminals: M1, M2A, M2B, M2C, M2D, M3		
Service Manual		
a CD-ROM with Speeder One software interface and all enclosures to service manual		<i>optional</i>
Motor inductance, 3x1.2mH, for cables over 20/25 meters in length		
an external braking resistor 200W - 22 ohm		
CBLS cable for motor feedback signal, encoder/resolver (meter multiple)		
CBLS power cable for motors series <i>SuperSAX</i> ; motors series <i>SuperSAX</i>		

All *optional* features have to be requested by using the proper ordering code (see "1.5 Product plate and Ordering code").

1.2 General view McbNET Digital



1.3 Technical Data

Rated Data					
Nominal Voltage	Vac	3-Phase: from 3x110Vac (-10%) to 3x230Vac (+10%), 50/60Hz Single phase: from 1x110Vac (-10%) to 1x230Vac (+10%), 50/60Hz			
Internal DC BUS (+AT, -AT)	Vdc	85 Vdc min - 400 Vdc max			
Size		2/4	4/8	6/12	8/16
Nominal current	Arms	2	4	6	8
Peak current for 2 sec.	Arms	4	8	12	16
Dissipation at nominal current	W	28	42	58	76
Dissipation with output stage disabled	W	12			
PWM output frequency	kHz	10			

Control signals	
Opto-isolated digital inputs	+24Vdc - 7mA (PLC compatible)
Opto-isolated digital outputs	+24Vdc - 50mA (PLC compatible)
Analog programmable outputs	±10V (±5%)
Common mode analog input (TPRC)	±10V max, 10kOhm input resistance
Differential or common mode analog input	±10V max, 40kOhm input resistance
Pulse/Dir digital inputs	+5V, optoisolated, max frequency 200kHz
Auxiliary supply input (+14Vdc)	+14V (±5%), 50mA max.
Emulated encoder outputs	$V_{OH}=2.5V \text{ min} - I_{OH}=-20mA$ $V_{OL}=0.5V \text{ max} - I_{OL}=20mA$


External braking resistor		
Continuous power of the braking module	W	200W max a 45°C
Brake circuit disconnection point DC	Vdc	370-375
Max Brake circuit set point DC	Vdc	385
Value of the resistor	Ohm	≥22 per 200W

1.3 Technical Data

Motor encoder inputs	
Encoder supply	+5V @ 220mA (±5%)
Differential encoder inputs line receiver RS485	AM26LS33
Differential hall signal inputs line receiver RS485	AM26LS33
Encoder max frequency	250kHz

External protections (fuses or similar)				
Size	2/4	4/8	6/12	8/16
F ₂ : Supply Line fuses (Time-Lag)	3A / 250V	5A / 250V	8A / 250V	10A / 250V
F ₃ : External braking resistor fuses	4A F (Fast)			


1.4 Mechanical Dimension




Mechanical properties					
Drive mounting		Panel			
Size		2/4	4/8	6/12	8/16
Radiator's case		PM4	PM4	PM4B	PM4V
External dimensions [mm]	H	137,7	137,7	137,7	137,7
	L	58	58	80	81
	S	127	127	127	127
Weight	Kg	0,6	0,6	0,7	1

1.5 Product plate and Ordering Code

On the side of each **McbNET Digital™** there is a **product plate** like the following:



To order a digital drive serie **McbNET Digital™** refer to this **ordering code**:





Chapter 2

Installation

2.1 General Advices	16
2.2 Positioning	19
2.3 Environmental conditions	20
2.4 Cables	21
2.5 Connection to ground and earth	22
2.6 Note about cable shielding	23
2.7 Base installation procedure	24
2.8 Example of base connection	25
2.9 Supply connections	26
2.10 Motor power connection	29
2.11 Relè OK and Back UP supply connections	30
2.12 Regen resistance connection	31
2.13 Digital inputs connection	32
2.14 Digital outputs connections	33
2.15 Analog outputs connections	34
2.16 Analog inputs connections	35
2.17 Emulated encoder outputs connection	36
2.18 Pulse/Dir inputs connections	37
2.19 Feedback signals connections	39
2.20 RS232 connection	41
2.21 Multidrop connection	42
2.22 Canbus connection	43
2.23 Motor Test	44

2.1 General Advices

Transport

During the transport of the drive respect the following indications:

- the transport must be made by qualified personnel;
- avoid shocks;
- the temperature range must be between -20°C and +55°C;
- the max. humidity must be 95% (without condensation);
- the converters contains elements which are sensitive to electrostatic discharges. These elements can be damaged by careless manipulation.

Discharge static electricity from your body before touching the converter.

Avoid contact with material that insulates well (synthetic fibres, films of plastic material and so forth).

- we suggest to check the motor condition at its arrival to survey eventual damages.

Storage

The unused drives must be storage in an environment having the following characteristics:

- temperature from -20°C to +55°C;
- max. relative humidity 95% (without condensation);
- max. time with the drive powered off (without supply connections):
 - ✓ drive having a power supply $\geq 220\text{VAC}$ \Rightarrow **1 year**
 - ✓ drive having a power supply $\leq 145\text{VAC}$ (200VDC) \Rightarrow **2 years**

After this time, before enable the drive, it is necessary activate the capacitors following this procedure: remove all electrical connections, then supply the input terminals of the supply with the main voltage (three phase or single phase) for 30 minutes. So, in this case power the **McbNET Digital™** by using a single phase (or three phase) supply equal to 110÷130VAC.

In order to avoid this procedure, we suggest to power on the drive with its rated voltage for 30 minutes, before the max. time is reached.

Maintenance

The drives does not need maintenance.

Otherwise:

- if the casing is dirty: clean it with isopropanol or similar;
- if the drive is dirty: the cleaning is reserved to the producer;
- if the fans are dirty: clean them by using a dry brush.

Disposal

The disposal should be carried out by a certified company.

2.1 General Advices

Security standard

• **This manual is exclusively addressed to technical personnel with the following requirements:**

- **Technician with knowledge on movimentation of elements sensitive to electrostatic discharges (for the transport).**
- **Technician with appropriate technical training and with vast knowledge on electrotechnics/drive technical field (for the installation and operation of servodrives).**

Using the drive incorrectly can injure people or damage things. Fully respect the technical data and indications on connection conditions.



• As well as the points described in this manual, current regulations regarding safety and accident prevention must be followed in order to prevent accidents and residual risks.

• The user must analyse possible machine risks and take the necessary measures to avoid injuries to people and damage to things because of unpredictable movements.

• The converters contains elements which are sensitive to electrostatic discharges. These elements can be damaged by careless manipulation.

Discharge static electricity from your body before touching the converter.

Avoid contact with material that insulates well (synthetic fibres, films of plastic material and so forth).

• During operation, the converter surface can become hot. Protect the user from accidental contact and keep the indicated distances from all objects.

• Never loosen electrical connections while the servoamplifiers are being powered.

The appropriate terminals of the drive must always be connected to earth as instructed in this manual. After having disconnected the converters from the supply current, always wait at least 5 minutes before touching the powered components (e.g. contacts) or loosening connections.

• Switch off the converter and wait at least 5 minutes before opening it. Remove the fuses or switch off the main switch before removing the drive. When opening, place the converter on a surface that does not belong to the electrical panel.

• The residual charges in the capacitors can remain at a dangerous level for up to 5 minutes after disconnection from the mains. Measure the voltage at the intermediate circuit (+AT/-AT) and wait until it is below 15V.

• The command and power connections can still hold current even when the motor has stopped.

• The **McbNET Digital™** is equipped with electronic protections that deactivate it in case of irregularities. The motor, as a result, is not controlled and can stop or go into neutral (for a time determined by the type of system).


• During installation, avoid letting any residue with metallic components fall inside the drive.

2.1 General Advices

- Protect the converter from excessive mechanical vibrations in the electrical box.
- Check that the main supply and the nominal current are coherent with the rating of the drive. Be sure that the voltage between the connectors L1-L2-L3 is not greater than 10% of the nominal values. An excessively high voltage causes the breakdown of the load circuitry and of the drive.
- The **McbNET Digital™** is equipped with an integrated **EMI anti-disturbance filter** at the 3-phase power supply input.
Being implicit to filter operation the deviation towards earth or mass of the undesired frequencies, ensure that these devices can produce leakage currents towards earth, which are measurable in milliAmps. Please remember that "leakage currents" must be considered when settings differential devices in order to avoid useless interventions.
For safety reasons connect the prepared terminal to earth before powering the drive. Incorrect connections make filter operation unreliable.

2.2 Positioning

The **McbNET Digital™** is made to be fixed vertically to the **bottom of the electrical box** in order to guarantee reliable cooling, respecting the following distances:



Note: Arrange the power components (converters, main's filters, resistors, terminals, ...) in bins of the electrical panel different from those reserved to the command or control systems (PLC, PC, CNC, regulators, ...). This improves the level of immunity to interference of the system.

2.3 Environmental conditions

During the storage and the installation respect the followings environmental conditions:

Environmental conditions	
Ambient temperature in operation	From 0°C to +45° C (no derating). From +45°C to +55°C the drive must be derated 2.5%/°C in reference to nominal and peak current.
Storage temperature	-20°C...+55°C
Humidity	10%...85% without condensation
Altitude	Up to 1500m without restrictions. From 1500m to 2500m the output current must be derated 2%/100m.
Enclosure protection	IP20
Pollution level	LEVEL 2 Norm EN60204/EN50178

Notes:

- The electrical box must have suitably **filtered air vents**.
Leave the necessary space both above and below the converters.
- Periodically check drive case and fans for excess dust or dirt, that could interfere with the correct dissipation of the drive.

2.4 Cables

The following table illustrates the technical characteristics of all cables:


Cables (as norm EN60204)		
Type	Section	Notes
for the Main Supply	1.5mm ² /15AWG	Always insert a power relay or a thermal magnet on every phase of the products power supply.
for the Auxiliary Supply	1.5mm ² /15AWG	Connect the 0V of the auxiliary supply to the ground bar.
for the Motor's Brake	0.75mm ²	It must shielded.
for the Motor's Power	1.5mm ² /15AWG	It must be shielded. It must have a capacity of ≤150pF/m. In the configuration without filter, the cable can reach a maximum length of 20/25m. If the length exceeds 20/25m, insert an Axor 3x1.2mH filter.
for the Control signals and I/O signals from PLC/CNC	0.5mm ² /20AWG	See "2.6 Note about cable shielding".
for the Encoder signals	0.25-0.35mm ² / 22-24AWG	It must be shielded.
for the Resolver signals		It must have a capacity less than 120pF/m.
for external resistor	1.5mm ² /15AWG	The cable must be as short as possible. If the cable length is greater than 20/30cm, it must be twisted and shielded. The shield must be connected to ground on both ends, utilising u-clamps to the zinced panel of the electrical box.
for the RS232 communication	0.22mm ² /24AWG or 0.34mm ² /22AWG	The length of the cable must be equal to or less than 2.5m. It must be connected when the main supply and the auxiliary supply are both powered off. It must have a capacity less than 160pF/m.
for the CanBus communication	0.25mm ² /0.34mm ²	Cable capacitance: max 60 nF/km. Impedance characteristics : 100...120Ω. Lead resistance (loop): 159,8 Ω/km. The length depends upon the transmission speed: <ul style="list-style-type: none"> • 1000kbit/s ⇨20m max; • 500kbit/s ⇨70m max; • 250kbit/s ⇨115m max.
<p>Note:</p> <ul style="list-style-type: none"> • Avoid crossing, overlapping and twisting cables together. If it is absolutely necessary to cross them, do so at 90°. • On request Axor provides motor signal cables series <i>encoder or resolver</i> for motors series <i>Super-SAX</i>. 		

You can find more information about cables on enclosure "**Cables Manual**" available on the CD provided with the drive.

2.5 Connection to ground and earth

Make sure that the servodrive and the motor are connected to earth in accordance with the current norms.

This connection must be done by using a copper bar, mounted on insulating supports:



l	Bar's section
0,5 ... 1 m	5x40 mm
1 ... 2 m	5x50 mm

then follow these indications:

1. Connect to the ground bar:

- ✓ the **earth power terminal of the drives**;
- ✓ the **CHASSIS** of all drives;
- ✓ the **DGT-IN RTN** pin of the digital inputs for each drive;
- ✓ the **0V of the auxiliary supply**;
- ✓ the **internal zero voltage of the CNC**;
- ✓ the **earth terminals of the PLC/CNC frames**;

2. Connect the **ground bar** to the zinced panel of the drive by using a screw, then connect that screw to **earth**.


3. Connect earth to the **motor's carcass**.

Symbol	Description
	It suggests a conductive connection as much as possible to the chassis, or the heat-sink, or the mounting panel of the electrical box.
	It refers to the earth connection.
	It refers to the connection of the shield to the connector's metal ring.

2.6 Note about cable shielding

Control signal cables

The conductor of the analogic signal must be twisted and shielded, and the shield must be connected to ground as illustrated below:




Note:

- To reduce the capacitive and inductive coupling, these cables must be run keeping a distance of more than 30cm from the power cables (10 cm if they are shielded).
- If it is absolutely necessary to cross the control cables with the I/O's, do so at 90°, in order to reduce the effect of the magnetic fields.

Motor cables

The shield of the motor cable (power and signal cables) are connected as follows:

- *drive side* (20:50cm) ⇒ remove the outside sheath and fix shield to the zinc panel, by using a u-clamp:



- *motor side* ⇒ The shield is internally connected to the metal ring of the motor connector, thus to earth through the motor's carcass.

2.7 Base installation procedure



This procedure must be done only by qualified personnel which are familiar with drives. If you need more information contact Axor.


- a) **Power off** all the supplies of the electrical box.
- b) Verify:
 - ✓ the **drive-motor coupling** ⇒ the stall current (I_s) of the motor should be equal to/or greater than the nominal output current of the drive;
 - ✓ the **positioning** of the drive into the electrical box;
 - ✓ the **pollution level** and the **ventilation**;
 - ✓ the **connection to earth** of the electrical box where the drive is installed (see "2.5 Connection to ground and earth").
- c) Execute the wiring following this order, avoiding that wiring's pieces, cables, wires, screws, conductive objects, etc. do not enter into the drive through its slits:
 - 1- First connect **earth**.
 - 2- Connect the **cables for the motor's power** (U, V, W) and the **filter 3x1.2mH**, if the cable length is greater than 20/25m.
 - 3- Connect the **earth of the motor's power** (PE).
 - 4- Connect the **external shield** of the motor's cable: it must be shielded utilising a u-clamp to the zinc panel of the electrical box (see "2.6 Note about cable shielding").
 - 5- Connect the **external braking resistor** between pins EXT and R-, by using a cable as short as possible. If the cable length is greater than 20/30 cm, the cable must be twisted and shielded, besides the shield must be connected to ground on both ends utilising u-clamps to the zinc panel of the electrical box.
 - 6- Connect the motor's feedback cable to the drive's **J1** connector
 - 7- Connect the **main power supply cable** (L1-L2-L3) and the **earth cable** (PE).
Always insert a power relay or a thermal magnet on every phase of the products power supply.
 - 8- If necessary, connect the **auxiliary supply cable** (+24V).
We suggest the use of an external power supply, that must be stabilized and galvanically isolated from the main supply.
 - 9- Connect the PC to the drive utilising the **RS232** cable.
 - 10- Supply the drive with the **main supply** and, if necessary, with the **auxiliary supply**.
 - 11- Open the *Speeder One* interface.
 - 12- Execute the tests on the drive and the motor.

In the following page there is an *example of a basic connection*.

You can find more information about all interfaces on enclosures "**Operative Modes Manual**", "**Additional Features Manual**", "**Positioner Manual**" available on the CD provided with the drive.


2.8 Example of base connection

Example of BASE connection:



2.9 Supply connections

POWER SUPPLY Connection



Notes:

- **Always insert a power relay or a thermal magnet on every phase of the products power supply.**

- If the drive is supplied by using a transformer, the **nominal power of that transformer** is calculated by adding the various wattage of each motor:

$$P_t = P_n + P_n + P_n + \dots$$

P_t = nominal power of the transformer (VA)

P_n = nominal power of each motor (VA), which can be calculated in this way:

$$P_n = n \times C_n / 9,55$$

P_n = nominal motor power (W)

n = motor speed (rpm)

C_n = motor nominal torque (Nm)


- Instead of the 3-phase or single phase power supply, it is possible to use a continuous voltage, utilising the +AT and -AT pins on the M1 connector.

- **You must not connected the DC buses of more than one drive in parallel, due to the drive's braking circuitry.**
This note must be respected, otherwise the drive may not function properly and be damaged.




2.9 Supply connections

The figura below displays some supply possibilities for the **McbNET Digital™**.



2.9 Supply connections



In the **single phase power supply** version it has an output voltage given by the following formula:

$$V_{out} = 0,9 * (V_{ac} - V_d)$$

where


V_{out} = drive's output voltage.

V_{ac} = power supply between **L2** and **L3/N**.

V_d = voltage fall caused by the single phase supply, proportional to the current absorbed by the motor, as can be seen in the figure near here:


Example: If the current absorbed by the motor is 6A, the voltage drop is about 17V; so in this case the maximum voltage output is 192V, infact:

$$V_{out} = 0,9 * (230 - 17) = 192V$$



2.10 Motor power connection


MOTOR POWER



Note:

a- Use **3x1.2mH - 20Arms** filter series for connections with cables longer than 20/25 meters.

b- The **earth connection** of the power cable's shield must be made on the zinc-coated panel (using a u-clamp) near the drive (20-50cm). Motor side: the shield is connected to connector's metal ring, so it is connected to ground through motor's carcass.




c- Pins +AT and -AT allow you to connect to DC bus.

ATTENTION: NOT CONNECT +Br AND - Br CONDUCTORS OF MOTOR POWER CABLE, PROVIDED BY AXOR, TO PINS +AT AND -AT.

ATTENTION: McbNET Digital DOES NOT MANAGE ELECTROMECHANICAL BRAKE INTEGRATED IN THE MOTOR.


IF MOTOR HAS NOT BRAKE, +Br AND -Br CONDUCTORS ARE NOT TO BE CONNECTED; IF MOTOR HAS BRAKE, THE BRAKE MANAGEMENT IS MADE EXTERNALLY BY PLC OR CN.

Example of connection:



2.11 Relè OK and Back UP supply connections


RELE' OK connection



It is normally open when the drive is not supplied;
it is normally closed when the drive is supplied and
it has not active alarms.

30V_{AC/DC} - 500mA max

BACK-UP SUPPLY (+24Vdc) connection




This supply is utilised to power the logic board and the encoder when the drive is shut off. In this condition the display visualises the symbol "---", while the "Relè OK" contact remains open.

Notes:

- Accepted current by input M2A-16: **+24Vdc** (+25%, -30%).
- The current's absorption on terminal M2A-16 is about **100mA**.
- Connect the 0V reference to the ground bar of the system.

2.12 Regen resistance connection



If during the deceleration phase the led "**PA**" turns on, (**Pre-alarm Recovery**), probably it is necessary to change the R1 resistor with a higher resistor of **200W - 22 Ohm (R2)**.

If the power accumulated by the motor during deceleration exceeds the set load power, the converter activates the **alarm 8, "I2t Brake"**. This causes the opening of the "Relè OK" contact and the drive's stop. In this case disable the drive, then:


- be sure that the external resistance has the correct Ohm value and that it is connected as described in the manual;
- check the AC power supply input;
- check that the working cycles are not excessive;
- verified if the motor, going at half speed, shows the same problem;

reset the alarm, then enable the drive.

Before changing the R1 resistor, we suggest to contact Axor.

2.13 Digital inputs connection

DIGITAL INPUTS connection




Notes:

- The enable signal should be **+24VDC-7mA** (PLC compatible). The enable range is between **+14V Min** and **+30V Max**.
- The **M2A-1** terminal (**DGT-IN1 (ENABLE)**) is used only as the drive's enable. If M2-4 is HIGH (+24VDC) the drive is enabled (without active alarms); if M2A-1 is LOW (0V), the motor is without torque.
ATTENTION: THE DRIVE'S ENABLE/DISABLE, BY USING THE ENABLE INPUT, IS NOT CONSIDERED A SECURITY FUNCTION.
- The other inputs can be used to activate pre-programmed functions of the drive (for example: limit switch, homing and positioning procedures, emergency stop, etc.).
For a detailed description of the pre-programmed functions see enclosure "**Speeder One Interface**", "**Additional Features Manual**" and "**Positioner Manual**" on the CD provided with the drive.
- Connect pin **M2A-10 (DGT-IN RTN)** to the ground bar of the system.



2.14 Digital outputs connections

DIGITAL OUTPUT Connection (example)



Max. load for each output:
50[mA].


Always use a relay with a diode
in parallel.



This digital output can be used to send messages from the pre-programmed function of the drive.
For a detailed description of the pre-programmed functions see enclosure "**Speeder One Interface**"
on the CD provided with the drive.

2.15 Analog outputs connections

ANALOG OUTPUTS Connections



They permit visualisation by oscilloscope of some of the drive's measurement values.

The two outputs furnish **+/-10Volt** as the low scale setting refers to.


They can be set by the *Speeder One* interface.

Note: We suggest to connect the shield on both sides: drive side follow the indications illustrated on paragraph 2.6.


2.16 Analog inputs connections

ANALOG DIFFERENTIAL OR COMMON MODE INPUT (+/-Vref and TPRC) connection

DIFFERENTIAL MODE (+/-Vref)



COMMON MODE (+/-Vref)




The **technical characteristics** of +/-Vref inputs are as follows:

- ✓ Voltage: $\pm 10\text{V}$ Max.
- ✓ Input impedance: **40kOhm**.

To change the sense of rotation, apply the positive voltage reference to **M2B-10**, or change the **Rotary Direction** parameter in the **Speed** window (from **Positive** to **Negative**).

Note: We suggest connecting the shield on both sides: drive side, follow the indications illustrated on paragraph 2.6.

COMMON MODE (TPRC)



The **technical characteristics** of TPRC input are as follows:


- ✓ Voltage: $\pm 10\text{V}$ Max.
- ✓ Input impedance: **10kOhm**.

Note: We suggest connecting the shield on both sides: drive side, follow the indications illustrated on paragraph 2.6.


2.17 Emulated encoder outputs connection

EMULATED ENCODER OUTPUTS connection

LINE RECEIVER CN inputs



COMMON MODE CN inputs




Note: We suggest connecting the shield on both sides: drive side, follow the indications illustrated on paragraph 2.6.

2.18 Pulse/Dir inputs connections


PULSE/DIRECTION MODE connection

Logical signal 0/+5V




Note: We suggest connecting the shield on both sides: drive side, follow the indications illustrated on paragraph 2.6.

Logical signal 0/+24V open collector NPN



Note: We suggest to shield separately the couples of cable and to connect the shields together and to the PLC ground.

ELECTRICAL AXIS (GEARING) Connection




Note: We suggest connecting the shield on both sides: drive side, follow the indications illustrated on paragraph 2.6.

2.19 Feedback signals connections

Motor signal connector (*differential mode inputs*)

The figure illustrates the connections between an **Encoder with RS485 differential outputs** and the **McbNET Digital™**:

With this configuration improved transmission signal immunity is guaranteed as opposed to common mode type signals.





Motor signal connector (*common mode inputs*)

The figure illustrates the connections between an **Encoder with Open Collector type outputs** and the **McbNET Digital™**:

If the motor has not the thermal protection (PTC MOTOR) you should bridge the 4 and 17 pins on the "J1, Sub-D 25 pole" connector of the drive.

Note: The **ground connection** of the external shield must be made on the zinc-coated panel (using a cable tie) near the drive (20-50cm).




Motor size the shield is connected to connector's metal ring.



2.19 Feedback signals connections


RESOLVER FEEDBACK connection

OPTIONAL



If the motor does not have thermal protection (PTC MOTOR) you should bridge pins 4 and 17 on the "J1, Sub-D 25 pole" connector of the drive.


Note: The **ground connection** of the external shield must be made on the zinc-coated panel (using a u-clamp) near the drive (20-50cm).
Motor side: the shield is connected to connector's metal ring.



2.20 RS232 connection

McbNET Digital™ (RJ11 - 6 pole):


Sub-D 9 pole



connector
PC side

Sub-D	MCBNETD
n.c.	Pin 1 -
n.c.	Pin 2 -
Pin 2 (RxD)	Pin 3 (TxD)
Pin 3 (TxD)	Pin 4 (RxD)
Pin 5 (GND)	Pin 5 (GND)
n.c.	Pin 6 -

**RJ11
6 pole**




connector
DRIVE side

2.20 Multidrop connection

MULTIDROP connection

OPTIONAL



Notes:

- Connect the first **McbNET Digital™** to the **Master** by using the RS232 cable (**J2** connector) and to the following drive by using the CANBus cable; connect each drive with the following by using "T" RJ11 adaptors; connect a **RESISTOR (120 Ohm, 1/4W)** between the pins of the last drive.


- Axor drives use **MODBUS communication protocol** specified in the **Modicon** instructions (see <http://www.modicon.com/techpubs/>).

For more information see enclosure "**Modbus Manual**" on the CD provided with the drive.

2.21 Canbus connection

CANBUS connection

OPTIONAL




Note: Connect the first **McbNET Digital™** to the **MASTER** by using a CanBus cable (from the **J3** connector to the Master); connect each **McbNET Digital™** to the following by using "T" RJ11 adaptors; connect a **RESISTOR (120 Ohm, 1/4W)** between the pins of the last drive of the network.

2.22 Motor Test

This procedure is a guide line for the first power up of the drive-motor system. **It must only be executed by technically qualified personnel. If you need more information contact Axor.**



- 1) Follow the basic procedure previously described. **ATTENTION: do not apply load to the motor.**
- 2) Install *Speeder One* interface from CD.
- 3) Power up the drive: apply the auxiliary supply and then the main supply (follow the procedure previously described).
- 4) Open the *Speeder One* interface clicking on "Axormb.exe" executable file on directory: "C:\Programm\Axor". The main window "Axor Servo Drive" and the "Select Driver" windows open simultaneously. On the **Select Driver** window insert the drive's address (all drives have **1 set** as default value), then click OK.



5) If the drive is "**Not configured**", it is necessary to open a pre-set configuration file, following this procedure:

- in the main window select the "**File**" menu and then "**Open**";
- in the directory: ...\Axor\Data\Devices\ select a file reference to the coupling drive-motor, then click on "**Open**";
- save load parameters by using "**Save Data To EEPROM**" icon.

If the drive is *configured for a specified motor*, it is sufficient to check these parameters:

- ✓ Main voltage (*Main Voltage* menu in the main window of the interface)
- ✓ Number of motor poles (*Motor* window)
- ✓ Feedback type (*Motor* window)
- ✓ Encoder impulse/rev or resolver n° of poles (*Motor* window)
- ✓ Irms current (*Current* window)
- ✓ Ipk current (*Current* window)
- ✓ Speed Limit (*Speed* window)

2.22 Motor Test

6) If alarm should appear, resolve them before going forward (see chapter 3).

7) Set the operative mode "**1: Digital Speed**", set a speed reference equal to 100rpm, enable the drive with the **Enable** button.

If shaft turns correctly, at the set speed, without alarms, it is possible to connect the load and cable the machine. È possibile procedere con il collegamento del carico e con il cablaggio della macchina; al contrario, if alarms should be compare or if the behavior should not be as set, we suggest to control the connections and the settings (eventually contact Axor).

8) Connecting the load to the motor, it should be necessary to connect gains of speed loop, following this procedure:

a- set the "**10: Square wave**" operating mode.

b- Set the "Speed_RPM" parameter on the "Analog OUT1" menu.

c- Connect the probe of the oscilloscope on pins **AN.OUT1** (speed signal) and **AGND** (zero signal).

d- enable the drive


e- Adjust the KP and KI gains in a way that you obtain a stable step response in both directions. Increasing KP decreases the system's response time; however, the system gets closer to becoming unstable; therefore, during adjustment increase the KP to the oscillation limit and then reduce until secure oscillation stoppage.

Increasing KI the steady state diminishes, however increasing the overshoot, therefore after adjusting KP increase KI keeping the overshoot within authorized limits ($\pm 10\%$).

The figure below illustrates some typical oscilloscope tracks:

A) Proportional and integral gains too low. Increase the numerical values of KP and KI.

B) and C) Good proportional and integral gains.



9) At this point it is possible to set other parameters in reference to the desired operative mode (see enclosures "**Operative modes Manual**", "**Additional Features Manual**", "**Speeder One Interface**" available on the CD provided with the drive.



Chapter 3


Diagnostic

3.1 Display
3.2 Alarms

48
49

3.1 Display

A **display LED** visualises: the drive's status, the inserted values, the alarms.

Symbol	Description
F	The digital input ENABLE is enabled, while the digital input set with the "Ref on" function is disabled.
E	The digital input ENABLE is disabled, while the digital input set with the "Ref on" function is enabled.
[]	The digital input ENABLE and the digital input set with the "Ref on" function are both enabled; the motor does not move.
 <p>(segment appears rotating in a clockwise or counter-clockwise direction)</p>	The rotor is turning in a clockwise or counter-clockwise direction.
0_I	This appears when the negative limit switch (NSTOP) is interrupted.
0_I	This appears when the positive limit switch (PSTOP) is interrupted.
- - -	This appears when the converter is correctly powered on, the digital input ENABLE is disabled and there are no alarms.
24 UP	This appears when there is the +24VDC auxiliary supply, but not the main supply.
ALxx	There is alarm xx.

You can find more information on enclosure "**Display and Keypad Manual**" available on the CD provided with the drive.

3.2 Alarms

The table below illustrates all the message errors:

ALARM		SOLUTION
AL1	EEPROM alarm Error while memorising parameter to the drive's EEPROM or while reading parameters from drive's Eeprom.	Disable the drive, try to memorise the parameter, then re-enable.
AL2	Overcurrent alarm Short circuit between U, V, W or towards earth.	Disconnect the power, verify the wiring, then power up again.
AL3	Drive Temperature alarm Heat sink temperature too high, >75°C.	Disable the drive, verify: <ul style="list-style-type: none"> the forced ventilation functioning, the ambient temperature, wait until the radiator has cooled off, reset the alarm then enable the drive.
AL4	Hall alarm This alarm comes on if one or more of the hall cell's wires are disconnected.	Disable the drive, verify the cell's wire connection, reset the alarm, then enable the drive.
AL5	Encoder alarm This alarm comes on if one or more of the encoder channels are interrupted.	Disable the drive, control the connections, reset the alarm, then enable the drive. If the alarm persists contact Axor.
AL6	I^{2t} Drive alarm The internal I ^{2t} function has reached the maximum permitted. The cause could be one of the following: <ul style="list-style-type: none"> the working cycle could be too heavy; a possible mechanical block; motor phase inversion; the electronic brake is not unblocked; the amplifier's dynamic constants: "KP", "KI" and "KD", could create useless current oscillation. 	<i>It is only a message.</i> This does not cause the disabling of the drive's functioning. The current is limited to the rated one, set in "Current" window.
AL7	Motor Temperature alarm Heat sink temperature too high. This causes the opening of the Ok Relè contact and disables the drive.	Disable the drive: <ul style="list-style-type: none"> control the heat sink temperature; decrease the dynamic constant if the motor is vibrating. This situation causes current oscillation and consequently the overheating of the motor. Wait until the motor has cooled off, reset the alarm, then enable the drive.
AL8	Regenerative Resistance alarm The value I ^{2t} energy recovery has reached the maximum allowed. This causes the opening of the Ok Relè contact and disables the drive.	Disable the drive: <ul style="list-style-type: none"> check the AC power supply input; check that the working cycles are not excessive; verify if the motor, going at half speed, shows the same problem. Reset the alarm, then enable the drive.
AL9	Min/Max Voltage alarm Minimum or maximum converter voltage. This causes the opening of the Ok Relè contact and disables the drive.	Disable the drive, wait until the DC power supply voltage reaches the correct threshold, check the AC power supply input, then enable the drive.
AL10	Pre-Alarm Recovery alarm 80% of the I ^{2t} energy recovery value has been reached. This does not cause the disabling of the drive.	Check the AC power supply input and the working cycles. This is <i>only a message</i> , it anticipates the intervention of the "Maximum recovery" alarm.

3.2 Alarms

AL12	<p>Resolver alarm Missing one or more resolver signals. This causes the opening of the Ok Relè contact and disables the drive.</p>	Disable the drive, control the resolver's contact, reset the alarm, then enable the drive.
AL14	<p>Following Error The error between the position reference and the position feedback exceeds the "Max Position Error" parameter, because the "Max Position Error" parameter is too small, or the dynamic gains of the velocity-positioning loop are wrong. This causes the opening of the Ok Relè contact and disables the drive.</p>	Disable the drive, check the Max Position Error parameter, check the dynamic gains, reset the alarm, then enable the drive.
AL15	<p>Limit Switch The two fixed limited positions have both been disabled or interrupted. This causes the opening of the Ok Relè contact and disables the drive.</p>	Disable the drive, check the limit contacts and external connections, then enable the drive.
24 UP	<p>In-rush Bus <i>This is not an alarm.</i> <i>Indication of the drive's in-rush phase.</i></p>	
AL23	<p>Flash Alarm Errors in reading/writing parameters on the Flash memory, or Flash memory is empty. This causes the opening of the Ok Relè contact and disables the drive's functionality.</p>	Disable the drive, save new values, then re-enable. If the problem persists contact Axor.
AL24	<p>Can Bus Alarm Error during communication with CanOpen protocol. This causes the opening of the Ok Relè contact and disables the drive's functionality.</p>	Disable the drive, check the cabling and re-enable. If the problem persists contact Axor.
AL26	<p>Homing Error Position error too high during the homing procedure. The motor stops, but it is not disabled.</p>	Check the homing setup, then reset the alarm using the "Start Homing" function.

You can find more information on enclosure "**Alarm Manual**" available on the CD provided with the drive.

Index

A

Alarms 47
analog common mode input (TPRC) 7, 35
analog differential or common mode inputs (+/-Vref) 7, 35
Analog outputs 7, 34

C

Cables 21
Canbus connection 43
Conformity 53
Connection to earth 22
Connection to ground 22

D

Digital inputs 7, 32
Digital output 7, 33
Display 7, 48
Disposal 16

E

EMI filter 8
emulated encoder outputs 7, 36
Environmental conditions 20
equipment 8
Example of base connection 25
Expansion cards 8

F

Fuses 11

G

General view 9

I

installation procedure 24

K

KeyPad 7

M

Maintenance 16
Main supply
 connection scheme 27
Mechanical Dimension 12
Motor power 29
Multidrop connection 42

Index

O

Operative Modes 6
 CanBus 6
 electrical axis 6
 multidrop RS232 6
 position control 6
 pulse/direction mode 6
 speed control 6
 Torque control 6
Ordering code 13

P

Positioning 19
Power supply 26
Product plate 13
Pulse/Dir digital inputs 37

R

Rele' OK 30
resolver connection 40

S

Safety 8
Security standard 16, 17, 18
Shielding 23
Speeder One 7
Storage 16

T

Transport 16

Conformity

European directives and norms

The servodrives are "*components*" that are intended to be incorporated into electrical plant and machines for industrial use.

When the servodrive is used into machines or plant, the electrical plant/machine must respect the following directives: **EC Machinery Directive (2006/42/EC)**, **EC Directive on EMC (2004/108/EC)**, **Low Voltage Directive (2006/95/EEC)**.

The machine/plant manufacturer must examine whether with its machine/plant still further or other standards or EEC guidelines are to be used.

EC Conformity

The **EC** mark that is applied to the drives references to the **Low Voltage Directive (2006/95/EC)** and **EC Directive on EMC (2004/108/EC)**.

The standard EN 61800-5-1 is applied to ensure conformance with the Low Voltage Directive.

The standard EN 61800-3 is applied to ensure conformance with the EMC Directive.

In reference to noise immunity and noise emission the converters fulfil the requirement to the category *second environment* (industrial environment).

If the installation of the drive is carried out differently than described in this manual, the user must carry out new measures to satisfy the requisites of law.



AXOR IND. s.a.s.

viale Stazione, 5 - 36054 Montebello Vic.no
Vicenza - Italy

phone (+39) 0444 440441

www.axorindustries.com - info@axorindustries.com

