

MACHINE PARAMETERS MANUAL

DA-65 (V7)
DA-69 (V7)
DA-68PL (V7)
DA on Windows (V1)

GENERAL INTRODUCTION

In this machine parameter manual you find the explanation on:

- the input and output signals (X- and Y-axis and general);
- the selection possibilities of the machine parameter menu;
- the value and function of the machine parameters of the X- and Y-axis;
- the auxiliary axes with corresponding parameters.

The first chapter describes the function of the general input and output signals and the input and output signals of the X- and Y-axis and in what way these signals should be connected to the axis module. A DA-60 series control with a DM02 gives the basic machine configuration.

The High Speed Bus (HSB) takes care of the communication between the control and the modules. Via this HSB line the modules are programmed with the appropriate machine parameter values to control the axes. The programmed values of the axes are compared with the actual axes positions and the machine parameter settings. If the 'new' values are within the range the 'new' values become the actual values.

The machine parameters (including all axis parameters) are programmed in the machine parameter menu of the control. Besides the programming of the machine parameters you have several other selection possibilities in this machine parameter menu. These selection possibilities are explained in chapter 2.

The basic machine parameters are to control the Y-axis. In chapter 3 these machine parameters are explained. The explanation comprises the parameter range, the default value, the parameter function and a description.

From chapter 4 until chapter 10 the parameters of the auxiliary axes and special functions are given. The auxiliary axes are grouped per type of axis. The next type of axes and special functions are explained:

- auxiliary axes (chapter 4);
- axes types and parameters (chapter 5);
- crowning (chapter 6);
- digital outputs (chapter 7);
- I-axes (chapter 8);
- part support (chapter 9);
- sensor machine parameters (chapter 10, not yet implemented).

This manual is valid for the following Delem control types:

- DA-65 (V7)
- DA-69 (V7)
- DA-68PL (V7)
- DA on Windows (V1)

MACHINE PARAMETERS MANUAL

Table of contents

	PAGE
GENERAL INTRODUCTION	0.2
Table of contents	0.3
1. INPUT AND OUTPUT SIGNALS	1.1
1.1. Introduction	1.1
1.2. Y-axis input signals	1.1
1.3. Y-axis output signals	1.2
1.4. X-axis signals	1.4
1.5. Axis signals	1.4
1.6. Various input and output signals	1.5
2. MACHINE PARAMETERS MENU	2.1
2.1. Introduction	2.1
2.2. Selection procedure of machine parameters menu	2.1
2.3. Y-axis and general parameters	2.2
2.4. Auxiliary Axes	2.2
2.5. Module configuration	2.3
2.6. Update control	2.5
2.7. Machine parameters backup	2.8
2.8. Changing the menu name	2.8
2.9. Changing the access code	2.9
2.10. Options	2.10
2.11. Leaving the machine parameters menu	2.11
3. Y-AXIS AND GENERAL PARAMETERS	3.0
Parameter 1	
Service row 1/0	3.1
Parameter 2	
Y-max	3.2
Parameter 3	
Y-min	3.3
Parameter 4	
Y-direction +/- (1/0)	3.4
Parameter 5	
Linear Scale Ref. left (Y1)	3.5
Parameter 6	
Linear Scale Ref. right (Y1)	3.6
Parameter 7	
Tool Reference	3.7
Parameter TR	

Tool Reference correction	3.7a
Parameter 8	
Linear scale direction Y1 (0/1)	3.8
Parameter 9	
Linear scale direction Y2 (0/1)	3.9
Parameter 10	
Tandem 1/0	3.10
Parameter 11	
Parallel switch 1/0	3.11
Parameter 12	
Max. Parallelism	3.12
Parameter 13	
Y-opening default	3.13
Parameter 14	
Braking time max	3.14
Parameter MP	
Mute programmable per bend step 1/0	3.14.a
Parameter 15	
Calibrate valves 1/0	3.15
Parameter 16 - 19	
Not used	3.16
Parameter 20	
Relaxation Stiffness	3.20
Parameter 21	
Stiffness of frame	3.21
Parameter 22	
Calibration 1/0	3.22
Parameter 23	
Force max.	3.23
Parameter 24	
Force min.	3.24
Parameter FM	
Force Middle	3.24a
Parameter 25	
Output max.	3.25
Parameter 26	
Output min.	3.26
Parameter OM	
Output middle	3.26a
Parameter 27	
Pressure ramp	3.27
Parameter 28	
Not used	3.28
Parameter 29	
Not used	3.29
Parameter 30	
Closing speed	3.30

Parameter 31	
Closing speed incr.	3.31
Parameter 32	
Closing ramp offset	3.32
Parameter 33	
Del. before closing	3.33
Parameter 34	
Opening speed	3.34
Parameter 35	
Opening ramp offset	3.35
Parameter 36	
Del. before opening	3.36
Parameter 37	
Max. pressing speed	3.37
Parameter 38	
Delay before pressing	3.38
Parameter 39	
Delay before pressing force	3.39
Parameter 40 - 41	
Not used	3.40
Parameter 42	
Y-ref search speed	3.42
Parameter 43 - 45	
Not used	3.43
Parameter 46	
Closing brake ramp trim	3.46
Parameter 47	
Closing gain trim	3.47
Parameter 48	
Opening gain trim	3.48
Parameter 49	
Pressing gain trim	3.49
Parameter 50	
Machine length between the cylinders	3.50
Parameter 51	
Inertia under beam	3.51
Parameter 52	
Inertia upper beam	3.52
Parameter 53	
Not used	3.53
Parameter 54	
Total machine length	3.54
Parameter 55	
Punch clamp pressure	3.55
Parameter 56	
Die clamp pressure	3.56
Parameter 57	

Valve ramp closing	3.57
Parameter 58	
Not used	3.58
Parameter 59	
Opening pressure	3.59
Parameter 60 - 119	
Not used	3.60
Parameter 120	
KO-table from floppy on/off 1/0	3.120
Parameter 121	
Sequencer from floppy on/off 1/0	3.121
Parameter 122	
Sequencer debug on/off 1/0	3.122
Parameter 123-130	
Sequencer options	3.123
Parameter 131	
UAP from floppy on/off 1/0	3.131
4. AUXILIARY AXES	4.1
4.1. Introduction	4.1
4.2. Configuration procedure of axes	4.1
4.3. R-axis specific parameters.....	4.5
4.4. Z-axis specific parameters	4.7
4.5. A second X-axis.....	4.9
Parameter XX	
X2 relative to X (1=on, 0=off)	4.10
Parameter 7	
Max. X1X2 difference	4.11
Parameter 8	
Backgauge type	4.12
Parameter 9 - 12	
Distance A-D	4.14
4.6. X1X2 diference programming(option)	4.15
4.7. The spindle correction table	4.18
5. AUXILIARY AXES PARAMETERS	5.1
5.1. Introduction	5.1
5.2. Standard axis parameters	5.1
Parameter 7	
Min. value	5.2
Parameter 8	
Max. value	5.3
Parameter 12	
In position tolerance	5.4

Parameter 28	
Position measurement system	5.5
Parameter SL	
Number of slaves	5.6
Parameter 9	
Pre scaling	5.7
Parameter 5	
Reference position	5.8
Parameter 6	
Reference search direction	5.9
Parameter 17	
RSD switch mounted	5.10
Parameter 21	
Reference search speed	5.13
Parameter 29	
AD-min	5.14
Parameter 30	
AD-max	5.14
Parameter 24	
Encoder count dir (0/1)	5.15
Parameter 14	
Default value	5.16
Parameter 76	
Spindle allowance	5.17
Parameter 84	
Overrun	5.18
Parameter 85	
Overrun wait time	5.19
Parameter 15	
Decimal point pos.	5.20
Parameter 27	
Correction (X)	5.21
Parameter 27	
Correction (X)	5.22
Parameter 25	
Correction (Z)	5.23
Parameter 25	
Correction (Z)	5.24
Parameter 26	
Correction (R)	5.25
Parameter 26	
Correction (R)	5.26
Parameter 122	
Axis retract programmable	5.27
Parameter 130	
Safety distance	5.28
Parameter 131	

Safety speed	5.29
5.3. Parameters for Servo axes	5.30
Parameter 2	
Gain	5.31
Parameter 3	
Switch	5.32
Parameter 4	
Ramp	5.33
Parameter 11	
Manual speed high	5.34
Parameter 13	
Acceleration ramp	5.35
Parameter 34	
Axis speed programmable	5.36
5.4. Parameters AC axes	5.37
Parameter 78	
Drive type	5.39
Parameter FG	
Break point high speed (Bfs)>	5.40
Parameter SG	
Break point low speed (Bss)>	5.41
Parameter FS	
Break point high speed (Bfs)<	5.42
Parameter SS	
Break point low speed (Bss)<	5.43
Parameter 83	
Stop time	5.44
Parameter 86	
Dc low speed	5.45
Parameter 87	
Dc high speed	5.46
Parameter 88	
Dc low speed >	5.47
Parameter 89	
Dc high speed >	5.48
6. CROWNING	6.1
6.1. Introduction	6.1
6.2. Installation of the crowning device	6.2
6.3. Crowning device programming and adjusting	6.3
6.4. Crowning parameters	6.5
Parameter 7	

	Min. value	6.6
	Parameter 8	
	Max. value	6.7
	Parameter 15	
	Decimal point pos.	6.8
	Parameter 18	
	DA-min	6.9
	Parameter 19	
	DA-max	6.10
	Parameter 22	
	DA-out linear/table (0/1)	6.11
	Parameter 23	
	Hysteresis	6.12
	Parameter 14	
	Default value	6.12
	Parameter 31	
	Max computed value	6.13
	Parameter 31	
	Standard / high resolution (0/1)	6.14
	Parameter AR	
	Automatic R-axis correction (0/1)	6.15
7.	DIGITAL OUTPUTS	7.1
	7.1. Introduction	7.1
	7.2. Digital R-axis.....	7.1
	Parameter 14	
	Default value	7.4
	7.3. On/off outputs.....	7.5
	Parameter NO	
	Number of FD outputs	7.6
	Parameter LS	
	Ls FD output	7.7
	Parameter 14	
	Default value	7.8
8.	I-AXES	8.1
	8.1. Introduction	8.1
	8.2. I-axis with 1 speed AC motor with potentiometer feedback.....	8.2
	8.3. Digital I-axis parameters.....	8.3
	Parameter Nr	
	Nbr positions	8.4
	Parameter LS	
	Ls FD output	8.5

Parameter PT	
Positioning time	8.6
Parameter P1..P4	
Position 1...4	8.7
9. PART SUPPORT	9.1
9.1. Introduction	9.1
9.2. Digital part support.....	9.2
9.2.1. Installation	9.2
9.2.2. Parameters digital part support.....	9.4
Parameter 7	
Min. Angle	9.6
Parameter 8	
Max. Angle	9.6
Parameter 18	
Min. AD-value	9.7
Parameter 19	
Max. AD-value	9.7
Parameter RF	
Delay before retour factor	9.8
Parameter SL	
Nbr. of slaves	9.9
Parameter 14	
Default value	9.10
Parameter SA	
Safety stop angle	9.11
Parameter MS	
Max. angle speed	9.12
Parameter ML	
Mean angle speed low	9.13
Parameter MH	
Mean angle speed high	9.13
Parameter PN	
Proportional gain min	9.14
Parameter PX	
Proportional gain max	9.14
Parameter FN	
Feedforward gain min	9.15
Parameter FX	
Feedforward gain max	9.15
Parameter DN	
Differential gain min	9.16
Parameter DX	
Differential gain max	9.16
Parameter AM	
Adjustment mode	9.17

Parameter 12	
In Position tolerance	9.18
9.2.3. Adjustment procedures	9.19
9.2.4. Extra info and recommendations	9.23
9.3. Additional part support axes.....	9.27
9.4. Analog part support	9.29
9.4.1. Introduction	9.29
9.4.2. Installation and adjustment of the DBT01 control card.....	9.29
9.4.3. Parameters analog part support.....	9.32
Parameter 7	
Min. value	9.32
Parameter 8	
Max. value	9.32
Parameter 18	
DA-min	9.32
Parameter 19	
DA-max	9.33
Parameter RF	
Delay before retour factor	9.34
Parameter NR	
Nbr. of units	9.35
Parameter 14	
Default value	9.36
Parameter SA	
Safety stop angle	9.36
Parameter MS	
Max. angle speed	9.36

1 Input and output signals


1.1 Introduction

All input and output signals are indicated with LED's on the front panel of the I/O modules. When an input or output signal is active, the corresponding LED is on. There are three kinds of signals: Y-axis signals, X-axis signals and general signals. In the next sections of this chapter these input and output signals are explained.

There is a strong relation between the Y-axis signals. This relation has been laid down in the timing diagram of the press cycle.

The timing diagram of the CNC-RDY signal has also been included. The numerical control ready signal indicates that the active bend program can be executed. The CNC-RDY signal depends on the status of start button, the position of the Y-axis and the position of the X-axis.

1.2 Y-axis input signals

Symbol	Function
↑	Opening command. This input must be active when the beam has to move in the opening direction (Y-axis status 6).
↓	Pressing command. This input must be active to move the press beam during the pressing phase (Y-axis status 3). This input must also stay active during the holding time (dwell time) at bend position and during decompression (Y-axis status 4 and 5).
↓↓	Fast closing command. This input must be active when the beam has to move with high speed in the closing direction (Y-axis status 2).
	Manual. This input must be active when the beam must be moved manually with the handwheel. This is only possible when the control is in Manual mode and the beam is below the mute position. When this input is active this is displayed with the text 'adjust' in the lower right corner of the control screen.
=	Parallelism switch input. See description of Y-axis machine parameter 'parallelism switch'.

1.3 Y-axis output signals

Symbol Function

↑	Upper dead point. This output is active when the beam is at the programmed upper dead point or higher.
ER	End of decompression. This output becomes active after the beam has reached the bending position, the holding time has elapsed and the decompression distance is completed. It goes low again (inactive) when the opening input (↑) becomes active.
↓ ↓	Mute output. This output becomes active when the beam reached the muting point. This output stays active as long as the beam is below the mute position.
↓ *	CNC-started. This output is active when the start button on the DA-control is pressed.
↓ ↓	Special mute output / 2nd mute (for servo hydraulics). An optional mute output can be used to obtain that the beam will stop more accurate at the muting point. This feature can be useful when using servo hydraulics. The optional mute output will be active from a certain distance before the actual muting point.




Figure 1.3.a

The braking ramp for stopping at the optional muting point is computed automatically by the control. The distance between the two muting points is fixed in the software. This value can only be changed by Delem on request. The default value is 0 mm. This means that the two mute outputs become active at the same time.




Figure 1.3.b

The point at which the optional mute output becomes active can also be shifted with an offset. This offset does not shift the computed braking point. Just like the distance between the two muting points this offset can only be changed by Delem on request. The default setting is 0.



Clamping (pinching) point output. This output becomes active when the beam reaches the clamping (pinching) point and stays active as long as the beam is below the clamping point.



Lower dead point output. This output becomes active at the end position of the press beam. This output is active during Y-axis status 4.

1.4 X-axis signals

Symbol	Function
--------	----------

R-in	<p>R-axis positive input. This input must be active (+24V) to have the X-axis moving within the safety zone of the applied die. Otherwise the X-axis will not move within this zone and as a result the CNC-RDY output will never become active!</p> <p>When the R-axis is negative and the R-in input is active, the R-axis will first move to a positive position before the X-axis will move to a position within the safety zone.</p>
------	---




Figure 1.4.a

1.5 Axis signals

Symbol	Function
--------	----------

INPOS	<p>This output is active when the actual position value of the axis is within the in position tolerance range of the programmed position. This in position tolerance range can be set with the machine parameter 'In position tolerance' (parameter 12).</p>
START	<p>Input for an axis module, to signal that equipment is ready and the module can start positioning the axis. Can be used to monitor 'ready' signal from a motor drive.</p>
RSD	<p>For taking the reference marker from the encoder you must connect this input to the reference search direction switch. The reference search cycle is then as described at the machine parameter 17 (RSD-switch). Usually the RSD input is taken from the End Of Travel switch.</p>

When you use an RSD-switch for reference search the motor drive does not need any direction sensitive enable/disable input for reference search. You are also free to place this switch anywhere you want. You can also combine the RSD-switch with one of the EOT switches.

Overall you could have a shorter reference search cycle time. Another advantage is that it is not necessary to mount limit switches for reference search.

1.6 Various input and output signals

⊙	Pump started.	This input must be active to be able to press the start button on the DA-control. When this input is not active the start button will not be accepted and the control will display the message **machine not started** .
T	Tandem input.	Tandem input for tandem or robot applications. See description of parameter 10 of the Y-axis parameters menu. For robot applications ask for the special robot function manual.
C	Cycle input.	This input can be used to realise an external step change. This is done by programming the program specific CX-code parameter in the programs.
↓*	CNC-START.	The start command for the control. This output can only be active (start button on control) when the pump start input is active.

FUNCTION OUTPUTS

F1, F2, F3, F4 are general purpose outputs. When you use a motorized deflection unit then output F3 is standardly used for 'A<' and output F4 for 'A>'. In this case you also have to connect the motorized deflection potentiometer between 'REF', '0V' and 'AI1'


CNC-RDY

Numerical control ready. This output is always off when the DA control is in the stop-mode (direct after power on, or after pressing the stop button). This output can only become active when the control is in:

- the manual mode. The start button is pressed and the X-axis is at the programmed position.
- the automatic mode or step-by-step mode. The following conditions must be present:
 - the start button has been pressed and
 - the X-axis is at the programmed position and
 - the press beam is in the upper dead point position.

When these conditions have been answered the CNC-RDY cycle results from the timing diagram.

OK	Module initialisation ready.	Output signal from a module, to indicate that the module is properly initialised and is ready for action. Can be used as enable signal to e.g. a motordrive.
----	------------------------------	--



Explanation of CNC-RDY timing diagram

- Y-axis status. The Y-axis status is the number of the Y-axis control program, which depends on the Y-axis command inputs. The number is shown on the service row (when activated) in the header of the screen.
- Upper dead point. Y-axis output indicating that press beam is in the upper dead point position.
- X-axis at programmed position. This line shows the actual X-axis position. This is the same as the programmed position.

The start button must be pressed (1). When in this case the press beam is in the upper dead point (output active) and the X-axis reaches the programmed position (2) the CNC-RDY output becomes active (3). The CNC-RDY output stays active during fast closing of the press beam (4), pressing (5) (when no X-axis retraction is programmed), dwell time (6) and decompression (7). The CNC-RDY becomes inactive after decompression of the beam (ER output active) at the step change position where the X-axis moves to the next programmed position. Depending on the X-axis code this can take place at:

- end of decompression;
- mute (passed in opening direction);
- upper dead point.

The CNC-RDY signal becomes active again (9) when the X-axis is at its programmed position and the Y-axis is in the upper dead point.

CNC-RDY signal during pressing with retraction programmed

There are two situations during pressing with retraction programmed (point 5 of CNC-RDY cycle).

- The press beam does not wait at the pinching point for X-axis retraction to complete (X-axis code < 10). The CNC-RDY output stays active while the X-axis moves to the retract position.
- The press beam stops at the pinching point and waits until X-axis retraction is completed (X-axis code > 10). The CNC-RDY output stays active while the X-axis is moving to the retract position. The press beam moves again when the X-axis has reached the retract position.

There is also a third situation, but this is an option.

- The press beam stops at the pinching point and waits until the X-axis retraction has been completed (X-axis code > 10). The CNC-RDY output is **off** while the X-axis is moving to the retract position. The CNC-RDY output becomes active again when the X-axis has reached the retract position.

Note 1 : Leave unconnected pins open.


Note 2 : Cut off yellow/brown wire (0-10V P) if cable DK-02VSWA-HBG-1.0 is used.

Note 3 : Diodes across valves (D) must be a BYV39E (Philips) or equivalent for currents 0-800mA or a BYM36E (Philips) or equivalent for currents 0-1500mA.

Note 4 : * = 1.5 Ampere outputs. Maximum of 9 Ampere over all outputs

Note 5 : 24V relays supply must be separated from 24V supply

T	Tandem
=	CNC-Ready signal
=	step Change
=	R axis positive input
=	Reference Search Direction switch
=	Upper Dead Point
=	End of Relaxation
=	Lower Dead Point
=	X - IP
=	X-axis In Position
=	F function output 1,2,3,4



In case motorized Deflection unit is used

In case hydraulic Deflection unit is used

In case of 12VSE bridge pins 6, 7, 8 and 9

ENCODER IN 12 POLE	5VSE	12VSE 9 POLE	5VSE	5VDE
1	T2 (B)	T0 (REF)	T0	T0
2	+5V	T2 (B)	T2	T2
3	T0 (REF)	T1 (A)	T1	T1
4	T0 (REF)	+12V	GND	GND
5	T1 (A)	+12V	GND	GND
6	T1 (A)	T0 (REF)	T0	T0
7	T2 (B)	T2 (B)	T2	T2
8	GND	T1 (A)	T1	T1
9	shield	GND	GND	GND
10	GND	shield	shield	shield
11	GND	GND	GND	GND
12	+5V	+5V	+5V	+5V

ENCODER IN 9 POLE	5VSE	5VDE
1	T0 (REF)	T0
2	T2 (B)	T2
3	T1 (A)	T1
4	+12V	GND
5	GND	GND
6	T0 (REF)	T0
7	T2 (B)	T2
8	T1 (A)	T1
9	+5V	+5V

Notes	Retracted	MM	15-11-1997	15-11-1998	Notes	Retracted	MM	Date
Description	HYDRAULIC DEFLECTION ADDED			Totally redrawn			3-1-08-1999	
Notes	Retracted	VW	22-07-1966					
Description	TEXT 24V AND P-SWAPPED							
Notes	Retracted	VW	16-01-1997					
Description	Example Hoerbiger (0-1500mA)							
Notes	Retracted	VW	27-09-1995					
Description	No unauthorized copying allowed							

Delem
 Leuchthausweg 42, 56571 BB
 Erndorfer, the NETHERLANDS

Connection DAXX - DM02
 Example Hoerbiger (0-1500mA)

9027-102 G

Note 1 : Leave unconnected pins open.


Note 2 : Cut off blue/red wire (0-10V P) if cable DK-02VSWVA-BSH-1.0 is used.

Note 3 : Diodes across valves (D) must be a BYV38E (Philips) or equivalent for currents 0-800mA or a BYM38E (Philips) or equivalent for currents 0-1500mA.

Note 4 : * = 1.5 Ampere outputs. Maximum of 9 Ampere over all outputs

Note 5 : 24V relays supply must be separated from 24V supply

T	Tandem
=	CNC-RDY signal
=	step Change
=	R axis positive input
=	Reference Search Direction switch
=	Upper Dead Point
=	End of Relaxation
=	Lower Dead Point
=	X-I P
=	Function output 1,2,3,4



Note	Redrawn	MI	Date	Redrawn	Date
Description	18-10-1989				
Description: Shrinklines added - 1/25-cable (not redrawn)					
Note	Redrawn	MI	Date	Redrawn	Date
Description	11-11-1997				
Description:					
Note	Redrawn	VW	Date	Redrawn	Date
Description	03-02-1987				
Description:					
Measure in mm unless specified			Drawn	VW	Date
Schémae specified			22-07-1986		

Delem
Luchthavenweg 42, 5657 BB
Eindhoven, the NETHERLANDS

Connection DAXX - DM02
Example Ext. Valve Amplifier (0-1500mA)

FORMA A3
NUMBER 9027-103
SCALE C

No unauthorized copying allowed

ENCODER IN	5VSE	5VDE	12VSE	5VSE	5VDE
1	T2 (B)	T2 (+5V)	T0 (REF)	T0	T0
2	+5V	T0	T2 (B)	T2	T2
3	T0 (REF)	T0	T1 (A)	T1	T1
4	T0 (REF)	T1	+12V	/	/
5	T1 (A)	T1	GND	GND	GND
6	T1 (A)	/	T0 (REF)	T0	T0
7	/	/	T2 (B)	T2	T2
8	T2 (B)	T2	T1 (A)	T1	T1
9	shield	shield	/	/	/
10	GND	GND	/	/	/
11	GND	+5V	/	/	+5V
12	+5V	+5V	/	/	/

In case of 12VSE bridge pins 6,7,8 and 9

ENCODER IN	5VSE	5VDE
1	T2 (B)	T2 (+5V)
2	+5V	T0
3	T0 (REF)	T0 (REF)
4	T0 (REF)	T1
5	T1 (A)	T1
6	T1 (A)	/
7	/	/
8	T2 (B)	T2
9	shield	shield
10	GND	GND
11	GND	+5V
12	+5V	+5V

2 Machine parameters menu

2.1 Introduction

In this chapter the selection possibilities of the machine parameters menu are explained. The next selection possibilities are discussed:

- selection procedure machine parameters menu (section 2.2);
- a brief introduction on the Y-axis and general parameters (section 2.3);
- a brief introduction on the auxiliary axes (section 2.4);
- notes about module configuration and module software (section 2.5);
- update control procedure (section 2.6);
- machine parameters backup procedure (section 2.7);
- changing the menu name (section 2.8);
- changing the access code (section 2.9);
- enabling and disabling options (section 2.10).

2.2 Selection procedure of machine parameters menu

The selection procedure of the machine parameters menu is the same for each type of control of the DA-60 series.

Do the following to get access to the machine parameter menu:

1. Select the programming mode.
2. Enter 19 to select the machine parameter menu.
3. Enter the access code.
The default access code is 14753 for changing a basic set of machine parameters. The machine parameters followed by (2) can not be changed with this code. When you want to change all the machine parameters you require the special factory code. This code may only be used by authorised people.
4. Press the enter key.

In the machine parameter main menu you also find the versions of the current KO-table and the sequencer file. For detailed information upon the KO-table and Sequencer file version please contact Delem.

In figure 2.2.a you see the main machine parameter menu of the control.




Figure 2.2.a

2.3 Y-axis and general parameters

Behind this selection possibility you find the basic machine parameters to control the Y-axis. This menu also includes the parameters to program the press brake specifications, such as dimensions. See also section 2.7 for parameters backup and chapter 3 for full explanation upon the parameters.

2.4 Auxiliary Axes

Per type of control you can activate a number of auxiliary axes. An auxiliary axis is not active when it is disabled in the axes menu. The required function of an auxiliary axis is determined by the combination of 'axis type' and 'drive type'. Not all combinations are permitted.

Based on the allowed combinations the chapters 4 until 9 have been defined. In these chapters you find explanation on the parameters in more detail. In this section some attention points are mentioned with respect to:

- configuration and enabling auxiliary axes;
- the use of 'dummy axes';
- using an input/output module.

Configuration of axes

To install an axis, two steps must be taken:

1. the module must be selected through menu 3: 'module configuration'. See the next paragraph.
2. the intended axis must be selected through menu 2: 'auxiliary axis'.

'Dummy axis'

There is a situation in which you have to use the auxiliary menu, but you do not have a 'real' axis to control: a so-called 'dummy axis'.

For example, you have a mechanical Z-axis. The control can not automatically control that axis, but you still want the control to calculate the Z-axis positions. In this case you can simulate a Z-axis. The control calculates the positions and you can manually adjust your Z-axis.

To do so, enable an axis and select 'No control' in the axis menu. For such a dummy axis, there is no need to configure a module.

Using an I/O module

For some applications it is only necessary to have extra I/O's and you do not want to control an axis. These extra I/O's can be supplied by a DM04. To add a DM04 to your configuration you can follow the standard procedure of module configuration and selecting an axis in the auxiliary axis menu. Choose the axis type 'IO'.

As the DM04 does not control an axis, no parameters are displayed in the user menus of the programming mode and the execution modes.

2.5 Module configuration

This function serves to select the connected modules in the system and assign the proper axes to those modules.

Chapter 4 contains a detailed description of axis configuration. This should be done first, because otherwise no axis can be controlled.

Futhermore, A new software version for the modules can be loaded directly from floppy disk via the control. Obtain from DELEM a floppy disk with the latest module software. When in the menu 'module configuration' do the following steps:

Step 1: Press the softkey 'update software'.

Step 2: The control checks the files on floppy. When the files have been read the files are displayed on the control screen. An example of this screen:

FILES AVAILABLE ON FLOPPY

DM05 V2.2

MODULE	ID	Boot	Flash
DM05	200766	V1.2	V1.8

Step 3: Check whether the version numbers of the files on floppy have correct version number.

- Step 4: Select with the cursors keys the module you want to upgrade and press S1. Or press S2 to upgrade all the modules at once.
- Step 5: The control displays the message 'are you sure 1/0'. Press 1 to confirm.
- Step 6: The upgrading process starts. When the upgrading process has been finished the message appears 'update successful'.

Illegal DM application

When for some reason illegal DM application software is present in one of the DM modules (meaning you cannot work with the module) then you have to follow the next procedure:

- Step 1: Put a floppy with the application file in the disk drive.
- Step 2: Go to the machine parameters menu and go to the update screen.
- Step 3: Reset the modules by removing and connecting the power supply of the modules.
- Step 4: Select the module to be upgraded and press S1 'update module'.

Causes of possible illegal DM application software in the DM module are:

- Switching off the power supply while upgrading the software.
- Corrupted file with a correct checksum.

2.6 Update control

A new software version for the controls can be loaded directly from floppy disk.

When you load a new software version you also load the language files. Every application floppy contains 12 european and 4 asian languages. Which language files are really loaded, depends on the copy commands in the appl.cmd file. You find this file on the application disk. The following subjects are discussed in this section:

- update control;
- emergency procedure software installation;
- the files on the application floppy;
- loading language sets (european, asian).

Update control procedure

- Step 1: Obtain from DELEM a floppy disk with the latest control (application) software.
- Step 2: Turn the power of the control ON.
- Step 3: Put the floppydisk in the diskdrive of your control.
- Step 4: Go to the machine parameter menu (menu 19).
- Step 5: Enter the access code 14753. The main screen of the machine parameter menu appears.
- Step 6: Select '4' in the machine parameter menu. The next screen appears.




Figure 2.6.a

Make a backup of the current control software with 'create backup'. It is very important to create a backup, because the new software overwrites the current software. Without a backup you might lose valuable information.

Note

When loading a new software version the new software is checked first. If the size of the files on the floppy is **not** correct, the message appears: ** new software too large for memory **.

Note

Starting the control after the update procedure results in the following message:

** parameters in manual mode have been set to initial values **.

This means that the programmed data in the manual mode are lost. This also includes that the previous selected program in the auto mode is not active anymore.

Emergency procedure software installation

In case the above described procedure for updating the control software did not succeed, you can always install the new software following the next procedure. The main difference is that there is no check and there is no backup created.

Step 1: Put the floppy disk in the diskdrive of your control.

Step 2: Switch the power OFF.

Step 3: Switch the power ON.

Step 4: Press '7' immediately after switching the control on. Software is automatically loaded.

The files on the application floppydisk

APPL.CMD	Installation batch file. Contains information for the control how to install the files that are included in this file. You can easily edit this file with a DOS-editor or ASCII-editor.
D*.A00	Application program file: Contains the application for the control.
KO-NNN.BIN	KO-table file (the number NNN differs for each machine supplier). Contains the specification for the unique parameters of the machine. For example: type of hydraulic valve.
PRESS.DEF	Text file with text definitions of the numbers in the sequencer file. Contains definition macro's for use in sequencer source.
SEQ_INP.TXT	Sequencer file: Contains information on the mapping of the internal I/O of the control to the outside I/O (PLC-functionality).
TXT_NNN.BIN	Language text file (for each language a separate file): Contains the text strings of the menus of the control per language. For example: NNN = GB than the language file is english, NNN = I than the language file is italian, etc.

Loading languages

The floppy with the control application contains language text files. There are 16 different languages available: 12 european languages and 4 asian languages. These languages can be divided in two language sets. The european language set contains:

- TXT_GB.BIN (english, compulsory)
- TXT_DK.BIN (danish)
- TXT_D.BIN (german)
- TXT_F.BIN (french)
- TXT_I.BIN (italian)
- TXT_NL.BIN (dutch)
- TXT_S.BIN (swedish)
- TXT_CS.BIN (czech, slovak)
- TXT_ESP.BIN (spanish)
- TXT_FL.BIN (finnish)
- TXT_PL.BIN (polish)
- TXT_LI.BIN (lithuanian)

The asian language set contains:

- TXT_GB.BIN (english, compulsory)
- TXT_CHI.BIN (chinese)
- TXT_CHT.BIN (chinese traditional)
- TXT_JAP.BIN (japanese)
- TXT_KO.BIN (korean)

To load a language the file “appl.cmd” must contain the following command:

```
COPY A:\TXT_NNN.BIN C:\TXT_NNN.BIN
```

This command is necessary for each language you want to load.

When you want to load one or more asian languages, you must also add the following command: COPY A:\ASIA.IMG C:\ASIA.IMG. This file is necessary to load the special asian character font.

You can add these strings to the appl.cmd file using a DOS-editor.

- Type the command ‘EDIT APPL.CMD’ behind the DOS-prompt.
- Add the required language files (and the asia.img file, if necessary).
- Save the changes.
- Load the application.

It is possible to load all language files at once, but this is not recommended. When you load all languages you occupy too much memory. It is advised to load the european set (default situation) **or** the asian set.

Possible problems

- There are no text string on the screen after loading the application. You have forgotten to add the TXT_GB.BIN file (english language) to the APPL.CMD file. The control always starts up in the english language.
- The asian languages have been loaded, but there are no asian characters. You have forgotten to add the ASIA.IMG file to the APPL.CMD file.

Correction tables

A correction table is used to define axis setpoints required by the user. This way, positioning inaccuracies or mechanical errors can be corrected.

There are two table types that are supported by the DA-65/DA-69 controls:

- spindle correction tables;
- bend-allowance tables;

Both tables have a pre-defined format. The spindle correction table is described in section 4.7, the bend-allowance table is described in a separate manual[1].

Loading a spindle correction table

Each axis can have its own spindle correction file. There are three ways to load the spindle correction tables into the control:

- copy the file in the 'appl.cmd' during installation. The concerning files must be copied to b:\tools\mpsupp.
- use a softkey 'load cor. table' in the machine parameter menu page of the particular axis.
- restore the machine parameters from floppy.

When such a table is loaded for a particular axis this is indicated in the machine parameter menu. A backup of the machine parameters will also backup the correction files.

2.7 Machine parameters backup

It is very important to make a backup of the machine parameters each time they have been changed.

- backup parameters (S1) To save the machine parameters on floppy disk.
- restore parameters (S2) To load the machine parameters from floppy disk.
- format disk (S4) You can format a floppy disk with the control to be sure you can always read from and write to the floppy disk. Keep the floppy disks formatted with the control separate from the disks formatted with your PC. Only use 3.5" 1.44Mb disks.

2.8 Changing the menu name

The menu name text is displayed in the header of the main menu of the programming mode. You can change this name using the numerical keys of the frontpanel and the function keys ('alphanumeric'). Press the enter key to accept the new value or name. The maximal length of the menu name is 20 characters.

After 'init memory' in the diagnostic mode the original text string (DELEM) appears again. See also section 2.9 'changing the access code'

2.9 Changing the access code

You can change the access code of the machine parameters menu. The procedure is as follows:

- enter old code;
- enter new code;
- (re)enter new code;
- press the enter key to accept the new value.

Without the correct access code it is impossible to enter the machine parameters menu.

Therefore, be sure if you want to change the default access code (14753). There is one option to reset the access code to its default code. After 'initialise memory' in the diagnostic mode the access code is again reset to the default code.

2.10 Options

A new option can only be used when the option has been enabled in the control. There are seven options to be enabled. For each option that has not been enabled (**not** yet preceded by √ - sign) you have to contact Delem for the unique code. The options with the √ - sign are already enabled in the control and can be used.

OPTIONS		opt. id : 022560	
Part support.....	:	1	
X1-X2 difference.....	:	2	
Ethernet.....	:	3	
Flash disk.....	:	4	
Sensor support.....	:	5	
√ Remote Diagnosis.....	:	6	
Bar code reader.....	:	7	
enter number : =		0	19.1

Figure 2.10.a

Obtaining the option code

The option code can be obtained by ordering the required option. The ordering information must always include the option ID-number. The option id-number of your control is indicated in the header of the option screen. In figure 2.10.a the option id is 022560.

Entering the option code

The option code consist of 16 digits. The 16 digits are divided in 4 groups of 4 digits. The groups are separated by a slash '/'. For each option you require another code.

Example: you have bought the ethernet option. After you have installed this option you have to enable the ethernet option.

- Enter 3 for enabling the ethernet option.
- Enter the Delem code. An example code is 1234/5678/9012/3456. Do not forget the slashes, because these are necessary. You can enter a slash by pressing the frontpanel key with the '.'-sign.

Disabling software options

The software option can simply be disabled by selecting the software option number and entering the option code. This is the same option code as you have used to enable the software option. The ‘√’-sign will disappear.

2.11 Leaving the machine parameters menu

When leaving the machine parameters menu, beware of two things.

- The control checks if all programmed axes are properly assigned to DM modules. If this is not the case, the control issues a warning. See also chapter 4.
- If no machine parameter has been changed, the control returns to the main menu. If any parameter has been changed, the control will reset. If ‘enter’ is pressed while the cursor is on a machine parameter, the control will assume this parameter has been changed and will reset itself when the menu is left.

3 Y-axis and general parameters

In this chapter the general machine parameters and parameters of the Y-axis are described. Each parameter explanation comprises the following items:

- Parameter number. Each parameter has a unique number or code.
- Parameter name. Each parameter has a unique name.
- Range. The maximal value and minimal value that can be programmed.
- Default. The initial value of this parameter. This is also the value after an initialisation.
- Units. The unit of the parameter (s, mm, kg, DA-points, etcetera).
- Function. The function of the parameter.
- Description. Full description of the use and meaning of the parameter.

Standardly all parameters are valid for all controls mentioned in this manual. If there are exceptions then this is indicated.

Parameter 1: Service row 1/0

Range : 0-1
Default : 0
Units : -

Function

To display the actual Y-axis linear scale readings, status and cycle numbers on the screen. There are two possibilities:

1 = Service row present

0 = Service row not present

Press the key  to select the required setting.

Description

The service row is displayed on the upper row of the screen. When switched on the actual Y-axis linear scale readings, the status and cycle numbers are displayed on the screen.

On the control the following line is displayed.

Y1 = 123.15 Y2 = 123.21 status= 1 cyclus = 0 Idle

The service row contains 5 information fields:

Y1 = left side linear scale reading

Y2 = right side linear scale reading

Status = status number

Cyclus = cycle number

Idle = communication information

The fields status, cyclus and communication information can have several values:

- The status number gives information about the Y-axes servo valve control.
 - 1 = no valve control
 - 2 = fast closing
 - 3 = pressing (working stroke)
 - 4 = holding at bending position
 - 5 = decompression
 - 6 = fast opening
 - 7 = manual mode
 - 8 = reference opening Y-axis
 - 9 = reference closing Y-axis
- The cyclus number gives information about the backgauge status.
 - 0 = No movement control of X-axis
 - 1 = Manual mode
 - 2 = Control waits until X-axis reference is passed
 - 1 = Control waits until backgauge is in position, the beam is in UDP, and the opening command is released
 - 2 = Control waits until beam is at muting
 - 3 = Control waits until beam is at clamping point
 - 4 = Control waits until retract of backgauge is completed
 - 5 = Control waits until beam is at bending position, and decompression is completed
 - 6 = Control waits until beam is at muting point after bending (in opening direction of beam)
 - 7 = Control waits until upperbeam has moved from muting to UDP in opening direction
 - 8 = Control waits in UDP until dwell time in UDP has been expired.
 - 11 = Wait until beam is in UDP in case of step-by-step mode when no auto-step-change is selected.
 - 12 = Waiting for C-input active in case step-change code CX = 4 or 5 is selected.
 - 20 = Waiting until all axes have been started.

Note:

When an optional second servo axis is enabled, this will have consequences for cycle numbers -2, and -1:

- 2 = Control waits until X-axis and second servo-axis references are passed. (e.g. X2- or R-axis)
- 1 = Control waits until X-axis and second servo axis are both in position, the beam is in UPD and the opening command is released.

When the second servo axis is configured as X2-axis also cycle number 4 is affected.

- 4 = Control waits until retraction of X-axis and X2-axis are both completed.

- Communication information

The communication information indicates the status of the serial link. The three possible states are:

- Idle: there is no communication
- Busy: communication takes place
- Error: an error has been detected.

The following errors are reported:

- parity error
- overrun error
- framing error

The occurrence of one of these errors is indicated by a number which is displayed on the service row. A combination is also possible. The error numbers are:

16 = parity error

32 = overrun error

64 = framing error

When a combination of errors occur the sum of the error numbers is displayed.

Example:

When a parity and an overrun error occur at the same time the error number will be $16 + 64 = 80$.

code	parity	overrun	framing
16	X		
32		X	
48	X	X	
64			X
80	X		X
96		X	X
112	X	X	X

If you have an error message in the service row, check first whether the specification parameters for serial communication are equally programmed in the control and in the connected computer.

Parameter 2: Y-max

Range : 0.00 - 9999.99
Default : 150.00
Units : mm

Function

Maximal Y-axis value

Description

The maximum position the beam can be moved to. This value is used as a soft limit. When the start button on the control is pressed, the control checks all Y-axis parameters, which are programmed or computed. If a programmed or computed Y-axis value is greater than Y-max the value is limited at the Y-max value and the following error message appears on the screen:

**** Y-axis >>limit ****

The following causes for this error message are possible:

- programmed or computed bending position > Y-max
- programmed or computed mute point > Y-max
- computed clamping point > Y-max

Parameter 3: **Y-min**

Range : 0.00-9999.99
Default : 10.00
Units : mm

Function

Minimal Y-axis value

Description

The minimum position the beam can be moved to. This value is used as a soft limit. When the start button on the control is pressed the control checks all Y-axis parameters, which are programmed or computed. If a programmed or computed Y-axis value is smaller than Y-min the value is limited at the Y-min value and the following error message appears on the screen.

**** Y-axis << limit ****

There are the following causes possible for this error message:

- programmed or computed bending position < Y-min
- programmed or computed mute point < Y-min
- computed clamping point < Y-min

Note

Make sure that the beam can reach this minimum value for the Y-axis. For example, when the beam is in the mechanical top dead centre and the Y-axis value is 5 mm, Y-min must be bigger than 5 mm.

Parameter 4: Y-direction +/- (1/0)

Range : 0-1
Default : 1
Units : -

Function

Y-axis counting direction

Description

When you have programmed '1', the Y-axis value on the user screen counts up when the beam closes. When you have programmed '0', the Y-axis value on the user screen counts down when the beam closes.

Press the key  to select the required setting.

Note

The definition of all the Y-axis machine parameters such as 'Y-max' and 'Y-min' is always in the count up direction.

Example

Y-max = 150.00 mm

Y-min = 10.00 mm




Figure 4.a

Parameter 5: Linear Scale Ref. left (Y1)

Range : 0.00-9999.99
Default : 25.00
Units : mm

Function

Y-axis left side linear scale reference position and parallelism adjustment.

Description

This value is displayed on the screen when the reference on the linear scale is passed. When the reference marker on the linear scale is passed, a reference impulse is given to the electronics. (To see left and right side separately switch service row on).

Note

This value must be greater than the mechanical travel distance on the scale from reference point position to the scale end. This travel distance must also be greater than the mechanical travel of the cylinder from reference point position to the upper dead point mechanical in the cylinder. Make sure that when the cylinder is on the mechanical upper dead stop the Y-axis value read-out is between 5 and 10 mm.

Parameter 6: **Linear Scale Ref. right (Y2)**

Range : 0.00-9999.99

Default : 25.00

Units : mm

Function

Y-axis right side linear scale reference position and parallelism adjustment.

Description

See description 'Linear scale Ref.left'.

Parameter 7: Tool Reference

Range : 0.00-9999.99
Default : 320.00
Units : mm

Function

The reference height for the computation of the Y-axis bend position in case you have selected angle programming. This value is used in the computation of the bending depth, mute point and clamping point.

Description

Maximal opening of the machine measured between beam and table.




Figure 7.a

Parameter TR: Tool Reference correction

Range : 0.00-9.99
Default : 0.00
Units : mm

Function

A correction of the Tool Reference value for head mounted punches.

Description

The control can make a distinction between 'head mounted' punches and 'shoulder mounted' punches.

In case of a shoulder mounted punch (default situation), the control uses the Tool reference and the Tool height to compute the correct Y-axis position. Since the Tool height is measured from the punch' shoulder, this leads to accurate positioning.

In case of head mounted punches, the punch' shoulder might not correspond with the lower edge of the pressbeam. In that case, the position of the Y-axis is no longer accurate.





Figure 7.b

In such case, a correction of the Tool Reference value can be programmed.

Parameter TR: Tool Reference correction (continued)

The Tool reference correction is only taken into account, when a head mounted punch is used in a bend program. Otherwise, it is ignored. The type of punch can be programmed at the punch parameters in programming mode:

PUNCHES		No : 5
		Code: REF PUNCH-0105/DLA
CODE.....		C= REF PUNCH-0105/DLA
RESISTANCE.....	R=	51.23 kN/mm
LENGTH.....	L=	453 mm
Z POSITION.....	Z=	128 mm
RADIUS.....	RA=	1.56 mm
FLATTENING HEIGHT.....	FH=	175.00 mm
SUPPORT TYPE SHOULDER/HEAD 0/1....	ST=	0
HEIGHT 1.....	H1=	20.0 mm
HEIGHT 2.....	H2=	15.0 mm
WIDTH.....	W=	15.0 mm



C=	REF PUNCH-0105/DLA	7.2
	alphanum.	

Figure 7.c

0 = shoulder mounted (default)

1 = head mounted




Figure 7.d

Parameter 8: Linear scale direction Y1 (0/1)

Range : 0-1
Default : 0
Units : -

Function

To change the counting direction of the linear scale encoder pulses of Y1.

Description

Generally the position counting of Y1 should be upcounting when the beam is moving down. With this parameter the counting direction can be inversed to have it correct.

Press the key  to select the required setting.

Parameter 9: Linear scale direction Y2 (0/1)

Range : 0-1
Default : 0
Units : -

Function

To change the counting direction of the linear scale encoder pulses of Y2.

Description

Generally the position counting of Y2 should be upcounting when the beam is moving down. With this parameter the counting direction can be inverted to have it correct.

Press the key  to select the required setting.

Parameter 10: Tandem 1/0

Range : 0-2
Default : 0
Units : -

Function

You have to program this parameter '1', if the tandem option has been installed. When you program this parameter to '2', you can use the tandem input to stop the beam for robot-interfacing.

Description

There are two possible values:

1. One of the outputs of the optional Tandem card, type DBT-01 which has to be used in case of 'tandem', must be connected to the tandem input of the control.
T-input active means that there is no Y-axis speed control. Program this parameter '0' if tandem option is not installed. When you want to apply the tandem function, please ask for our general Tandem description.
2. The same 'tandem' T-input can be used when you have your machine in a robot application.
In this case the beam will be stopped in the pressing phase as long as the T-input is active and will continue the pressing movement when the T-input is no longer active.
Programming this parameter to the value 2 will create the clamp output to be active as well on the clamp position as well on the bending position, after the holding time has been elapsed. With help of this clamp-output signal you can create a T-input signal to keep the beam at the bend position till the robot handling has been finished.
When you want to apply the robot interfacing, please ask for our general robot interfacing description.

Press the key  to select the required setting.

Parameter 11: Parallel switch 1/0

Range : 0-1
Default : 0
Units : -

Function

Parallelism indication switch mounted to use before Y-axis references are passed.

Description

You have to program '1', if you want to use the parallelism switch option. The parallelism switch must be connected to the '='-input of the control. With this input the control has an indication of the parallelism of the upperbeam. When this input is active (switch closed) the left side cylinder is higher than the rightside cylinder. When this input is not active (switch opened) the right side cylinder is higher than the left side cylinder.

When the control gets a fast opening (\uparrow) or fast closing ($\downarrow\downarrow$) command the first time after power on, only one cylinder moves until the '='-input changes from open to closed or vice versa. In this situation the beam is parallel and both cylinders will move to pass the Y-axis references.



When the parallel switch is not mounted (program 0) the control will not use this input before the references are passed.

Press the key  to select the required setting.

After giving a fast opening or fast closing command the relative parallelism of the left side and the right side cylinder will be maintained until references of both linear scales are passed.

See also included drawing.

FIGURE 1



Note	Redrawn	Date		Delem Luchthavenweg 42, 5657 EB Eindhoven, the NETHERLANDS	
Description					
Note	Redrawn	Date		Mounting example of Parallelism Indication Switch	
Description					
Measures in mm, unless otherwise specified	Drawn MI	Date 22-01-1999	Format A4	Number 9056-901	Issue -
			No unauthorized copying allowed		Scale

Parameter 12: **Max. Parallelism**

Range : 0.00-50.00
Default : 2.00
Units : mm

Function

Total maximum allowed parallelism of the beam.

Description

The parallelism is the difference between the left hand cylinder (Y1) and the right hand cylinder (Y2). For the controls there are two parameters that influence the beam parallelism:

1. Parallelism programmable under the programming parameters. This value has effect over the entire stroke of the beam.
2. Parallelism programmable in data preparation, data editing and manual mode. This value is taken into account when the beam reaches the clamping point and stays active until the opening command (↑) becomes active.

The total parallelism is the sum of the values described under 1 and 2. When in automatic mode a total parallelism that is greater than the max. parallelism is detected the control goes to stop and the following warning is displayed on the screen:

**** Parallelism > max. parallelism ****

Parameter 13: Y-opening default

Range : -9999.9 - + 9999.9
Default : 20.0
Units : mm

Function

Default Y-axis opening value.

Description

The value programmed here is used as initial value for the parameter 'Y-axis opening' in the Data Preparation menu of the programming mode.

Parameter 14: **Braking time max**

Range : 0-200

Default : 0

Units : 5 ms

Function

Maximal allowed braking time of the beam.

Description

Every time the control is switched on, the braking time of the beam can be measured. This measurement is initiated the first time a closing command (↓↓) becomes active after power on. The beam starts moving in the closing direction. The control goes to stop 4 mm after both references have been passed and the CNC start output goes low.

This means that the beam must stop. The CNC start output should be connected in such a way that the fast closing command will be switched off and the height retaining valves are closed. When the 'braking time max' has elapsed the speed of the beam must be 2 mm/s or less.

When the speed of the beam is lower than 2mm/s within the allowed time the following message appears on the screen:

**** BRAKING DIST ok, press start to cont. ****

After the start button is pressed again the bending can be continued.

When the beam does not stop within the allowed time the following message appears on the screen:

**** BRAKING DIST too large, cannot continue ****

In this situation it is not possible to continue with bending. If you try to press the start button again the following message appears on the screen:

**** not possible, BRAKING DIST too large ****

Note:

When this parameter is programmed zero the braking distance measurement is disabled.

Parameter MP: Mute programmable per bend step 1/0


Range : 0-1
Default : 0
Units : -

Function

Enable or disable the mute parameter for the operator in the data edit mode.

Description

In the standard situation (OFF), the mute point for each bend is calculated from the mute distance of the die. In some situations, it is desired that the operator can change the mute point for a bend. When this parameter is switched ON, the mute point can be changed for each individual bend of a program.

Press the key  to select the required setting.

Parameter 15: Calibrate valves 1/0

Range : 0-1
Default : 0
Units : -

Function

To adjust the valve offset of the servo valves in the manual mode (not for Hoerbiger hydraulics application).

Description

For valve types that use the $\pm 10V$ output of the DM02, there are two ways to adjust the offset:

- In the diagnostic mode (without using this parameter).
It is possible to adjust the offset of these valves on the valve deflection page in the DM02 module test menu. If the cursor on the screen is set at one of the offsets, it can be adjusted using the handwheel. The range is between -127 and +127. This corresponds with an offset in the range between -600 and +600 mV.
- In the manual mode.
It is also possible to adjust the position of the beam in manual mode with the handwheel. The best way to do this is during the dwell time (status 4) and by programming a long dwell time. This adjustment mode must be enabled with this machine parameter.

When you have programmed this parameter to '1', the softkey 'Y1/Y2 cal. select' appears in the manual mode. With this softkey you select Y1 or Y2 for offset adjustment. The selected side is highlighted on the service row. The selected side can now be adjusted with the handwheel. The corresponding valve offset will be memorized in the DM02 when the other side is selected or on exit of the manual mode.

After the offset adjustment has been finished, this parameter must be reset to zero again.

Press the key  to select the required setting.

Note 1

Offset adjustment for Hoerbiger valves must always be adjusted in the diagnostic program. They cannot be adjusted with the manual mode.

Parameter 16 - 19: **Not used**

Parameter 20: **Relaxation Stiffness**

Range : 0.000-99.900

Default : 0.300

Units : $\mu\text{m/kN}$

Function

Stiffness of frame used to compute decompression.

Description

The stiffness of the frame is used to compute the decompression distance. This value will be multiplied with computed force to obtain decompression distance.

Parameter 21: **Stiffness of frame**

Range : 0.0-100.0
Default : 0.0
Units : %

Function

Stiffness of frame, used for Y-axis depth computation.

Description

When you program bending angles, the corresponding bending depth is computed automatically. Stiffness of frame is used to compute a correction for this bending depth due to the deflection of the frame.

The deflection compensation arm will not fully compensate the deflection of the side frame in order to compensate the Y-axis bend position. Bending the same metal with length of 0,5 meter must have the same angle when bending it with a length of 1 meter or longer.

The difference between the two bends is the tonnage. With 1 meter length the frame will deflect more because it requires more tonnage when bending 0,5 meter.

The value programmed for this parameter must be the deflection of the side frame which is not compensated by the compensation arm. This value is programmed as a percentage of the value programmed for the machine parameter 'Relaxation Stiffness'.


Parameter 22: Calibration 1/0

Range : 0-1
Default : 0
Units : -

Function

Pressure valve calibration.

Description

Program '1' if you want to calibrate proportional pressure valve control. Press the key  to select the required setting. The units at the force parameter in manual mode will be in points from 0 to 255 max. in stead of tons. (0 = 0 mA, 255 = 800 mA)

Calibration procedure:

1. Set parameter to '1';
2. Leave the machine parameter menu;
3. Go to the manual mode;
4. Program e.g. 200 points at the tonnage parameter;
5. Select bottoming;
6. Mount pressure gauge on hydraulic block (pump pressure);
7. Programm Dwell time = 5 s;
8. Perform a working stroke with the press. The tools are now pressed together (punch in die) (Note: Only use punch and die which may work on max. pressure)
9. When tools are pressed together read pressure gauge. In case the pressure is not sufficient for max. tonnage, reprogram DA-output (max. 255) at tonnage parameter. Repeat until your max. tonnage is reached. Remember output value. The value must be programmed at machine parameter 'output- max'.
10. Program a small value at tonnage parameter, e.g. 30 points. Now find min.value at which the beam begins to move in the pressing mode. Make note of this minimum value. This value must be programmed at machine parameter 'output-min'.
11. Select again the machine parameters menu.
12. Now you must program at machine parameters 'Force max.' and 'Force min.' the maximum and minimum tonnage of your press which corresponds with the force units (0-255) at machineparameters 'output -max' and 'output- min'.




Figure 22.a

Note

The mechanical adjustment of the pressure valve has to be done before this calibration procedure.

Parameter 23: **Force max.**

Range : 0-32000
Default : 1100
Units : kN

Function

Maximal tonnage of press brake

Description

Maximal tonnage of the press brake is used to compute the pressure valve output deflection. It is also used to check the programmed and computed values for the force. If the computed force is greater than force max. the following error message will be displayed on the screen.

**** computed force > force max. ****

The message can also appear when the decompression distance is computed because the control needs to compute the force before computing the decompression. When the start button is pressed in manual mode or automatic mode, and the programmed force > force max then the following error message will appear on the screen.

**** programmed force > force max. ****

The value programmed for force is limited at force max. See also calibration procedure described with machine parameter calibration (parameter 22).

Parameter 24: **Force min.**

Range : 0-32000
Default : 100
Units : kN

Function

Minimal tonnage of press brake.

Description

Minimal tonnage of the press brake is used to compute the pressure valve output deflection. It is also used to check the programmed force value. When the start button is pressed and the programmed force is less than force min, the force is limited at force min. See also calibration procedure described with machine parameter calibration.

Parameter FM: **Force Middle**

Range : 0 - 32000

Default : ____

Units : kN

Pressure valve calibration enhancement

When the relation between the output deflection and the pressure is linear then you only have to program force max. and force min. In case the relation between the output deflection and the pressure is not linear you can program force middle.

The default value for this middle parameter is '____', meaning that this parameter is not active.

Parameter 25: **Output max.**

Range : 0-255
Default : 255
Units : DA-points

Function

Pressure valve deflection for max. force.

Description

Output deflection for proportional pressure valve in DA-points to give max. force. There are two ranges of pressure valves:

- 800 mA. These valves can be programmed to max. 136 DA-points.
- 1500 mA. These valves can be programmed to max. 255 DA-points.

See also calibration procedure with machine parameter Calibration.

Parameter 26: **Output min.**

Range : 0-255
Default : 48
Units : DA-points

Function

Pressure valve deflection for minimal force.

Description

Output deflection for proportional pressure valve in DA-points to give min.force.
There are two ranges of pressure valves:

- 800 mA. These valves can be programmed to max 136 DA-points.
- 1500 mA. These valves can be programmed to max 255 DA-points.

See also calibration procedure with machine parameter Calibration.

Parameter OM: **Output middle**

Range : 0 - 255
Default : ____
Units : DA-points

Pressure valve calibration enhancement

When the relation between the output deflection and the pressure is linear then you only have to program output max. and output min. In case the relation between the output deflection and the pressure is not linear you can program output middle.

The default value for this middle parameter is '____', meaning that this parameter is not active.

Parameter 27: Pressure ramp

Range : 0 - 255
Default : 255
Units : DA-points

Function

To program a ramp with which you control the pressure output.

Description

It is possible to program a ramp with which the pressure output will be activated. A lower value will give a large ramp. This parameter is activated at every pressure change.




Figure 27.1 Low-high pressure change




Figure 27.2 High-low pressure change

Parameter 28: **Not used**

Parameter 29: **Not used**

Parameter 30: Closing speed

Range : 0 - 250

Default : 80

Units : mm /s

Function

Fast closing speed

Description

Y-axis speed during fast closing (status = 2, see service row).

The control regulates the closing speed to the value of this parameter.

Parameter 31: Closing speed incr.

Range : 0.0 - 200.0
Default : 100.0
Units : Steps per 5ms.

Function

Y-axis closing acceleration

Description

Acceleration of the Y-axis during closing.

When the beam is in the upper dead point, it accelerates with this value when the closing command becomes active (status = 2, see "service row") until the value "closing speed" is reached.




Figure 31.a

Parameter 32: Closing ramp offset

Range : -9.99 + 9.99
Default : 2.50
Units : mm

Function

Offset to adjust beam at mute position.

Description

When the beam approaches the mute point it starts braking. The braking ramp is computed by the control. With the parameter "closing ramp offset" the start of the braking ramp can be set relative to the mute position.




Figure 32.a

Parameter 33: Del. before closing

Range : 0-200
Default : 0
Units : 5 ms

Function

Synchronised start of beam speed.

Description

When the fast closing command (↓↓) becomes active, the proportional valves will not be opened until this delay time has elapsed.

This time is needed to open the height retaining units before the proportional valves are opened.

Parameter 34: Opening speed

Range : 0 - 250
Default : 80
Units : mm /s

Function

Fast opening speed.

Description

Y-axis speed during fast opening (status=6, see service row).

The control regulates the beam speed during opening of the beam.

Parameter 35: Opening ramp offset

Range : - 9.99 - +9.99

Default : - 1.50

Units : mm

Function

Offset to adjust stop position in UDP.

Description

When the beam is opening with fast speed (status = 6, service row) it starts braking when it approaches the upper dead point. The braking ramp is computed by the control. With this offset the start of the braking ramp can be set relative to the UDP.




Figure 35.a

Parameter 36: **Del. before opening**

Range : 0 - 200
Default : 10
Units : 5 ms

Function

Synchronised start of beam speed

Description

When the opening command (\uparrow) becomes active the proportional valves are not opened until this time delay has elapsed. During this time delay the suction valves must be opened and/or high retaining valves must be closed.

Parameter 37: **Max. pressing speed**

Range : 0.0 - 30.0

Default : 30.0

Units : mm/s

Function

Maximum pressing speed programmable by the operator.

Description

Maximum programmable pressing speed in data preparation, data editing and manual mode.

Parameter 38: **Delay before pressing**

Range : 0 - 200

Default : 40

Units : 5 ms

Function

Synchronised start of press speed.

Description

When the beam is at the mute point and the pressing command (↓) becomes active the proportional valves are not opened until this time delay has elapsed. During this delay the suction valves must be closed.

Parameter 39: Delay before pressing force

Range : 0 - 9999
Default : 0
Units : kN

Function

Pressure during delay before pressing.

Description

During the time delay before pressing the proportional valves are closed (See machine parameter delay before pressing). The pressure valve has a deflection during this time delay which corresponds with the force programmed here.




Figure 39.a

Parameter 40 - 41: **Not used**

Parameter 42: Y-ref search speed

Range : 10.0 - 250.0
Default : 125.0
Units : mm/s

Function

Setting of the Y-axis speed during reference search.

Description

This is the speed with which the beam is controlled in the upward direction during the reference search cycle.

When the reference search cycle of the Y-axis is started, the beam is controlled in the upward direction with the speed which is programmed here. The sequence of the complete reference cycle depends on the position of the beam:

- if the beam was positioned below the reference point, the Y-axis will reach the reference point and set the position;
- if the beam was positioned above the reference point, the beam will also move upwards with the programmed speed. When the beam reaches the mechanical upper dead point, the control will detect after a short period that there is no movement and will stop the movement. As soon as a closing command is generated, the beam is controlled downwards with closing speed (parameter 30). The beam should now find reference.

Parameter 43 - 45: **Not used**

Parameter 46: Closing brake ramp trim

Range : -2.0 - +2.0
Default : 0.0
Units : -

Function

To adjust the ramp to brake the beam from the fast closing phase to mute.

Description

For large machines it is sometimes desired to adjust (or trim) the brake ramp during closing.




Figure 46.a

The recommended way to adjust this parameter

- Program the closing speed lower or equal to the hydraulic closing speed.
- Program machine parameter 32 (closing ramp offset) to 0 (zero).
- Set the machine to 'adjust' mode (hand input active).
- Adjust parameter 46 until you get a smooth stop of the beam at the mute point.
- Program then machineparameter 32 to a value that the beam stops about 0.5 - 1 mm lower than the programmed mute position.

Note

This parameter is related to machine parameter 47 (= gain trim for closing movement), increasing this parameter will also result in steeper braking and vice versa.

Parameter 47: Closing gain trim

Range : -1.0 - +1.0
Default : 0.0
Units : -

Function

To adjust the gain in fast closing phase of the beam.

Description

It is sometimes desired to adjust (trim) the preset gain of the pressbrake movement during the closing phase. Especially when you have some vibrations in the closing phase, you can decrease the gain.

Programming 0.0 will give the preset standard value for the gain.

Parameter 48: **Opening gain trim**

Range : -1.0 - +1.0
Default : 0.0
Units : -

Function

To adjust the gain in the opening phase of the beam.

Description

It is sometimes desired to adjust (trim) the preset gain of the pressbrake movement during the opening phase. Especially when you have some vibrations in the opening phase you can decrease the gain.

Programming 0.0 will give the preset standard value for the gain.

Parameter 49: Pressing gain trim

Range : -1.0 - +1.0
Default : 0.0
Units : -

Function

To adjust the gain in the pressing phase of the beam.

Description

It is sometimes desired to adjust (trim) the preset gain of the pressbrake movement during the pressing and decompressing phase. Especially when you have some vibrations in the pressing phase you can decrease the gain. But also the positioning at the programmed position must be correct.

Programming 0.0 will give the preset standard value for the gain.

Parameter 50: Machine length between the cylinders

Range : 0 - 15000

Default : 2000

Units : mm

Function

The length of machine table between the cylinders will be used to compute the table deflection.

Description

This parameter is used to compute the machine table deflection. The table deflection is only computed when a crowning adjustment device is connected. (See chapter 6).

You have to program the machine length between the mid position of the 2 cylinders. See also machine parameters 'Inertia under beam', and 'Inertia upper beam'.




Figure 50.a

Parameter 51: **Inertia under beam**

Range : 0 - 99999
Default : 624
Units : 1000 cm⁴

Function

The inertia of the machine table is used to compute table deflection.

Description

This parameter is used to compute the machine table deflection. The table deflection is only computed when a crowning adjustment device is connected (see chapter 6).

See also machine parameters 'Machine length between the cylinders' and 'Inertia upper beam'.

Example

Inertia = 1349000

Program: 1349

Parameter 52: **Inertia upper beam**

Range : 0 - 99999
Default : 776
Units : 1000 cm⁴

Function

The inertia of the machine upper beam is used to compute table deflection.

Description

This parameter is used to compute the machine table deflection. The table deflection is only computed when a crowning adjustment device is connected. (See chapter 6).

See also machine parameters 'Inertia under beam' and 'Machine length between the cylinders'.

Example

Inertia = 1349000

Program: 1349

Parameter 53: **Not used**

Parameter 54: **Total machine length**

Range : 0 - 15000
Default : 2000
Units : mm

Function

Total machine length for check in relation with the product length.

Description

When the operator programs a bending length longer than the programmed total machine length a warning appears on the screen.

Parameter 55: **Punch clamp pressure**

Range : 0-255
Default : 0
Units : DA-points

Function

Pressure setting for correct punch clamping.

Description

It is possible to control the pressure valve output for the hydraulic system, specifically meant for the punch-clamp application. This can only be achieved by means of the sequencer file.

Parameter 56: **Die clamp pressure**

Range : 0-255
Default : 0
Units : DA-points

Function

Pressure setting for correct die clamping.

Description

It is possible to control the pressure valve output for the hydraulic system, specifically meant for the die clamp application. This can only be achieved by means of the sequencer file.

Parameter 57: Valve ramp closing

Range : 0 - 255
Default : 255
Units : DA-points / 5 ms

Function

To program a valve deflection ramp at the start of status closing (status 2).

Description

When you program 255 than you have no ramp. The lower the value you program the longer the ramp will be.




Figure 57.a

Parameter 58: **Not used**

Parameter 59: **Opening pressure**

Range : 35 - 100
Default : 100
Units : %

Function

Pressure setting during the opening phase.

Description

You can adjust the pressure during the opening movement of the beam. This value is a percentage of the maximum pressure (machine parameter 25).

Note

Make sure that the value for this parameter is high enough! If it is too low the beam will not move. This is a dangerous situation! When after switching on the pump the beam does not move upwards, the control sets the output signal UDP active.
When the beam is below its reference point it will come down without finding its reference when a closing command is given. This can damage the tools!

Therefore the minimum value is set to 35%.

Parameter 60 - 119: **Not used**

Parameter 120: **KO-table from floppy on/off 1/0**

Range : 0 - 1
Default : 0
Units : -

Function

To read the KO-table from floppy.

Description

During development and testing of KO-tables it can be helpful to read this file from floppy instead of loading a complete new application.

0 = using KO-table from the internal application;

1 = loading KO-table from floppy.

Press the key  to select the required setting.

With this parameter set to 1 the KO-table is only read from floppy during start up.

After testing the KO-tables you should set this parameter to 0 again. Make sure the required KO-table is on the application floppy with the other files and execute the normal application load procedure.

Parameter 121: Sequencer from floppy on/off 1/0

Range : 0 - 1
Default : 0
Units : -

Function

To read the sequencer file from floppy.

Description

During development and testing of sequencer files it can be helpful to read this file from floppy instead of loading a complete new application.

0 = using sequencer file from the internal application

1 = loading sequencer file from floppy

Press the key  to select the required setting.

With this parameter set to 1 the sequencer file is only read from floppy during start up.

After testing the sequencer file you should set this parameter to 0 again. Make sure the required sequencer file is on the application floppy with the other files and execute the normal application load procedure.

Parameter 122: Sequencer debug on/off 1/0

Range : 0 - 1
Default : 0
Units : -

Function

To activate the sequencer debug facility. Press the key  to select the required setting.

Description

When the sequencer debug facility has been switched on (=1) a soft key appears in the manual mode. Activating this key will generate a test row on top of the screen. In this row you can check the equations of the sequencer. This test row overwrites the service row (in case the service row is active).




Figure 122.a

Parameter 123-130: Sequencer options

Range : 0000 - 1111
Default : 0000
Units : -

Function

To set general purpose sequencer option flags.

Description

You can set 4 flags per sequencer option parameter. Each flag can have the value 0 or 1.

- sequencer option flags 4..1 123 = 0000
- sequencer option flags 8..5 124 = 0000
- sequencer option flags 12..9 125 = 0000
- sequencer option flags 16..13 126 = 0000
- sequencer option flags 20..17 127 = 0000
- sequencer option flags 24..21 128 = 0000
- sequencer option flags 28..25 129 = 0000
- sequencer option flags 32..29 130 = 0000

To set option flag 1 and 2 you should program parameter 123 as 0011. Pay attention that you count **from right to left**. The lowest flag of each parameter is the most right digit.

These option flags are mapped on the flags 7664 - 7695. These flags have also been added to the press.def file. Therefore with parameter 123 set to 0011 the flags 7664 and 7665 will be set to 1.

Variable	Flag
M-OPTION1	7664
M-OPTION2	7665
...	...
M-OPTION32	7695

Note 1

If you are using the standard Delem sequencer and not creating your own sequencer, then these parameters have no function.

Note 2

For more information about working with the sequencer file please refer to the sequencer manual. This manual can be requested at Delem.

Parameter 131: UAP from floppy on/off 1/0

Range : 0 - 1
Default : 0
Units : -

Function

To read the UAP.CMD file from floppy.

Description

During development and testing it can be helpful to read the UAP.CMD file from floppy instead of loading a complete new application.

0 = use the internal UAP file, if valid.

1 = load UAP.CMD from floppy

Press the key  to select the required setting.

With this parameter set to 1 the UAP.CMD file is read from floppy during start up.

The file UAP.CMD can be compared with the file APPL.CMD: it is a short text file with instructions for the control to copy UAP files from floppy to the control. Make sure the intended UAP (User Application) is present on the floppy disk.

After testing the UAP.CMD file you should set this parameter to 0 again. Once the UAP has been tested and approved, the instructions of the UAP.CMD file can be integrated in the normal application loading procedure. Therefore you should modify the APPL.CMD file on the application floppy. Make sure the required UAP file is on the application disk with the other files.

For more information about UAPs please contact Delem.

4 Auxiliary axes

4.1 Introduction

In this chapter the configuration procedure of axes is explained. This procedure is valid for all axes, except the Y-axis.

Typical parameters for servo drives or AC drives are explained in chapter 5. Special axes and their parameters are explained in the chapters 6 through 9.

The following axis types can be programmed on a control:

- X-axis
- X2-axis
- R-axis
- R1-axis
- R2-axis
- R3-axis
- R4-axis
- Z-axis
- Z1-axis
- Z2-axis
- ZM-axis
- I-axis (chapter 8)
- general purpose, X1-axis
- general purpose, X2-axis
- general purpose, X3-axis
- general purpose, X4-axis
- Part support and additional axes (chapter 9)
- Crowning (chapter 6)
- Digital axes (chapter 7)

4.2 Configuration procedure of axes


An axis is configured in two steps:

1. select and configure the correct module for an axis,
2. enable an axis and program its parameters.

The only exception to this rule is the Y-axis. Once a module is configured to control the Y-axis, the parameters for the Y-axis can immediately be programmed through option 1: Y-axis and general parameters.

Box number The boxnumber consists of 2 digits. The first digit indicates the type of connected module and the second digit indicates the sequence number of the same types of modules. The box number helps you organize your relay cabinet.

Box Number = X X



Module type

Sequence number 0 - 9

DM01 = 1

DM02 = 2

DM04 = 4

DM05 = 5

Example:

A DA-65 connected with 1x DM02, 1x DM05 and 3x DM01 will have box numbers 20, 50, 10, 11 and 12 to be programmed at the box number parameters at the respective axes.

By default, 8 modules can be connected to the control through the HSB link.

On the DA-65 and DA-69 it is possible to create two additional HSB links with option cards, which makes it possible to connect a total of 24 modules to a control.

If more than ten modules of the same type are present in the system, the second digit of the box number may also be an alphanumeric character. For example, for more than ten DM01 modules the box numbers are: 10..19, 1A, 1B, etc. The alpha-numerical input can be done in the standard way.

DM-identifier Every module has been foreseen with a sticker, indicating the unique identifier. When the cursor is placed on the identifier parameter it will therefore be possible to list the identifier numbers of the connected modules. The number is also known in the board computer of the module. The control communicates via the high-speed bus with the connected modules.

NOTE


The CNC control and the connected modules must get their power supply at the same time for correct communication and initializing. The modules within 1 second after switching on the control.

Step 2 is done with option 2 of the parameters menu: Auxiliary axis. The following screen appears:

MACHINE CONSTANTS				mach.no: 1
AXIS: 1	enabled	X	Servo	
AXIS: 2	enabled	XZ	Servo	
AXIS: 3	enabled	R	Servo	
AXIS: 4	disabled	R	No Control	
AXIS: 5	disabled	R	No Control	
AXIS: 6	disabled	R	No Control	
AXIS: 7	disabled	R	No Control	
AXIS: 8	disabled	R	No Control	
				19.0
previous page	next page		change par.	enable/disable

Figure 4.2.b

A maximum of 24 axis can be configured through this menu.

- In the first column is indicated whether an axis is switched on or off. Use the softkey S6 'enable/disable' to change its setting.
- In the second column the axis type is selected with the key . A pop-up menu appears, in which all known axis types are listed. Select the correct type.
- In the last column the drive type for the axis is selected. Available choices are Servo, AC or No Control. If 'No Control' is selected, the axis values are calculated and displayed in the user screens, but no 'real' axis is controlled: a so-called 'dummy axis'.

Once an axis has been configured in this menu, press softkey S5 'change par.' to program the parameters of the axis.

When the machine parameters menu is left, the control checks if the axes are configured properly. If this is not the case, the control will issue a warning:

**** Warning: Not all axes are mapped on a module. ****

Continue ? 1/0:

Press 1 to continue or 0 to return to the machine parameters menu. To solve this issue, repeat steps 1 and 2 and check your axis/module configuration.

4.3 R-axis specific parameters

The following R-axis specific parameters are explained:

- backgauge-die collision detection with R-axes;
- automatic R-axis adjustment.

Backgauge-against-die collision detection

When you have enabled a R-axis (also R1 and R2) then the collision detection for backgauge-against-die is active. A collision can occur when the R-axis position is negative. This means that the backgauge finger lower is than the die height.

There are three critical situations. For all these situations a necessary condition is that the **R-in** input has to be active to be able to move the X-axis into the safety zone!

- The X-axis has to move into the V-die safety zone. The R-axis will first move to a positive position before the X-axis moves to the programmed position.




Figure 4.3.a

- When the R-axis has to move from positive to negative, the X-axis must move out of the V-die safety zone. The X-axis starts moving backwards but the R-axis does not move until the X-axis is out of the safety zone.




Figure 4.3.b

- When the next R-position is negative and within the V-die safety this will always give collision. The control will give a warning and the "start" button will not be accepted.




Figure 4.3.c

Automatic R-axis adjustment

The zero position of the R-axis always corresponds with the position (height) of the upper side of the die. When the height of the die changes - you have selected a die with another height - the zero position of the R-axis is automatically adjusted to the height of the new programmed die.

In the machine parameters menu of the R-axis it is also necessary to program the R-axis reference value (parameter 5, only in case of encoder position measurement). This parameter is necessary to be able to adjust the R=0 position to the top of the die. The reference value you have to program is the distance between the R-axis position at the reference pulse (of the encoder) and the top of the die.




Figure 4.3.d

Besides the zero position adjustment you also have to program in the machine parameters the maximum and minimum value of the R-axis. These values are related to the absolute R-axis values. These R-axis values have to be determined without tools. The maximum value of the R-axis is the mechanical stroke length above the table and the minimum value of the R-axis is the mechanical stroke length below the table. So the Rmax. and the Rmin. parameter are related to the top of the table.

The value of the R-axis on the control screen always relates to the top of the die!

4.4 Z-axis specific parameters

There are two types of Z-axis:

- A single Z-axis. In this case both fingers move symmetrically from and to each other from the middle of the machine. The sheet is also always positioned from the middle of the machine.
- A Z1-axis and a Z2-axis. In this case the fingers are separately controlled by an auxiliary axis. Default the middle of the sheet is positioned in the middle of the machine, but also other positions can be programmed.

A single Z-axis

The Z-axis position is automatically computed. To compute these positions the parameter Z-distance is necessary. You can find the Z-distance parameter in the program constants menu of the programming mode. The Z-distance is the distance from the end of the sheet to the middle of the Z-axis finger.




Figure 4.4.a

In data preparation and data editing the Z-value is automatically computed during postprocessing. The Z-axis value is computed according to the formula:

- $Z = L - 2 \times Z\text{-distance}$ (L = programmed product length)

A Z1-axis and Z2-axis

When you have a Z1-axis and a Z2-axis, you have to program four machine parameters:

- Z1min;
- Z1max;
- Z2min;
- Z2max.

To prevent collision of the fingers the following condition is necessary:

- $Z2\text{min} - Z1\text{min} > \text{mechanical distance}$

This distance should always be taken into account.

Therefore you must program Z1min value and Z2min value with respect to this distance.

Example: if the mechanical distance between the fingers is 25mm and Z1min = 100. Then you have to program Z2min to 125. Furtheron the control will take care that this distance is always respected.

When you press the start button and 'Z2min - Z1min is smaller than the mechanical distance between Z1 and Z2', the message 'Z1 - Z2 axis conflict' appears on the screen. Start is not accepted in this case.

In the automatic mode and manual mode the programmed values for Z1 and Z2 are checked to prevent collision between the Z1- and Z2-axis.




Figure 4.4.b

For calculation of the Z-axis positions, the following operator parameters are relevant:

- Product length. This is a product parameter.
- Z-distance. This parameter can be found in the program constants menu and defines the distance of the end of the sheet to the middle of the Z-finger.
- Z-position. This is a punch parameter to program an offset for the punch position, related to the middle of the machine. As such, this parameter can be positive or negative.

Default the Z1- and Z2-axis values are computed positioning the middle of the sheet in the middle of the machine. The next formulas are used:

- $Z1 = 0,5 (Z2max - Z1min) + Z1min - 0,5L + Z\text{-distance} + Z\text{-position}$
- $Z2 = 0,5 (Z2max - Z1min) + Z1min + 0,5L - Z\text{-distance} + Z\text{-position}$

When you want to use another machine position then you can program the Z1-axis value. The corresponding Z2-axis value will be computed when you place the cursor at the Z2-axis parameter in the data preparation or data editing menu. In this case the following formula is used:

- $Z2 = Z1 + L - 2x Z\text{-distance}$

Example

The following parameters have been programmed.

- Z1min = 0
- Z1max = 3000
- Z2min = 200
- Z2max = 3200

- Z-distance = 10 mm
- Product length = 1000 mm

In figure 4.4.c you find the computed values for the default situation and the situation with a programmed Z1-position.




Figure 4.4.c

When the Z1 and Z2 axes have to move in the same direction, a collision could occur when the speed of both axes is not adjusted exactly the same. Delaying the start of the movement of one of the axes will prevent this. Which one of the axes is delayed depends on the direction of the movement. The delay time is 500ms.

Zm: a third Z-axis

For long, narrow sheets it can be useful to have a 3rd Z-axis (Z_m) to support the sheet in the middle. By adding Z_m to the configuration, the sheet will be perpendicular to the press beam when the operator pushes the sheet against the back gauge (see figure).




Figure 4.4.d

The position of Z_m is automatically calculated to be in the middle between Z_1 and Z_2 . The minimum distance between the axes is guarded and the post processing also includes Z_m . For the moment Z_m is not supported in 3D graphical mode.

4.5 A second X-axis

A second X-axis is called an X2-axis. When you have enabled an X2-axis then the programmed value of the X-axis (or X1-axis, this is programmable with machine parameter X/X1 select) is automatically copied to the X2-axis. In data editing the X-axis value is prompted when you are with the cursor on the X2-axis.


Also the programmed values for X-opening (retraction) and X-code will also be active for the X2-axis. In automatic mode and Step-by-step mode you can program corrections for the X-axis as well as for the X2-axis.

When a second X-axis is implemented, several X2-specific parameters should be programmed. These parameters are used to describe the backgauge construction that is installed and will be described in this section.

Parameter: XX
X2 relative to X (1=on, 0=off)

Range : 0-1
Default : 0
Units : -

Function

To indicate whether or not a special X2-axis is installed, which movement is relative to the movement of the X-axis. Press the key  to select the required setting.

Description

This parameter must be set to '1' if a special backgauge is installed. With this system, the backgauge finger for the X-axis is fixed on a beam and the X2-construction is mounted on the same beam.




Figure 4.5.a

Such an axis should be configured as follows:

- the parameter 'X2 relative to X' should be programmed to 1
- the parameter 'backgauge type' should be programmed to 0(=console)
- the parameter 'decimal point position' should be the same as for the X-axis
- the minimum and maximum values should be according to the mechanical range of the X2-gauge
- the reference position should be adjusted such, that its zero position equals the position of the X1-axis.

In user mode the X2 value is converted for the user. If X1 and X2 are programmed equal then the two fingers will have the same backgauge position.

Parameter: 7
Max X1X2 difference

Range : 0 - 9999

Default : 0

Units : mm

Function

To program the maximum allowed difference between the two X-axes.

Description

With this parameter a maximum allowed difference in values between the X1- and X2-axis can be programmed.

Parameter: 8
Backgauge type

Range : 0-1
Default : 0
Units : -

Function

To program the type of backgauge construction that is used.

Description

With this parameter the type of backgauge instruction on the machine is indicated. The control makes a distinction between two types of backgauges, console type or crossbeam type.

0 = console type (default)

1 = crossbeam

Press the key  to select the required setting.

The different backgauge types are described at the beginning of this section. For a system with a relative X2 axis as described with parameter XX, this parameter should also be set to 0.

Console type

This is a backgauge construction with independent gauges, each backgauge is driven by its own gauge construction. The positions of X1 and X2 can be programmed directly. The parameter 'backgauge type' should be programmed to 0.

In user mode, the gauge positions and axis values are identical.




Figure 4.5.b

Crossbeam

With this construction both gauges are mounted on one beam. Different positions for X1 and X2 are achieved by turning the beam. The parameter 'backgauge type' should be programmed to 1. In case of a crossbeam construction, the four distances A, B, C and D should be programmed to describe the dimensions of the gauge construction. These dimensions will be used in the calculation of gauge positions.




Figure 4.5.c

Parameter: 9 - 12
Distance A-D

Range : 0 - 9999
Default : 0
Units : mm

Function

Dimensions of a crossbeam backgauge system.

Description

These four distances are used to describe the geometry of the machine in case a crossbeam is used.

The meaning of these dimensions is:

- A: Length of fingers measured perpendicular from the turning point of the Z-axes to the end of the fingers.
- B: Distance between the turning points of the crossbeam.
- C: Z1-axis position of the left turning point of the crossbeam.
- D: Radius of the end of the finger (0=no radius).




Figure 4.5.d

4.6 X1X2 difference programming (option)

This option serves to determine the X1 and X2 axes positions from the required backgauge positions. It means that the user can program the required backgauge positions in the data edit mode and the control will automatically calculate the necessary axis values. This feature can be used with a crossbeam system or a console system. For this matter, a system with a relative X2-axis may also be considered as a console system. There should also be a Z1- and Z2-axis installed.

There are two ways to program X1X2 difference:

- angular method
- projection method

These methods can be chosen in menu 11 with the program constant 'X1X2 difference programming'.

Angular method

With the angular method, the finger positions can be programmed with an angle value and the distance between the two fingers. The angle is defined as the angle between the bend line and the fingers of the crossbeam.

These values can be programmed in data edit mode in a special pop-up window. This pop-up window can be activated through a softkey 'gauge func' that is only available when the cursor is placed on X or X2. Values of either X1 or X2 can be adjusted according to this cursor position.

DATA EDITING		bending no: 1	prod.no: 1003																
		draw.no:																	
punch.....UP=		2																	
die.....UN=		2																	
bend method.....BM=		0																	
<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: right;">ANGLE.....α =</td> <td style="text-align: right;">-7.13</td> </tr> <tr> <td style="text-align: right;">LENGTH.....ΔZ=</td> <td style="text-align: right;">383</td> </tr> <tr> <td style="text-align: right;">Gauge pos.....GP=</td> <td style="text-align: right;">0</td> </tr> <tr> <td style="text-align: right;">R-finger position....R =</td> <td style="text-align: right;">0</td> </tr> <tr> <td style="text-align: right;">X1-finger position...X1=</td> <td style="text-align: right;">98.4</td> </tr> <tr> <td style="text-align: right;">X2-finger position...X2=</td> <td style="text-align: right;">50.9</td> </tr> <tr> <td style="text-align: right;">Z1-finger position...Z1=</td> <td style="text-align: right;">1666</td> </tr> <tr> <td style="text-align: right;">Z2-finger position...Z2=</td> <td style="text-align: right;">2049</td> </tr> </table>				ANGLE.....α =	-7.13	LENGTH.....ΔZ=	383	Gauge pos.....GP=	0	R-finger position....R =	0	X1-finger position...X1=	98.4	X2-finger position...X2=	50.9	Z1-finger position...Z1=	1666	Z2-finger position...Z2=	2049
ANGLE.....α =	-7.13																		
LENGTH.....ΔZ=	383																		
Gauge pos.....GP=	0																		
R-finger position....R =	0																		
X1-finger position...X1=	98.4																		
X2-finger position...X2=	50.9																		
Z1-finger position...Z1=	1666																		
Z2-finger position...Z2=	2049																		
delay time.....TX=	0	sec																	
R-axis.....R =	0	mm																	
Z1-axis.....Z1=	1666	mm																	
α =		-7.13 °	4.2																
			cancel																

Figure 4.6.a

If the cursor is on X and the pop-up window is activated, the values for the angle, the distance and the position of the X1-finger can be programmed through X1 and Z1. The values of X2 and Z2 will be adjusted according to the values of distance and angle, they cannot be altered directly. If the cursor is on X2 and the function is activated, angle, distance and the position of the X2-finger can be altered and X1 and Z1 will then be calculated.




Figure 4.6.b

In case of a crossbeam system, X1/X2 must be programmed as the distance from the bend line to the gauge point, Z1/Z2 is simply the value of the Z-axis on the crossbeam.

In the case of a console system, the programmed gauge position co-ordinates and the calculated axis values are similar.

Projection method

With the projection method, the exact gauge positions of the two fingers must be entered in a similar pop-up screen in user mode. Both X- and Z- values refer to the finger positions. The resulting axes values will be calculated from these finger positions.

In the case of a crossbeam system, axis values will be calculated from the position co-ordinates. In the case of a console system, the gauges co-ordinates and the axis values are identical. Hence there is not much sense in using the projection method with a console type system: axis values can be programmed directly in data edit mode anyway.




Figure 4.6.c

4.7 The spindle correction table

With this feature an axis position can be corrected for deviations in the spindle. The spindle deviations can be programmed in a table. The correction at every other position of the spindle is computed by means of linear interpolation.

A method to determine the contents of this table can be the following:

- First adjust the reference position of the axis.
- Program a value for the axis position in Manual mode and press start. Measure the actual backgauge position.
- Repeat this procedure several times.
- Compute the deviation of each measured point according to the following definition:
 $\Delta(\text{Delta}) = \text{measured value} - \text{programmed value}$

Note

The number of points which must be measured depends on the specification of the spindle.

- Now make a graph of these results.




Figure 4.7.a

Select up to the maximal number of points from this graph which will give the best approximation of the original curve. These points must be programmed in the table.

The resolution of the axis values in the correction table is 1mm. The resolution of the deviation (delta) is 10 times the axis resolution. E.g. axis resolution is 0.1 mm, then the resolution of the deviation is 0.01mm. The points must be programmed in an increasing order of the axis positions. The length of the intervals between the points may vary. An entry with the axis position not programmed (____) or programmed with a lower value as its predecessor will be considered as the end of the table.

To build a spindle correction table, a plain ASCII text file must be created with table values as follows:

```
;VERSION: Example-X
;CONFIG: X: C
X10 C0.5
X500 C1.0
X1000 C2.6
```

In this example, three setpoints are defined for the X-axis. The 'VERSION' statement on the first line can be used to define a name or version for the table, but this is not compulsory. The 'CONFIG' statement must be used to define the format of table entries. On the lines that follow, the actual table entries are written.

A spindle correction table can be loaded from floppy. To be able to recognise a table for a certain axis, each table has a unique filename, 'spcorXX.tab'. In this name, 'XX' must be replaced by the index number of the required axis.

The following axis numbers can be used in filenames for tables:

00	X-axis
01	R-axis
02	R1-axis
03	R2-axis
06	Z-axis
09	Z1-axis
10	Z2-axis
13	I-axis
15	X2-axis
17	general purpose, X3-axis
18	general purpose, X4-axis
19	general purpose, X1-axis
20	general purpose, X2-axis
21	Part support
40	R3-axis
41	R4-axis

A table can be loaded in the parameter menu of the appropriate axis. In this menu the softkey 'load cor. table' is available. When pressed, the control will search for a valid file in the floppy drive. If loading was successful, the string 'SpCor.:' will appear in the top row followed by the name or version of the table, if present in the textfile. If loading was not successful, the message 'File does not exist' is displayed.

A loaded correction table can also be erased with the softkey 'delete cor. table'. This softkey appears automatically after a table has been loaded.

The contents of the spindle correction tables can be edited on the DA control. When a spindle correction table is installed for a servo axis the following soft key will appear in the auxiliary axis screen:

S6: edit table

If S6 is selected, a submenu is opened. The actual contents of the table are shown on the screen. Two columns are shown with the following tags:

X = axis position

C= correction value

The tags shown on the screen should correspond with the tags as specified in the table file.

With the softkeys the following functions are available:

S3	modify entry	the contents of the line, which is selected with the cursor, can be modified
S4	new entry	enter a new line in the table
S5	delete entry	the line, which is selected with the cursor, can be deleted
S6	save table	the file, as shown on the screen, is saved to the internal memory

5 Auxiliary axes parameters

5.1 Introduction

In this chapter the machine parameters for several axis types are explained.

Paragraph 5.2 shows standard parameters for axes.

Paragraph 5.3 shows parameters for Servo axes.

Paragraph 5.4 shows all parameters for axes with AC drives.

Parameters for special axes are explained in chapters 6 through 9.

5.2 Standard axis parameters

On the following pages the standard axis parameters are explained.

These standard parameters will occur on almost all axes, regardless of Servo control or AC control.

Parameter 7: **Min. value**

Range : -999999.00 - +999999.00

Default : -9999.00

Units : mm

Remark : In case of an R-axis (R, R1 and R2) see also section 4.3.

Function

Minimal auxiliary axis value in display units. When the axis is moved manually the position is also limited at this value.

Parameter 8: **Max. value**

Range : -999999.00 - +999999.00

Default : 9999.00

Units : mm

Remark : In case of a R-axis (R, R1 and R2) see also section 4.4.

Function

Maximal auxiliary axis value. When the axis is moved manually the position is also limited at this value.

Parameter 12: In position tolerance

Range : 1.0 - 999.0

Default : 1.0

Units : mm

Function

Zone in which the in-position output is active.

Description

Each axis has an in-position output. The parameter 'In position tolerance' defines the zone in which this output is active. The output is active when:

Programmed value - actual value < +/- In position tolerance




Figure 5.2.a

Parameter 28: **Position measurement system**

Range : 0 - 1
Default : 0
Units : -

Function

To select the position measurement system of the axis.

Description

You can select for each axis two types of position measurement systems.

0 = encoder

1 = potentiometer

Press the key  to select the required setting.

Encoder position measurement

The value of this parameter has also consequences for the use of other parameters.

When you have the encoder position measurement, then you can program the following parameters:

Pre scaling.....	9
Reference position.....	5
Ref. search direction.....	6
RSD switch mounted.....	17
Reference search speed.....	21

Potentiometer position measurement

When you have the potentiometer position measurement you have instead of parameters 9, 5, 6, 17 and 21 the following parameters to program:

AD-min.....	29
AD-max.....	30

Parameter SL: Number of slaves

Range : 0 - 4
Default : 0
Units : -
Remark : Not for X- and X2-axis

Function

To program the number of slave axes.

Description

It is possible to have four axis in slave function of the master axis. This means that up to five R-axes can be driven to the same value as programmed for one single R-axis in the control. Each slave axis is independently controlled by a DM module.

You only have to program the master axis position and the slaves axes will follow. The slave axes positions will not appear in the user interface. When you have defined the number of slaves, the softkey 'show slaves' appears. With this softkey you get access to the slave axes parameters. The following parameters are required for each slave axis:

- Reference position;
- encoder count direction.

All other machine parameter settings are automatically used/copied from the master axis.

Note

The control also has the possibility to program the slave axes positions individually. In this case the parameter Individual pos. programmable should be 1. In Data preparation, Data editing and Manual mode the softkey 'show slaves' will appear to program the slave positions.

Parameter 9: **Pre scaling**

Range : 0.000 - 9999.999

Default : 1.000

Units : counts/mm

Remark : Only in combination with the **encoder position measurement system**.

Function

To set the scaling for correct encoder counting. Number of count pulses (of the encoder) per mm.

Description

This parameter defines the relation between the count pulses and the values programmed and displayed on the control.

Example

Axis with spindle with pitch of = 5.0 mm and 50 encoder pulses per rotation. This means 50 pulses/5.0 mm displacement.

50 pulses/5.0 mm = 10 pulse/mm

The encoder pulses should be multiplied by 4 because, all four states of one period are counted by the control.

Pre scaling = $10 * 4 = 40$

Parameter 5: **Reference position**

Range : -9999.99 - +9999.99

Default : 0.00

Units : mm

Remark : Only in combination with the **encoder position measurement system**.

Function

Auxiliary axis reference position.

Description

This is the position of the reference encoder on an auxiliary servo axis.

In the manual mode of the control you can display the actual position of an auxiliary axis with the softkey 'manual positioning'. If the auxiliary axis has not passed its reference yet the position is displayed as follows: -.-.

The auxiliary axis will start its reference search cycle after it receives its first position from the control.

The reference search cycle is as follows:

- 1 Push the start button of the control.
- 2 The axis moves to one side until an end of travel (EOT)-switch is reached.
The direction in which the axis starts moving depends on the parameter 'reference search direction'. Reference pulses during this movement are ignored.
- 3 After 200 milliseconds the axis moves in the opposite direction until the reference is passed.
- 4 Axis moves to the programmed position.

Parameter 6: Reference search direction

Range : 0 - 1

Default : 0

Units : -

Remark : Only in combination with the encoder position measurement system.

Function

Axis reference search direction.


Description

When the start button on the control is pressed the first time after power on, all the axes start their reference search cycle. This also includes auxiliary servo axes.

This parameter defines the direction in which the servo axis starts moving to search for the reference:

0 = search in counting down direction

1 = search in counting up direction

Press the key  to select the required setting.

The complete reference search cycle is described at parameter 17, 'RSD switch mounted'.

Parameter 17: RSD switch mounted

Range : 0 - 1

Default : 1

Units : -

Remark : Only in combination with the encoder position measurement system.

Function

RSD-switch mounted and used for reference search yes (1) or no (0).

Description

Two systems for reference search are implemented:

1. without reference search direction switch (program 0)
2. with a reference search direction switch (program 1)

Press the key  to select the required setting.

System 1

The standard reference search system. For this system the motor drive must be equipped with a direction sensitive enable/disable input.

System 2

The motordrive does not need any direction sensitive enable/disable input for reference search. Also you are free where you place the reference search direction switch (RSD). It may be the same switch; EOT-switch.




Figure 5.2.a

The advantage of the reference search cycle with system 2 is that in case the RSD switch is mounted in the middle of the X-axes stroke, the control senses the status of this switch. In case the X-axis is between the die and RSD switch a normal reference search cycle is initiated. In case the X-axis is between the RSD and EOT+ switch the status of the RSD switch indicates that reference search can start in the direction of the RSD switch (forward). Overall you will have shorter reference search cycle time. Another advantage is the fact that it is not needed to mount the limit switches for ref.-search.

Note 1

Reference switch activated means RSD input on axis connector is low. Reference switch not activated means input is high (+24V).

Note 2

To be sure that the Ref.-switch (RSD) is mounted, the control will only move the backgauge over the following distance for taking reference. This in case the RSD-switch input is active (low) at the start of the reference search cycle.

- A) Ref. search direction backwards: 1.5 x (max. position - ref. position)
- B) Ref. search direction forwards: 1.5 x (ref. position - min. position)

Reference search sequence in combination with R- and Z-axes

When the start button is pressed the first time after power on all axis will search reference first. During reference search the following cycle will be respected:

1. The X- and X2-axis move to the reference search direction switch (RSD). When RSD is activated the X- and X2 is stopped.
2. Start Z- and R-axes reference search cycle.
3. In case of Z1 Z2 they will stop at their reference position.
4. When the R-axes have found their reference they will move directly to their programmed positions.
5. When the Z-axes are at their reference position and the R-axes are at their programmed position the X-axis will start to move and take their reference. At the same time all other axes, except the R-axes, will start to move.




Figure 5.2.b

Parameter 21: Reference search speed

Range : 1-100

Default : 50

Units : %

Remark : Only in combination with the **encoder position measurement system**.

Function

Setting of the axis speed during reference search.

Description

The search speed for the reference marker can be adjusted by programming a percentage of the max. output voltage (10V).

Parameter 29: **AD-min**

Range : 0 - 1024 (10 bits)
Default : 0
Units : AD-points
Remark : Only in combination with the **potentiometer position measurement** system.

Function

Value in AD (analog-digital)-points corresponding to the minimal axis position.

Description

As there is in this case no encoder and therefore no reference pulse to determine the position of the axis you have to measure the position. If the control knows which voltage corresponds to the minimal and the maximal position, then each position in between can be determined.

The value of the analog input of the module varies between 0 V and 10 V. The accuracy of the analog inputs is 10 bits, meaning that you can divide the 10 V into 1024 steps or AD-points. So 1 V corresponds with 102.4 AD-points.

Move the axis to the minimal mechanical position (this corresponds with the programmed Min. Value), measure the voltage between the analog input and the 0V and calculate the corresponding AD-points. This value should be entered.

Parameter 30: **AD-max**

Range : 0 - 1024 (10 bits)
Default : 0
Units : AD-points
Remark : Only in combination with the **potentiometer position measurement** system.

Function

Max value in AD-points of axis position.

Description

see description AD-min.

Parameter 24: Encoder count dir (0/1)

Range : 0 - 1

Default : 0


Units : -

Remark : Only in combination with the **encoder position measurement system**.

Function

To change the counting direction of the axis encoder pulses.

Description

The position counting of the axis can be changed with this parameter. Press the key  to select the required setting.

Parameter 14: **Default value**

Range : -9999.99 - +9999.99
Default : 0.00
Units : mm

Function

Auxiliary axis default (position) value.

Description

This value is displayed on the control as initial value for the axis position when making a new program in Data Preparation. This value is also displayed in the Manual mode after the control is initialized.

Parameter 76: Spindle allowance

Range : 0-1

Default : 1


Units : -

Function

One or two side positioning selection:

0= one side positioning

1= two side positioning

Press the key  to select the required setting.

Description

The one or two side positioning can be selected to overcome mechanical tolerances with two side positioning. In case of one side positioning the positioning direction is from a larger to a smaller position.

Parameter 84: **Overrun**

Range : 0 - 9999
Default : 50
Units : count pulses of encoder

Function

Overrun distance in case of one-side positioning.

Description

The overrun value is always in the upcounting direction and is only valid with one-side positioning.

Parameter 85: **Overrun wait time**

Range : 0 - 999
Default : 500
Units : 5 ms

Function

Wait time at the overrun position (see parameter 84) before the axis starts positioning in the opposite direction.

Description

This parameter can be used to program a delay before the motor is controlled in the opposite direction.

Parameter 15: **Decimal point pos.**

Range : 0 - 3
Default : 0
Units : -

Function

Decimal point position of auxiliary axis value.

Description

This parameter defines the resolution (digits after the decimal point) in which the auxiliary axis values are programmed and displayed on the control.

0 = no resolution, value in mm

1 = 0.1 mm units

2 = 0.01 mm units

3 = 0.001 mm units

Press the key  to select the required setting.

Parameter 27: Correction (X)

Range : -9.999 - +9.999
Default : 0.000
Units : mm / 100mm
Remark : In case of R-, R1-, R2-axes.

Function

To compensate for mechanical deviations during X-axis movements.

Description

When the X-axis moves to another position it is possible that the R (R1,R2)-axis position changes. You can use this parameter to program a position correction.
See figure 4.2j how to program the parameter. Notice the sign of the parameter value!

Correction (x) = measured value - programmed value

Example
= 80mm - 82mm = -2 mm/ 50mm
= -4 mm / 100 mm




Figure 5.2.c

Parameter 27: Correction (X)

Range : -9.999 - +9.999

Default : 0.000

Units : mm / 100mm

Remark : In case of a Z1- and Z2-axis, only in combination with a X1-axis and a X2-axis.

Function

To compensate for mechanical deviations during X-axis movements.

Description

When the X-axis moves to another position it is possible that the Z1Z2-axis position changes. You can use this parameter to program a position correction.

See figure 4.2k how to program the parameter. Notice the sign of the parameter value!

Correction (X) = measured value - programmed value

Example

= 135 mm - 140 mm = 5 mm / 50 mm

= 10 mm / 100 mm




Figure 5.2.d

Parameter 25: Correction (Z)

Range : -9.999 - +9.999
Default : 0.000
Units : mm / 100mm
Remark : In case of a X1-axis and a X2-axis

Function

To compensate for mechanical deviations during Z1Z2-axis movements.

Description

When the Z1Z2-axis moves to another position it is possible that the X1- and X2-axis position changes. You can use this parameter to program a position correction.

See figure 4.21 how to program the parameter. Notice the sign of the parameter value!

Correction (Z) = measured value - programmed value

Example

= 53 mm - 50 mm = 3 mm / 25 mm
= 12 mm / 100 mm




Figure 5.2.e

Parameter 25: Correction (Z)

Range : -9.999 - +9.999
Default : 0.000
Units : mm / 100mm
Remark : In case of R1-axis, R2-axis

Function

To compensate for mechanical deviations during Z1Z2-axis movements.

Description

When the Z1Z2-axis moves to another position it is possible that the R1(R2)-axis position changes. You can use this parameter to program a position correction.

See figure 4.2m how to program the parameter. Notice the sign of the parameter value!

Correction (Z) = measured value - programmed value

Example

$$\begin{aligned} &= 80 \text{ mm} - 81 \text{ mm} = -1 \text{ mm} / 25 \text{ mm} \\ &= -4 \text{ mm} / 100 \text{ mm} \end{aligned}$$




Figure 5.2.f

Parameter 26: Correction (R)

Range : -9.999 - +9.999
Default : 0.000
Units : mm / 100mm
Remark : In case of X2-axis

Function

To compensate for mechanical deviations during R-axis movements.

Description

When the R-axis moves to another position it is possible that the X2-axis position changes. You can use this parameter to program a position correction.

See figure 4.2n how to program the parameter. Notice the sign of the parameter value!

Correction (R) = measured value - programmed value

Example

= 100.8 mm - 100 mm = 0.8 mm / 20 mm
= 4 mm / 100 mm




Figure 5.2.g

Parameter 26: Correction (R)

Range : -9.999 - +9.999
Default : 0.000
Units : mm / 100mm
Remark : In case of Z1-axis, Z2-axis

Function

To compensate for mechanical deviations during R-axis movements.

Description

When the R-axis moves to another position it is possible that the Z1 (Z2)-axis position changes. You can use this parameter to program a position correction. See figure 4.2o how to program the parameter. Notice the sign of the parameter value!

Correction (R) = measured value - programmed value

Example

$$\begin{aligned} &= 105 \text{ mm} - 103 \text{ mm} = 2 \quad \text{mm} / 50 \text{ mm} \\ &= 4 \text{ mm} / 100 \text{ mm} \end{aligned}$$




Fig. 5.2.h

Parameter 122: Axis retract programmable


Range : 0 - 1
Default : 0
Units : -

Function

To enable or disable a retract for the selected axis.

Description

A retract can be programmed for each axis by the operator for each step in a bending program. A softkey is then made available to the operator, in which the retract distance for a particular step can be programmed.

To enable this possibility, this parameter should be set to '1'. Press the key  to select the required setting.

Parameter 130: Safety distance

Range : 0.00 - 999999.00

Default : 50

Units : mm


Remark: only for X/X1 axis, not for X2 axis

Function

To program a safety zone for the backgauge, where the backgauge will move with low speed.

Description

Sometimes it is required that the backgauge moves with low speed when it is within a small distance from the die. This depends on local regulations. With this parameter, a safety distance is programmed. When the backgauge moves within this distance from the die, the backgauge will move with a low speed. This safety distance is related to the limit of the safety zone of the die (it is not an X-position!).



The maximum allowed speed within this area can be programmed at parameter 131, Safety speed.

For an X2 axis this parameter is not available: the safety distance programmed at the X/X1 axis is also valid for the X2 axis.

Parameter 131: **Safety speed**

Range : 0 - 100
Default : 1
Units : %

Function

To program a low, safe speed for the backgauge when it is within a programmed distance from the die.

Description

Low speed setting for the backgauge, valid when it is within the safety distance from the die. See parameter 130, Safety distance, for more information. This speed is programmed in a percentage of the maximum speed.

5.3 Parameters for Servo axes

On the following pages the servo axis parameters are explained. These parameters will occur at all servo axes, unless otherwise indicated.

The first few parameters are specific servo gain parameters to optimise servo axis positioning.

The following servo parameters are valid:

- 2 Gain
- 3 Switch
- 4 Ramp

Inside the switch zone the Gain is active and outside the switch zone the Ramp is active. See the Axis parameters 'Gain', 'Switch' and 'Ramp'.




Fig. 5.3.a

These parameters must be programmed as follows:

- Increase gain until servo motor starts to oscillate.
- Decrease the value until the oscillation disappears and program this value for the gain.

Parameter 2: **Gain**

Range : 1.0 - 15.0
Default : 9.0
Units : -

Function

Position gain factor.

Description

For an accurate servo axis positioning three parameters are used: 'Ramp', Switch and 'Gain'.

- When the actual position is near the programmed position the factor 'Gain' is used. The gain factor is valid within the programmed 'switch' zone.

Parameter 3: **Switch**

Range : 1 - 100

Default : 3

Units : mm

Function

Axis switching point from 'ramp' area to 'gain' area.

Description

For an accurate servo axis positioning three parameters are used: 'Ramp', 'Switch' and 'Gain'.
When (actual position - programmed position) > Switch, the braking factor 'Ramp' is used,
otherwise 'Gain' is used.

Parameter 4: Ramp

Range : 0.0 - 1000.0

Default : 5.0

Units : -

Function

Servo axis braking factor.

Description

Servo axis braking factor in case $(\text{actual position} - \text{programmed position}) > \text{switch}$.
See also Auxiliary axis parameters 'Gain' and 'Switch'.




Figure 5.3.c

Parameter 11: **Manual speed high**

Range : 1.00 - 100.00
Default : 10.00
Units : %

Function

Axis manual movement high speed limit.

Description

In manual mode and the automatic mode you can select 'manual position'. The axis can now be moved with the handwheel on the front panel. The movement is depending on the speed with which you turn the handwheel.

This parameter value is the highest possible axis speed for manual movement. You program this parameter as a percentage of the speed output (+/- 10V).

Parameter 13: Acceleration ramp

Range : 5 - 1275

Default : 160

Units : ms

Function

Acceleration ramp for the connected axis.

Description

This parameter defines the time needed to reach the full speed output. An acceleration ramp means that when the axis starts moving to a new position the speed signal increases with a certain ramp until the maximum needed speed has been reached.





Figure 5.3.e

Parameter 34: Axis speed programmable

Range : 0-1
Default : 0
Units : -

Function
To enable axis speed programming in user mode.

Description
This parameter defines whether or not the speed of the selected axis can be programmed in user mode. Press the key  to select the required setting. If enabled, then in programming mode and manual mode the operator can program the axis speed in a percentage of the maximum speed.




Figure 34.a

5.4 Parameters AC axes

In this paragraph, the parameters for axes with AC drives are discussed.

When using AC drives, it is possible to program 1-side positioning or 2-side positioning. Beside this, it must be indicated whether a one-speed or 2-speed motor drive is used.

With these parameters you can optimize the positioning accuracy of the AC-axis:

- Breakpoint high speed (Bfs)
- Breakpoint low speed (Bss)
- Overrun (OR)
- Overrun wait time
- Stop time (T)

Two side positioning:




Figure 5.4.a

When the axis approaches the programmed position the motor output is switched off when the actual position is within Bss and the stop time T has elapsed.

The stoptime should be less then the time between two successive encoder pulses.

One side positioning:




Figure 5.4.b

One side positioning is useful to overcome mechanical inaccuracies in the spindle. Final positioning of the axis is always done from a higher to a lower position. So when the axis moves from a high to a low position, positioning is done immediately. When the axis moves from a low to a high position, the axis will move to the overrun position (= programmed position +OR). After that, the axis starts moving in the opposite direction and positioning takes place.

When the difference between the new programmed position and the actual position is smaller than BSS the axis is always moved to the overrun position first, also in case of two side positioning.

Parameter 78: Drive type

Range : 1 - 2

Default : 1

Units : -

Function

Selection of type of drive.

Description

1= one-speed AC- or DC-drive (digital outputs)

2= two-speed AC-or DC-drive (digital outputs)

Press the key  to select the required setting.

Parameter FG: **Break point high speed (Bfs)**>

Range : 0 - 9999
Default : 100
Units : count pulses of encoder
Remark : Only in case of two side positioning

Function

Switch point from high speed to low speed.

Description

This is the breakpoint for one-and two-speed drives.

Parameter SG: **Break point low speed (Bss)**>

Range : 0 - 9999
Default : 10
Units : count pulses of encoder
Remark : Only in case of two side positioning

Function

Switch point from slow speed to off.

Description

This is the point to switch off the low speed.

Parameter FS: **Break point high speed (Bfs)**<

Range : 0 - 9999
Default : 100
Units : count pulses of encoder
Remark : Only in case of one side positioning

Function

Switch point from high speed to low speed.

Description

This is the breakpoint for one-and two-speed drives.

Parameter SS: **Break point low speed (Bss)**<

Range : 0 - 9999
Default : 10
Units : count pulses of encoder
Remark : Only in case of one side positioning

Function

Switch point from slow speed to off.

Description

This is the point to switch off the low speed.

Parameter 83: **Stop time**

Range : 0 - 99

Default : 0

Units : 5 ms

Function

Stop time for correct positioning.

Description

This is the delay time before switching off the low speed after the 'Breakpoint slow speed' (BSS) has been reached. See also figure 5.3.a and 5.3.b.

Parameter 86: Dc low speed

Range : 1 - 100
Default: : 4
Units: : %

Function

To program the low speed when a 2-speed DC-motor has been applied.

Description

It is possible to control a 2-speed motor drive through the analog output of the DM module. In that case, high and low speed are recognised by two voltage levels which must be programmed in the machine parameters. You have to program a percentage of the maximum output control voltage which is +/- 10V.

This parameter refers to low speed of the negative direction movement.

Parameter 87: Dc high speed

Range : 1 - 100

Default: : 4

Units: : %

Function

To program the high speed when a 2-speed DC-motor has been applied.

Description

You have to program a percentage of the maximum output control voltage which is +/- 10V.

This parameter refers to high speed of the negative direction movement. See also parameter 86 for more information.

Parameter 88: **Dc low speed** >

Range : 1 - 100

Default: : 4

Units: : %

Function

To program the low speed when a 2-speed DC-motor has been applied.

Description

You have to program a percentage of the maximum output control voltage which is +/- 10V.

This parameter refers to low speed of the positive direction movement. See also parameter 86 for more information.

Parameter 89: Dc high speed >

Range : 1 - 100

Default: : 4

Units: : %

Function

To program the high speed when a 2-speed DC-motor has been applied.

Description

You have to program a percentage of the maximum output control voltage which is +/- 10V. This parameter refers to high speed of the positive direction movement. See also parameter 86 for more information.

6 Crowning

6.1 Introduction

In the auxiliary axes menu you can program the required axes. The number of axes you can program depends on the type of control.

The following axes combinations can be programmed:

- Calculated crowning value: choose axis type 'CROWNa'
- Non calculated crowning value: choose axis type 'CROWN'.

Both axis types can be used for AC crowning and hydraulic crowning. In section 6.3 the parameters are discussed in order of appearance. The connection and adjustment of an AC crowning device is different from the connection of an hydraulic crowning device. Another difference is the fact that AC crowning has a position feedback and hydraulic crowning not.

If you have programmed the required 'axis type' you can program the corresponding parameters after pressing the softkey 'change parameters'.

6.2 Installation of the crowning device

There are two types of crowning devices:

- AC crowning;
- Hydraulic crowning.

Installation of an AC crowning device

An AC crowning device has normally a potentiometer feedback for the actual value. The position of the deflection device is controlled by a (one speed) AC motor. To control this motor the Y-axis module has two outputs: "A>" and "A<". These outputs correspond with the outputs 12 and 13 of the DM02 in the standard connection diagram.




Figure 6.2.a

Installation of an hydraulic crowning device

In case of hydraulic crowning you should connect the crowning axis according to the standard connection diagram as indicated by DF-out.




Figure 6.2.b

6.3 Crowning device programming and adjusting

The crowning device position and the crowning device adjustment are necessary to work properly with the crowning device.

Crowning device position and adjustment for calculated purposes

When you use the calculated crowning device then the required crowning is based on the programmed values of three machine parameters. The following machine parameters must therefore be programmed (See also Y-axis and general parameters of chapter 3):

- inertia upper beam;
- inertia under beam;
- machine length.

The required crowning value is calculated (computed value in data preparation and data editing). To be sure that the crowning device reaches the computed position, the crowning device should be adjusted as follows:

- Go to to the auxiliary menu and program axis 'CROWNa'.
- Press 'change parameters'.
- Program for Min. value and DA-min 0.
- Program for Max. value and DA-max 255 (standard resolution) or 1023 (high resolution).
- Move the crowning device to its mechanical minimal position by means of the handwheel.
- Measure the deflection in hundreds of mm. Remember this value and program it at the end of the adjustment procedure for the parameter Min. value. The programmed Min. value is the measured value times hundred. Measured value 1.05, programmed value 105 (In most cases this value will be near to zero).
- Read out the deflection value on the screen (Manual mode, manual positioning). This value corresponds with the number of DA-points. Remember that value and program it at the end of the adjustment procedure at the parameter DA-min.
- Now move the crowning device to its mechanical maximal position.
- Measure the deflection in hundreds of mm. Remember this value and program it at the end of the adjustment procedure for the parameter Max. value. The programmed Max. value is the measured value times hundred.
- Read out the deflection value on the screen (Manual mode, manual positioning). This value corresponds with the number of DA-points. Remember the value and program it at the end of the adjustment procedure at the parameter DA-max.
- Program now the found values to the corresponding machine parameters.

Example

The crowning device position must always be programmed in 0.01 mm units and the initial value and the decimal point position must be 0.

- The minimal deflection = 0 mm at 25 DA-points.
- The maximal deflection = 1.20 mm at 185 DA-points.

For this example the crowning device parameters must be programmed as follows:

DA-min. = 25
Min. value = 0
Max. value = 120

DA-max. = 185

Note: The unit indication "mm" will not be displayed on the screen (data preparation and data editing) of the control.

Crowning device position and adjustment for non calculated purposes

When you use the non calculated crowning device the required crowning is not based on the three machine parameters, as described before. You have to program the required value.

To be sure that the crowning device is adjusted to the programmed position. The crowning device should be adjusted as follows:

- Go to to the auxiliary menu and program axis 'CROWN'.
- Press 'change parameters'.
- Program for Min. value and DA-min 0.
- Program for Max. value and DA-max 255 (standard resolution) and 1023 (high resolution).
- Move the crowning device to the mechanical minimal position by means of the handwheel or to the position that corresponds with 0 % crowning.
- Read out the deflection value on the screen (Manual mode, manual positioning). This value corresponds with the number of DA-points. Remember that value and program it at the end of the adjustment procedure at the parameter DA-min.
- Now move the crowning device to the mechanical maximal position or to the position that corresponds with 100% crowning.
- Read out the deflection value on the screen (Manual mode, manual positioning). This value corresponds with the number of DA-points. Remember the value and program it at the end of the adjustment procedure at the parameter DA-max.
- Program now the found DA-values to the corresponding machine parameters and program Min. Value at 0 (read 0 %) and Max. Value at 100 (read 100 %).

6.4 Crowning parameters

AUXILIARY AXIS 5		text:	deflect	
		axis type:	An. out	
Min. value.....	7=	0.00	%	(2)
Max. value.....	8=	100.00	%	(2)
Standard/high resolution (0/1).....	31=	0	Standard	(2)
DA-min.....	18=	0.00	%	(2)
DA-max.....	19=	100.00	%	(2)
DA-out linear/table (0/1).....	22=	0	Linear	
Hysteresis.....	23=	0.00		
Default value.....	14=	0.00	%	
Decimal point pos.....	15=	0	1	(2)
Max computed value.....	31=	0	kN	
Automatic R-axis correction (0/1).....	AR=	1	ON	
7=		0.00		19.51
		reset to default		

Figure 6.4.a

Parameter 7: **Min. value**

Range : -999999.00 - +999999.00
default : -9999.00
Units : display units

Function

Minimal value of auxiliary axis in defined display units. When the axis is moved manually the position is also limited at this value.

Description

The value of this parameter depends on the accuracy you want to have for your axis. For calculated crowning the resolution must always be in hundreds (0.01).

The parameter 'decimal point position' should stay 0 (default value) in this case. See parameter 15.

Example

The axis must be programmed with a resolution of 0.01 mm. When the minimal value of the axis is 10.00, you should program 1000.

In case of non calculated crowning the Min. Value is normally 0 (0%). Depending on the parameter 'Decimal point position' this value can also be 0.0 or 0.00 or 0.000.

Parameter 8: **Max. value**

Range : -999999.00 - +999999.00

Default : 9999.00

Units : display units

Function

Maximal value of auxiliary axis in defined display units. When the axis is moved manually the position is also limited at this value.

Description

See description Min. Value.

Parameter 15: **Decimal point pos.**

Range : 0 - 3
Default : 0
Units : -

Function

Decimal point position of auxiliary axis value.

Description

This parameter should always have the value 0 in case of the calculated crowning axis function.

In the non calculated crowning selection it is possible to set the decimal point position as required.

0 = no resolution

1 = 0.1 resolution

2 = 0.01 resolution

3 = 0.001 resolution

Press the key  to select the required setting.

Parameter 18: DA-min

Range : 0.00 - 100.00

Default : 0.00

Units : %

Function

Minimal value in percentage.

Description

With this parameter the minimum voltage value of the crowning unit is programmed in a percentage of the maximum voltage.

Parameter 19: **DA-max**

Range : 0.00 - 100.00

Default : 1.00

Units : %

Function

Maximal value in percentage.

Description

With this parameter the maximum voltage value of the crowning unit is programmed in a percentage of the maximum voltage.

Parameter 22: DA-out linear/table (0/1)

Range : 0 - 1
Default : 0
Units : -

Function

Linear or non-linear output scaling of the crowning device.


Description

The output scaling of the crowning device can be based on a linear relation between the output signal and the position of the crowning device (minimum + maximum position).

It is also possible to drive a non-linear crowning device.

0 = linear

1 = table (non- linear)

Press the key  to select the required setting.

When you have selected the non-linear crowning device you can program the output scaling via a table. The values of DA-min and DA-max are ignored in this case. Go to the table with the 'next page' softkey.

The table has 10 entries. For each position the output value (in DA-points) can be programmed. At least 2 entries should be programmed. The actual output value will be computed by means of linear interpolation. In case of two entries you should program the first and second entry.

AUXILIARY AXIS 5		text:	deflect
		axis type:	5
PROGRAMMED AXIS POSITION		DA OUTPUT VALUE	
position....P 1=	___	da-output...DA 1=	0
position....P 2=	___	da-output...DA 2=	0
position....P 3=	___	da-output...DA 3=	0
position....P 4=	___	da-output...DA 4=	0
position....P 5=	___	da-output...DA 5=	0
position....P 6=	___	da-output...DA 6=	0
position....P 7=	___	da-output...DA 7=	0
position....P 8=	___	da-output...DA 8=	0
position....P 9=	___	da-output...DA 9=	0
position....P10=	___	da-output...DA10=	0
P 1= 0		19.32	
previous page		erase point	
		reset to default	

Figure 6.4.b

Parameter 23: **Hysteresis**

Range : 0.00 - 100
Default : 1
Units : DA-points

Function

To determine the switch-off point (switch-off zone) for the programmed DA-value. See also figure 6.1a.

Description

The hysteresis value determines the switch-off zone around the DA-value in the feedback application. The value of the hysteresis depends on your crowning device. A hysteresis might be necessary to stop the crowning device at the correct position, because of the inertia of the crowning device.

Parameter 14: **Default value**

Range : -999999.00 - +999999.00
Default : 0.00
Units : display units

Function

Initial axis value

Description

The default value is used as initial value for the axis in case of a new numerical program (data preparation menu).

Parameter 31: **Max. computed value**

Range : 0.00 - 9999.99
Default : 0.00
Units : mm

Function

To program the maximum value that the control will calculate when calculated crowning is used.

Description

When the crowning position is calculated for a bending step, it will never exceed this value.

Parameter 31: **Standard / high resolution (0) /1**

Range : 0 - 1
Default : 0
Units : -


Function

To determine the resolution of the potentiometer

Description

0 = standard resolution of potentiometer, 8 bits (values 0 - 255)

1 = high resolution of potentiometer, 10 bits (values 0 - 1023)

Press the key  to select the required setting.

See also parameters DA-min, DA-max and hysteresis.

Parameter AR: **Automatic R-axis correction (0/1)**

Range : 0 - 1
Default : 1
Units : -

Function

This parameter serves to switch automatic correction of the R-axis position on or off.

Description

Normally the R-axis position is corrected to compensate for the crowning movement. This to avoid collision between backgauge and die.

It may not always be necessary to adjust the R-axis position to compensate for the crowning movement. In case of an hydraulic crowning, the crowning-pressure is built-up in the lower machine table only during the pressing cycle. Since the backgauge is not moving during that phase, there is no need to adjust the R-axis value. This parameter can then be used to have automatic correction or not.

Press the key  to select the required setting.

7 Digital outputs

7.1 Introduction

Digital output axes are 'axes' that are driven by digital outputs. They do not require an additional DM-module. The number of axes you can program depends on the type of control.

The following Digital output axes can be programmed:

- R-digital: axis type 'RD'.
- on / off: axis type 'FD'
- second on/off: axis type 'FD2'

For each axis, choose drive type 'dig. out'.

The parameters are discussed in order of appearance. You can program the corresponding parameters after pressing the softkey 'change parameters'.

The parameters of R-digital are discussed in section 7.2 and the parameters of On/off in section 7.3.

7.2 Digital R-axis

You can use a digital R-axis in stead of a fully motor driven R-axis (servo R-axis or AC R-axis). This type of axis is driven with digital outputs. These digital outputs - F1 and F2 in the included default connection diagram - determine the possible digital R-axis situations or positions.

As there are only two digital outputs available, you can program maximal 4 different positions of the digital R-axis.

There are seven different R-axis situations. Therefore some situations must be regarded as the same axis position.

For each situation you have to program a parameter. Each parameter has three digits. The right digit is to determine if this R-axis situation is allowed. When a situation is not allowed ($A = 0$) then the values of F1 and F2 are ignored. The construction of your digital R-axis determines which situations should be regarded as the same position (programmed with the same F1 and F2 value).

In the data preparation menu you must enter the three digit code that corresponds with the required R-axis position. When you program a graphical product, then the positions are computed automatically during postprocessing. The lay-on backgauge functionality is not supported by the 3D bend sequence menu. In figure 7.2a you see the possible situations.




Figure 7.2.a

Example

First you decide which situations are allowed. Then you determine which of the allowed situation have the same R-axis position. Then you determine which F1-F2 code belongs to the - maximal four - situations.

A possible solution might be (see figure 7.2a):

- situation 1, 2, 3 and 4 have the same R-axis position. This is position 1 and is allowed.
- situation 5. This is position 2 and is allowed
- situation 6. This is position 3 and is allowed
- situation 7. This is position 4 and is not allowed

The parameters values are now for example:

- parameter HG (position 1) 001
- parameter HS (position 1) 001
- parameter MG (position 1) 001

- parameter MS (position 1) 001
- parameter LE (position 2) 011
- parameter OE (position 3) 101
- parameter O2 (position 4) 110

The digital outputs F1 and F2 can have the values 0 and 1. The three digit code of the parameters is entered from right to left. In figure 7.2b you see the default parameter screen.




Figure 7.2.b

Parameter 14: **Default value**

Range : 00 - 11
Default : 00
Units : -

Function

Auxiliary axis default situation value.

Description

This value is displayed on the control as initial value when making a new program in Data Preparation. This value is also displayed in Manual mode after the control is initialized.

7.3 On/off outputs

If you require digital outputs then you can define the number. The maximum number of digital outputs you can program is 5: F5, F4, F3, F2 and F1. The outputs F1 - F4 correspond with the output pins 10 - 13 of the DM02 in the standard connection diagram. F5 is standard not mapped on an output.

However, when you already have enabled a digital R-axes you only have three digital outputs left. The R-digital always uses F1 and F2. In this case you can only use F3, F4 and F5 for additional digital outputs.

AUXILIARY AXIS 6		text:	on/off
		axis type:	11
Number of FD outputs.....NO=	3		(2)
Ls FD output.....LS=	3		(2)
Default value.....14=	000		
NO= 3		19.31	
		reset to default	

Figure 7.3.a

There are three parameters to define the number of digital outputs, the least significant digital output and the default value of the selected digital outputs in the user screens.

There is a possibility to program a second set of digital function outputs. To activate these outputs, choose axis type 'FD2' in the auxiliary axis menu. This will enable a second set of digital outputs to a maximum of 5. This second set can be programmed in the same way as the first set.

These 5 output signals are not mapped on module outputs. To utilise these outputs, the Delem sequencer on the control will have to be modified.

Parameter NO: **Number of FD outputs**

Range : 1 - 5
Default : 5
Units : -

Function

The number of digital outputs you want to use. The number you can use is always related to the use of a digital R-axis. The digital outputs you want to use, are always in succession.

Parameter LS: Ls FD output

Range : 1 - 5
Default : 3
Units : -

Function

To define the least significant digital output. The default value is F3, because in case of a digital R-axis F2 and F1 are already used. The digital output numbering is from right to left, from least significant to most significant.

Parameter 14: Default value

Range : 00000 - 11111

Default : 00000

Units : -

Function

The default value of the digital outputs - programmed in this menu - in the user screens. If the Number of FD outputs is 3, then the range of the default value becomes automatically 000 - 111. So, the number of digits refers to the number of digital output programmed.

Examples digital outputs

	digital outputs				
	F5	F4	F3	F2	F1
Situation 1:			X	X	
Situation 2:	X	X			
Situation 3:		X	X	X	X
Situation 4:	X		X	X	
Situation 5:		X		X	X

In **situation 1** there is no digital R-axis and the on-off parameters should be programmed as:

- the number of digital outputs: 2
- the least significant output: 2
- default value: 00 (this can be programmed to 01, 10 or 11)

In **situation 2** there is no digital R-axis and the on-off parameters should be programmed as:

- the number of digital outputs: 2
- the least significant output: 4
- default value: 00 (this can be programmed to 01, 10 or 11)

In **situation 3** there are two solutions:

3a: there is no digital R-axis and the on-off parameters should be programmed as:

- the number of digital outputs: 4
- the least significant output: 1
- default value: 0000 (this can be programmed from 0000 to 1111)

3b: there is a digital R-axis and the on-off parameters should be programmed as:

- the number of digital outputs: 2
- the least significant output: 3
- default value: 00 (this can be programmed to 01, 10 or 11)

Situation 4 is not allowed, because the digital outputs are not in succession.

In **situation 5** the only solution is that there is a digital R-axis and:

- the number of digital outputs: 1
- the least significant output: 4
- default value: 0 (or 1)

8 I-axes

8.1 Introduction

In the auxiliary axes menu you can program the required axes. There are three different types of I-axes controlling the die movement. The number of axes you can program depends on the type of control.

The following types of I-axes can be programmed:

- Servo I-axis
- AC I-axis
- I-axis with 1-speed AC-motor with potentiometer feedback
- Digital I-axis

The parameters are discussed in order of appearance.

- The servo I-axis and AC I-axis contain the same parameters as discussed in chapter 5.
- The I-axis with 1 speed AC-motor is discussed in section 8.2. This type of axis can be compared with the crowning axes of chapter 6.
- The digital I-axis is discussed in section 8.3.

If you have programmed the required 'axis type' you can program the corresponding parameters after pressing the softkey 'change parameters'.

8.2 I-axis with 1 speed AC motor with potentiometer feedback

Parameter programming and adjustment procedure for this axis is similar to the crowning device, as described in chapter 6.

AUXILIARY AXIS 6		text:	I-axis
		axis type:	5
Min. value.....	7=	-9999.00	(2)
Max. value.....	8=	9999.00	(2)
Standard/high resolution (0/1).....	31=	0	(2)
DA-min.....	18=	0.00 %	(2)
DA-max.....	19=	100.00 %	(2)
DA-out linear/table (0/1).....	22=	0	
Hysteresis.....	23=	0.00	
Default value.....	14=	0.00	
Decimal point pos.....	15=	0	(2)
Max computed value.....	31=	0.00	
7=		-9999.00	19.31
		reset to default	

Figure 8.2.a

8.3 Digital I-axis parameters

AUXILIARY AXIS 6		text: I-axis
		axis type: 11
Nbr positions.....NR=	2	(2)
LS FD output.....LS=	1	(2)
Positioning time.....PT=	0.1	(2)
Position 1.....P1=	00	(2)
Position 2.....P2=	01	(2)
Position 3.....P3=	10	(2)
Position 4.....P4=	11	(2)
NR= 2	19.31	
	reset to default	

Figure 8.3.a

Parameter Nr: **Nbr positions**

Range : 2 - 4

Default : 2

Units : -

Function

to determine the number of positions of the I-axis.

Parameter LS: Ls FD output

Range : 1 - 5

Default : 3

Units : -

Function

To determine the least significant digital function output. There are five digital function outputs. F1 and F2 are used by the digital R-axis, if available. Therefore the default value is 3 (=F3). Depending on the Number of positions of the digital I-axis you require one or two digital outputs.

In case you require two digital outputs these digital outputs have to be in succession. In this case the value of the least significant FD output can never be 5.

Parameter PT: **Positioning time**

Range : 0.0 - 99.0

Default : 0.0

Units : s

Function

to determine the time the X-axis has to wait before it can go to its new position. In the intermediate time the I-axis moves to its new position.

Parameter P1..P4: **Position 1..4**

Range : 00 - 11 (binary values)
Default : 00
Units : -

Function
to define the binary value of the digital output of the several possible positions of the die.

Description
The I-axis (die shifting) moves from position to position as defined by the values of the digital outputs. When you have enabled a digital I-axis then you also have to program the correct I-axis position in the menu of the dies in the programming mode. In figure 8.3b you see the die parameter screen with I-axis enabled.

BOTTOM DIES		No : 5
		Code: REF DIE-0105/DLA
CODE	C=	REF DIE-0105/DLA
RESISTANCE.....	R=	0.30 kN/mm
X-SAFE.....	SN=	21.4 mm
X-SAFE TURNED (NEGATIVE).....	ST=	32.8 mm
MUTE.....	M=	4
FLATTENING HEIGHT.....	FH=	55.00
I-axis.....	ID=	1
2ND X-SAFE.....	SN=	21.4
2ND X-SAFE TURNED (NEGATIVE).....	ST=	32.8
C= REF DIE-0105/DLA		8.2
		alphanum.

Figure 8.3.b

Notice that you program the positions of the I-axis in such a way that the moving direction of the I-axis is the same as the backgauge. This is to prevent collision between the die and the backgauge finger. This means moving backward when moving to a higher position, moving forward when moving to a lower position. So:

- the I-axis moves forward when the die has to go to a lower position (for example from position 3 to position 2)
- the I-axis moves backward when the die has to go to a higher position (from position 1 to position 2)

For each I-axis position you should program a separate die that corresponds with that situation in the bending point.




Figure 8.3.c

9 Part support

9.1 Introduction

The part support system

The system has been designed to control the angle at which the sheet must be supported by the part support arm. Figure 9.1 shows how the angle is defined: when the sheet has been clamped by the punch, at the clamping point, the angle of the part support arm is zero. When the sheet is moved upwards as result of a bending action, a positive angle is obtained.




Figure 9.1.a

In the auxiliary axes menu you can program the required axes. The part support option can be programmed by selecting axis 'PS'.

There are two axis types that can be selected:

- 'Dig. part support' to select the digital part support.
- 'Servo' to select a classic part support control system with the DBT-01 control card.

Press the softkey 'change parameters' to program the parameters of the selected axis.

The digital part support control is integrated in a standard DM01 module, no additional hardware is necessary. The digital part support is described in section 9.2.

If a part support unit is installed which can be moved along the machine, additional axes can be programmed to control the part support movement. See section 9.3.

For a part support control system with the DBT-01 control card we refer to section 9.4.

9.2 Digital part support

9.2.1 Installation

Install the following equipment for the part support function:

- DM01 module
- drive system (motor drive and motor or a hydraulic system)
- the part support arm
- a potentiometer for a position feedback signal.




Figure 9.2.a

See drawing number 9024-112 for proper connection of a DM01 module.


In the following table, the definitions for control signal and part support movement are explained.

Control signal DM01	voltage potentiometer	movement part support
> 0	bigger	up
0	equal	none
< 0	smaller	down

In order to achieve acceptable results with a part support system, the system should meet several requirements.

Like every Delem module, the DM01 module for the part support has several LED's on the front which indicate the status of the module.

When used for a part support, the LED's 1 and 2 have the following meaning:




	Diag 1	Diag 2
Part support disabled	OFF	OFF
Part support enabled	ON	OFF
Part support angle larger than minimum angle.	OFF	ON

9.2.2 Parameters digital part support

AUXILIARY AXIS 4		text: Part support
		axis type: 6
Sheet follow function (on=1/off=0)...127= 0		
Number of slaves.....SL= 0		
Default value.....14= 0001		
X-movement.....124= X_GP1		
R-movement.....125= R_GP1		
Z-movement.....126= Z_GP1		
127= 0	19.41	
	reset to default	

Figure 9.2.b

Sheet follow function on/off

This parameter serves to switch the 'sheet follow function' on or off. Press the key  to select the required setting.

When switched on, the part support is controlled to guide the metal sheet during bending. In this situation all positioning parameters must be programmed correctly to ensure good positioning behaviour of the part support.

When switched off, the part support arm is not controlled during bending. In this situation no positioning parameters are to be programmed, only the additional parameters for positioning of the part support unit. This allows you to program and control a supporting unit that is not made to follow sheet movement during bending, but can be used to place a sheet in front of the machine.

See section 9.3 for more information about the additional axes.

On the following pages the part support parameters are explained.

AUXILIARY AXIS 4		text:	Part support
		axis type:	6
Sheet follow function (on=1/off=0)...127=		1	
Min. Angle..... 7=	0	°	(2)
Max. Angle..... 8=	0	°	(2)
Min. AD-value.....18=	0		
Max. AD-value.....19=	0		
Delay before retour factor.....RF=	1.0		
Safety stop angle.....SA=	0.0	°	
Max. Angle speed.....MS=	0	°/sec	
Number of slaves.....SL=	0		
Default value.....14=	0001		
X-movement.....124=	X_GP1		
R-movement.....125=	R_GP1		
Z-movement.....126=	Z_GP1		
127= 1		19.41	
next page	reset to default		

Figure 9.2.c

AUXILIARY AXIS 4		text:	Part support
		axis type:	6
Mean angle speed: low.....ML=		0	°/sec
high.....MH=		0	°/sec
Proportional gain: min.....PN=	0		
max.....PX=	0		
Feedforward gain: min.....FN=	0		
max.....FX=	0		
Differential gain: min.....DN=	0		
max.....DX=	0		
Retour movement gain.....RG=	1		
Adjustment mode.....AM=	0		
In position tolerance.....12=	0	°	
ML= 0	19.42		
previous page	reset to default		

Figure 9.2.d

Parameter 7: **Min. Angle**

Range : 0.0 - 90.0
Unit : degrees (°)
Default : 0.0

Function

The minimum angle at which the support arm may be positioned. This is a software limit.

Parameter 8: **Max. Angle**

Range : 0.0 - 90.0
Unit : degrees (°)
Default : 0.0

Function

The maximum angle at which the support arm may be positioned. This is a software limit.

Parameter 18: **Min. AD-value**

Range : 0 - 1023

Unit : -

Default : 0

Function

Minimum value of AD-converted potentiometer voltage. This value represents the minimum angle at which the part support arm may be positioned.

Parameter 19: **Max. AD-value**

Range : 0 - 1023

Unit : -

Default : 1023

Function

Maximum value of AD-converted potentiometer voltage. This value represents the maximum angle at which the part support arm may be positioned.

Parameter RF: **Delay before retour factor**

Range : 0.0 - 9.9

Units : -

Default : 1.0

Function

Multiply factor, used to program the time the part support arm must stay on the final position. The parameter 'Delay Before Opening' is multiplied by 'Delay Before Retour Factor' to program how long the part support arm must stay. If 'Delay Before Retour Factor' is set to 1.0, pressbeam and part support arm will move back simultaneously.

Parameter SL: Nbr. of slaves

Range : 0 - 4

Units : -

Default : 0

Function

The number of part support units that is installed. 5 units at most can be controlled.

Parameter 14: **Default value**

Range : 0000 - 1111 (binary values)

Unit : -

Default : 0000

Function

Toggle on/off function for each part support unit. A “1” means it is switched ON, “0” means it is switched OFF. For instance, 1000 means that one part support axis is enabled, on the first position.

Parameter SA: Safety stop angle

Range : 0.0 - 90.0

Unit : degrees (°)

Default : 0.0

Function

Angle at which the part support arm is stopped in the retour movement. The part support arm can be moved back to its minimum position by setting flag 8128 in the Delem Sequencer. See the manual “Delem Sequencer Programming Language” for information about programming the Sequencer.

If no sequencer is used, leave this parameter at 0.0.

Parameter MS: Max. angle speed

Range : 0 - 255

Unit : degrees per second ($^{\circ}/s$).

Default : 10

Function

The maximum angle speed at which the support arm can move.

As shown in figure 9.2.a, the control gains can vary according to a linear function of the mean part support angle speed.

The setpoints with minimum and maximum values of gain and speed can be adjusted in the following machine parameters. The min. gain and max. gain should be set as high as possible, but without causing oscillation of the part support arm as it moves.




Figure 9.2.e

Parameter ML: **Mean angle speed low**

Range : 0.0 - 999.9

Unit : degrees per second (°/s)

Default : 1.0

Function

lowest value of angle speed, belonging to the first setpoint in the speed/gain function.

Parameter MH: **Mean angle speed high**

Range : 0.0 - 999.9

Unit : degrees per second (°/s)

Default : 1.0

Function

Highest value of angle speed, belonging to second setpoint in speed/gain function.

Parameter PN: **Proportional gain min**

Range : 0 - 9999

Unit : -

Default : 0

Function

Gain of the reference input signal. This value is for the first setpoint of the speed/gain function.

Parameter PX: **Proportional gain max**

Range : 0 - 9999

Unit : -

Default : 0

Function

Gain of the reference input signal. This value is for the second setpoint of the speed/gain function.

The next four parameters for minimum and maximum values of feedforward gain en differential gain are optional. They might help to reduce the maximum error of the part support, but this depends on the accuracy that is required. See sections 9.2.3 and 9.2.4 for more information about gain parameters and adjustment procedures.

Parameter FN: **Feedforward gain min**

Range : 0 - 255

Unit : -

Default : 0

Function

Optional gain of the reference input signal, to reduce the maximum error.

Parameter FX: **Feedforward gain max**

Range : 0 - 255

Unit : -

Default : 0

Function

Optional gain of the reference input signal, to reduce the maximum error.

Parameter DN: **Differential gain min**

Range : 0 - 255

Unit : -

Default : 0

Function

Optional gain of the error signal, to reduce the maximum error in the system.

Parameter DX: **Differential gain max**

Range : 0 - 255

Unit : -

Default : 0

Function

Optional gain of the error signal, to reduce the maximum error in the system.

Parameter AM: **Adjustment mode**

Range : 0 - 6

Unit : -

Default : 0

Function

When Part Support is switched on in manual mode, the user can monitor a value in the “zoomed values” menu. With this parameter, you can program which value you want to be displayed in that menu. There are seven possibilities:

- 0: Actual part support angle [°]. This is the standard setting;
- 1: Actual error [°];
- 2: Maximum error per bend [°];
- 3: Minimum error per bend [°];
- 4: Actual part support angle speed [°/s];
- 5: Maximum part support angle speed per bend [°/s];
- 6: Mean reference angle speed per bend [°/s];

Normally during operation this parameter is set to 0, but during adjustment the settings 1-6 are useful to monitor the behaviour of the part support.

Parameter 12: In Position tolerance

Range : 0.0 - 90.0

Unit : degrees (°)

Default : 2.0

Function

Error tolerance of the part support angle. When the part support angle is within this tolerance, the value after 'PS= ..' in the menu "zoomed values" in manual mode is highlighted, meaning that the part support is 'In Position'. When the error in the part support angle is bigger than this tolerance, the value in manual mode is not highlighted.

9.2.3 Adjustment procedures

There are several adjustment procedures to program the part support. The following adjustment procedures can be executed:

- determination of Max AD-value and Min. AD-value;
- determination of the maximum angle speed of the part support;
- adjustment procedure of control gains:
 - adjustment of proportional gain max;
 - adjustment of proportional gain min;
 - adjustment of feedforward gains;
 - adjustment of differential gains.

- **Initial values**

Before starting adjustment procedures, some parameters should be set to initial values:

Min. Angle	=	.. (machine dependent)
Max. Angle	=	.. (machine dependent)
Max. angle speed	=	0 °/s
Mean angle speed:	low	= 1 °/s
	high	= 1 °/s
Proportional gain:	min.	= 1
	max.	= 1
Feedforward gain:	min.	= 0
	max.	= 0
Differential gain:	min.	= 0
	max.	= 0
Adjustment mode	=	0
In position tolerance	=	.. ° (to be determined by user)

- **Determination of Max AD-value and Min. AD-value**

The voltage signal from the potentiometer is converted to a digital value. The parameters for AD-values serve to indicate which value represents the minimum angle and which value the maximum angle. The range for AD-points is 0 - 1023. These AD-values can be determined in the diagnostic mode. Proceed as follows:

1. Go to diagnostic program, select 'DM Module Test' and select the module for part support.
2. Move the cursor to 'Output 0'.
3. Position the part support with the handwheel at its minimum angle, read the AD-value at 'Input1'. This will be the minimum AD-value.
4. Position the part support with the handwheel at its maximum angle, read the AD-value at 'Input1'. This will be the maximum AD-value.
5. Go to the digital part support machine parameters (Axis-type 6 and Text no 21) and set the parameters 'Min. AD-value' and 'Max. AD-value' to the values found at point 3 and 4.

- **Determination of the maximum angle speed of the part support**

1. Go to the machine parameters for digital part support.
2. Select 'Adjustment mode = 5' (on the second page) to ensure that the part support maximum angle speed will be displayed in the 'Zoomed Values' menu.
3. Go to manual mode, select a die with a V-opening between 5 and 7 mm and select the maximum possible press speed for this specific machine.
4. Enter such an angle for bending, that the part support will go to 90% of its maximum angle. This bend angle can be calculated as follows:

$$\alpha_{\text{bend}} = 2 \bullet (90^\circ - 0.9 \bullet \alpha_{\text{max}})$$

in which α_{max} is the maximum angle of the part support).

Example: If the maximum part support angle for your machine is 60° , then the angle that must be used for bending would be 72° .

5. Enable the part support by setting 'Part Support' to 1.
6. Set the part support correction 'G-corr.' to 0.0.
7. For the other values for bending, scroll through the list by pressing <enter>. Go to 'Zoomed Values' menu, perform a bend and check for the maximum angle speed (displayed at 'PS =..'), rounded at $1^\circ/\text{s}$ (no decimals).
8. At the part support machine parameters, increase 'Proportional Gain Max.' by 1. Go back to Manual mode, open the 'Zoomed Values' menu, perform a bend and check for the maximum angle speed, again rounded at $1^\circ/\text{s}$.
9. Repeat the last step until the maximum angle speed does not increase anymore.
10. Note the reached value (rounded at 1), this is the maximum angle speed of the part support.
11. Go to the part support machine parameters and fill in the maximum angle speed.

- **Adjustment procedure of control gains**

For all adjustments, choose the following settings in Manual menu:

1. Select a die with V-opening between 5 and 7 mm.
2. Select such an angle, that the part support will go to 90% of its maximum angle, as already used in the previous paragraph.
3. Select a bending dwell-time ('d-time') of at least 2 seconds.

If gain values are set too high, the part support arm does not run smoothly anymore, but starts oscillating. This is not acceptable. Adjust gain values for optimal performance, without oscillating.

- **Adjustment of Proportional gain max**

To adjust 'Proportional Gain Max.' perform the following steps:

1. Go to the digital part support machine parameters.
2. Select 'Proportional Gain Max = 1'.
3. Set 'Adjustment Mode' to 6 for displaying the reference mean angle speed [$^\circ/\text{s}$].

4. Go to Manual mode. Adjust the pressing speed (further on called S_{high}) to the maximum pressing speed and press 'Start'. In the menu 'Zoomed Values' the angle speed is displayed (this value is calculated after pressing Start, **so no bending cycle is necessary**). Adjust the pressing speed S_{high} to such a value, that the angle speed displayed is about 85% of the Maximum Angle Speed, as determined in paragraph 4.3. Write down the value of S_{high} . This value will also be used when adjusting the other gain values, Feedforward and Differential Gain.
5. Go to the digital part support machine parameters and set 'Adjustment Mode' to 2 for displaying the maximum error in degrees.
6. Go to manual mode, perform a bend, consider the maximum error (in degrees) displayed in 'Zoomed Values' menu, and increase 'Proportional Gain Max.' by 1 until the maximum error is as small as possible, while the movement of the part support is still acceptable.

- **Adjustment of Proportional gain min**

To adjust Proportional Gain Min, perform the following steps:

1. Go to the digital part support machine parameters and fill in at 'Mean Angle Speed high' the Maximum Angle Speed, as determined in paragraph 4.3.
2. Set 'Proportional Gain min' to 1.
3. Select 'Adjustment Mode' 2 for displaying the maximum error in degrees.
4. Go to Manual menu, select a press speed of 0.2 mm/s and perform a bend.
5. Consider the displayed maximum error, increase 'Proportional Gain min.' by 1 and perform a bend. Repeat this until the maximum error is as small as possible, while the movement of the part support is still acceptable.

Adjustment of the next two parameters, Differential gain and Feedforward gain, is optional. When adjusted properly, these parameters could help to reduce the maximum error.

- **Adjustment procedure for Feedforward gains**

The value for 'Feedforward Gain Min' should always be 0.

To adjust 'Feedforward Gain Max.' perform the following steps:

1. Go to the digital part support machine parameters and set 'Feedforward Gain Max' to 1.
2. Set 'Adjustment mode' to 2 for displaying the maximum error in degrees.
3. Go to Manual Mode and set the press speed S_{high} to the value as already determined in the section about Adjustment of Proportional Gain Max.
4. Perform a bend, consider the displayed maximum error and increase 'Feedforward Gain Max.' by 1 until the movement of the part support becomes unacceptable.

- **Adjustment procedure for Differential gains**

The value for 'Differential Gain Min.' should always be 0.

To adjust 'Differential Gain Max.' perform the following steps:

1. Go to the digital part support machine parameters and set 'Differential Gain Max.' to 10.
2. Set 'Adjustment Mode' to 2 for displaying the maximum error in degrees.
3. Go to Manual menu, select press speed S_{high} and perform a bend.

4. Consider the the maximum error, and increase 'Differential Gain Max' by 10 until the maximum error is reduced sufficiently, while the movement of the part support is still acceptable. If the maximum error does not become smaller while increasing 'Differential Gain Max.', set 'Differential Gain Max.' to zero.

When the procedure is finished, make sure to set the parameter 'Adjustment Mode' to 0. This way, the actual angle of the part support will be displayed in Manual mode.

9.2.4 Extra info and recommendations

Utilities while adjusting control gains

It is not required, but it may be useful to make use of the following utilities while performing the adjustment procedure of the control gains:

- **In Position Tolerance**

The digital part support machine parameter 'In Position Tolerance' can be used while adjusting the control gains.

When the part support angle error is smaller than the angle given by In Position Tolerance, the displayed value in Zoomed Values menu (after PS=) is highlighted.

Otherwise, the displayed value in Zoomed Values menu is not highlighted.

- **Overshoot measurement**

When choosing the control gains too high, this may result in an overshoot. This means that the part support will first go somewhat further than the final desired angle before the part support moves back to the desired angle.

The overshoot can also be measured by setting 'Adjustment Mode' to 3 in the part support machine parameters.

In the 'Zoomed Values' menu, after 'PS = ..', the amount of overshoot (in degrees) can then be read off in press status 4. In case of an overshoot this value is negative, since it is calculated as the difference between the programmed value and the actual value:

$$\text{overshoot} = \text{programmed value} - \text{actual value}$$


Select a dwell-time of at least 2 seconds, to be able to read this value.

If necessary, there are two possibilities to decrease the overshoot:

- increase the value of the Differential Gain Max. This can decrease the overshoot value, but the movement of the part support arm may become less smooth.
- decrease the value of the Proportional Gain Max. This can also decrease the overshoot value, but the accuracy of the part support movement with respect to the pressing movement will be less.

Gain parameters

The figure below illustrates the function of the gain parameters in a control technical schematic.



In this schematic, the following parameters are shown:

P.S. = Part Support

K_p = Proportional gain

K_d = Differential gain

K_{ff} = Feedforward gain

The parameter for proportional gain must always be adjusted, the two others are optional.

Requirements and recommendations for part support systems

The following remarks are meant to give some recommendations for building an adequate part support system.

Acceleration and deceleration of the part support system

The part support mechanism should be capable of fast movement and quick response: it should be able to move with the maximum required speed during bending but it should also be capable of changing speed quickly when a bending starts or stops.

When a large maximum part support speed is required, even so a large acceleration and deceleration of the part support is needed to limit the maximum position error and overshoot.

The relation between maximum part support speed and required acceleration / deceleration is quadratic. When the maximum speed becomes twice as large, the required acceleration becomes four times as large to maintain the same maximum position error.

Hydraulic part support systems

1. Hose lines

Special care should be taken when using hose lines, because they react elastically on internal over pressures. Hose lines can have the following disadvantages:

- An increased maximum position error.
- An increased amount of overshoot.

Hose lines should not be mounted between the flow control valve and the cylinder, but for instance between the pressure control valve and the flow control valve.

2. Flow control valve

The maximum flow of the control valve should not be too large, but should be just large enough to be able to reach the desired maximum part support speed.

To limit the maximum position error of the part support, it is better to select a flow control valve which has a relatively short response time.

The flow control valve should be mounted as close as possible to the cylinder, to eliminate the effect of hydraulic lines between the flow control valve and the cylinder.

Control voltage to part support system

The control voltage to the part support system can be tested in the module test of the diagnostic program. The voltage can be varied between -255 and 255 DA-points, which resembles a range between -10V and 10V.

The part support system should respond to the control signal as follows:

- At a control signal of 0 V the part support should not move.
- At a control signal of 40 mV (1 DA point for DA60 series controls) the part support should not stand still and should reach a maximum speed of 0.5°/s. When the part support has an angle range of e.g. 60°, it should take at least 120 s to move the part support from its minimum to its maximum angle, at a control signal of 40 mV.
- At a control signal of -40 mV, the part support should not stand still and the part support should reach a maximum speed of 0.5°/s in the opposite direction. When the part support has an angle range of e.g. 60°, it should take at least 120 s to move the part support from its maximum to its minimum angle, at a control signal of -40 mV.
- The relation between input voltage of the part support and the corresponding part support speed should be linear. Non-linearity can have a bad influence on the part support movement.

Potentiometer voltage

The feedback voltage from the potentiometer should have a large range between minimum and maximum values which correspond with the minimum and maximum angle. This will benefit the behaviour of the part support control system.

The feedback voltage is converted to AD points, ranging from 0 to 1023. In formula, the potentiometer voltage has to meet the following requirement:

$$\text{Angle resolution} = \frac{\text{Max. Angle} - \text{Min. Angle}}{\text{Max. AD value} - \text{Min. AD value}} \leq 0.1$$

This means a difference of 1 AD point should correspond to a part support angle of maximal 0.1°.

Play and stiffness of mechanical construction

Play

The play of the potentiometer construction has to meet the following requirement:

$$\text{Play} < \frac{\text{Angle resolution}}{2}$$

Play can cause a worse standstill of the part support and can lead to an increment in overshoot.

Stiffness

The stiffness of the mechanical construction of the potentiometer has to be large enough to have no negative influence on the measurement of the part support angle. An insufficient stiffness can increase the maximum position error and can cause an increased overshoot.

9.3 Additional part support axes

If the part support unit on the machine is equipped with additional spindles to be able to move along the machine, then additional axes can be programmed on the control to control these spindles. Each of these axes can be selected from the parameter screen of the digital part support.




Fig. 9.3.a

It is possible to program three axes for each part support unit:

- X_GP
- R_GP
- Z_GP

Since it is possible to program four part supports on a machine, four names for each axis type are reserved: X_GP1, X_GP2, etc.

Programming any such axis for a part support involves the following:

1. in the parameter screen of the part support, select the axis name for each movement (X_GP1 for X-movement, etc.),
2. go to the auxiliary axis menu and program an auxiliary axis with the name that was chosen,
3. program the parameters for this axis,
4. make sure this axis is mapped on a module.

Step 1 is carried out by moving the cursor to the movement parameter. When the cursor is placed on one of these parameters, a pop-up window can be activated with the softkey 'select axis'.




Fig. 9.3.b

Choose the required axis from the list.

For the other steps, the standard procedure for programming an axis can be followed. This procedure is described in detail in chapter 4.

9.4 Analog part support

9.4.1 Introduction

A part support system can also be driven by connecting a DBT01 card to a DM01. If that is the case, axis type 'servo' must be selected for the part support in the menu of the auxiliary axis.

In the beginning of the bend the metal plate accelerates very fast while the angle variation is not of the same speed order. High accuracy part support control requires closed loop regulated speed and angle control of one or more support arms. Therefore the DBT01 is equipped with an angle control amplifier and a speed regulator.

With the P-m potentiometer (or angle deflection potentiometer) the angle of the part support arm is measured (diagram Part support control) . The signal of this potentiometer is compared with the 0 - 10V angle output signal of the DM01 module. The difference of these signals controls the output voltage to for example an hydraulic valve amplifier (AL and AR in diagram Part support control. This diagram represents a dual part support system). Subsequently the hydraulic valve is controlled to move the part support arm. (Instead of a hydraulic valve the part support arm can also be controlled by a motor drive.)

At the same time the speed of the arm is measured (angle variation per unit of time). The output voltage variation of the controller and the speed variation signal of the angle potentiometer (P-m) are compared (speed difference). The difference of these signals is used to accelerate the speed of the control arm.

In case the acceleration required to move the arm is too high for the support arm to follow the sheet metal plate then a PWM-signal is generated at the Y-brake signal of the module to slow down the speed of the Y-axis of the press brake.

When the Y-axis moves slower then also the angle variation per unit of time will be slower.

In case of using two support arms the speed of both arms are compared and the slowest arm will regulate the speed of the Y-axis (Dual part support application).

9.4.2 Installation and adjustment of the DBT01 control card

The DBT-01 control card is used for the part support function. First the DBT01 card is installed then the part support arm should be adjusted. Both procedures are discussed.

Installation procedure

- Connect the part support control card DBT01 according to the standard connection diagram.
- Put the part support brackets in a horizontal position
- Make sure that the potentiometer - which reads the actual position of the part support - is then not more than 25 degrees turned from the zero-position. This should correspond with approximately 0,5 Volt on the runner of the potentiometer
- Adjust the following potentiometers before you start the adjustment procedure. See also diagram of DBT01 component layout:

Potentiometer nr.	Function	Start position
RP1	offset feedback	minimal = completely turned to the right
RP2	gain feedback	maximal = completely turned to the left
RP4	gain braking on Y-brake	minimal = completely turned to the left
RP5	slip factor	minimal = completely turned to the left
RP6	gain differential	minimal = completely turned to the left

- The potentiometers RP3, RP7, RP8, RP9 and RP10 are factory set to optimal values.

Adjustment procedure part support

- Go to the diagnostic mode
 - Select DM01 module that controls the part support.
 - Move cursor to the speed output parameter 'output0' with cursor key.
 - Select 0 (= 0%).
 - Start the machine and the hydraulic pump of the part support construction.
 - Follow the next adjustment procedures:
- ** Adjustment of the feedback offset (see O1 in the blockdiagram of principle PID-controller)
- Turn RP1 until the part support is in the horizontal position.
In case the part support can not be adjusted in an optimal way turn potentiometer RP6 a couple of turns to the right.
- ** Adjustment of the feedback gain (see A1 in the blockdiagram of principle PID-controller)
- Select 50% of 'output0'. This corresponds with the value 127.
 - Turn potentiometer RP2 until the part support brackets are exactly halfway the maximum required angle.
- ** Adjustment of the differential gain (see A3 in the blockdiagram of principle PID-controller)
- Leave the diagnostic program.
 - Program the part support machine parameters before continuing this procedure. See section 9.3.
 - Select the manual mode.
 - Program the manual mode parameters and program the pressing speed not too high, e.g. 2 mm/s.
 - Make some pressing movements and turn potentiometer RP6 during the pressing phase so, that the part support is not oscillating and following the pressing movement fluently.
- ** Adjustment of the slipfactor (differentiating gain D in the blockdiagram of principle PID-controller)

- Make some more pressing movements and turn potentiometer RP5 until the part support is following the part bending in a optimal way and is not faster than the beam movement.
- ** Adjustment of the gain on deceleration of the beam (see O2 in the blockdiagram of principle PID-controller) Part support arms cannot follow the plate, e.g. Y-axis too fast.
The beam will be decelerated by activating the Y-brake input of the module.
- Release the pressing command during the bending stroke, so that the part support is in a lifted position.
- Turn potentiometer RP4 until the Y-brake input of the module is just starting to light (activating).
- Now you can check whether the part support is also following the part while bending with higher pressing speeds. The bigger the difference between the required part support angle and the measured angle the more the Y-brake will be activated, so that the beam will be braked more frequently.
- For dual part support you must first adjust each part support separately, as they are single part supports. Then make the connections as in the connection diagram. The Y-brake will be active when one of the two support arms will have a too large error signal. Potentiometer RP4 needs only to be adjusted at the DBT01 card of which output T (See standard connection diagram) is connected to the module input Y-brake.

9.4.3 Parameters analog part support

Parameter: 7
Min. Value

Range : 0.0 - 90.0
Default : 90.0
Unit : degrees (°)

Function

The minimum angle at which the support arm may be positioned. This is a software limit. See also adjustment procedure part support parameters.

Parameter: 8
Max. Value

Range : 0.0 - 90.0
Default : 90.0
Unit : degrees (°)

Function

The maximum angle at which the support arm may be positioned. This is a software limit. See also adjustment procedure part support parameters.

Parameter: 18
DA-min

Range : 0 - 255
Default : 0
Unit : -

Function

Minimum value of AD-converted potentiometer voltage. This value represents the minimum angle at which the part support arm may be positioned. See also adjustment procedure part support parameters.

Parameter: 19
DA-max

Range : 0 - 255

Default : 1

Unit : -

Function

Maximum value of AD-converted potentiometer voltage. This value represents the maximum angle at which the part support arm may be positioned. See also adjustment procedure part support parameters.

Adjustment procedure part support parameters

To be sure that the part support is following the sheet metal plate fluently. The part support should be adjusted as follows:

- Go to to the auxiliary menu and program the part support (1, 21).
- Press 'change parameters' and program the DM-identifier and Box-number.
- Program for Min. value and DA-min 0.
- Program for Max. value and DA-max 255.
- Go to the manual mode.
- Move the part support arm to the mechanical minimal position by means of the handwheel or to the position that corresponds with 0 degrees angle.
- Read out the value on the screen (Manual mode, manual positioning). This value corresponds with the number of DA-points. Remember that value and program it at the end of the adjustment procedure at the parameter DA-min.
- Now move the part support to the mechanical maximal position or to the position that corresponds with 90 degrees angle.
- Read out the value on the screen (Manual mode, manual positioning). This value corresponds with the number of DA-points. Remember the value and program it at the end of the adjustment procedure at the parameter DA-max.
- Program now the found DA-values to the corresponding machine parameters and program Min. Value at 0 (read 0 degrees) and Max. Value at 90 (read 90 degrees).

Parameter: RF
Delay before retour factor

Range : 0.0 - 9.9

Default : 1.0

Unit : -

Function

Multiply factor, used to program the time the part support arm must stay on the final position. The parameter 'Delay Before Opening' (chapter 3, parameter 36) is multiplied by 'Delay Before Retour Factor' to program how long the part support arm must stay.

If 'Delay Before Retour Factor' is set to 1.0, pressbeam and part support arm will move back simultaneously.

Parameter: NR
Nr. of Units

Range : 1 - 4
Default : 1
Unit : -

Function

The number of part support arms that can be controlled.

Description

In the default situation you require one DBT01 card with which one part support arm is controlled with Y-brake feedback to the DM01 module.

For each extra part support axis you require a separate DBT01 control card. Two or more part support arms can be controlled in two ways:

- Synchronised. In this case all part support arms are used or are not used: together 'On' or together 'off'. The Y-brake feedback of the latest DBT01 is connected to the DM01 module. See also connection diagram dual part support as an example of two synchronised part support arms.

Program 'Number of units' for synchronised control always the value 1.

- Separate. In this case you can specify which part support arms should be used or not. To control the part support arms separately you have to program some flags in the sequencer program. The control data for each part support arm should be matched on a digital output on the DM01. These digital outputs have to be connected to the DBT01 output (C18) to disable the control of the valve card or the motor drive. The Y-brake feedback may not be connected in this case!

See also the 'Delem Sequencer Programming Language' manual for information about programming the sequencer for driving separate part support arms.

Program 'Number of units' for separate control equal to the number of part support arms.

Parameter: 14
Default value

Range : 0000 - 1111 (binary values)

Default : 0000

Unit : -

Function

Toggle on/off function for each part support unit.

Description

A “1” means that the part support axis is used for the active bending (is switched ON), “0” means that the part support axis is not used (is switched OFF).

Example

1000 means that for a specific bending one part support axis is enabled, i.e the part support axis on the first position.

Parameter: SA
Safety stop angle

Range : 0.0 - 90.0

Default : 0.0

Unit : degrees (°)

Function

Angle at which the part support arm is stopped in the retour movement.

Parameter: MS
Max. angle speed


Range : 0 - 255

Default : 1

Unit : degrees per second (°/s)

Function

The maximum angle speed at which the support arm can move.



Delem
 Iuchthavenweg 42, 5657 EB
 Eindhoven, the NETHERLANDS

Connection DA6X - DM01
 Digital Part Support

Format **A3** Number 9024-113 Issue -

No unauthorized copying allowed Scale

Note	Redrawn	Date
Description		
Note	Redrawn	Date
Description		
Measures in mm, unless otherwise specified		Drawn
		MI
		Date
		26-11-1998