

# Lift Vector AC Drives



# ARTDriveL

## ARTDriveL

**AVy...-...-AC**

**AVy...-...-AC4**

**AVy...-...-BR**

**AVy...-...-BR4**

■ ■ ■ ■ ..... Instruction Manual



Thank you for choosing this Gefran-Siei product.

We will be glad to receive any possible information which could help us improving this manual. The e-mail address is the following: [techdoc@siei.it](mailto:techdoc@siei.it).

Before using the product, read the safety instruction section carefully.

Keep the manual in a safe place and available to engineering and installation personnel during the product functioning period.

The manufacturer has the right to modify products, data and dimensions without notice.

The data can only be used for the product description and they can not be understood as legally stated properties.

All rights reserved

**This manual is updated according to software version 3.5XX and RV33-4 regulation card.**

The identification number of the software version can be read on the inverter nameplate or on the label on the FLASH memories mounted on the regulation card.

# Table of Contents

|   |           |
|---|-----------|
| <b>Safety Symbol Legend - Precautions de sécurité</b> .....   | <b>6</b>  |
| <b>Chapter 0 - Safety Precautions</b> .....   | <b>7</b>  |
| <b>Chapter 1 - Functions and General Features</b> .....   | <b>13</b> |
| 1.1 Drive .....   | 13        |
| 1.2 Motors .....  | 15        |
| <b>Chapter 2 - Inspection procedures, Components Identification and Standard Specifications</b> ....        | <b>17</b> |
| 2.1 Upon Delivery Inspection Procedures .....   | 17        |
| 2.1.1 General .....   | 17        |
| 2.1.2 Inverter type designation .....   | 17        |
| 2.1.3 Nameplate .....   | 18        |
| <i>Figure 2.1.3.1: Identification nameplate</i> .....   | 18        |
| <i>Figure 2.1.3.2: Firmware &amp; Card revision level nameplate</i> .....                                   | 18        |
| <i>Figure 2.1.3.3: Nameplates position</i> .....  | 18        |
| 2.2 Component Identification .....  | 19        |
| <i>Figure 2.2.1: Basic Setup of Frequency Inverter</i> .....  | 19        |
| 2.3 Standard Specifications .....   | 20        |
| 2.3.1 Permissible Environmental Conditions .....  | 20        |
| Disposal of the Device .....  | 21        |
| 2.3.2 AC Input/Output Connection .....  | 21        |
| 2.3.3 AC Input .....  | 21        |
| 2.3.4 AC Output .....   | 21        |
| <i>Figure 2.3.4.1: Rating of Drive in Function of Switching Frequency</i> .....                             | 22        |
| <i>Table 2.3.4.1: AC Input/Output Specifications</i> .....  | 23        |
| <i>Table 2.3.4.2-A: Overload Capability (Sizes 1007 ... 4370)</i> .....                                     | 24        |
| <i>Table 2.3.4.2-B: Overload Capability (Sizes 5450... 81600)</i> .....                                     | 25        |
| 2.3.6 Accuracy .....  | 26        |
| <i>Table 2.3.6.1: Maximum / Minimum Output Frequency</i> .....  | 26        |
| 2.3.5 I/O and Encoder Specifications .....  | 26        |
| <i>Table 2.3.6.4: Torque Specifications</i> .....   | 27        |
| <i>Table 2.3.6.2: Speed Reference / Feedback Resolution and Maximum Limits</i> .....                        | 27        |
| <i>Table 2.3.6.3: Speed Regulator Bandwidth</i> .....   | 27        |
| <b>Chapter 3 - Mechanical Installation Guidelines</b> .....   | <b>28</b> |
| 3.1 Dimensions and Mounting Methods .....   | 28        |
| <i>Figure 3.1.1: Drive Dimensions (Sizes 1007 ... 3150)</i> .....   | 28        |
| <i>Figure 3.1.2: Mounting Methods (Sizes 1007 ... 3150)</i> .....   | 28        |
| <i>Table 3.1.1: Drive Dimensions and Weights (Sizes 1007 ... 3150)</i> .....                                | 29        |
| <i>Figure 3.1.3: Drive Dimensions (Sizes 4220 ... 81600)</i> .....  | 29        |
| <i>Figure 3.1.4: Mounting Methods (Sizes 4220 ... 81600)</i> .....  | 30        |
| <i>Table 3.1.2: Drive Dimensions and Weights (Sizes 4220 ... 81600)</i> .....                               | 30        |
| <i>Figure 3.1.5: Keypad Positioning</i> .....   | 30        |
| 3.2 Watts Loss, Heat Dissipation, Internal Fans and Minimum Cabinet Opening Suggested for the Cooling ..... | 31        |
| <i>Table 3.2.1: Heat Dissipation and Required Air Flow</i> .....  | 31        |
| <i>Table 3.2.2: Minimum Cabinet Opening Suggested for the Cooling</i> .....                                 | 31        |
| 3.2.1 Cooling Fans Power Supply .....   | 32        |
| <i>Figure 3.2.1: UL Type Fans Connections on AVy7900, AVy71100 and AVy71320 Sizes</i> .....                 | 32        |
| <i>Figure 3.2.2: UL Type Fans Connections on AVy6750 and AVy81600 Sizes</i> .....                           | 32        |
| <i>Figure 3.2.3: Example for External Connection</i> .....  | 33        |

|  |           |
|--|-----------|
| 3.3 Installation Mounting Clearance .....  | 34        |
| Figure 3.3.1: Max. Angle of Inclination .....  | 34        |
| Figure 3.3.2: Mounting Clearance .....   | 34        |
| <b>Chapter 4 - Wiring Procedure .....</b>  | <b>35</b> |
| 4.1 Accessing the Connectors .....   | 35        |
| 4.1.1 Removing the Covers .....  | 35        |
| Figure 4.1.1: Removing the Covers (Sizes 1007 to 3150) .....   | 35        |
| Figure 4.1.2: Removing the Covers (Sizes 4185 to 81600) .....  | 36        |
| 4.2 Power Section .....  | 36        |
| 4.2.1 Terminal Assignment on Power Section / Cable Cross-Section .....   | 37        |
| Table 4.2.1.1: Power Section Terminals from 1007 to 3150 .....   | 37        |
| Table 4.2.1.2: Power Section Terminals from 4185 to 81600 .....  | 37        |
| Table 4.2.1.3: Maximum Cable Cross Section for Power Terminals .....   | 38        |
| Table 4.2.1.4: Maximum Permissible Cable Cross-section on the Plug-in Terminals of the Regulator Section ..... | 39        |
| Table 4.2.1.5: Maximum Control Cable Lengths .....   | 39        |
| 4.3 Regulation Section .....   | 40        |
| 4.3.1 RV33-4 Regulation Card Switch & Jumpers .....  | 40        |
| Table 4.3.1.1: LEDs & Test points on Regulation Card .....   | 40        |
| Table 4.3.1.2: Jumpers and dip-switches on Regulation Card RV33 .....  | 41        |
| 4.3.2 Terminal Assignments on Regulation Section .....   | 42        |
| Table 4.3.2.1: Plug-in Terminal Strip Assignments .....  | 42        |
| 4.4 Potentials of the Control Section .....  | 43        |
| Figure 4.4.1-A: Potentials of the control section, Digital I/O NPN connection .....                            | 43        |
| Figure 4.4.1-B: Potentials of the control section, Digital I/O PNP connection .....                            | 44        |
| 4.5 Encoders .....   | 45        |
| Table 4.5.1: Recommended Cable Section and Length for the Connection of Encoders .....                         | 46        |
| Table 4.5.2: Encoders Setting via S11...S23 Jumpers .....  | 46        |
| Table 4.5.3: Encoders Connections .....  | 46        |
| Table 4.5.4: Assignment of the High Density XE Connector for a Sinusoidal or a Digital Encoder .....           | 49        |
| 4.5.1 XFR Connector Assignments (on optional EXP-RES Expansion Board for Resolver) .....                       | 49        |
| 4.5.2 Encoder Simulation .....   | 50        |
| 4.6 Connection Diagrams .....  | 51        |
| Figure 4.6.1: Standard Connection Diagram .....  | 51        |
| 4.6.1 Expansion Card Connection .....  | 52        |
| Figure 4.6.2: Common Output Contactors Management .....  | 52        |
| Figure 4.6.3: Separate Output Contactors Management .....  | 53        |
| 4.7 Circuit Protection .....   | 54        |
| 4.7.1 External Fuses for the Power Section .....   | 54        |
| Table 4.7.1.1: External Fuse Types for AC Input Side .....   | 54        |
| 4.7.2 External Fuses for the Power Section DC Input Side .....   | 55        |
| Table 4.7.2.1: External Fuses Type for DC Input Side .....   | 55        |
| 4.7.3 Internal Fuses .....   | 55        |
| Table 4.7.3.1: Internal Fuses .....  | 55        |
| 4.8 Chokes / Filters .....   | 56        |
| 4.8.1 AC Input Chokes .....  | 56        |
| Table 4.8.1.1: 3-Phase AC Input Chokes .....   | 56        |
| 4.8.2 Output Chokes .....  | 56        |
| Table 4.8.2.1: Recommended Output Chokes .....   | 57        |
| 4.8.3 Interference Suppression Filters .....   | 57        |
| 4.9. Braking Units .....   | 58        |
| Figure 4.9.1: Operation with Braking Unit (Principle) .....  | 58        |
| 4.9.1 Internal Braking Unit .....  | 58        |

|  |            |
|--|------------|
| Figure 4.9.1.1: Connection with Internal Braking Unit and External Braking Resistor .....                | 58         |
| 4.9.2 External Braking Resistor .....  | 59         |
| Table 4.9.2.1: Lists and Technical Data of the External Standard Resistors .....                         | 59         |
| Figure 4.9.2.2: Limit Operating Braking Cycle with Typical Triangular Power Profile .....                | 59         |
| Figure 4.9.2.3: Braking Cycle with TBR / TC = 20% .....  | 60         |
| Figure 4.9.2.4: Generic Braking Cycle with Triangular Profile .....                                      | 61         |
| Table 4.9.2.2: Braking Thresholds for Different Mains .....  | 62         |
| Table 4.9.2.3: Technical Data of the Internal Braking Units .....  | 62         |
| 4.10 Buffering the Regulator Supply .....  | 63         |
| Table 4.10.1: DC Link Buffer Time .....  | 63         |
| Figure 4.10.1: Buffering the Regulator Supply by Means of Additional Intermediate Circuit Capacitors ... | 64         |
| 4.11 Discharge Time of the DC-Link .....   | 65         |
| Table 4.11.1: DC Link Discharge Time .....   | 65         |
| <b>Chapter 5 - Serial Interface Description .....</b>  | <b>67</b>  |
| Figure 5.1: RS485 Serial Interface .....   | 67         |
| 5.1 RS 485 Serial Interface Connector Description .....  | 68         |
| Table 5.1.1: Assignment of the Plug XS Connector for the RS 485 Serial Interface .....                   | 68         |
| <b>Chapter 6 - Keypad Operation .....</b>  | <b>69</b>  |
| 6.1 LEDs & Keys .....  | 69         |
| 6.2 Moving Inside a Menu .....   | 71         |
| 6.3 Using Keypad Help .....  | 71         |
| 6.4 Drive Main Menu .....  | 72         |
| <b>Chapter 7 - Commissioning via Keypad .....</b>  | <b>73</b>  |
| 7.1 Commissioning for AVy...AC / AC4 (Asynchronous Motors) .....   | 73         |
| 7.1.1 Field Oriented mode .....  | 75         |
| 7.1.2 Sensorless vector mode .....   | 85         |
| 7.1.3 V/f Control mode .....   | 86         |
| 7.2 Commissioning for AVy...BR / BR4 (Brushless Motors) .....  | 99         |
| <b>Chapter 8 - Lift Sequencies .....</b>   | <b>115</b> |
| Figure 8.1: Standard Commands Sequence .....   | 116        |
| Figure 8.2: Detail Starting .....  | 117        |
| Figure 8.3: Detail Stopping .....  | 118        |
| Figure 8.4: Relation between Direction Commands and Contactor Control Signals .....                      | 119        |
| <b>Chapter 9 - Parameter .....</b>   | <b>121</b> |
| 9.1 Parameter Legend .....   | 121        |
| 9.2 Parameter Description .....  | 122        |
| <b>Chapter 10 - Troubleshooting .....</b>  | <b>206</b> |
| Figure 10.1: Led Status and Keypad .....   | 206        |
| 10.1 List of Regulation Alarm Events .....   | 207        |
| Table 10.1.1 Regulation Alarm Events .....   | 208        |
| 10.2 List of Configuration and DataBase Error Alarm Events .....   | 210        |
| 10.2.1 Configuration Errors .....  | 210        |
| 10.2.2 Database Errors (DB Errors) .....   | 211        |
| 10.2.3 List of Error Codes for All Autotune Procedures .....   | 213        |
| Table 10.2.3.1: Error Messages from Autotune Procedures .....  | 213        |
| <b>Chapter 11 - EMC Directive - Declaration of Conformity .....</b>                                      | <b>214</b> |
| <b>Chapter 12 -Parameters Index .....</b>  | <b>217</b> |

## Safety Symbol Legend - Precautions de sécurité



**Indicates a procedure, condition, or statement that, if not strictly observed, could result in personal injury or death.**

*Indique le mode d'utilisation, la procédure et la condition d'exploitation. Si ces consignes ne sont pas strictement respectées, il y a des risques de blessures corporelles ou de mort.*



**Indicates a procedure, condition, or statement that, if not strictly observed, could result in damage to or destruction of equipment.**

*Indique et le mode d'utilisation, la procédure et la condition d'exploitation. Si ces consignes ne sont pas strictement respectées, il y a des risques de détérioration ou de destruction des appareils*



**Indicates a procedure, condition, or statement that should be strictly followed in order to optimize these applications.**

*Indique le mode d'utilisation, la procédure et la condition d'exploitation. Ces consignes doivent être rigoureusement respectées pour optimiser ces applications..*

### **Note!**

**Indicates an essential or important procedure, condition, or statement.**

*Indique un mode d'utilisation, de procédure et de condition d'exploitation essentiels ou importants*

## Chapter 0 - Safety Precautions

According to the EEC standards the ARTDriveL and accessories must be used only after checking that the machine has been produced using those safety devices required by the 89/392/EEC set of rules, as far as the machine industry is concerned. These standards do not apply in the Americas, but may need to be considered in equipment being shipped to Europe.

Drive systems cause mechanical motion. It is the responsibility of the user to insure that any such motion does not result in an unsafe condition. Factory provided interlocks and operating limits should not be bypassed or modified.

*Selon les normes EEC, les drives ARTDriveL et leurs accessoires doivent être employés seulement après avoir vérifié que la machine ait été produit avec les même dispositifs de sécurité demandés par la réglementation 89/392/EEC concernant le secteur de l'industrie.*

*Les systèmes provoquent des mouvements mécaniques. L'utilisateur est responsable de la sécurité concernant les mouvements mécaniques. Les dispositifs de sécurité prévues par l'usine et les limitations opérationnelles ne doivent être dépassés ou modifiés.*



### Electrical Shock and Burn Hazard:

When using instruments such as oscilloscopes to work on live equipment, the oscilloscope's chassis should be grounded and a differential amplifier input should be used. Care should be used in the selection of probes and leads and in the adjustment of the oscilloscope so that accurate readings may be made. See instrument manufacturer's instruction book for proper operation and adjustments to the instrument.

*Décharge Électrique et Risque de Brûlure :*

*Lors de l'utilisation d'instruments (par exemple oscilloscope) sur des systèmes en marche, le châssis de l'oscilloscope doit être relié à la terre et un amplificateur différentiel devrait être utilisé en entrée.*

*Les sondes et conducteurs doivent être choisis avec soin pour effectuer les meilleures mesures à l'aide d'un oscilloscope. Voir le manuel d'instruction pour une utilisation correcte des instruments.*

### Fire and Explosion Hazard:

Fires or explosions might result from mounting Drives in hazardous areas such as locations where flammable or combustible vapors or dusts are present. Drives should be installed away from hazardous areas, even if used with motors suitable for use in these locations.

*Risque d'incendies et d'explosions:*

*L'utilisation des drives dans des zones à risques (présence de vapeurs ou de poussières inflammables), peut provoquer des incendies ou des explosions. Les drives doivent être installés loin des zones dangereuses, et équipés de moteurs appropriés.*

**Strain Hazard:**

**Improper lifting practices can cause serious or fatal injury. Lift only with adequate equipment and trained personnel.**

*Attention à l'Élévation:*

*Une élévation inappropriée peut causer des dommages sérieux ou fatals. Il doit être élevé seulement avec des moyens appropriés et par du personnel qualifié.*

**Drives and motors must be ground connected according to the NEC.**

*Tous les moteurs et les drives doivent être mis à la terre selon le Code Electrique National ou équivalent.*

**Replace all covers before applying power to the Drive. Failure to do so may result in death or serious injury.**

*Remettre tous les capots avant de mettre sous tension le drive. Des erreurs peuvent provoquer de sérieux accidents ou même la mort.*

**Adjustable frequency drives are electrical apparatus for use in industrial installations. Parts of the Drives are energized during operation. The electrical installation and the opening of the device should therefore only be carried out by qualified personnel. Improper installation of motors or Drives may therefore cause the failure of the device as well as serious injury to persons or material damage.**

**Drive is not equipped with motor overspeed protection logic other than that controlled by software. Follow the instructions given in this manual and observe the local and national safety regulations applicable.**

*Les drives à fréquence variable sont des dispositifs électriques utilisés dans des installations industriels. Une partie des drives sont sous tension pendant l'opération. L'installation électrique et l'ouverture des drives devrait être exécuté uniquement par du personnel qualifié. De mauvaises installations de moteurs ou de drives peuvent provoquer des dommages matériels ou blesser des personnes. On doit suivre les instructions données dans ce manuel et observer les règles nationales de sécurité.*

**Always connect the Drive to the protective ground (PE) via the marked connection terminals (PE2) and the housing (PE1). AC Input filters have ground discharge currents greater than 3.5 mA. EN 50178 specifies that with discharge currents greater than 3.5 mA the protective conductor ground connection (PE1) must be fixed type and doubled for redundancy.**

*Il faut toujours connecter le variateur à la terre (PE) par les des bornes (PE2) et le châssis (PE1). Le courant de dispersion vers la terre est supérieur à 3,5 mA sur les filtres à courant alterné (CA). Les normes EN 50178 spécifient qu'en cas de courant de dispersion vers la terre, supérieur à 3,5 ma, la mise à la terre (PE1) doit avoir une double connexion pour la redondance.*



**Warning**



**The drive may cause accidental motion in the event of a failure, even if it is disabled, unless it has been disconnected from the AC input feeder.**

*En cas de panne, le variateur peut causer une mise en marche accidentelle, même s'il est désactivé, sauf s'il a été débranché de l'alimentateur à courant alterné.*

**Never open the device or covers while the AC Input power supply is switched on. Minimum time to wait before working on the terminals or inside the device is listed in section 4.12 on Instruction manual .**

*Ne jamais ouvrir l'appareil lorsqu'il est sous tension. Le temps minimum d'attente avant de pouvoir travailler sur les bornes ou bien à l'intérieur de l'appareil est indiqué dans la section 4.12.*

**If the front plate has to be removed because of ambient temperature higher than 40 degrees, the user has to ensure that no occasional contact with live parts may occur.**

*Si la plaque frontale doit être enlevée pour un fonctionnement avec la température de l'environnement plus haute que 40°C, l'utilisateur doit s'assurer, par des moyens opportuns, qu'aucun contact occasionnel ne puisse arriver avec les parties sous tension.*



**Do not connect power supply voltage that exceeds the standard specification voltage fluctuation permissible. If excessive voltage is applied to the Drive, damage to the internal components will result.**

*Ne pas raccorder de tension d'alimentation dépassant la fluctuation de tension permise par les normes. Dans le cas d'une alimentation en tension excessive, des composants internes peuvent être endommagés.*

**Power supply and grounding / Attention ! Alimentation puissance et mise à la terre**

In case of a three phase supply not symmetrical to ground, an insulation loss of one of the devices connected to the same network can cause functional problem to the drive, if the use of a wye/delta transformer is avoided.


- 1 The drives are designed to be powered from standard three phase lines that are electrically symmetrical with respect to ground (TN or TT network).
- 2 In case of supply with IT network, the use of wye/delta transformer is mandatory, with a secondary three phase wiring referred to ground.

Please refer to the following connection sample.

*Si le réseau n'est pas équilibré par rapport à la terre et qu'il n'y a pas de transformateur raingle/étoile, une mauvaise isolation d'un appareil électrique connecté au même réseau que le variateur peut lui causer*

des troubles de fonctionnement.

- 1 Les variateurs sont prévus pour être alimentés par un réseau triphasé équilibré avec un régime de neutre standard (TN ou TT).
- 2 Si le régime de neutre est IT, nous vous recommandons d'utiliser un transformateur triangle/étoile avec point milieu ramené à la terre. Vous pouvez trouver ci-après des exemples de câblage.



**Do not operate the Drive without the ground wire connected. The motor chassis should be grounded to earth through a ground lead separate from all other equipment ground leads to prevent noise coupling.**

*Ne pas faire fonctionner le drive sans prise de terre. Le châssis du moteur doit être mis à la terre à l'aide d'un connecteur de terre séparé des autres pour éviter le couplage des perturbations. Le connecteur de terre devrait être dimensionné selon la norme NEC ou le Canadian Electrical code.*



**The grounding connector shall be sized in accordance with the NEC or Canadian Electrical Code. The connection shall be made by a UL listed or CSA certified closed-loop terminal connector sized for the wire gauge involved. The connector is to be fixed using the crimp tool specified by the connector manufacturer.**

*Le raccordement devrait être fait par un connecteur certifié et mentionné à boucle fermée par les normes CSA et UL et dimensionné pour l'épaisseur du câble correspondant. Le connecteur doit être fixé à l'aide d'un instrument de serrage spécifié par le producteur du connecteur.*

**Do not perform a megger test between the Drive terminals or on the control circuit terminals.**

*Ne pas exécuter un test megger entre les bornes du drive ou entre les bornes du circuit de contrôle.*

**Because the ambient temperature greatly affects Drive life and reliability, do not install the Drive in any location that exceeds the allowable temperature. Leave the ventilation cover attached for temperatures of 104° F (40° C) or below.**

*Étant donné que la température ambiante influe sur la vie et la fiabilité du drive, on ne devrait pas installer le drive dans des places où la température permise est dépassée. Laisser le capot de ventilation en place pour températures de 104°F (40°C) ou inférieures.*

**If the Drive's Fault Alarm is activated, consult the TROUBLESHOOTING section of this instruction book, and after correcting the problem, resume operation. Do not reset the alarm automatically by external sequence, etc.**

*Si la Fault Alarm du drive est activée, consulter la section du manuel concernant les défauts et après avoir corrigé l'erreur, reprendre l'opération. Ne pas réinitialiser l'alarme automatiquement par une séquence externe, etc*

**Be sure to remove the desiccant dryer packet(s) when unpacking the Drive. (If not removed these packets may become lodged in the fan or air passages and cause the Drive to overheat).**

*Lors du déballage du drive, retirer le sachet déshydraté. (Si celui-ci n'est pas retiré, il empêche la ventilation et provoque une surchauffe du drive).*



**Caution**

**The Drive must be mounted on a wall that is constructed of heat resistant material. While the Drive is operating, the temperature of the Drive's cooling fins can rise to a temperature of 194° F (90° C).**

*Le drive doit être monté sur un mur construit avec des matériaux résistants à la chaleur. Pendant le fonctionnement du drive, la température des ailettes du dissipateur thermique peut arriver à 194°F (90°).*

**Do not touch or damage any components when handling the device. The changing of the isolation gaps or the removing of the isolation and covers is not permissible.**

*Manipuler l'appareil de façon à ne pas toucher ou endommager des parties. Il n'est pas permis de changer les distances d'isolement ou bien d'enlever des matériaux isolants ou des capots.*

**Protect the device from impermissible environmental conditions (temperature, humidity, shock etc.)**

*Protéger l'appareil contre des effets extérieurs non permis (température, humidité, chocs etc.).*

**No voltage should be connected to the output of the drive (terminals U2, V2 W2). The parallel connection of several drives via the outputs and the direct connection of the inputs and outputs (bypass) are not permissible.**

*Aucune tension ne doit être appliquée sur la sortie du convertisseur (bornes U2, V2 et W2). Il n'est pas permis de raccorder la sortie de*

*plusieurs convertisseurs en parallèle, ni d'effectuer une connexion directe de l'entrée avec la sortie du convertisseur (Bypass).*

**A capacitive load (e.g. Var compensation capacitors) should not be connected to the output of the drive (terminals U2, V2, W2).**

*Aucune charge capacitive ne doit être connectée à la sortie du convertisseur (bornes U2, V2 et W2) (par exemple des condensateurs de mise en phase).*



**The electrical commissioning should only be carried out by qualified personnel, who are also responsible for the provision of a suitable ground connection and a protected power supply feeder in accordance with the local and national regulations. The motor must be protected against overloads.**

*La mise en service électrique doit être effectuée par un personnel qualifié. Ce dernier est responsable de l'existence d'une connexion de terre adéquate et d'une protection des câbles d'alimentation selon les prescriptions locales et nationales. Le moteur doit être protégé contre la surcharge*

**No dielectric tests should be carried out on parts of the drive. A suitable measuring instrument (internal resistance of at least 10 k $\Omega$ /V) should be used for measuring the signal voltages.**

*Il ne faut pas exécuter de tests de rigidité diélectrique sur des parties du convertisseurs. Pour mesurer les tensions, des signaux, il faut utiliser des instruments de mesure appropriés (résistance interne minimale 10 k $\Omega$ /V).*

**NOTE!**

If the Drives have been stored for longer than two years, the operation of the DC link capacitors may be impaired and must be “reformed”.

Before commissioning devices that have been stored for long periods, connect them to a power supply for two hours with no load connected in order to regenerate the capacitors, (the input voltage has to be applied without enabling the drive).

*En cas de stockage des variateurs pendant plus de deux ans, il est conseillé de contrôler l'état des condensateurs CC avant d'en effectuer le branchement. Avant la mise en service des appareils, ayant été stockés pendant longtemps, il faut alimenter variateurs à vide pendant deux heures, pour régénérer les condensateurs : appliquer une tension d'alimentation sans actionner le variateur .*

**NOTE!**

The terms “Inverter”, “Controller” and “Drive” are sometimes used interchangeably throughout the industry. We will use the term “Drive” in this document.

*Les mots “Inverter”, “Controller” et “Drive” sont interchangeables dans le domaine industriel. Nous utiliserons dans ce manuel seulement le mot “Drive”.*

# Chapter 1 - Functions and General Features

## 1.1 Drive

The ARTDrive Lift is a field-oriented vector drive with excellent speed control properties and a high torque dedicated to elevator industry and in general to hoisting applications. It can be applied to both geared and gearless systems.

Available control modes according to the installed firmware are:

|               | <b>AVy ... AC / AVy ... AC4</b><br><b>Asynchronous motor firmware</b>                    | <b>AVy ... BR / AVy ... BR4</b><br><b>Synchronous motor firmware</b> |
|---------------|--|--|
| Control Modes | - Field oriented vector control<br>- Sensorless vector control<br>- V/f advanced control | -Brushless control   |

### Dedicated features

- **Lift sequence**  
Typical sequence of input / output signals used in elevator application, brake, output contactor & door control
- **Parameters in linear units**  
It is possible to select different engineering units for principal parameters determining the movement, rpm for speed and rpm/s, rmp/s<sup>2</sup> for acceleration referred to motor or mm/s for speed, mm/s<sup>2</sup>, mm/s<sup>3</sup> for acceleration referred to car.
- **Lift mechanical parameters**  
Parameters of mechanical system like Pulley diameter and Gearbox ratio for transformation between unit systems and System weights to calculate inertia and tune speed regulator for desired response.
- **Ramp generation**  
Two independent S ramps selectable through digital input with 4 independent jerk settings. Dedicated deceleration ramp corresponding to stop command.
- **Multi speed**  
8 preset speed reference values. At start, possibility to overwrite with additional value to achieve smooth start.
- **Pre-torque**  
Initialisation of speed regulator from weight sensor to avoid saging or lifting at start.
- **Landing control**  
Precision control of car position in floor zone through internal position regulator.
- **Higher overload**  
Overload capability corresponding to typical load cycle used in elevator application.
- **Fan control logic function** (only for sizes AVy2040AC4 / BR4 up to AVy5550AC4 / BR4)

Fan control logic function allows to run internal inverter fans only when the drive is enabled. Fan control logic function signal is also repeated on the drive power board FEXT terminals, for an auxiliary external fan.

- **Emergency Module Supply**

Emergency Module Supply control (EMS or MW22U) allows emergency lift manoeuvres (auxiliary battery pack is required). Both devices must be signal interfaced with drive power board EM terminal. Please refer to EMS or MW22U user manual for technical specification.

- **Easy of use menu**

Menus with elevator terminology separated for MONITORing, motor STARTUP and TRAVEL settings.

### **Drive features**

- Self tuning procedure for current, flux and speed regulators, automatic phasing for brushless motors.
- Space vector modulation keeps the noise level to a minimum.
- Switching frequencies selectable 2, 4, 8, 12, 16 kHz.
- Output voltage up to 98% of input voltage.
- Fault register storing the last 30 fault alarms with the associated lifetime.
- Overload protection for drive, motor and brake unit.
- Three freely configurable analog inputs on the standard device.
- Expansion of the analog / digital outputs and analog / digital inputs via option cards (EXP D8R4, EXP D14A4F).
- Speed and torque current regulation possible.
- Management of many different types of speed feedback devices (encoder).
- Adaptive speed regulation.
- Speed-related alarms.

Simple operation of the drive can be via

- the terminal strip
- the user-friendly keypad
- the PC program supplied and the RS485 serial interface
- a fieldbus connection (optional): INTERBUS-S, PROFIBUS-DP, GENIUS, CANopen or DeviceNet.

The Drives are fitted with IGBTs (insulated gate bipolar transistors).

The output is protected against ground fault and phase to phase output short circuit.

Regulator power supply via switched-mode power supply unit from the DC Bus circuit. Power supply backup in the event of short-term voltage dips.

Galvanic isolation between control section and command terminals.

Analog inputs designed as differential inputs.

## 1.2 Motors

The AVy Drives designed for the field oriented regulation of standard three-phase induction AC motors. A sinusoidal encoder or digital encoder can be used for feedback in proportion to speed.

The electrical and mechanical data of standard three-phase motors refers to a particular operating range. The following points should be noted when these motors are connected to an AC Drive:

### **Is it possible to use standard induction motors?**

With the AVy Drives it is possible to use standard induction motors. Some features of the motor have a great influence on the obtained performances. Notice also what is stated in section 2.3.2, “AC Output”, about the voltages and the motor power.

### **Which properties of the asynchronous motors have an unfavorable result in operation with frequency inverters?**

Motors with double squirrel-cage rotors or deep rotor bars should not be used.

### **Star or delta connection?**

Motors can be connected in both star or delta connections. Experience has shown that star connected motors have better control properties, so star connections are preferred.

### **Cooling**

The cooling of three-phase motors is normally implemented by means of a fan that is mounted on the motor shaft. Remember that the air flux produced by the fan is reduced when the motor is running at lower speeds, which in certain circumstances may mean that the cooling is insufficient for the motor. Check with the motor manufacturer whether an external fan is required and the motor speed range in the application concerned.

### **Operation above the rated speed**

Due to the mechanical factors involved (bearings, unbalance of rotor) and due to the increased iron losses, consult the manufacturer of the motor if this is operated above the rated speed .

### **What motor data is required for connecting the frequency inverter?**

Motor nameplate specifications

#### *Asynchronous induction motor*

- Rated voltage
- Rated frequency
- Rated current
- Rated speed
- Rated power
- Cosphi
- Efficiency

### *Synchronous brushless motor*

- Rated voltage
- Rated current
- Rated speed
- Pole pairs
- Torque constant
- EMF constant
- Stator resistance
- Ls S inductance

### **Motor protection**

#### Thermistors

PTC thermistors according to DIN 44081 or 44082 fitted in the motor can be connected directly to the frequency inverter via terminals 78 and 79. In this case the resistor (1Kohm) mounted between the terminals 78 and 79 has to be removed.

#### Temperature-dependent contacts in the motor winding

Temperature-dependent contacts “Klixon” type can disconnect the drive via the external control or can be reported as an external fault on the frequency inverter (terminal 15). They can also be connected to the terminals 78 and 79 in order to have a specific error signal. In this case connect the existing 1 Kohm resistor in series to the wiring, note that one side of it must be connected directly to terminal 79.

#### **NOTE!**

The motor PTC interface circuit (or klixon) has to be considered and treated as a signal circuit. The connections cables to the motor PTC must be made of twisted pairs with a shield, the cable route should not be parallel to the motor cable or far away at least 20 cm.

#### Current limitation of the frequency inverter

The current limitation can protect the motor from impermissible overloads. For this the current limitation and the motor overload control function of the Drive (“Motor protection”) must be set so that the current is kept within the permissible range for the motor concerned.

#### **NOTE!**

Remember that the current limitation can control an overheating of the motor only due to overload, not due to insufficient ventilation. When the drive is operated at low speeds the additional use of PTC resistors or temperature-dependent contacts in the motor windings is recommended, unless separate forced ventilation is available.

#### Output chokes

When using general purpose standard motors, output chokes are recommended to protect winding isolation in some cases. See section 4.8.2, “Output chokes”.



# Chapter 2 - Inspection procedures, Components Identification and Standard Specifications

## 2.1 Upon Delivery Inspection Procedures

### 2.1.1 General

A high degree of care is taken in packing the ARTDriveL drives and preparing them for delivery. They should only be transported with suitable transport equipment (see weight data). Observe the instructions printed on the packaging. This also applies when the device is unpacked and installed in the control cabinet.

Upon delivery, check the following:

- the packaging for any external damage
- whether the delivery note matches your order.

Open the packaging with suitable tools. Check whether:

- any parts were damaged during transport
- the device type corresponds to your order

In the event of any damage or of an incomplete or incorrect delivery please notify the responsible sales offices immediately.


The devices should only be stored in dry rooms within the specified temperature ranges.

### **Note!**

A certain degree of moisture condensation is permissible if this arises from changes in temperature (see section 2.3.1, “Permissible Environmental Conditions”). This does not, however, apply when the devices are in operation. Always ensure that there is no moisture condensation in devices that are connected to the power supply!

### 2.1.2 Inverter type designation

The technical specification of the AVy Drive is stated in the type code. Example:






### 2.1.3 Nameplate

Check that all the data stated in the nameplate enclosed to the inverter correspond to what has been ordered.

Figure 2.1.3.1: Identification nameplate

|       |   |     |          |
|-------|---|-----|----------|
| Type: | AVy3150-KBL AC4                                 | S/N | 02006233 |
| Inp:  | 230-480 Vac (Fctry Set=400) 50/60Hz 3Ph Zmin=1% |     |          |
|       | 28,2A@400Vac 24,5A@480Vac With line choke       |     |          |
| Out:  | 0-400Vac 0-500Hz 3Ph 20HP @ 460Vac/15kW@400Vac  |     |          |
|       | 33A@400V Cont. Serv. 26,9A@480V                 |     |          |



 LISTED INDUSTRIAL CONTROL EQUIPMENT 31KF
 


- Type:** Inverter model
- S/N:** Serial number
- Inp:** Power supply voltage range, frequency and AC Input current
- Out:** Output voltage, Output frequency, Output power and current

Figure 2.1.3.2: Firmware & Card revision level nameplate

| Firmware Release | HW release |   |     |     |   | S/N | 0162330 | Prod. CONF |
|------------------|------------|---|-----|-----|---|-----|---------|------------|
|                  | D          | F | P   | R   | S | BU  | SW.CFG  |            |
| 1.000            | 0.A        |   | 0.A | 0.A |   |     | 1.000   | D1         |


Figure 2.1.3.3: Nameplates position



## 2.2 Component Identification

An ARTDriveL converts the constant voltage and frequency of a three-phase power supply into a direct voltage and then converts this direct voltage into a new three-phase power supply with a variable voltage and frequency. This variable three-phase power supply can be used for infinitely variable adjustment of the speed of three-phase asynchronous and synchronous motors.

Figure 2.2.1: Basic Setup of Frequency Inverter



- 1 AC Input supply voltage**
- 2 AC Mains choke**  
See section 4.8.1
- 3 Three-phase rectifier bridge**  
Converts the alternating current into direct current using a three phase full wave bridge.
- 4 DC intermediate circuit**  
With charging resistor and smoothing capacitor.  
Direct voltage ( $U_{DC}$ ) =  $\sqrt{2}$  x Mains voltage ( $U_{LN}$ )
- 5 IGBT inverter**  
Converts direct voltage to a variable three-phase alternating voltage with variable frequency.
- 6 Configurable control section**  
Modules for open-loop and closed-loop control of the power section. This is used for processing control commands, reference values and actual values.
- 7 Output voltage**  
Three-phase, variable alternating voltage.
- 8 Encoder**  
For speed feedback (see section 3.4.2).

## 2.3 Standard Specifications

### 2.3.1 Permissible Environmental Conditions

#### ENVIRONMENT

|   |  |
|---|--|
| <b>T<sub>A</sub> Ambient temperature [°C]</b> _____ | 0 ... +40; +40...+50 with derating   |
| <b>T<sub>A</sub> Ambient temperature [°F]</b> _____ | 32 ... +104; +104...+122 with derating   |
| <b>Installation location</b> _____                  | Pollution degree 2 or better (free from direct sunlight, vibration, dust, corrosive or inflammable gases, fog, vapour oil and dripped water, avoid saline environment) |
| <b>Degree of protection</b> _____                   | IP20<br>IP54 for the cabinet with externally mounted heatsink (size type 1007 to 3150)   |
| <b>Installation altitude</b> _____                  | Up to 1000 m (3280 feet) above sea level; for higher altitudes a current reduction of 1.2% for every 100 m (328 feet) of additional height applies .                   |
| <b>Temperature:</b>                                 |  |
| <b>operation</b> <sup>1)</sup> _____                | 0...40°C (32°...104°F)   |
| <b>operation</b> <sup>2)</sup> _____                | 0...50°C (32°...122°F)   |
| <b>storage</b> _____                                | -25...+55°C (-13...+131°F), class 1K4 as per EN50178<br>-20...+55°C (-4...+131°F), for devices with keypad   |
| <b>transport</b> _____                              | -25...+70°C (-13...+158°F), class 2K3 as per EN50178<br>-20...+60°C (-4...+140°F), for devices with keypad   |
| <b>Air humidity:</b>                                |  |
| <b>operation</b> _____                              | 5 % to 85 %, 1 g/m <sup>3</sup> to 25 g/m <sup>3</sup> without moisture condensation or icing (Class 3K3 as per EN50178)   |
| <b>storage</b> _____                                | 5% to 95 %, 1 g/m <sup>3</sup> to 29 g/m <sup>3</sup> (Class 1K3 as per EN50178)   |
| <b>transport</b> _____                              | 95 % <sup>3)</sup> , 60 g/m <sup>3</sup> <sup>4)</sup>   |
| <b>Air pressure:</b>                                |  |
| <b>operation</b> _____                              | [kPa] 86 to 106 (class 3K3 as per EN50178)   |
| <b>storage</b> _____                                | [kPa] 86 to 106 (class 1K4 as per EN50178)   |
| <b>transport</b> _____                              | [kPa] 70 to 106 (class 2K3 as per EN50178)   |

#### STANDARD

|                                     |   |
|-------------------------------------|---|
| <b>Climatic conditions</b> _____    | IEC 68-2 Part 2 and 3                             |
| <b>Clearance and creepage</b> _____ | EN 50178, UL508C, UL840 degree of pollution 2     |
| <b>Vibration</b> _____              | IEC68-2 Part 6                                    |
| <b>EMC compatibility</b> _____      | EN61800-3 (see "EMC Guidelines" instruction book) |
| <b>Approvals</b> _____              | CE, UL, cUL                                       |

- 1) Parameter Ambient temp = 40°C (104°)  
Ambient temp = 0 ... 40°C (32°...104°F)  
Over 40°C: - current reduction of 2% of rated output current per K  
- remove front plate (better than class 3K3 as per EN50178)
- 2) Parameter Ambient temp = 50°C (122°F)  
Ambient temp = 0 ... 50°C (32°...122°F)  
Current derated to 0.8 rated output current  
Over 40°C (104°): removal of the top cover (better than class 3K3 as per EN50178)
- 3) Greatest relative air humidity occurs with the temperature @ 40°C (104°F) or if the temperature of the device is brought suddenly from -25 ...+30°C (-13°...+86°F).
- 4) Greatest absolute air humidity if the device is brought suddenly from 70°...15°C (158°...59°F).

## DISPOSAL OF THE DEVICE

The AVy Drive can be disposed as electronic scrap in accordance with the currently valid national regulations for the disposal of electronic parts. The plastic covers of the Drives (up to size 3150) are recyclable: the material used is >ABS+PC<.

### 2.3.2 AC Input/Output Connection

The AVy Drive must be connected to an AC mains supply capable of delivering a symmetrical short circuit current (at 480V +10% Vmax) lower or equal to the values indicated on table 2.3.4.1. For the use of an AC input choke see chapter 4.8.1.

No external connection of the regulator power supply to the existing AC Input supply is required since the power supply is taken from the DC Link circuit. When commissioning, set the **Mains voltage** parameter to the value of the AC Input voltage concerned. This automatically sets the threshold for the Undervoltage alarm at the appropriate level.

#### **Note!**

In some cases AC Input chokes, and possibly noise suppression filters should be fitted on the AC Input side of the device. See chapter “Chokes/Filters”.

Adjustable Frequency Drives and AC Input filters have ground discharge currents greater than 3.5 mA. EN 50178 specifies that with discharge currents greater than 3.5 mA the protective conductor ground connection (PE1) must be fixed type.

### 2.3.3 AC Input

The Input current of the Drive depends on the operating state and the service conditions of the connected motor, and the use of input reactors. The table 2.3.4.1 shows the values corresponding to rated continuous service (IEC 146 class 1), keeping into account typical output power factor for each size

### 2.3.4 AC Output

The output of the AVy Drive is ground fault and phase to phase short protected. The switching frequency is constant in the speed range and depends on the drive size.

The connection of an external voltage to the output terminals of the Drive is not permitted!

---

#### **Note!**

**It is allowed to disconnect the motor from the Drive output, by means of output contactor only after the Drive has been disabled.**

---

The value for the continuous output current rating ( $I_{CONT}$ ) depends on AC Input voltage ( $K_V$ ), Ambient temperature ( $K_T$ ) and Switching frequency ( $K_F$ ), values of derating factor are the listed on table 2.3.4.1:

$$I_{CONT} = I_{2N} \times K_V \times K_T \times K_F$$

The applicable deratings are automatically set when selecting the appropriate values of AC Input voltage, Ambient temperature and Switching frequency.

Figure 2.3.4.1: Rating of Drive in Function of Switching Frequency




Table 2.3.4.2 shows overload current values for typical service profiles (Ambient temperature =40°C [104°F], standard switching frequency).

After overload cycle, the output current is reduced to nominal output current by the drive control. In order to allow next overload cycle, output current should be decreased (reducing the load) to value less than nominal. Table states overload recovery (pause) time with current reduced to 90% continuous current.

The coordination of the motor rated powers with the Drive type presented in the table below refers to the use of standard 4 poles motors with a rated voltage equal to the rated voltage of the input supply.

As for those motors with different voltages, the type of Drive to use is determined by the rated current of the motor.

**Motor nominal current cannot be lower than  $0,3 \times I_{2N}$ . Magnetizing motor current must not be higher of  $I_{CONT}$ .**

Table 2.3.4.1: AC Input/Output Specifications



| Type   | 1007  | 1015   | 1022 | 1030 | 2040 | 2045 | 2075 | 3110 | 3150 | 4185 | 4220  | 4300 | 4370 | 5450 | 5550 | 6750 | 7900 | 71100 | 71320 | 81600 |       |     |  |  |  |
|--|-------|--|------|------|------|------|------|------|------|------|---|------|------|------|------|------|------|-------|-------|-------|-------|-----|--|--|--|
| Inverter Output (IEC 146 class1), Continuous service<br>P <sub>N</sub> mot (recommended motor output):<br>@ U <sub>LN</sub> =230VAc; f <sub>sw</sub> =default; IEC 146 class 1<br>@ U <sub>LN</sub> =400VAc; f <sub>sw</sub> =default; IEC 146 class 1<br>@ U <sub>LN</sub> =460VAc; IEC 146 class 1 | [kVA] | 1.6  | 2.7  | 3.8  | 5    | 6.5  | 8.5  | 12   | 16.8 | 22.4 | 26.5  | 32   | 42   | 55   | 64   | 79   | 98   | 128   | 145   | 173   | 224   |     |  |  |  |
| [kW]   | 0.37  | 0.75   | 1.1  | 1.5  | 2.2  | 3    | 4    | 5.5  | 7.5  | 9    | 11  | 18.5 | 22   | 22   | 30   | 37   | 55   | 75    | 90    | 110   | 150   | 200 |  |  |  |
| [kWh]  | 0.75  | 1.5  | 2.2  | 3    | 4    | 5.5  | 7.5  | 11   | 15   | 18.5 | 22  | 30   | 37   | 45   | 55   | 75   | 90   | 110   | 132   | 160   | 200   | 268 |  |  |  |
| [HP]   | 1     | 2  | 3    | 3    | 5    | 7.5  | 10   | 15   | 20   | 23   | 30  | 40   | 50   | 60   | 75   | 100  | 125  | 150   | 150   | 150   | 200   | 268 |  |  |  |
| U <sub>2</sub> : Max output voltage  | [V]   | 0.98 x U <sub>LN</sub> (AC Input voltage)  |      |      |      |      |      |      |      |      |   |      |      |      |      |      |      |       |       |       |       |     |  |  |  |
| f <sub>5</sub> : Max output frequency (*)  | [Hz]  | 400  |      |      |      |      |      |      |      |      |   |      |      |      |      |      |      |       |       |       |       |     |  |  |  |
| T <sub>50</sub> : Rated output current :   | [A]   | 2.4  | 4    | 5.6  | 7.5  | 9.6  | 12.6 | 17.7 | 24.8 | 33   | 39  | 47   | 63   | 79   | 93   | 114  | 142  | 185   | 210   | 250   | 324   |     |  |  |  |
| P <sub>50</sub> : Rated output power :   | [W]   | 2.1  | 3.5  | 4.9  | 6.5  | 8.3  | 11   | 15.4 | 21.6 | 28.7 | 34  | 40   | 54   | 68   | 81   | 99   | 124  | 160   | 183   | 217   | 282   |     |  |  |  |
| U <sub>sw</sub> : switching frequency (Default)  | [kHz] | 8  |      |      |      |      |      |      |      |      |   |      |      |      |      |      |      |       |       |       |       |     |  |  |  |
| U <sub>sw</sub> : switching frequency (Higher)   | [kHz] | 12 / 16  |      |      |      |      |      |      |      |      |   |      |      |      |      |      |      |       |       |       |       |     |  |  |  |
| Derating factor:   |       | 8  |      |      |      |      |      |      |      |      |   |      |      |      |      |      |      |       |       |       |       |     |  |  |  |
|  |       | --   |      |      |      |      |      |      |      |      |   |      |      |      |      |      |      |       |       |       |       |     |  |  |  |
|  |       | K <sub>T</sub> at 460/480VAc   |      |      |      |      |      |      |      |      |   |      |      |      |      |      |      |       |       |       |       |     |  |  |  |
|  |       | K <sub>T</sub> for ambient temperature   |      |      |      |      |      |      |      |      |   |      |      |      |      |      |      |       |       |       |       |     |  |  |  |
|  |       | K <sub>F</sub> for switching frequency   |      |      |      |      |      |      |      |      |   |      |      |      |      |      |      |       |       |       |       |     |  |  |  |
|  |       | 0.87   |      |      |      |      |      |      |      |      |   |      |      |      |      |      |      |       |       |       |       |     |  |  |  |
|  |       | 0.7 for f <sub>sw</sub> =16; 0.85 for f <sub>sw</sub> =12  |      |      |      |      |      |      |      |      |   |      |      |      |      |      |      |       |       |       |       |     |  |  |  |
|  |       | 0.8 @ 50°C (122°F)   |      |      |      |      |      |      |      |      |   |      |      |      |      |      |      |       |       |       |       |     |  |  |  |
|  |       | 0.7 for f <sub>sw</sub> higher then default  |      |      |      |      |      |      |      |      |   |      |      |      |      |      |      |       |       |       |       |     |  |  |  |
| U <sub>LN</sub> : AC Input voltage   | [V]   | 230 V -15% ... 480 V + 10%; 3Ph  |      |      |      |      |      |      |      |      |   |      |      |      |      |      |      |       |       |       |       |     |  |  |  |
| AC Input frequency   | [Hz]  | 50/60 Hz ±5%   |      |      |      |      |      |      |      |      |   |      |      |      |      |      |      |       |       |       |       |     |  |  |  |
| I <sub>N</sub> : AC Input current for continuous service :<br>- Connection with 3-phase reactor  | [A]   | 1.7  | 2.9  | 4    | 5.5  | 7    | 9.5  | 14   | 18.2 | 25   | 32.5  | 39   | 55   | 69   | 84   | 98   | 122  | 158   | 192   | 220   | n.a.  |     |  |  |  |
| N <sub>N</sub> : AC Input current for continuous service :<br>@ 230VAc; IEC 146 class1   | [A]   | 1.9  | 3.3  | 4.5  | 6.2  | 7.9  | 10.7 | 15.8 | 20.4 | 28.2 | 36.7  | 44   | 62   | 77   | 94   | 110  | 137  | 177   | 216   | 247   | 309   |     |  |  |  |
| P <sub>N</sub> : AC Input power for continuous service :<br>@ 400VAc; IEC 146 class1   | [A]   | 1.7  | 2.9  | 3.9  | 5.4  | 6.7  | 9.3  | 13.8 | 17.8 | 24.5 | 32.5  | 37   | 53   | 66   | 82   | 96   | 120  | 153   | 188   | 214   | 268   |     |  |  |  |
| U <sub>N</sub> : AC Input voltage for continuous service :<br>- Connection without 3-phase reactor   | [A]   | 3.6  | 4.4  | 6.8  | 7.9  | 11   | 15.5 | 21.5 | 27.9 | 35.4 | For these types an external inductance is recommended |      |      |      |      |      |      |       |       |       |       |     |  |  |  |
| N <sub>N</sub> : AC Input current for continuous service :<br>@ 230VAc; IEC 146 class1   | [A]   | 3.9  | 4.8  | 7.4  | 9    | 12   | 16.9 | 24.2 | 30.3 | 40   |   |      |      |      |      |      |      |       |       |       |       |     |  |  |  |
| P <sub>N</sub> : AC Input power for continuous service :<br>@ 400VAc; IEC 146 class1   | [A]   | 3.4  | 4.2  | 6.4  | 7.8  | 10.4 | 14.7 | 21   | 26.4 | 34.8 |   |      |      |      |      |      |      |       |       |       |       |     |  |  |  |
| U <sub>N</sub> : AC Input voltage for continuous service :<br>@ 460VAc; IEC 146 class1   | [kVA] | 160  | 270  | 380  | 500  | 650  | 850  | 1200 | 1700 | 2250 | 2700  | 3200 | 4200 | 5500 | 6400 | 7900 | 9800 | 12800 | 14500 | 17300 | 22400 |     |  |  |  |
| Max short circuit power without line reactor (Z <sub>min</sub> =1%)  | [kVA] | 820 V <sub>DC</sub>  |      |      |      |      |      |      |      |      |   |      |      |      |      |      |      |       |       |       |       |     |  |  |  |
| Overvoltage threshold  | [V]   | 230 V <sub>DC</sub> (for 230 V <sub>AC</sub> mains); 400 V <sub>DC</sub> (for 400V <sub>AC</sub> mains); 460 V <sub>DC</sub> (for 460 V <sub>AC</sub> mains) |      |      |      |      |      |      |      |      |   |      |      |      |      |      |      |       |       |       |       |     |  |  |  |
| Undervoltage threshold   | [V]   | 230 V <sub>DC</sub> (for 230 V <sub>AC</sub> mains); 400 V <sub>DC</sub> (for 400V <sub>AC</sub> mains); 460 V <sub>DC</sub> (for 460 V <sub>AC</sub> mains) |      |      |      |      |      |      |      |      |   |      |      |      |      |      |      |       |       |       |       |     |  |  |  |
| Braking IGBT Unit (standard drive)   |       | Standard internal (with external resistor); Braking torque 150%  |      |      |      |      |      |      |      |      |   |      |      |      |      |      |      |       |       |       |       |     |  |  |  |
|  |       | Option internal (with external resistor); Braking torque 150%  |      |      |      |      |      |      |      |      |   |      |      |      |      |      |      |       |       |       |       |     |  |  |  |
|  |       | External braking unit (optional)   |      |      |      |      |      |      |      |      |   |      |      |      |      |      |      |       |       |       |       |     |  |  |  |
| (*) Max output frequency refer to regulation in field oriented mode. See table at chapter 3.5.6 for other details<br>For AVy...AC4 and AVy...BR4 series only the models on grey field are available.   |       |  |      |      |      |      |      |      |      |      |   |      |      |      |      |      |      |       |       |       |       |     |  |  |  |

TADL2000

Table 2.3.4.2-A: Overload Capability (Sizes 1007 ... 4370)

| Model | Continuous current @400V | Overload factor | T1 Overload time | Overload current | T2 Overload pause time @90% Cont curr | T3 Overload pause time @0% Cont curr | LOW Frequency < 3Hz overload factor | LOW Frequency < 3Hz overload time |
|-------|--------------------------|-----------------|------------------|------------------|---------------------------------------|--------------------------------------|-------------------------------------|-----------------------------------|
|       | [A]                      |                 | [sec]            | [A]              | [sec]                                 | [sec]                                |                                     |                                   |
| 1007  | 2.4                      | 1.83            | 10               | 4.4              | 124                                   | 24                                   | 1.5                                 | 2                                 |
| 1015  | 4                        |                 |                  | 7.3              |                                       |                                      |                                     |                                   |
| 1022  | 5.6                      |                 |                  | 10.2             |                                       |                                      |                                     |                                   |
| 1030  | 7.5                      |                 |                  | 13.7             |                                       |                                      |                                     |                                   |
| 2040  | 9.6                      |                 |                  | 17.6             |                                       |                                      |                                     |                                   |
| 2055  | 12.6                     |                 |                  | 23.1             |                                       |                                      |                                     |                                   |
| 2075  | 17.7                     |                 |                  | 32.4             |                                       |                                      |                                     |                                   |
| 3110  | 24.8                     |                 |                  | 45.4             |                                       |                                      |                                     |                                   |
| 3150  | 33                       |                 |                  | 60.4             |                                       |                                      |                                     |                                   |
| 4185  | 39                       |                 |                  | 71.4             |                                       |                                      |                                     |                                   |
| 4221  | 47                       |                 |                  | 86.0             |                                       |                                      |                                     |                                   |
| 4301  | 63                       |                 |                  | 115.3            |                                       |                                      |                                     |                                   |
| 4371  | 79                       |                 |                  | 144.6            |                                       |                                      |                                     |                                   |

TL2020




- (1) Load current must be reduced to 90% level to allow next overload cycle.
- (2) Drive current is limited to 100% level when drive overload alarm is selected as Ignore or Warning
- (3) No limit on duration of this time interval @ 100% Cont current
- (4) Next overload cycle is allowed after T3



Table 2.3.4.2-B: Overload Capability (Sizes 5450... 81600)

| Model | Continuous current @400V | SLOW Overload factor | T1 SLOW Overload time | SLOW Overload current | T2 SLOW Overload pause time @90% Cont curr | FAST Overload factor | TF FAST Overload time [sec] | FAST Overload current | LOW Frequency < 3Hz overload factor | LOW Frequency < 3Hz overload time |
|-------|--------------------------|----------------------|-----------------------|-----------------------|--|----------------------|-----------------------------|-----------------------|-------------------------------------|-----------------------------------|
|       | [A]                      |                      | [sec]                 | [A]                   | [sec]                                      |                      | [sec]                       | [A]                   |                                     | [sec]                             |
| 5450  | 93                       | 1.36                 | 60                    | 126.5                 | 300  | 1.83                 | 0.5                         | 170.2                 | 1.36                                | 2                                 |
| 5550  | 114                      |                      |                       | 155                   |  |                      |                             | 208.6                 |                                     |                                   |
| 6750  | 142                      |                      |                       | 193.1                 |  |                      |                             | 259.9                 |                                     |                                   |
| 7900  | 185                      |                      |                       | 251.6                 |  |                      |                             | 338.6                 |                                     |                                   |
| 71100 | 210                      |                      |                       | 285.6                 |  |                      |                             | 384.3                 |                                     |                                   |
| 71320 | 250                      |                      |                       | 340                   |  |                      |                             | 457.5                 |                                     |                                   |
| 81600 | 324                      |                      |                       | 440.6                 |  | 1.4                  | 1.0                         | 453.6                 |                                     |                                   |

TL2021



### 2.3.5 I/O and Encoder Specifications

#### I/O

Enable inputs \_\_\_\_\_ 0 / 15...30 V 3.2...6.4 mA (5 mA @ 24 V)  
 Analog inputs \_\_\_\_\_ Selectable 0... ± 10 V 0.25mA max  
 0...20 mA 10V max  
 4...20 mA 10 V max  
 Max common mode voltage: 0...± 10 V

Analog outputs \_\_\_\_\_ 0...± 10 V 5 mA max per output  
 Digital inputs \_\_\_\_\_ 0 / 15...30 V 3.2...6.4 mA (5 mA @ 24 V)

Digital outputs \_\_\_\_\_ Supply + 15...35 V  
 Signals + 15...35 V 40 mA max per output

#### Int. voltage supply

Load capacity \_\_\_\_\_ + 5 V, 160 mA Plug connector  
 + 10 V, 10 mA Terminal 7  
 - 10 V, 10 mA Terminal 8  
 + 24 V, 120 mA Terminal 19  
 Tolerance \_\_\_\_\_ + 10 V ± 3 % <sup>1)</sup>  
 - 10 V ± 3 % <sup>1)</sup>  
 + 24 V + 20 ... 30 V, not stabilized  
 XE for digital encoder, PIN 7/9

<sup>1)</sup>The tolerance between positive and negative amplitudes is ± 0.5%

### 2.3.6 Accuracy

Table 2.3.6.1: Maximum / Minimum Output Frequency

| Regulation mode | Output frequency (Hz)     |     |     |     |                   | Resolution |
|-----------------|---------------------------|-----|-----|-----|-------------------|------------|
|                 | Maximum                   |     |     |     | Minimum (a)       |            |
|                 | Switching frequency (kHz) |     |     |     |                   |            |
|                 | 2                         | 4   | 8   | 16  |                   |            |
| Field oriented  | 200                       | 200 | 400 | 400 | 0                 | 0.005      |
| Sensorless vect | 200                       | 200 | 200 | 200 | 0.6               |            |
| V/f control     | 200                       | 300 | 600 | 600 | 2*motor slip freq |            |
| Brushless       | 200                       | 200 | 400 | 400 | 0                 |            |

(a): 1.5 \* Rated motor torque capability

**Table 2.3.6.2: Speed Reference / Feedback Resolution and Maximum Limits**

| Regulation mode | Speed reference resolution (rpm)     | Speed feedback resolution (rpm)                           |   |                |             | FSS max value (rpm)                  | Limit speed (rpm)                      |
|-----------------|--------------------------------------|---|---|----------------|-------------|--------------------------------------|--|
|                 |                                      | Enc Sin   | Enc Dig Fmode   | Enc Dig Fpmode | SinCos/Res. |                                      |  |
| Field oriented  | 0.03125<br>0.125<br>0.25<br>0.5<br>1 | Higher from [60000/(4096*ppr) - SpdD ref res]             | Higher from [60000/(40*ppr)- SpdD ref res]              | SpdD ref res   | N/A         | 512<br>2048<br>4096<br>8192<br>16384 | 1024<br>4096<br>8192<br>16384<br>32768 |
| Sensorless vect | 0.03125<br>0.125<br>0.25<br>0.5<br>1 | Highest value from (0.3 - SpdD ref res) (b)               |   |                | N/A         | 512<br>2048<br>4096<br>8192<br>16384 | 1024<br>4096<br>8192<br>16384<br>32768 |
| V/f control     | 0.03125<br>0.125<br>0.25<br>0.5<br>1 | N/A   |   |                |             | 512<br>2048<br>4096<br>8192<br>16384 | 1024<br>4096<br>8192<br>16384<br>32768 |
| Brushless       | 0.03125<br>0.125<br>0.25<br>0.5<br>1 | Higher value of either [60000/(4096*ppr)] or SpdD ref res | Higher value of either [60000/(40*ppr)] or SpdD ref res | SpdD ref res   | 2.5         | 512<br>2048<br>4096<br>8192<br>16384 | 1024<br>4096<br>8192<br>16384<br>32768 |

(b): 4 pole motor

**Table 2.3.6.3: Speed Regulator Bandwidth**

| Regulation mode | Spd Control range | Max Spd reg bandwidth (rad/sec) |               |                              |             | Typ Spd Reg Accuracy (c) [%] |
|-----------------|-------------------|---------------------------------|---------------|------------------------------|-------------|------------------------------|
|                 |                   | Enc Sin                         | Enc Dig Fmode | Enc Dig Fpmode               | SinCos/Res. |                              |
| Field oriented  | > 10000:1         | 450                             | 100           | 300 (Spd>15rpm for ppr=1024) | N/A         | 0.01                         |
| Sensorless vect | >500:1            | 100 (Spd>FSS/100)               |               |                              | N/A         | 0.3@FSS<br>0.5@FSS/50        |
| V/f control     | > 100:1           | N/A                             |               |                              |             | 1%                           |
| Brushless       | > 10000:1         | 450                             | 100           | 300 (Spd>15rpm for ppr=1024) | 100         | 0.01%                        |

(c): Standard 1500rpm

**Table 2.3.6.4: Torque Specifications**

| Regulation mode | Torque ref resolution | Typ Torque Reg Accuracy (d) [%] | Trq Control range | Typ Trq Rise time [ms] |
|-----------------|-----------------------|---------------------------------|-------------------|------------------------|
| Field oriented  | >1:1000               | 4                               | >20:1             | 0.8                    |
| Sensorless vect | >1:1000               | 8                               | >20:1             | 0.8                    |
| V/f control     | N/A                   | N/A                             | N/A               | N/A                    |
| Brushless       | >1:1000               | 1                               | >20:1             | 0.8                    |

(d): Mot rated torque=100%  
 Spd range: Max=Mot Rated speed; min=Mot Rated speed/10  
 Torque range: Max=Mot Rated torque; min=Mot Rated torque/10

# Chapter 3 - Mechanical Installation Guidelines

## 3.1 Dimensions and Mounting Methods

Figure 3.1.1: Drive Dimensions (Sizes 1007 ... 3150)




Figure 3.1.2: Mounting Methods (Sizes 1007 ... 3150)




Table 3.1.1: Drive Dimensions and Weights (Sizes 1007 ... 3150)

| Type                     | 1007      | 1015         | 1022      | 1030      | 2040         | 2055        | 2075 | 3110         | 3150 |
|--------------------------|-----------|--------------|-----------|-----------|--------------|-------------|------|--------------|------|
| <b>Drive dimensions:</b> |           |              |           |           |              |             |      |              |      |
| a                        | mm (inch) | 105.5 (4.1)  |           |           | 151.5 (5.9)  |             |      | 208 (8.2)    |      |
| b                        | mm (inch) | 306.5 (12.0) |           |           |              |             |      | 323 (12.7)   |      |
| c                        | mm (inch) | 199.5 (7.8)  |           |           |              |             |      | 240 (9.5)    |      |
| d                        | mm (inch) | 62 (2.4)     |           |           |              |             |      | 84 (3.3)     |      |
| D1                       | mm (inch) | 69 (2.7)     |           |           | 115 (4.5)    |             |      | 168 (6.6)    |      |
| D2                       | mm (inch) |              |           |           | 296.5 (11.6) |             |      | 310.5 (12.2) |      |
| E1                       | mm (inch) | 69 (2.7)     |           |           | 115 (4.5)    |             |      | 164 (6.5)    |      |
| E2                       | mm (inch) |              |           |           | 299.5 (11.7) |             |      | 315 (12.4)   |      |
| E3                       | mm (inch) | 99.5 (3.9)   |           |           |              |             |      | 199 (7.8)    |      |
| E4                       | mm (inch) |              |           |           | 284 (11.2)   |             |      | 299.5 (11.8) |      |
| E5                       | mm (inch) |              |           |           | 9 (0.35)     |             |      |              |      |
| Ø d                      |           |              |           |           | M5           |             |      |              |      |
| <b>Weight</b>            | kg (lbs)  | 3.5 (7.7)    | 3.6 (7.9) | 3.7 (8.1) |              | 4.95 (10.9) |      | 8.6 (19)     |      |

tad3100

Figure 3.1.3: Drive Dimensions (Sizes 4220 ... 81600)




Figure 3.1.4: Mounting Methods (Sizes 4220 ... 81600)





Table 3.1.2: Drive Dimensions and Weights (Sizes 4220 ... 81600)

| Type                     | 4185-4221 | 4300-4301 | 4370-4371  | 5450 | 5550       | 6750 | 7900         | 71100 | 71320      | 81600 |
|--------------------------|-----------|-----------|------------|------|------------|------|--------------|-------|------------|-------|
| <b>Drive dimensions:</b> |           |           |            |      |            |      |              |       |            |       |
| a                        | mm (inch) |           | 309 (12.1) |      | 376 (14.7) |      | 509 (20)     |       |            |       |
| b                        | mm (inch) |           | 489 (19.2) |      | 564 (22.2) |      | 741 (29.2)   |       | 909 (35.8) |       |
| c                        | mm (inch) |           | 268 (10.5) |      | 308 (12.1) |      | 297.5 (11.7) |       | 442 (17.4) |       |
| D1                       | mm (inch) |           | 225 (8.8)  |      |            |      |              |       |            |       |
| D2                       | mm (inch) |           |            |      | 150 (5.9)  |      |              |       |            |       |
| D3                       | mm (inch) |           |            |      |            |      | 100 (3.9)    |       |            |       |
| D4                       | mm (inch) |           | 475 (18.7) |      | 550 (21.6) |      | 725 (28.5)   |       | 891 (35)   |       |
| Ø                        | M6        |           |            |      |            |      |              |       |            |       |
| Weight                   | kg        | 18        | 22         | 22.2 | 34         | 34   | 59           | 75.4  | 80.2       | 86.5  |
|                          | lbs       | 39.6      | 48.5       | 48.9 | 74.9       | 74.9 | 130          | 166.1 | 176.7      | 190.6 |

tadi3105

Figure 3.1.5: Keypad Positioning



To allow a comfortable viewing angle, the keypad can be oriented on three different positions.

## 3.2 Watts Loss, Heat Dissipation, Internal Fans and Minimum Cabinet Opening Suggested for the Cooling

The heat dissipation of the Drives depends on the operating state of the connected motor. The table below shows values that refer to operation at default switching frequency (see section 2.3.2, “AC Input/Output Connection”),  $T_{amb} \leq 40^{\circ}\text{C}$ , typ. motor power factor and nominal continuous current.

Table 3.2.1: Heat Dissipation and Required Air Flow

| Type      | Heat Dissipation [W]                      |   | Airflow of fan [ $\text{m}^3/\text{h}$ ] |               |
|-----------|---|---|--|---------------|
|           | (@ $U_{LN}=400\text{Vac}$ <sup>1)</sup> ) | (@ $U_{LN}=460\text{Vac}$ <sup>1)</sup> ) | Internal fan                             | Heatsink fans |
| 1007      | 48.2                                      | 45.0                                      | 11                                       | -             |
| 1015      | 77.5                                      | 72.0                                      | 11                                       | 30            |
| 1022      | 104.0                                     | 96.3                                      | 11                                       | 30            |
| 1030      | 138.3                                     | 126.7                                     | 11                                       | 30            |
| 2040      | 179.5                                     | 164.1                                     | 11                                       | 2x30          |
| 2055      | 233.6                                     | 215.6                                     | 11                                       | 2x30          |
| 2075      | 327.4                                     | 300.8                                     | 11                                       | 2x30          |
| 3110      | 373                                       | 340                                       | 30                                       | 2x79          |
| 3150      | 512                                       | 468                                       | 30                                       | 2x79          |
| 4185      | 560                                       | 500                                       |  | 80            |
| 4220-4221 | 658                                       | 582                                       |  | 80            |
| 4300-4301 | 864                                       | 780                                       |  | 170           |
| 4370-4371 | 1100                                      | 1000                                      |  | 170           |
| 5450      | 1250                                      | 1100                                      |  | 340           |
| 5550      | 1580                                      | 1390                                      |  | 340           |
| 6750      | 1950                                      | 1750                                      |  | 650           |
| 7900      | 2440                                      | 2200                                      |  | 975           |
| 71100     | 2850                                      | 2560                                      |  | 975           |
| 71320     | 3400                                      | 3050                                      |  | 975           |
| 81600     | 4400                                      | 3950                                      |  | 1820          |

1)  $f_{sw}$ =default;  $I_2=I_{2N}$

tadl0040

### None!

All the Drives have internal fans.

Heat dissipation losses refer to default Switching frequency.

Table 3.2.2: Minimum Cabinet Opening Suggested for the Cooling

| Type           | Minimum cooling opening [ $\text{cm}^2$ ] (sq.inch) |                    |
|----------------|---|--------------------|
|                | Control section                                     | Heatsink           |
| 1007 ... 1030  | 31 (4.8)  | 36 (5.6)           |
| 2040 ... 2075  | 31 (4.8)  | 72 (11.1)          |
| 3110 ... 3150  | 36 (5.6)  | 128 (19.8)         |
| 4185 ... 4221  | 2x150 (2x 23.5)                                     | 2x150 (2x 23.5)    |
| 4300 ... 4371  | 2x200 (2x31)  | 2x200 (2x31)       |
| 5450 ... 5550  | 2x370 (2x57.35)                                     | 2x370 (2x57.35)    |
| 6750 ... 71320 | 2x620 (2x96.1)                                      | 2x620 (2x96.1)     |
| 81600          | 2 x 1600 (2 x 248)                                  | 2 x 1600 (2 x 248) |

tadl0050

### 3.2.1 Cooling Fans Power Supply

#### Fan Control Logic function

(only for sizes AVy2040AC4 / BR4 up to AVy5550AC4 / BR4)

It allows to run internal fans **only when the drive is enabled**. Fans will stop when the drive is disabled after a period of 300sec and heatsink temperature is below 60 degrees.

Fan control logic function signal is also repeated on the drive power board FEXT terminals, for an auxiliary external fan.

#### Cooling Fans Power Supply for sizes AVy1007 to AVy5550

Power supply (+24VAC) for these fans is provided from the internal drive power supply unit.

#### Cooling Fans Power Supply for sizes AVy6750 to AVy81600

Power supply for the fans is externally connected by the user. AC Input voltage is connected at the power terminal strip:

- AVy6750: 0.8A@115V/60Hz, 0.45A@230V / 50Hz
- AVy7900 ... AVy71320: 1.2A@115V/60Hz, 0.65A@230V / 50Hz
- AVy81600: 1.65A@115V/60Hz, 0.70A@230V / 50Hz

Figure 3.2.1: UL Type Fans Connections on AVy7900, AVy71100 and AVy71320 Sizes




Figure 3.2.2: UL Type Fans Connections on AVy6750 and AVy81600 Sizes







Figure 3.2.3: Example for External Connection



**Note!**

An internal fuse (2.5A 250VAC slo-blo) for AVy7900, AVy71100 and AVy71320 sizes is provided.


On AVy6750 and AVy81600 sizes the fuse must be mounted externally.

### 3.3 Installation Mounting Clearance

**NOTE!**

The dimensions and weights specified in this manual should be taken into consideration when the device is mounted. The technical equipment required (carriage or crane for large weights) should be used. Improper handling and the use of unsuitable tools may cause damage.

Figure 3.3.1: Max. Angle of Inclination




The maximum angle of inclination is 30°

**NOTE!**

The drives must be mounted in such a way that the free flow of air is ensured. The clearance to the device must be at least 150 mm (6 inches). A space of at least 50 mm (2 inches) must be ensured at the front. On size 81600 the top and bottom clearance must be at least 380 mm (15 inches), on front and sides must be ensured a space of at least 140 mm (5.5 inches). Devices that generate a large amount of heat must not be mounted in the direct vicinity of the drive.

Figure 3.3.2: Mounting Clearance



**NOTE!**

Fastening screws should be re-tightened after a few days of operation.

# Chapter 4 - Wiring Procedure


## 4.1 Accessing the Connectors

### 4.1.1 Removing the Covers

**Note!**

Observe the safety instructions and warnings given in this manual. The devices can be opened without the use of force. Only use the tools specified.

Figure 4.1.1: Removing the Covers (Sizes 1007 to 3150)



#### Sizes 1007 to 2075:

The terminal cover and cable entry plate of the device must be removed in order to fit the electrical connections:

- unscrew the screw (1), remove the cover of devices (2) by pressing on both sides as shown on the above figure (3).
- unscrew the two screws (4) to remove the cable entry plate.

The top cover must be removed in order to mount option cards and change the internal jumper settings:

- remove the keypad and disconnect the connector (5)
- lift the top cover on the bottom side (over the connector level) and then push it to the top (6).

#### Sizes 3110 to 3150:


The terminal cover and cable entry plate of the device must be removed in order to fit the electrical connections:

- unscrew the two screws (1) and remove the cover of devices
- unscrew the two screws (4) to remove the cable entry plate.

The top cover must be removed in order to mount the option card and change the internal jumper settings:

- remove the keypad and disconnect the connector (5)
- lift the top cover on the bottom side (over the connector level) and then push it to the top (6)

Figure 4.1.2: Removing the Covers (Sizes 4185 to 81600)



**Sizes 4185 to 81600:**

The terminal cover of the device must be removed in order to fit the electrical connections: unscrew the two screw (2) and remove the cover (1)


The top cover must be removed in order to mount the option card and change the internal jumper settings: unscrew the two screw (3) and remove the top cover by moving it as indicated on figure (4).



---

**In order to avoid damage to the drive it is not allowed to transport it by holding the cards!**

---



**4.2 Power Section**

---




Please note that a wrong connection on motor phases can cause the motor to move without control and can destroy the drive.

Please check that motor phases are connected in the right sequence before enabling the drive.

---

## 4.2.1 Terminal Assignment on Power Section / Cable Cross-Section


Table 4.2.1.1: Power Section Terminals from 1007 to 3150



**Note!**

EM and FEXT terminals are available on sizes AVy2040AC4 / BR4 up to AVy5550AC4 / BR4 only.

Table 4.2.1.2: Power Section Terminals from 4185 to 81600



**Note!**

EM and FEXT terminals are available on sizes AVy2040AC4 / BR4 up to AVy5550AC4 / BR4 only.

(\*) Fans will be always start when the drive is enabled.

Fans will stop when the drive is disabled after a period of 300 sec. and heatsink temperature is below 60°C.

### Power terminals lay-out sizes 1007 to 3150

The terminals of the devices are made accessible by removing the cover and the cable entry plate (see section 4.1, “Accessing the connectors”), on some drive types it is also possible to extract the removable connector. All the power terminals are located on the power card PV33-...

### Power terminals lay-out sizes 4185 to 81600

The terminals of the devices are made accessible by removing the cover (see section 4.1, “Accessing the connectors”).

### Maximum cable sizes for power terminals U1, V1, W1, U2, V2, W2, C, D, PE

Table 4.2.1.3: Maximum Cable Cross Section for Power Terminals

| Type                                   |                 | 1007           | 1015 | 1022 | 1030    | 2040    | 2055             | 2075             | 3110    | 3150    | 4185...4221 | 4300-3401 |   |
|--|-----------------|----------------|------|------|---------|---------|------------------|------------------|---------|---------|-------------|-----------|---|
| U1, V1, W1, U2, V2, W2, C, D terminals | AWG             | 14             |      |      |         | 12      | 10               |                  | 8       | 6       |             |           | 4 |
|  | mm <sup>2</sup> | 2              |      |      |         | 4       |                  | 8                | 10      | 16      |             | 25        |   |
|  | (sq in)         | (0.003)        |      |      |         | (0.006) |                  | (0.012)          | (0.016) | (0.025) |             | (0.039)   |   |
| Tightening torque                      | Nm              | 0.5 to 0.6     |      |      |         |         |                  | 1.2 to 1.5       |         | 2       |             | 3         |   |
|  | (lbf. in)       | (4.4) to (5.3) |      |      |         |         |                  | (10.6) to (13.2) |         | (17.7)  |             | (26.5)    |   |
| BR1 terminals                          | AWG             | 14             |      |      | 12      | 10      |                  | 8                | 6       | 10      | 8           |           |   |
|  | mm <sup>2</sup> | 2              |      |      | 4       |         | 8                | 10               | 6       | 10      |             |           |   |
|  | (sq in)         | (0.003)        |      |      | (0.006) |         | (0.012)          | (0.016)          | (0.009) | (0.016) |             |           |   |
| Tightening torque                      | Nm              | 0.5 to 0.6     |      |      |         |         | 1.2 to 1.5       |                  | 0.9     |         | 1.6         |           |   |
|  | (lbf. in)       | (4.4) to (5.3) |      |      |         |         | (10.6) to (13.2) |                  | (7.9)   |         | (14.1)      |           |   |
| PE1, PE2 terminals                     | AWG             | 14             |      |      | 12      | 10      |                  | 8                | 6       |         | 6           |           |   |
|  | mm <sup>2</sup> | 2              |      |      | 4       |         | 8                | 10               | 16      |         | 16          |           |   |
|  | (sq in)         | (0.003)        |      |      | (0.006) |         | (0.012)          | (0.016)          | (0.025) |         | (0.025)     |           |   |
| Tightening torque                      | Nm              | 0.5 to 0.6     |      |      |         |         | 1.2 to 1.5       |                  | 2       |         | 3           |           |   |
|  | (lbf. in)       | (4.4) to (5.3) |      |      |         |         | (10.6) to (13.2) |                  | (17.7)  |         | (26.5)      |           |   |

| Type                                   |                 | 4370-4371 | 5450    | 5550                    | 6750    | 7900             | 71100   | 71320         | 81600 |
|--|-----------------|-----------|---------|-------------------------|---------|------------------|---------|---------------|-------|
| U1, V1, W1, U2, V2, W2, C, D terminals | AWG             | 2         | 1/0     | 2/0                     | 4/0     | 300*             | 350*    | 4xAWG2        |       |
|  | mm <sup>2</sup> | 35        | 50      | 70                      | 95      | 150              | 185     | 4x35          |       |
|  | (sq in)         | (0.054)   | (0.078) | (0.109)                 | (0.147) | (0.233)          | (0.287) | (0.006x0.054) |       |
| Tightening torque                      | Nm              | 4         |         | 12                      |         | 10 - 30          |         |               |       |
|  | (lbf. in)       | (0.006)   |         | (106.2)                 |         | (88.5) - (265.5) |         |               |       |
| BR1 terminals                          | AWG             | 8         | 6       | terminals not available |         |                  |         |               |       |
|  | mm <sup>2</sup> | 10        | 16      |                         |         |                  |         |               |       |
|  | (sq in)         | (0.016)   | (0.025) |                         |         |                  |         |               |       |
| Tightening torque                      | Nm              | 1.6       | 3       |                         |         |                  |         |               |       |
|  | (lbf. in)       | (14.1)    | (26.5)  |                         |         |                  |         |               |       |
| PE1, PE2 terminals                     | AWG             | 6         |         |                         | 2       |                  |         |               |       |
|  | mm <sup>2</sup> | 16        |         |                         | 50      |                  |         |               |       |
|  | (sq in)         | (0.025)   |         |                         | (0.078) |                  |         |               |       |
| Tightening torque                      | Nm              | 3         |         |                         | 4       |                  |         |               |       |
|  | (lbf. in)       | (26.5)    |         |                         | (35.4)  |                  |         |               |       |

\* = kcmils

| Type               |                 | 2040 up to 5550 |
|--------------------|-----------------|-----------------|
| EM, FEXT terminals | AWG             | 28 ... 16       |
|                    | mm <sup>2</sup> | 0.14 ... 1.5    |
|                    | (sq in)         |                 |
| Tightening torque  | Nm              | 0.4             |
|                    | (lbf. in)       |                 |

lad4040L

The grounding conductor of the motor cable may conduct up to twice the value of the rated current if there is a ground fault at the output of the ARTDriveL drive.

### Note!

Use 60°C / 75°C copper conductor only.

## Maximum Cable Sizes for control terminals

Table 4.2.1.4: Maximum Permissible Cable Cross-section on the Plug-in Terminals of the Regulator Section

| Terminals | Maximum Permissible Cable Cross-Section |              | AWG       | Tightening torque [Nm] |
|-----------|---|--------------|-----------|------------------------|
|           | [mm <sup>2</sup> ]                      |              |           |                        |
|           | flexible                                | multi-core   |           |                        |
| 1 ... 79  | 0.14 ... 1.5                            | 0.14 ... 1.5 | 28 ... 16 | 0.4                    |
| 80 ... 85 | 0.14 ... 1.5                            | 0.14 ... 1.5 | 28 ... 16 | 0.4                    |

tsv0065L

The use of a 75 x 2.5 x 0.4 mm (3 x 0.1 x 0.02 inch) flat screwdriver is recommended. Remove 6.5 mm (0.26 inch) of the insulation at the cable ends. Only one unprepared wire (without ferrule) should be connected to each terminal point.

## Maximum Cable Length

Table 4.2.1.5: Maximum Control Cable Lengths

|                                  |         |          |          |           |           |
|----------------------------------|---------|----------|----------|-----------|-----------|
| Cable section [mm <sup>2</sup> ] | 0.22    | 0.5      | 0.75     | 1         | 1.5       |
| Max Length m [feet]              | 27 [88] | 62 [203] | 93 [305] | 125 [410] | 150 [492] |

avy3130

## 4.3 Regulation Section

### 4.3.1 RV33-4 Regulation Card Switch & Jumpers




Table 4.3.1.1: LEDs & Test points on Regulation Card

| Designation | Color        | Function   |
|-------------|--------------|--|
| PWR         | green        | LED lit when the voltage +5V is present and at correct level     |
| RST         | red          | LED lit during the Hardware Reset                                |
| PWM         | green        | LED lit during IGBT modulation                                   |
| RUN         | green        | LED is flashing when regulation is running (not in STARTUP menu) |
| RS485       | green        | LED lit when RS485 interface is supplied                         |
| +5VE        | green        | LED lit when encoder power supply +5V (XE-9)                     |
| +8VE        | red          | LED lit when encoder power supply +8V (XE-2)                     |
| XY4         | (test point) | Phase current signal (U)   |
| XY5         | (test point) | Reference point  |



Table 4.3.1.2: Jumpers and dip-switches on Regulation Card RV33

| Designation                                | Function   | Factory setting   |
|--|--|-------------------|
| S3   | Factory use, the setting must not be changed   | -                 |
| S5 - S6                                    | Terminating resistor for the serial interface RS485<br>ON = Termination resistor IN<br>OFF = No termination resistor                                   | ON (*)            |
| S8   | Adaptation to the input signal of analog input 1 (terminals 1 and 2)<br>ON=0...20 mA / 4...20 mA<br>OFF=0...10 V / -10...+10 V                         | OFF               |
| S9   | Adaptation to the input signal of analog input 2 (terminals 3 and 4)<br>ON=0...20 mA / 4...20 mA<br>OFF=0...10 V / -10...+10 V                         | OFF               |
| S10  | Adaptation to the input signal of analog input 3 (terminals 5 and 6)<br>ON=0...20 mA / 4...20 mA<br>OFF=0...10 V / -10...+10 V                         | OFF               |
| S11 - S12 - S13<br>S14 - S15 - S16<br>(**) | Encoder setting (jumpers on kit EAM_1618 supplied with the drive)<br>ON=Sinusoidal SE or SESC encoder<br>OFF=Digital DE or DEHS encoder                | OFF               |
| S17<br>(**)                                | Monitoring of the C-channel of the digital encoder<br>ON=C-Channel monitored<br>OFF=C-Channel not monitored (required for single-ended channels)       | OFF               |
| S18 - S19<br>S20 - S21<br>(**)             | Encoder setting<br>Pos. B=digital DEHS encoder<br>Pos. A= sinusoidal SESC encoder  | A                 |
| S22 - S23<br>(**)                          | Analog input 3 enabling (alternative with SESC encoder)<br>Pos. A= if SESC encoder is used<br>Pos. B=analog input 3 enabled<br>Pos. OFF= resolver      | A                 |
| S26 - S27 (**)                             | Resolver use enabling<br>Pos. ON=when resolver is not used<br>Pos. OFF=resolver  | ON                |
| S28  | Encoder Internal power supply selection<br>ON / ON = +5 V<br>OFF / OFF = +8 V  | ON/ON             |
| S29  | Internal use   | A                 |
| S30  | Second encoder qualifier input<br>A=from EXP... board<br>B=from digital input "6" on RV33-4  | B                 |
| S34  | Jumper to disconnect 0V (+24V power supply) from ground<br>ON = 0V connected to ground<br>OFF = 0V disconnected from ground                            | ON<br>(hard-wire) |
| S35  | Jumper to disconnect 0V (regulation board) from ground<br>ON = 0V connected to ground<br>OFF = 0V disconnected from ground                             | ON<br>(hard-wire) |
| S36  | Internal use   | not mounted       |
| S37  | Internal use   | not mounted       |
| S38-S39                                    | Inverter size setting<br>ON = Read size on power board<br>OFF = Read size on regulation board (dip-switch or configuration file)                       | ON                |
| S40-S41<br>(***)                           | Power supply for the serial interface RS485<br>ON = Internal power supply (from pins XS.5 / XS.9)<br>OFF = External power supply (to pins XS.5 / XS.9) | OFF               |

AL4060

(\*) on multidrop connection the jumper must be ON only for the last drop of a serial line

(\*\*) see table 4.5.2 for more details on encoder jumper setting

(\*\*\*) see chapter 5.



**The devices are factory set accordingly.**

**When fitting a regulation card as a spare, remember to set again the encoders jumpers.**

### 4.3.2 Terminal Assignments on Regulation Section

Table 4.3.2.1: Plug-in Terminal Strip Assignments

| Strip X1 | Function                     | max  |
|----------|------------------------------|--|
| 1        | Analog input 1               | (20mA when current loop input)   |
| 2        | Reference point: terminal 2. |  |
| 3        | Analog input 2               |  |
| 4        | Reference point: terminal 4. |  |
| 5        | Analog input 3               |  |
| 6        | Reference point: terminal 6. |  |
| 7        | +10V                         | +10V/10mA  |
| 8        | -10V                         | -10V/10mA  |
| 9        | 0V                           | -  |
| 12       | Enable/Digital input 0       | +30V   |
| 13       | Digital input 1              | 3.2mA @ 15V  |
| 14       | Digital input 2              | 5mA @ 24V  |
| 15       | Digital input 3              | 6.4mA @ 30V  |
| 16       | COM D I/O                    | -  |
| 18       | 0 V 24                       | -  |
| 19       | +24V OUT                     | +22...28V<br>120mA @ 24V   |
| 21       | Analog output 1              | ±10V/5mA   |
| 22       | 0V                           | -  |
| 23       | Analog output 2              | ±10V/5mA   |
| 26       | BU comm. output              | +28V/15mA  |
| 27       | 0 V 24                       | -  |
| 28       | RESERVED                     | -  |
| 29       | RESERVED                     | -  |
| 36       | Digital input 4              | Default setting: MLT SPD S0  |
| 37       | Digital input 5              | Default setting: MLT SPD S1  |
| 38       | Digital input 6              | Default setting: MLT SPD S2. Configurable as 2nd encoder index qualifier (setting via S30 jumper. "Digital input 6" parameter must be set as not used) |
| 39       | Digital input 7              | Default setting: FAULT RESET. Configurable as 1st encoder index qualifier "Digital input 7" parameter must be set as not used)                         |
| 41       | Digital output 2             | Programmable output; Default setting: DRIVE READY  |
| 42       | Digital output 3             | Programmable output; Default setting: SPEED IS 0   |
| 46       | Supply D O                   | +30V/80mA  |
| 78       | Motor PTC                    | 1.5mA  |
| 79       |                              |  |
| 80       | Digital output 0 Relay       | 250V AC<br>1 A   |
| 82       |                              |  |
| 83       | Digital output 1 Relay       | 250V AC<br>1 A   |
| 85       |                              |  |

## 4.4 Potentials of the Control Section

The potentials of the regulation section are isolated and can be disconnected via jumpers from ground.

The connections between each potential are shown in Figure 4.4.1 .

The analog inputs are designed as differential amplifiers.


The digital inputs are optocoupled with the control circuit.

The digital inputs have terminal 16 as reference point.

The analog outputs are not designed as differential amplifiers and have a common reference point (terminal 22). The analog outputs and the  $\pm 10V$  reference point have same potential (terminal 9 and 22).

The digital outputs are optocoupled with the control circuit. The digital outputs (terminal 41 and 42) have same potential (terminal 16) and terminal 46 as common supply.


Figure 4.4.1-A: Potentials of the control section, Digital I/O NPN connection



**Note!**

Combination NPN inputs / PNP outputs and viceversa is not permitted.

Figure 4.4.1-B: Potentials of the control section, Digital I/O PNP connection



**Note!** Combination NPN inputs / PNP outputs and viceversa is not permitted.

## 4.5 Encoders

Several types of encoders may be connected to the XE connector (high density 15-pole socket, fitted on device), see the table 4.5.2 for the jumper settings.

### • AVy ... AC / AC4 :

- **DE**: digital incremental encoder with A+/A-,B+/B-,C+/C- traces
- **SE**: sinusoidal incremental encoder with A+/A-,B+/B-,C+/C traces

### • AVy ... BR / BR4 :

- **SEHS**: sinusoidal incremental encoder with A+/A-,B+/B-,C+/C- traces and three digital “Hall sensor” absolute position traces for initial synchronization (factory setting).
- **SESC**: sinusoidal incremental encoder with A+/A-,B+/B-,C+/C- traces and two analog Sin Cos absolute position traces for initial synchronization.
- **SExtern**: sinusoidal incremental encoder with A+/A-,B+/B-,C+/C- traces and absolute position information thought SSI serial interface for initial synchronization (requires APC100y card).
- **DEHS**: digital incremental encoder with A+/A-,B+/B-,C+/C- traces and three digital “Hall sensor” absolute position traces (factory setting).
- **DExtern**: digital incremental encoder with A+/A-,B+/B-,C+/C traces and absolute position information thought SSI serial interface for initial synchronization (requires APC100y card).
- **SC**: sinusoidal encoder with two analog SinCos absolute position traces
- **RES**: resolver (requires EXP-RES card)
- **SEHiperface**: sinusoidal incremental encoder with A+/A-,B+/B-, traces and Hiperface interface
- **SE Intern** sinusoidal incremental encoder with A+/A-,B+/B-,C+/C- traces, absolute position traces are not necessary because phasing is performed automatically at every start
- **DE Intern** digital incremental encoder with A+/A-,B+/B-,C+/C- traces, absolute position traces are not necessary because phasing is performed automatically at every start .

Encoders are used to feed back a speed signal to the drive. The encoder should be coupled to the motor shaft with a backlash free connection.

Optimal regulation results are ensured when using sinusoidal encoders. Digital encoders may also be used but regulation properties get worse at low speeds.

The encoder cable must made of twisted pairs with a global shield should be connected to the ground on the Drive side. Typically shield should not be connected to ground on the motor side. In some installation with high electromagnetical noise connecting the shield also on motor side helps to suppress pickup of false encoder pulses and reduces amount of disturbanes in the measured speed.

In case of brushless motor or where the cable length is more than 100 meters (328 feet), a cable with a shield on each conductor pair must be used. The shield must be connected to the common point (0V). The global shield must always be grounded.

Some types of sinusoidal encoders may require installation with galvanic isolation from the motor frame and shaft.

Table 4.5.1: Recommended Cable Section and Length for the Connection of Encoders

| Cable section | mm <sup>2</sup> | 0.22    | 0.5      | 0.75     | 1         | 1.5       |
|---------------|-----------------|---------|----------|----------|-----------|-----------|
| Max Length    | (m) [feet]      | 27 [88] | 62 [203] | 93 [305] | 125 [410] | 150 [492] |

txv0055

Table 4.5.2: Encoders Setting via S11...S23 Jumpers

| Encoder / Jumpers setting | S11 | S12 | S13 | S14 | S15 | S16 | S17 | S18 | S19 | S20 | S21 | S22 | S23 | S26 | S27 |
|---------------------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| DE                        | OFF | OFF | OFF | OFF | OFF | OFF | (*) | -   | -   | -   | -   | -   | -   | -   | -   |
| SE                        | ON  | ON  | ON  | ON  | ON  | ON  | (*) | -   | -   | -   | -   | -   | -   | -   | -   |
| SEHS                      | ON  | ON  | ON  | ON  | ON  | ON  | (*) | B   | B   | B   | B   | -   | -   | -   | -   |
| SESC                      | ON  | ON  | ON  | ON  | ON  | ON  | (*) | A   | A   | A   | A   | A   | A   | ON  | ON  |
| SExtern                   | ON  | ON  | ON  | ON  | ON  | ON  | (*) | -   | -   | -   | -   | -   | -   | -   | -   |
| DEHS                      | OFF | OFF | OFF | OFF | OFF | OFF | (*) | B   | B   | B   | B   | -   | -   | -   | -   |
| DExtern                   | OFF | OFF | OFF | OFF | OFF | OFF | (*) | -   | -   | -   | -   | -   | -   | -   | -   |
| SC                        | -   | -   | -   | -   | -   | -   | (*) | A   | A   | A   | A   | A   | A   | ON  | ON  |
| RES                       | -   | -   | -   | -   | -   | -   | (*) | -   | -   | -   | -   | OFF | OFF | OFF | OFF |
| RES (**)                  | -   | -   | -   | -   | -   | -   | (*) | OFF | OFF | OFF | OFF | A   | A   | ON  | ON  |
| SEHiface                  | ON  | ON  | ON  | ON  | ON  | ON  | (*) | -   | -   | -   | -   | -   | -   | -   | -   |

ai3150L

(\*) If the encoder is not provided of the zero channel : S17=OFF

(\*\*) With EXP-RES + Regulation card RV33-4B and higher

The jumper S17 selects the inhibition or the enabling of the channel C pulses reading. It has to be correctly selected in order to detect appropriately the encoder loss alarm.

S17 ON : channel C (index) reading=ON

S17 OFF: channel C (index) reading=OFF

Table 4.5.3: Encoders Connections

Regulation card

| Encoder type                             | Shielded cable | XE CONNECTOR PIN |          |         |         |         |         |         |         |          |          |          |          |          |          |          |
|--|----------------|------------------|----------|---------|---------|---------|---------|---------|---------|----------|----------|----------|----------|----------|----------|----------|
|  |                | 1<br>B-          | 2<br>+8V | 3<br>C+ | 4<br>C- | 5<br>A+ | 6<br>A- | 7<br>0V | 8<br>B+ | 9<br>+5V | 10<br>E+ | 11<br>E- | 12<br>F+ | 13<br>F- | 14<br>G+ | 15<br>G- |
| <b>Internal +5V Encoder Power Supply</b> |                |                  |          |         |         |         |         |         |         |          |          |          |          |          |          |          |
| DE                                       | 8 pole         | ●                | ●        | ●       | ●       | ●       | ●       | ●       | ●       | ●        |          |          |          |          |          |          |
| SE                                       | 8 pole         | ●                |          | ●       | ●       | ●       | ●       | ●       | ●       | ●        |          |          |          |          |          |          |
| SESC                                     | 12 pole        | ●                |          | ●       | ●       | ●       | ●       | ●       | ●       | ●        | ●        | ●        | ●        | ●        |          |          |
| DEHS                                     | 14 pole        | ●                |          | ●       | ●       | ●       | ●       | ●       | ●       | ●        | ●        | ●        | ●        | ●        | ●        | ●        |
| SEHS                                     | 14 pole        | ●                |          | ●       | ●       | ●       | ●       | ●       | ●       | ●        | ●        | ●        | ●        | ●        | ●        | ●        |
| <b>Internal +8V Encoder Power Supply</b> |                |                  |          |         |         |         |         |         |         |          |          |          |          |          |          |          |
| DE                                       | 8 pole         | ●                | ●        | ●       | ●       | ●       | ●       | ●       | ●       |          |          |          |          |          |          |          |
| SE                                       | 8 pole         | ●                | ●        | ●       | ●       | ●       | ●       | ●       | ●       |          |          |          |          |          |          |          |
| SESC                                     | 12 pole        | ●                | ●        | ●       | ●       | ●       | ●       | ●       | ●       | ●        | ●        | ●        | ●        | ●        |          |          |
| DEHS                                     | 14 pole        | ●                | ●        | ●       | ●       | ●       | ●       | ●       | ●       | ●        | ●        | ●        | ●        | ●        | ●        | ●        |
| SEHS                                     | 14 pole        | ●                | ●        | ●       | ●       | ●       | ●       | ●       | ●       | ●        | ●        | ●        | ●        | ●        | ●        | ●        |

ai3160

## Regulation card

| Encoder type  | Shielded cable | XE CONNECTOR PIN (RV33-3) |            |    |                       |                       |            |    |     |     |    |    |    |    |    |    |
|---------------|----------------|---------------------------|------------|----|-----------------------|-----------------------|------------|----|-----|-----|----|----|----|----|----|----|
|               |                | 1                         | 2          | 3  | 4                     | 5                     | 6          | 7  | 8   | 9   | 10 | 11 | 12 | 13 | 14 | 15 |
|               |                | B-                        | +8V        | C+ | C-                    | A+                    | A-         | 0V | B+  | +5V | E+ | E- | F+ | F- | G+ | G- |
| SEHiInterface | 6 pole         | ●                         | ●          |    |                       | ●                     | ●          | ●  | ●   |     |    |    |    |    |    |    |
|               |                | TERMINALS XS connector    |            |    |                       |                       |            |    |     |     |    |    |    |    |    |    |
|               |                | 1                         | 2          | 3  | 4                     | 5                     | 6          | 7  | 8   | 9   |    |    |    |    |    |    |
|               |                |                           | RxA<br>TxA |    | 0V                    |                       | RxB<br>TxB |    | +5V |     |    |    |    |    |    |    |
|               | 2 pole         |                           | ●          |    | connect<br>with pin 8 | connect<br>with pin 9 | ●          | ●  | ●   |     |    |    |    |    |    |    |

ai3161L

Note: - In this case the cable must be split in two

| Encoder / Jumpers setting | S11 | S12 | S13 | S14 | S15 | S16 | S17 | S18 | S19 | S20 | S21 | S22 | S23 | S26 | S27 |
|---------------------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| DE                        | OFF | OFF | OFF | OFF | OFF | OFF | (*) | -   | -   | -   | -   | -   | -   | -   | -   |
| SE                        | ON  | ON  | ON  | ON  | ON  | ON  | (*) | -   | -   | -   | -   | -   | -   | -   | -   |
| SEHS                      | ON  | ON  | ON  | ON  | ON  | ON  | (*) | B   | B   | B   | B   | -   | -   | -   | -   |
| SESC                      | ON  | ON  | ON  | ON  | ON  | ON  | (*) | A   | A   | A   | A   | A   | A   | ON  | ON  |
| SExtern                   | ON  | ON  | ON  | ON  | ON  | ON  | (*) | -   | -   | -   | -   | -   | -   | -   | -   |
| DEHS                      | OFF | OFF | OFF | OFF | OFF | OFF | (*) | B   | B   | B   | B   | -   | -   | -   | -   |
| DExtern                   | OFF | OFF | OFF | OFF | OFF | OFF | (*) | -   | -   | -   | -   | -   | -   | -   | -   |
| SC                        | -   | -   | -   | -   | -   | -   | (*) | A   | A   | A   | A   | A   | A   | ON  | ON  |
| RES                       | -   | -   | -   | -   | -   | -   | (*) | -   | -   | -   | -   | OFF | OFF | OFF | OFF |
| RES (**)                  | -   | -   | -   | -   | -   | -   | (*) | OFF | OFF | OFF | OFF | A   | A   | ON  | ON  |
| SEHiInterface             | ON  | ON  | ON  | ON  | ON  | ON  | (*) | -   | -   | -   | -   | -   | -   | -   | -   |

ai3150L

## Requirements:

### Sinusoidal encoders (XE connector on Regulation card)

Max. frequency \_\_\_\_\_ 80 kHz (select the appropriate number of pulses depending on required max. speed)

Number of pulses per revolution \_\_\_\_\_ min 512, max 9999 (see table below)

Channels \_\_\_\_\_ two-channel, differential

Input Voltage \_\_\_\_\_ 1 V pp

Power supply \_\_\_\_\_ + 5 V / +8V (Internal supply) \*

Load capacity \_\_\_\_\_ > 8.3 mA pp per channel (input resistance = 124 Ohms).

Cable max. \_\_\_\_\_ 500 feet (150 m), screened, 4 twisted pairs.

Configure drive software for the signal amplitude range of the encoder in use (STARTUP / Startup config / Encoders config / Std sin enc Vp)

| Speed D reference resolution (rpm) | Recommended min number of encoder pulses (ppr) |                |                |               |               |               | Max number of encoder pulses (ppr) |
|------------------------------------|--|----------------|----------------|---------------|---------------|---------------|------------------------------------|
| 0.003125                           | 4096   | 4096           | 4096           | 4096          | 4096          | 4096          | 80kHz* 60/FSS                      |
| 0.125                              | 1024   | 1024           | 1024           | 1024          | 1024          | 1024          |                                    |
| 0.25                               | 512  | 512            | 512            | 1024          | 1024          | 1024          |                                    |
| 0.5                                | 512  | 512            | 512            | 1024          | 1024          | 1024          |                                    |
| 1                                  | 512  | 512            | 512            | 1024          | 1024          | 1024          |                                    |
| Mot.pole pairs (rpm@50Hz)          | <b>1(3000)</b>                                 | <b>2(1500)</b> | <b>3(1000)</b> | <b>4(750)</b> | <b>5(600)</b> | <b>6(500)</b> | (FSS=Full scale speed)             |
| Mot.pole pairs (rpm@60Hz)          | <b>1(3600)</b>                                 | <b>2(1800)</b> | <b>3(1200)</b> | <b>4(900)</b> | <b>5(720)</b> | <b>6(600)</b> |                                    |

### Digital encoders (XE connector on Regulation card)

Type \_\_\_\_\_ standard and inverted signal  
 Max. frequency \_\_\_\_\_ 150 kHz (select the appropriate number of pulses depending on required max. speed )  
 Number of pulses per revolution \_\_\_\_\_ min 512, max 9999 (see table below)  
 Channels \_\_\_\_\_ - two-channel, differential A+ / A-, B+ / B-, C+ / C-. An encoder loss detection is possible via firmware setting.  
 - two channel, (A,B). Encoder loss detection is not possible.  
 Input Voltage \_\_\_\_\_ 5V  
 Power supply \_\_\_\_\_ + 5 V / +8V (Internal supply) \*  
 Load capacity \_\_\_\_\_ > 4.5 mA / 6.8 ... 10 mA per channel

\* Via keypad (STARTUP / Startup config / Encoder config) it is possible to select 4 different values of internal encoder supply voltage to compensate the voltage reduction due to encoder cable length and load current encoder.  
 Selection available, according to S28 jumper, are: 5.41V, 5.68V, 5.91V, 6.18V and 8.16V, 8.62V, 9.00V, 9.46V via **Std enc supply** parameter.

| Speed D reference resolution (rpm) | Recommended min number of encoder pulses (ppr) |                |                |               |               |               | Max number of encoder pulses (ppr) |
|------------------------------------|--|----------------|----------------|---------------|---------------|---------------|------------------------------------|
| 0.003125                           | 512  | 512            | 512            | 1024          | 1024          | 1024          | 150kHz* 60/FSS                     |
| 0.125                              | 256  | 512            | 512            | 1024          | 1024          | 1024          |                                    |
| 0.25                               | 256  | 512            | 512            | 1024          | 1024          | 1024          |                                    |
| 0.5                                | 256  | 512            | 512            | 1024          | 1024          | 1024          |                                    |
| 1                                  | 256  | 512            | 512            | 1024          | 1024          | 1024          |                                    |
| Mot.pole pairs (rpm@50Hz)          | <b>1(3000)</b>                                 | <b>2(1500)</b> | <b>3(1000)</b> | <b>4(750)</b> | <b>5(600)</b> | <b>6(500)</b> | (FSS=Full scale speed)             |
| Mot.pole pairs (rpm@60Hz)          | <b>1(3600)</b>                                 | <b>2(1800)</b> | <b>3(1200)</b> | <b>4(900)</b> | <b>5(720)</b> | <b>6(600)</b> |                                    |


### Encoder power supply test (if the internal supply +5V is used)

During the start up of the drive:

- verify the encoder power supply to the encoders terminals with all the encoders channels connected
- via **Std enc supply** parameter set the appropriate voltage if the encoder supply characteristic (example: +5V ± 5%) is out of range.

### Terminals for external encoder connections

Male terminals type: \_\_\_\_\_ 15 poles high density (VGA type)  
 Connector cover: \_\_\_\_\_ Standard 9 poles low profile (Example manufacturer code: AMP 0-748676-1, 3M 3357-6509)





The connection with the drive is through a 15 poles high density sub-D connector (VGA type). Please note that it is mandatory to use a shielded cable with at least 80 % coverage. The shield should be connected to ground on both sides.

**Note!**

For synchronous brushless firmware it is possible to use only encoder having pulses per revolution equal to number that is power of 2.  
Example: 512 ppr, 1024 ppr, 2048 ppr, etc.

*Table 4.5.4: Assignment of the High Density XE Connector for a Sinusoidal or a Digital Encoder*

| Designation | Function  | I/O | Max. voltage                    | Max. current                      |
|-------------|---|-----|---------------------------------|-----------------------------------|
| PIN 1       | ENC B-<br>Channel B-<br>Incremental encoder signal B negative                           | I   | 5 V digital or<br>1 V pp analog | 10 mA digital or<br>8.3 mA analog |
| PIN 2       | +8V Encoder supply voltage (see table 4.5.3)  | O   | +8 V                            | 200 mA                            |
| PIN 3       | ENC C+<br>Channel C+<br>Incremental encoder signal Index positive                       | I   | 5 V digital or<br>1 V pp analog | 10 mA digital or<br>8.3 mA analog |
| PIN 4       | ENC C-<br>Channel C-<br>Incremental encoder signal Index negative                       | I   | 5 V digital or<br>1 V pp analog | 10 mA digital or<br>8.3 mA analog |
| PIN 5       | ENC A+<br>Channel A+<br>Incremental encoder signal A positive                           | I   | 5 V digital or<br>1 V pp analog | 10 mA digital or<br>8.3 mA analog |
| PIN 6       | ENC A-<br>Channel A-<br>Incremental encoder signal A negative                           | I   | 5 V digital or<br>1 V pp analog | 10 mA digital or<br>8.3 mA analog |
| PIN 7       | GND<br>Reference point for +5V encoder supply voltage                                   | O   | -                               | -                                 |
| PIN 8       | ENC B+<br>Channel B+<br>Incremental encoder signal B positive                           | I   | 5 V digital or<br>1 V pp analog | 10 mA digital or<br>8.3 mA analog |
| PIN 9       | AUX+<br>+5V encoder supply voltage (see table 4.5.3)                                    | O   | +5 V                            | 200 mA                            |
| PIN 10      | HALL 1+/SIN+<br>Channel HALL1 + / SIN+<br>Hall 1 positive / Analog encoder Sin positive | I   | 5 V digital or<br>1 V pp analog | 10 mA digital or<br>8.3 mA analog |
| PIN 11      | HALL 1-/SIN-<br>Channel HALL 1- / SIN-<br>Hall 1 negative / Analog encoder Sin negative | I   | 5 V digital or<br>1 V pp analog | 10 mA digital or<br>8.3 mA analog |
| PIN 12      | HALL 2+/COS+<br>Channel HALL 2+ / COS+<br>Hall 2 positive / Analog encoder Cos positive | I   | 5 V digital or<br>1 V pp analog | 10 mA digital or<br>8.3 mA analog |
| PIN 13      | HALL 2-/COS-<br>Channel HALL 2- / COS-<br>Hall 2 negative / Analog encoder Cos negative | I   | 5 V digital or<br>1 V pp analog | 10 mA digital or<br>8.3 mA analog |
| PIN 14      | HALL 3+<br>Channel HALL 3 +<br>Hall 3 positive  | I   | 5 V digital or<br>1 V pp analog | 10 mA digital                     |
| PIN 15      | HALL 3-<br>Channel HALL 3 -<br>Hall 3 negative  | I   | 5 V digital or<br>1 V pp analog | 10 mA digital                     |

a3140L

**4.5.1 XFR Connector Assignments (on optional EXP-RES Expansion Board for Resolver)**

The connection with the drive is through a 15 poles high density sub-D connector (VGA type). Please note that for resolver feedback it is mandatory to use a twisted pair cable with shields on each pair and a global shield. The shield should be connected to ground on both sides.

| Assignment    |          | Function            | I/O | Max. voltage  | Max.current   |
|---------------|----------|---------------------|-----|---------------|---------------|
| Pin 1 ... 2   | -        | -                   | -   | -             | -             |
| Pin 3         | RES-SINP | Input sin +         | I   | 1 V pp analog | 3.8 mA analog |
| Pin 4         | RES-SINN | Input sin -         | I   | 1 V pp analog | 3.8 mA analog |
| Pin 5         | RES-COSP | Input cos +         | I   | 1 V pp analog | 3.8 mA analog |
| Pin 6         | RES-COSN | Input cos -         | I   | 1 V pp analog | 3.8 mA analog |
| Pin 7 ... 9   | -        | -                   | -   | -             | -             |
| Pin 10        | RES-ROTN | Excitation - Output | O   | 6 Volts       | 50 mA rms max |
| Pin 11 ... 14 | -        | -                   | -   | -             | -             |
| Pin 15        | RES-ROTP | Excitation + Output | O   | 6 Volts       | 50 mA rms max |

ai3140ER

**WARNING!** The pins number 1, 2, 7...9, 11...14 are reserved.

**NOTE!** Refer to EXP-RES manual (code 1S5E66) for more details.

#### 4.5.2 Encoder Simulation

The expansion board EXP-RES provides one incremental encoder output, with TTL Line Driver levels, that can be used for simulation of a servomotor feedback device.

This function is performed by the microprocessor and it is possible to simulate an encoder output with a programmable number of pulses/rev.

The output interface is optically isolated and therefore the encoder output must be supplied with an external 15.24 V supply that can be connected to terminals 96 and 97 of the EXP-RES expansion board.

The encoder output signals are available on the XFO connector with the following connection diagram:

| Designation |    | Function                                |
|-------------|----|---|
| Pin 1       | B- | Digital Encoder Simulation. B - channel |
| Pin 2       |    |   |
| Pin 3       | C+ | Digital Encoder Simulation. C + channel |
| Pin 4       | C- | Digital Encoder Simulation. C - channel |
| Pin 5       | A+ | Digital Encoder Simulation. A+ channel  |
| Pin 6       | A- | Digital Encoder Simulation. A - channel |
| Pin 7       |    |   |
| Pin 8       | B+ | Digital Encoder Simulation. B+ channel  |
| Pin 9 .. 15 |    |   |


ai3307L

**NOTE!** Jumper S2 and S3 on the EXP-RES optional board must be OFF.

**NOTE!** To enable encoder simulation set Rep/sim encoder parameter.

## 4.6 Connection Diagrams

Figure 4.6.1: Standard Connection Diagram




### None!

**Fan Control Logic function (only for sizes AVy2040AC4 / BR4 up to AVy5550AC4 / BR4)**

### 4.6.1 Expansion Card Connection

Figure 4.6.2: Common Output Contactors Management




**NOTES!**

Phase sequence does not change. This configuration must be used in FOC & BRS modes.

Expansion board digital outputs must be enabled via software through menu I/O CONFIG \ Digital Outputs \ Exp dig out en

In this example an expansion board is used, but same functionality can be accomplished also using standard digital outputs.

Figure 4.6.3: Separate Output Contactors Management



**Notes!**

Phase sequence changes according to direction selected. This configuration can be used in VF & SLS modes only.

Expansion board digital outputs must be enabled via software through menu I/O CONFIG \ Digital Outputs \ Exp dig out en

In this example an expansion board is used, but same functionality can be accomplished also using standard digital outputs.

## 4.7 Circuit Protection

### 4.7.1 External Fuses for the Power Section

The inverter must be fused on the AC Input side. Use fast fuses only.

**NOTE!**

Connections with three-phase inductance on AC input are not essential but will improve the DC link capacitors lifetime.

*Table 4.7.1.1: External Fuse Types for AC Input Side*

| Drive type                                       | DC link capacitors life time [h] | F1 - Fuses type (code)  |  |         |        |         |
|--|----------------------------------|---|--|---------|--------|---------|
|  |                                  | Europe  |  | USA     |        |         |
|  |                                  | Connections without three-phase reactor on AC input   |  |         |        |         |
| 1007   | 25000                            | GRD2/10 (F4D13) or Z14GR10 (F4M03)  |  | A70P10  | FWP10  | (S7G49) |
| 1015   |                                  |   |  |         |        |         |
| 1022   | 25000                            | GRD2/16 (F4D14) or Z14GR16 (F4M05)  |  | A70P20  | FWP20  | (S7G48) |
| 1030   | 10000                            |   |  |         |        |         |
| 2040   | 25000                            | GRD2/20 (F4D15) or Z14GR20 (F4M07)  |  | A70P20  | FWP20  | (S7G48) |
| 2055   | 25000                            | GRD2/25 (F4D16) or Z14GR25 (F4M09)  |  | A70P25  | FWP25  | (S7G51) |
| 2075   | 10000                            | GRD3/35 (F4D20) or Z22GR40  |  | A70P35  | FWP35  | (S7G86) |
| 3110   | 25000                            | Z22GR63 (F4M17)   |  | A70P60  | FWP60  | (S7G88) |
| 3150   | 10000                            |   |  |         |        |         |
| 4185 ... 81600                                   | 10000                            | For these types an external reactor is mandatory if the AC input impedance is equal or less than 1% |  |         |        |         |
| Connections with three-phase reactor on AC input |                                  |   |  |         |        |         |
| 1007   | 50000                            | GRD2/10 (F4D13) or Z14GR10 (F4M03)  |  | A70P10  | FWP10  | (S7G49) |
| 1015   | 50000                            |   |  |         |        |         |
| 1022   | 50000                            | GRD2/16 (F4D14) or Z14GR16 (F4M05)  |  | A70P10  | FWP10  | (S7G49) |
| 1030   | 50000                            |   |  |         |        |         |
| 2040   | 50000                            | GRD2/20 (F4D15) or Z14GR20 (F4M07)  |  | A70P20  | FWP20  | (S7G48) |
| 2055   | 50000                            | GRD2/25 (F4D16) or Z14GR25 (F4M09)  |  | A70P25  | FWP25  | (S7G51) |
| 2075   | 50000                            | GRD2/35 (F4D20) or Z22GR40  |  | A70P35  | FWP35  | (S7G86) |
| 3110   | 50000                            | Z22GR63 (F4M17)   |  | A70P60  | FWP60  | (S7G88) |
| 3150   | 50000                            |   |  |         |        |         |
| 4185 ... 4221                                    | 25000                            | S00üf1/80/80A/660V or Z22gR80   |  | A70P80  | FWP80  | (S7G54) |
| 4300   | 25000                            | S00üf1/80/100A/660V or M00üf01/100A/660V (F4G18)  |  | A70P100 | FWP100 | (S7G55) |
| 4301 - 4370                                      | 25000                            | S00üf1/80/125A/660V   |  | A70P150 | FWP150 | (S7G56) |
| 4371   | 25000                            | S00üf1/80/160A/660V or M00üf01/160A/660V (F4E15)  |  | A70P175 | FWP175 | (S7G57) |
| 5450   | 25000                            | S00üf1/110/250A/660V or M1üf1/250A/660V (F4G28)   |  | A70P300 | FWP300 | (S7G60) |
| 5550   | 25000                            | S2üf1/110/400A/660V or M2üf1/400A/660V (F4G34)  |  | A70P400 | FWP400 | (S7G62) |
| 6750   | 25000                            |   |  |         |        |         |
| 7900   | 25000                            |   |  |         |        |         |
| 71100  | 25000                            |   |  |         |        |         |
| 71320  | 25000                            |   |  |         |        |         |
| 81600  | 25000                            |   |  |         |        |         |

TADL4120

Fuse manufacturers: Type GRD2... (E27), GRD3... (E33), M... (blade fuses),

Z14... 14 x 51 mm, Z22... 22 x 58 mm, S....

A70P...

FWP...

Jean Müller, Eltville

Gould Shawmut

Bussmann

**NOTE!**

The technical data of the fuses, e.g. dimensions, weights, heat dissipation, auxiliary contactors, are found in the manufacturers data sheets.

## 4.7.2 External Fuses for the Power Section DC Input Side

Use the following fuses when a SR-32 Line Regen is used (see SR-32 instruction book for more details).

Table 4.7.2.1: External Fuses Type for DC Input Side

| Drive type  | Europe              |       | USA        |           |       |
|-------------|---------------------|-------|------------|-----------|-------|
|             | Fuses type          | Code  | Fuses type |           | Code  |
| 1007        | Z14GR10             | F4M03 | A70P10     | FWP10A14F | S7G49 |
| 1015        |                     |       |            |           |       |
| 1022        | Z14GR16             | F4M05 | A70P20     | FWP20A14F | S7G48 |
| 1030        | Z14GR20             | F4M07 | A70P20-1   | FWP20A14F | S7G48 |
| 2040        | Z14GR32             | F4M11 | A70P25-1   | FWP25A14F | S7G51 |
| 2055        |                     |       |            |           |       |
| 2075        | Z14GR50             | F4M15 | A70P50     | FWP50B    | S7G53 |
| 3110        | Z22GR63             | F4M17 | A70P60-4   | FWP60B    | S7I34 |
| 3150        | S00üF1/80/80A/660V  | F4M19 | A70P80     | FWP80     | S7G54 |
| 4185 - 4220 |                     |       |            |           |       |
| 4221 - 4300 | S00üF1/80/100A/660V | F4G18 | A70P100    | FWP100    | S7G55 |
| 4301 - 4370 | S00üF1/80/125A/660V | F4G20 | A70P150    | FWP150    | S7G56 |
| 4371 - 5450 | S00üF1/80/160A/660V | F4E15 | A70P175    | FWP175    | S7G57 |
| 5550        | S00üF1/80/200A/660V | F4G23 | A70P200    | FWP200    | S7G58 |
| 6750        | S1üF1/110/250A/660V | F4G28 | A70P250    | FWP250    | S7G59 |
| 7900        | S1üF1/110/315A/660V | F4G30 | A70P350    | FWP350    | S7G61 |
| 71100       | S1üF1/110/400A/660V | F4G34 | A70P400    | FWP400    | S7G62 |
| 71320       | S1üF1/110/500A/660V | F4E30 | A70P500    | FWP500    | S7G63 |
| 81600       | S1üF1/110/500A/660V | F4E30 | A70P500    | FWP500    | S7G63 |

TAVy4140

Fuse manufacturers: Type Z14..., Z22, S00 ..., S1...  
A70P...  
FWP...

Jean Müller, Eltville  
Gould Shawmut  
Bussmann

### **Note!**

The technical data of the fuses, e.g. dimensions, weights, heat dissipation, auxiliary contactors, are found in the manufacturers data sheets.

## 4.7.3 Internal Fuses

Table 4.7.3.1: Internal Fuses

| Drive type    | Designation | Protection of                         | Fuse (source)  | Fitted on:                           |
|---------------|-------------|---------------------------------------|--|--------------------------------------|
| 4185 to 81600 | F1          | +24V                                  | 2A fast 5 x 20 mm (Bussmann: SF523220 or Schurter: FSF0034.1519 or Littlefuse: 217002)                 | Power card PV33-4-<br>"D" and higher |
|               |             |                                       |  | Power card PV33-5-<br>"B" and higher |
| 1007 to 81600 | F1          | +24V                                  | Resettable fuse  | Regulation card<br>RV33              |
|               | F2          | RS485 serial interface supply circuit | Resettable fuse  | Regulation card<br>RV33-4 and higher |
| 6750 to 71320 | F3          | Fans transformer                      | 2.5A 6.3x32<br>(Bussmann: MDL 2.5, Gould Shawmut: GDL1-1/2, Siba: 70 059 76.2,5 , Schurter: 0034.5233) | Bottom cover (power terminals side)  |

tad10170

## 4.8 Chokes / Filters

### 4.8.1 AC Input Chokes

A three-phase inductance is strongly recommended to be connected on the AC Input side in order to:

- limit the input RMS current of ARTDriveL series drives.
- prolong the life time of the DC link capacitors and the reliability of the input rectifier.
- reduce the AC mains harmonic distortion
- reduce the problems due to a low impedance AC mains ( $\leq 1\%$ ).

The inductance can be provided by an AC Input choke or an AC Input transformer.

Table 4.8.1.1: 3-Phase AC Input Chokes

| Drive type  | Three-phase choke type | Code  |
|-------------|------------------------|-------|
| 1007        | LR3y-1007              | S7AAD |
| 1015        | LR3y-1015              | S7AAE |
| 1022        | LR3y-1022              | S7AAF |
| 1030        | LR3y-1030              | S7AB3 |
| 2040        | LR3y-2040              | S7AAG |
| 2055        | LR3y-2055              | S7AB5 |
| 2075        | LR3y-2075              | S7AB6 |
| 3110        | LR3y-3110              | S7AB7 |
| 3150        | LR3y-3150              | S7AB8 |
| 4185 - 4221 | LR3-022                | S7FF4 |
| 4300-4301   | LR3-030                | S7FF3 |
| 4370-4371   | LR3-037                | S7FF2 |
| 5450        | LR3-055                | S7FF1 |
| 5550        |                        |       |
| 6750        | LR3-090                | S7D19 |
| 7900        |                        |       |
| 71100       |                        |       |
| 71320       | LR3-160                | S7D40 |
| 81600       |                        |       |

TAVy4135

#### **NOTE!**

The current rating of these inductors (reactors) is based on the nominal current of standard motors, listed in table 2.3.4.1.

### 4.8.2 Output Chokes

The AVy Drive can be used with general purpose standard motors or with motors specially designed for Drive use. The latter usually have a higher isolation rating to better withstand PWM voltage.

Follow example of reference regulation:

*Low voltage general purpose standard motors*

|                   |                   |          |
|-------------------|-------------------|----------|
| VDE 0530:         | max peak voltage  | 1 kV     |
|                   | max. dV/dt        | 500 V/us |
| NEMA MG1 part 30: | max. peak voltage | 1 kV     |
|                   | min. rise time    | 2 us     |

*Low voltage motors for use on inverters*

|                   |                   |         |
|-------------------|-------------------|---------|
| NEMA MG1 part 31: | max. peak voltage | 1.6 kV  |
|                   | min. rise time    | 0.1 us. |



Motors designed for use with Adjustable Frequency Drives do not require any specific filtering of the voltage waveform from the Drive. For general purpose motors and using drives up to 2075 size, especially with long cable runs (typically over 100 m [328 feet]) an output choke is recommended to maintain the voltage waveform within the specified limits. Suggested choke ratings and part numbers are listed in table 5.7.2.1. The rated current of the filters should be approx. 20% above the rated current of the frequency Drive in order to take into account additional losses due to PWM waveform.

*Table 4.8.2.1: Recommended Output Chokes*

| Drive type  | Three-phase choke type | Code  |
|-------------|------------------------|-------|
| 1007        | LU3-003                | S7FG2 |
| 1015        |                        |       |
| 1022        |                        |       |
| 1030        |                        |       |
| 2040        | LU3-005                | S7FG3 |
| 2055        |                        |       |
| 2075        | LU3-011                | S7FG4 |
| 3110        |                        |       |
| 3150        | LU3-015                | S7FM2 |
| 4185 - 4221 | LU3-022                | S7FH3 |
| 4300 - 4301 | LU3-030                | S7FH4 |
| 4370 - 4371 | LU3-037                | S7FH5 |
| 5450        | LU3-055                | S7FH6 |
| 5550        |                        |       |
| 6750        | LU3-090                | S7FH7 |
| 7900        |                        |       |
| 71100       | LU3-160                | S7FH8 |
| 71320       |                        |       |
| 81600       |                        |       |

TAVq4150

***NOTE!***

When the drive is operated at the rated current and at 50 Hz, the output chokes cause a voltage drop of approx. 2% of the output voltage.

**4.8.3 Interference Suppression Filters**

The inverters of AVy series must be equipped with an external EMI filter in order to reduce the radiofrequency emissions on to the mains line. The filter selection is depending on the drive size and the installation environment. For this purpose see the “EMC Guidelines” instruction book. In the Guide it is also indicated how to install the cabinet (connection of filter and mains reactors, cable shield, grounding, etc.) in order to make it EMC compliant according the EMC Directive 89/336/EEC. The document describes the present situation concerning the EMC standards and the compliance tests made on the Gefran-Siei drives.

***NOTE!***


For the use of output sinusoidal filters, please contact the factory.

## 4.9. Braking Units

In oversynchronous or regenerative operation, the frequency-controlled three-phase motor feeds energy back to the DC link circuit via the drive. This creates an increase in the intermediate circuit voltage.

Braking units (BU) are therefore used in order to prevent the DC voltage rising to an impermissible value. When used, these activate a braking resistor that is connected in parallel to the capacitors of the intermediate circuit. The feedback energy is converted to heat via the braking resistor ( $R_{BR}$ ), thus providing very short deceleration times and restricted four-quadrant operation.

Figure 4.9.1: Operation with Braking Unit (Principle)



Drive sizes 1007 up to 3150 have, as standard configuration, an internal braking unit. Drive sizes 4220 up to 5550 can have an optional internal braking unit (see section 2.1.2 “Inverter type designation”) factory mounted. All the standard AVy... drive can be equipped with an external braking unit (BU-32... or BUy-...) connected to the terminals C and D.

### NOTE!

When the internal braking unit is present, or when circuit terminals C and D are connected to external devices, the AC Input must be protected with superfast semiconductor fuses! Observe the mounting instruction concerned. For braking resistor connection (terminals BR1 and C) a twisted cable has to be used. In case the braking resistor is supplied with thermal protection (klixon), it may be connected to the "External fault" drive input.




The braking resistors can be subject to unforeseen overloads due to possible failures. The resistors have to be protected using thermal protection devices. Such devices do not have to interrupt the circuit where the resistor is inserted but their auxiliary contact must interrupt the power supply of the drive power section.

In case the resistor foresees the presence of a protection contact, such contact has to be used together with the one belonging to the thermal protection device.

### 4.9.1 Internal Braking Unit

The Internal Braking Unit is included as standard (up to size 3150). The braking resistor is optional and has always to be mounted externally. For parameter setting refer to parameter list. The figure below shows the configuration for internal brake unit operation.

Figure 4.9.1.1: Connection with Internal Braking Unit and External Braking Resistor



## 4.9.2 External Braking Resistor

Recommended resistors for use with internal braking unit:

Table 4.9.2.1: Lists and Technical Data of the External Standard Resistors

| Inverter Type | Resistor Type  | $P_{NBR}$ [kW] | $R_{BR}$ [Ohm] | $E_{BR}$ [kJ] |
|---------------|----------------|----------------|----------------|---------------|
| 1007          | MRI/T600 100R  | 0.6            | 100            | 22            |
| 1015          |                |                |                |               |
| 1022          |                |                |                |               |
| 1030          |                |                |                |               |
| 2040          |                |                |                |               |
| 2055          | MRI/T900 68R   | 0.9            | 68             | 33            |
| 2075          |                |                |                |               |
| 3110          | MRI/T1300 49R  | 1.3            | 49             | 48            |
| 3150          | MRI/T2200 28R  | 2.2            | 28             | 82            |
| 4185 - 4221   | MRI/T4000 15R4 | 4              | 15.4           | 150           |
| 4300 - 4301   | MRI/T4000 11R6 | 4              | 11.6           | 150           |
| 4370 - 4371   | MRI/T4000 11R6 | 4              | 11.6           | 150           |
| 5450          | MRI/T8000 7R7  | 8              | 7.7            | 220           |
| 5550          | MRI/T8000 7R7  | 8              | 7.7            | 220           |


TADL0250

Parameters description:

- $P_{NBR}$  Nominal power of the braking resistor
- $R_{BR}$  Braking resistor value
- $E_{BR}$  Max surge energy which can be dissipated by the resistor
- $P_{PBR}$  Peak power applied to the braking resistor
- $T_{BRL}$  Maximum braking time in condition of limit operating cycle  
(braking power =  $P_{PBR}$  with typical triangular profile)

$$T_{BRL} = 2 \frac{E_{BR}}{P_{PBR}} = [s]$$

Figure 4.9.2.2: Limit Operating Braking Cycle with Typical Triangular Power Profile



$T_{CL}$  Minimum cycle time in condition of limit operating cycle (braking power =  $P_{PBR}$  with typical triangular profile)

$$T_{CL} = \frac{1}{2} T_{BRL} \frac{P_{PBR}}{P_{NBR}} = [s]$$

The **BU overload** alarm occurs if the duty cycle exceeds the maximum data allowed in order to prevent possible damage to the resistor.

**Resistor model: Standard resistor data**

Example code: MRI/T900 68R


MRI = resistor type  
 900 = nominal power (900 W)  
 T= with safety thermostat  
 68R = resistor value (68 ohm)

**NOTE!**

The suggested match of resistor-model and inverter-size, allows a braking stop at nominal torque with duty cycle  $T_{BR} / T_C = 20\%$

Where:  $T_{BR}$  = Braking time,  $T_C$  = Cycle time

Figure 4.9.2.3: Braking Cycle with  $T_{BR} / T_C = 20\%$



The standard resistor can be used for couplings, different from the ones above reported. These resistors, whose technical data are reported in the table 5.8.2.1, have been dimensioned to tolerate an overload equal to 4 time their nominal power for 10 seconds.

In any event they can tolerate also an overload, whose energy dissipation is the same of the maximum power level defined by:

$$P_{PBR} = \frac{V_{BR}^2 [V]}{R_{BR} [ohm]} = [w]$$

Where:

$V_{BR}$  = braking unit threshold (see table 4.9.2.2)

With reference to the figure 4.9.2.4, where the power profile is the typical triangular one, the following example can be taken into consideration (see also table 4.9.2.1).

### Resistor model: MRI/T600 100R

Nominal power  $P_{NBR} = 600$  [W]

Maximum energy  $E_{BR} = 4 \times 600[W] \times 10[s] = 24000[J]$

Inverter mains supply = 460V

Voltage threshold:  $V_{BR} = 780V$

$$P_{PBR} = \frac{V_{BR}^2}{R_{BR}} = \frac{780^2}{100} = 6084 \text{ [W]} \quad T_{BRL} = 2 \frac{E_{BR}}{P_{PBR}} = 2 \frac{24000}{6084} = 7.8[s]$$

It is necessary to consider the following relation:

A) If  $T_{BR} \leq E_{BR} / P_{NBR}$  verify:


1)  $P_{MB} \leq 2 * E_{BR} / T_{BR}$  Where:  $P_{MB}$  is the average power of the cycle (see.fig. 4.9.2.4)

$$2) \frac{P_{MB} \cdot T_{BR}}{2 T_C} \leq P_{NBR}$$

The average power of the cycle must not be higher than the nominal power of the resistor.

B) If  $T_{BR} > E_{BR} / P_{NBR}$  that is to say, in case of very long braking time, it must be dimensioned  $P_{MB} \leq P_{NBR}$

Figure 4.9.2.4: Generic Braking Cycle with Triangular Profile



If one of the above mentioned rules is not respected, it is necessary to increase the tested power of the resistor, respecting the limit of the internal braking unit (reported in table 4.9.2.3), or an external BU if necessary.

In order to protect these resistors from dangerous overload, software overload control logic is also available (STARTUP / Startup config / BU protection).

The default parameters in the drive match the recommended resistor pairing as for the table 4.9.2.1.

For non-standard pairing resistor see “STARTUP / Startup config / BU protection.

Table 4.9.2.2: Braking Thresholds for Different Mains

| Mains voltage | Braking threshold<br>V <sub>BR</sub> [V] |
|---------------|--|
| 230Vac        | 400                                      |
| 400Vac        | 680                                      |
| 460Vac/480Vac | 780                                      |

avy4200

When the duty cycle exceeds the data entered, the alarm **BU overload** automatically occurs in order to prevent possible damages to the resistor. The following table can be used to choose an external resistor, different from the standard series.

Table 4.9.2.3: Technical Data of the Internal Braking Units

| Inverter type | I <sub>RMS</sub> [A]             | I <sub>PK</sub> [A] | T [s] | Minimum R <sub>BR</sub> [ohm] |
|---------------|----------------------------------|---------------------|-------|-------------------------------|
| 1007          | 4.1                              | 7.8                 | 19    | 100                           |
| 1015          |                                  |                     |       |                               |
| 1022          |                                  |                     |       |                               |
| 1030          |                                  |                     |       |                               |
| 2040          |                                  |                     |       |                               |
| 2055          | 6.6                              | 12                  | 16    | 67                            |
| 2075          |                                  |                     |       |                               |
| 3110          | 12                               | 22                  | 17    | 36                            |
| 3150          | 17                               | 31                  | 16    | 26                            |
| 4185 ... 4221 | 18                               | 52                  | 42    | 15                            |
| 4300 - 4301   | 37                               | 78                  | 23    | 10                            |
| 4370 - 4371   | 29                               |                     | 37    |                               |
| 5450          | 50                               | 104                 | 22    | 7.5                           |
| 5550          |                                  |                     |       |                               |
| 6750          | External braking unit (optional) |                     |       |                               |
| 7900          |                                  |                     |       |                               |
| 71100         |                                  |                     |       |                               |
| 71320         |                                  |                     |       |                               |
| 81600         |                                  |                     |       |                               |

Tavy4210

- I<sub>RMS</sub> Nominal current of the braking unit
- I<sub>PK</sub> Peak current deliverable for 60 seconds max.
- T Minimum cycle time for a working at I<sub>PK</sub> for 10 seconds

Generally the following condition must be satisfied

$$I_{RMS} \geq \sqrt{\frac{1}{2} \cdot \frac{P_{PBR}}{R_{BR}} \cdot \frac{T_{BR}}{T_C}}$$

Each drive is provided of the terminals 26 and 27 which allows control of one or more external braking units, parallel connected. The drive will act as Master and the external braking units BU32 must be configured as Slave. In this way it will be possible to utilize the internal I<sup>2</sup> t protection. If more than one BU is used, each BU shall be connected to a single resistor. All Braking Unit shall be the same model and have same type resistor.

## 4.10 Buffering the Regulator Supply

The power supply of the control section is provided by a switched mode power supply unit (SMPS) from the DC Link circuit. The drive is disabled as soon as the voltage of the DC Link circuit is below the threshold value ( $U_{\text{Buff}}$ ). The regulator supply is buffered by the energy of the DC Link circuit until the limit value ( $U_{\text{min}}$ ) is reached. The buffer time is determined by the capacitance of the DC Link capacitors. The minimum values are shown in the table below. The buffer time ( $t_{\text{Buff}}$ ) can be extended (only on 11 kW drive and higher) by connecting external capacitors in parallel (on terminal C and D).


Table 4.10.1: DC Link Buffer Time

| Inverter type | Internal capacitance<br>$C_{\text{std}}$<br>[ $\mu\text{F}$ ] | Buffer time $t_{\text{Buff}}$<br>(minimum value) with the<br>internal capacitance at : |                                |                                | Maximum permissible external capacitance<br>$C_{\text{ext}}$ [ $\mu\text{F}$ ] | Maximum power required by switched mode power supply<br>$P_{\text{SMPS}}$ [W] |
|---------------|---|--|--------------------------------|--------------------------------|--|---|
|               |   | AC Input voltage = 230V<br>[s]   | AC Input voltage = 400V<br>[s] | AC Input voltage = 460V<br>[s] |  |   |
| 1007          | 220   | 0.02   | 0.165                          | 0.25                           | 0  | 65  |
| 1015          | 220   | 0.02   | 0.165                          | 0.25                           | 0  | 65  |
| 1022          | 330   | 0.03   | 0.24                           | 0.37                           | 0  | 65  |
| 1030          | 330   | 0.03   | 0.24                           | 0.37                           | 0  | 65  |
| 2040          | 830   | 0.08   | 0.62                           | 0.95                           | 0  | 65  |
| 2055          | 830   | 0.08   | 0.62                           | 0.95                           | 0  | 65  |
| 2075          | 830   | 0.08   | 0.62                           | 0.95                           | 0  | 65  |
| 3110          | 1500  | 0.28   | 1.12                           | 1.72                           | 1500   | 65  |
| 3150          | 1500  | 0.28   | 1.12                           | 1.72                           | 1500   | 65  |
| 4185 ... 4221 | 1800  | 0.58   | 1.54                           | 2.3                            | 4500   | 70  |
| 4300 - 4301   | 2200  | 0.62   | 1.88                           | 2.8                            | 4500   | 70  |
| 4370 - 4371   | 3300  | 0.72   | 2.83                           | 4.2                            | 4500   | 70  |
| 5450          | 4950  | 0.87   | 4.24                           | 6.3                            | 4500   | 70  |
| 5550          | 4950  | 0.87   | 4.24                           | 6.3                            | 4500   | 70  |
| 6750          | 6600  | 0.61   | 5.6                            | 8.1                            | 0  | 70  |
| 7900          | 6600  | 0.61   | 5.6                            | 8.1                            | 0  | 70  |
| 71100         | 9900  | 0.91   | 8.4                            | 12.1                           | 0  | 70  |
| 71320         | 14100   | 1.30   | 12.8                           | 17.2                           | 0  | 70  |
| 81600         | 14100   | 1.30   | 12.8                           | 17.2                           | 0  | 70  |

asy4220L

SMPS = Switched Mode Power Supply

Figure 4.10.1: Buffering the Regulator Supply by Means of Additional Intermediate Circuit Capacitors



**NOTE!**

When connecting the intermediate circuit terminals C and D the AC Input side **must** be protected with superfast semiconductor fuses!

Formula for calculating the size of the external capacitors:

$$C_{ext} = \frac{2 \cdot P_{SMPS} \cdot t_{Buff} \cdot 10^6}{U_{Buff}^2 - U_{min}^2} - C_{std} \quad \text{fA018}$$

|                     |             |  |
|---------------------|-------------|--|
| $C_{ext}, C_{std}$  | [ $\mu F$ ] | $U_{Buff} = 400 \text{ V}$ at $U_{LN} = 400 \text{ V}$ |
| $P_{SMPS}$          | [W]         | $U_{Buff} = 460 \text{ V}$ at $U_{LN} = 460 \text{ V}$ |
| $t_{Buff}$          | [s]         | $U_{min} = 250 \text{ V}$                              |
| $U_{Buff}, U_{min}$ | [V]         |  |

**Calculation example**

An AVy4220 drive is operated with an AC Input supply  $U_{LN} = 400 \text{ V}$ . A voltage failure buffer is required for max. 1.5 s.

|            |              |            |       |
|------------|--------------|------------|-------|
| $P_{SMPS}$ | 70 W         | $t_{Buff}$ | 1.5 s |
| $U_{Buff}$ | 400 V        | $U_{min}$  | 250 V |
| $C_{std}$  | 1800 $\mu F$ |            |       |

$$C_{ext} = \frac{2 \cdot 70 \text{ W} \cdot 1.5 \text{ s} \cdot 10^6 \mu F / F}{(400 \text{ V})^2 - (250 \text{ V})^2} - 1800 \mu F = 2154 \mu F - 1800 \mu F = 354 \mu F$$



## 4.11 Discharge Time of the DC-Link

Table 4.11.1: DC Link Discharge Time

| Type        | I <sub>2N</sub> | Time (seconds) | Type        | I <sub>2N</sub> | Time (seconds) |
|-------------|-----------------|----------------|-------------|-----------------|----------------|
| 1007        | 2.1             | 90             | 4300 - 4301 | 58              | 60             |
| 1015        | 3.5             |                | 4370 - 4371 | 76              | 90             |
| 1022        | 4.9             | 150            | 5450        | 90              | 120            |
| 1030        | 6.5             |                | 5550        | 110             |                |
| 2040        | 8.3             | 205            | 6750        | 142             |                |
| 2055        | 11              |                | 7900        | 180             |                |
| 2075        | 15.4            |                | 71100       | 210             |                |
| 3110        | 21.6            | 220            | 71320       | 250             |                |
| 3150        | 28.7            |                | 81600       | 310             |                |
| 4185 - 4221 | 42              | 60             |             |                 |                |

Tavy4250

This is the minimum time that must be elapsed when an AVy Drive is disconnected from the AC Input before an operator may service parts inside the drive to avoid electric shock hazard.

### **CONDITION**


The value consider the time to turn-off for a drive supplied at 480Vac +10%, without any options (the charge for the switching supply is the regulation card, the keypad and the 24Vdc fans “if mounted”). The drive is disabled. This represents the worst case condition.



## Chapter 5 - Serial Interface Description

The RS 485 serial interface enables data transfer via a loop made of two symmetrical, twisted conductors with a common shield. The maximum transmission distance is 1200 m (3936 feet) with a transfer rate of up to 38,400 KBaud. The transmission is carried out via a differential signal. RS 485 interfaces are bus-compatible in half-duplex mode, i.e. sending and receiving take place in sequence. Up to 31 ARTDriveL devices (up to 128 address selectable) can be networked together via the RS 485 interface. Address setting is carried out via the **Slave address** parameter. Further information concerning the parameters to be transferred, their type and value range is given in paragraph 9.2, COMMUNICATION \ RS 485.

Figure 5.1: RS485 Serial Interface



The RS 485 on the ARTDriveL series devices is located on the Regulation card in the form of a 9-pole SUB-D socket connector (XS). The communication may be with or without galvanic isolation: when using galvanic isolation an external power supply is necessary (+5V). Communication without galvanic isolation is suggested only in case of temporary connections for setup with one drive connected. The differential signal is transferred via PIN 3 (TxA/RxA) and PIN 7 (TxB/RxB). Bus terminating resistors must be connected at the physical beginning and end of an RS 485 bus in order to prevent signal reflection. The bus terminating resistors on ARTDriveL drives are connected via jumpers S5 and S6. This enables a direct point-to-point connection with a PLC or PC.

### **None!**

Ensure that only the first and last drop of an RS 485 bus have a bus terminating resistor (S5 and S6 mounted). In all other cases (within the line) jumpers S5 and S6 must not be mounted. With S40 and S41 mounted the drive supply the serial line. This modality is allowed on point-to-point connection without galvanic isolation only.

**NOTE!**

A connection point to point can be done using “PCI-485” option interface (S40 and S41 mounted).

For multidrop connection (two or more drive), an external power supply is necessary (pin 5 / 0V and pin 9 / +5V).

Pins 6 and 8 are reserved for use with the “PCI-485” interface card.

When connecting the serial interface ensure that:

- only shielded cables are used
- power cables and control cables for contactors/relays are routed separately

The communication protocol can be chosen between Slink4, Modbus, Jbus, ISO 1745 or Hiperface through “Protocol type” parameter (COMMUNICATION / RS 485 / Protocol type).

## 5.1 RS 485 Serial Interface Connector Description

*Table 5.1.1: Assignment of the Plug XS Connector for the RS 485 Serial Interface*

| Designation  | Function            | I/O | Elec. Interface |
|--------------|---------------------|-----|-----------------|
| <b>PIN 1</b> | Internal use        | –   | –               |
| <b>PIN 2</b> | Internal use        | –   | –               |
| <b>PIN 3</b> | RxA/TxA             | I/O | RS485           |
| <b>PIN 4</b> | Internal use        | –   | –               |
| <b>PIN 5</b> | 0V (Ground for 5 V) | –   | Power supply    |
| <b>PIN 6</b> | Internal use        | –   | –               |
| <b>PIN 7</b> | RxB/TxB             | I/O | RS 485          |
| <b>PIN 8</b> | Internal use        | –   | –               |
| <b>PIN 9</b> | +5 V                | –   | Power supply    |

ai4110

I = Input


O = Output

## Chapter 6 - Keypad Operation

The keypad is made of a LCD display with two 16-digit lines, seven LEDs and nine function keys. It is used:

- to start and stop the drive (this function can be disabled)
- to display the speed, voltage, diagnostics etc. during the operation
- to set parameters and enter commands

The LED module is made of 6 LEDs. It is used to display status and diagnostic information during the operation. Keypad and LED module can be installed or removed also while the drive is running.



**Note!**










a replacement keypad cable longer than 20 cm must be shielded.

### 6.1 LEDs & Keys


The LEDs present on the keypad are used to quickly diagnose the operating state of the drive.

| Designation | Color  | Function  |
|-------------|--------|---|
| -Torque     | yellow | the LED is lit when the drive operates with a negative torque |
| +Torque     | yellow | the LED is lit when the drive operates with a positive torque |
| ALARM       | red    | the LED is lit when the drive signals a trip                  |
| ENABLE      | green  | the LED is lit when the drive is enabled                      |
| Zero speed  | yellow | the LED is lit when motor speed is zero                       |
| Limit       | yellow | the LED is lit when the drive operates at a current limit     |
| Shift       | yellow | the LED is lit when the keypad second functions are enabled   |


ts030g

| Control Keys   | Text reference                  | Function   |
|--|---------------------------------|--|
|    | [START]                         | START key commands the drive to Enable and Start. ( <i>Command select</i> = I O key)   |
|    | [STOP]                          | STOP key commands to Stop and disable ( <i>Command select</i> = I O key)<br>Stop key also resets the sequencer after an alarm event  |
|    | [Increase] / [Jog]              | Motor pot and Jog functions are not available on ARTDriveL version.  |
|    | [Decrease] / [Rotation control] | Motor pot and Jog functions are not available on ARTDriveL version.  |
|    | [Down arrow] / [Help]           | Used to scroll down menu items in menu navigation, picklists in selectors, or digit values in numeric editing. After pressing shift key, an item-specific information menu is entered when applicable. Help menu can be browsed with up/down arrows. Left arrow returns to normal mode.  |
|    | [Up arrow] / [Alarm]            | Used to scroll up menu items in menu navigation, picklists in selectors, or digit values in numeric editing. After pressing Shift key, the Alarm list display mode is entered. Active alarms and Alarms pending for acknowledge can be browsed with up/downs arrows. Alarms can be acknowledged with the Enter key. Left arrow returns to normal mode. |
|  | [Left arrow] / [Escape]         | Used to go up one level in menu navigation; to scroll digits in numeric edit mode, to return to normal mode from alarm list or help modes.<br>After pressing shift key, it is used to Escape out of numeric edit or selection with no change.  |
|  | [Enter] / [Home]                | Used to go down one level in menu navigation; to enter Selections or numeric values after editing, to issue commands, to acknowledge alarms in the Alarm list mode.<br>Home second function, return to Monitor menu from any main menu level.  |
|  | [Shift]                         | Shift button enables the keypad second functions (Rotation control, Jog, Help, Alarm, Escape, Home)  |


## 6.2 Moving Inside a Menu



## 6.3 Using Keypad Help



## 6.4 Drive Main Menu



- \* SERVICE menu allows the setting of the password to enable Level 1 drive menus: 12345. To have the access of Level 1 drive menus, edit 12345 password into “Insert Password” parameter and confirm it using “Enter” button.

**Note!** Level 1 password must be set every recycle drive supply



## Chapter 7 - Commissioning via Keypad

The ARTDrive Lift can operate with advanced Voltage /Frequency control (as default), Sensorless vector control (open-loop), Field Oriented vector control (closed-loop) and Brushless.

All the regulation modes have their own-independent parameter sets.

A commissioning executed in one mode should be repeated or transferred to another regulation mode.

### 7.1 Commissioning for AVy...AC / AC4 (Asynchronous Motors)

#### Commissioning Set-up Procedure

| Step                           | Function   | Description  |
|--------------------------------|--|--|
|                                | <b>Closed-loop - Field Oriented mode (see chapter 7.1.1)</b> |  |
| <b>1</b>                       | <b>Select the Regulation mode</b>                            | Drive comes factory defaulted to V/f control, change to Field Oriented vector control.   |
| <b>2</b>                       | <b>Set Drive data</b>  | Go to Setup mode for drive data parametrization: Mains voltage, Ambient temp, Switching freq, Speed reference resolution   |
| <b>3</b>                       | <b>Set Motor data</b>  | Go to Setup mode for motor data parametrization: Rated voltage, Rated frequency, Rated current, Rated speed, Rated power, Cosphi   |
| <b>4</b>                       | <b>Run motor Autotune</b>                                    | Autotune procedure is a real motor parameters measurement; two options are available:<br>- <b>“Complete still”</b> can be used when motor is coupled to gearbox, brake is applied and lift car is installed. <b>It could cause limited shaft rotation</b> when brake is not applied.<br>- <b>“Complete rot”</b> can be used when motor is uncoupled or gearbox does not represent more than 5% load and lift car is not installed. <b>It causes motor shaft rotation close to the rated speed.</b> |
| <b>5</b>                       | <b>Set all system mechanical data</b>                        | System mechanical data:<br>Gearbox ratio, Pulley diameter, Full scale speed.   |
| <b>6.1</b><br>or<br><b>6.2</b> | <b>Encoder type configuration</b>                            | - <b>6.1</b> : Feedback from encoder connected to XE connector on Regulation card<br>- <b>6.2</b> : Feedback from encoder connected to XFI connector on EXP-... optional card  |

Go to step 6 up to step 9 of chapter 7.1.3

| Step | Function  | Description   |
|------|---|---|
| 1    | <b>Open-loop - Sensorless vector mode (see chapter 7.1.2)</b> |   |
|      | <b>Select the Regulation mode</b>                             | Drive comes factory defaulted to V/f control; Sensorless vector mode selection. |



Go to step 2 up to step 9 of chapter 7.1.3

| Step | Function                                    | Description  |
|------|---|--|
| 1    | <b>V/f control mode (see chapter 7.1.3)</b> |  |
|      | <b>Switch-on</b>                            | Drive comes factory defaulted to V/f control.  |
| 2    | <b>Set Drive data</b>                       | Go to Setup mode for drive data parametrization: Mains voltage, Ambient temperature and Switching freq.  |
| 3    | <b>Set Motor data</b>                       | Go to Setup mode for motor data parametrization: Rated voltage, Rated frequency, Rated current, Rated speed, Rated power, Cosphi.  |
| 4    | <b>Run motor Autotune</b>                   | Autotune procedure is a real motor parameters measurement; two options are available:<br>- “ <b>Complete still</b> ” can be used when motor is coupled to gearbox, brake is applied and lift car is installed. <b>It could cause limited shaft rotation</b> when brake is not applied.<br>- “ <b>Complete rot</b> ” can be used when motor is uncoupled or gearbox does not represent more than 5% load and lift car is not installed. <b>It causes motor shaft rotation close to the rated speed.</b> |
| 5    | <b>Set all system mechanical data</b>       | System mechanical data:<br>Gearbox ratio, Pulley diameter, Full scale speed.   |
| 6    | <b>Set all system weight data</b>           | System weights data:<br>Cabin weight, Counter weight, Load weight, Rope weight, Motor inertia, Gearbox inertia.  |
| 7    | <b>Set braking unit parameters</b>          | Braking Unit parameters: Braking unit type (internal / external), Braking unit resistance, Braking unit power.   |
| 8    | <b>Set speed profile</b>                    | A binary combination of three digital input allows to select up to 8 different speed setpoints   |
| 9    | <b>Set ramp profile</b>                     | Accelerations jerk and decelerations jerk can be set in the ramp profile   |

**Note!** Drive Startup procedure below take as example an AVy4220-KBL-AC4 drive (software revision 3.500).

### 7.1.1 Field Oriented mode

**1**  
Field oriented  
mode set up

Power up the drive. This operation will take about 10 seconds and the drive will display (LEDs blink for test):

AC Drive Lift  
Startup...

after 10 seconds

R: 0 S: 0  
MONITOR



R: 0 S: 0  
STARTUP



**Note!** Upon opening the STARTUP menu, the drive enters in the parametrization mode.

STARTUP  
Startup config



STARTUP  
Regulation mode




Regulation mode  
V/f control




Select new mode  
V/f control



Select new mode  
Field oriented

Press  to confirm Regulation mode database selected.

Transfer param ?  
Yes->Ent No->Esc

Press  to transfer parameters from previous regulation mode to a newly selected regulation mode. This operation is convenient only if some parameters have been set in previous regulation mode. Otherwise press Esc to not transfer parameters.

2

## Set Drive data

The drive will restart in the new regulation mode, this will take around 5 seconds:

Restart  
Please wait

then

STARTUP  
Regulation mode

Scroll  and 

STARTUP  
Startup config



The drive will show:

Startup config  
Enter setup mode

then press . The drive will restart to **SETUP MODE** menu, wait few seconds, messages sequence will follow:

Restart  
Please wait

then

SETUP MODE  
Drive data

Press  and set **Drive data** parameters:


SETUP MODE  
Drive data




Mains voltage  
400 V



Press  or  to select AC input voltage from the following list:

460 - 440 - 415 - 400 - 380 - 230V, press  to confirm.

If necessary, it is also possible to change : Ambient temperature and Switching frequency.

  
Ambient temp  
40° C



Switching freq  
8 KHz



Spd ref/fbk res  
0.250 rpm



Press or to select a speed resolution value based on max motor speed.

E.g.: if rated speed is 1460 rpm, set 0.125 rpm (see table)

| Speed resolution (Spd ref/fbk res) | Max speed value |
|------------------------------------|-----------------|
| 0.125 rpm                          | 2048 rpm        |
| 0.25 rpm                           | 4096 rpm        |
| 0.5 rpm                            | 8192 rpm        |
| 1 rpm                              | 16384rpm        |
| 0.03125 rpm                        | 512 rpm         |

Spd ref/fbk res  
0.125 rpm

Press to confirm the selection.

Press to exit from **Drive data**. The drive will show:

Busy  
Please wait ...

then

SETUP MODE  
Drive data



**Note!** If any changes have been made to **Drive data** menu parameters, with this operation, internal drive values will be calculated and autotune results will be initialized.



3

### Set Motor data

Set **Motor nameplate** parameters in Motor data menu (values accepted depend on drive size):

SETUP MODE  
Motor data

Enter

Rated voltage  
380.00 V

Enter to edit motor voltage. To confirm the new value press Enter, to cancel edit press Shift +  or scroll  to:

Rated frequency  
50.00 Hz

Enter to edit motor frequency, to confirm the new value press Enter.



Rated current  
43 A

Enter to edit motor current, to confirm the new value press Enter.

**NOTE!** The value should not be less than approx 0.3 times the drive rated current, output current class 1 @400V on the drive nameplate.



Rated speed  
1460.00 rpm

Enter to edit motor speed, to confirm the new value press Enter.


**NOTE!** The value is intended to be the motor full load speed at the rated frequency. If Slip is available on the motor nameplate, set "Rated speed" parameter as following:  
**Rated speed** = Synchronous speed - Slip



Rated power  
22 kW

Enter to edit motor power, to confirm the new value press Enter.

**NOTE!** For a motor nameplate rated in HP, set  
**Rated power kW** = 0.736 x motor **Hp** rating.



**Cosφ**  
0.85

to edit motor cos φ (power factor), to confirm the new value press .

**Note!** Leave default value for Cos φ if the data is not available from the nameplate.



**Efficiency**  
91.20 %

to edit motor efficiency, to confirm the new value press .

**Note!** Leave default value for efficiency if the data is not available from the nameplate.

Press to exit from **Motor data**; for some seconds the drive will show:

**Busy**  
**Please wait ...**

then

**SETUP MODE**  
**Motor data**

**Note!** If any changes have been made to **Motor data** menu parameters, with this operation internal drive values will be calculated and autotune results will be initialized.

If the operation generates any error messages or alarm led comes on, please check consistency of motor parameters and try again or see specific directions in section 10, Troubleshooting.

Scroll to perform Autotune procedure; two options can be used for this procedure: “**Complete still**” or “**Complete rot**”.

**Note!** When motor is coupled to gearbox and lift is installed, use “**Complete still**”(motor still).

When motor is uncoupled or gearbox does not represent more than 5% of load and lift car is not installed, use “**Complete rot**”(motor in rotation).

**WARNING !** Option “**Complete still**” may also cause limited shaft rotation.

**WARNING !** Option “**Complete rot**” causes motor shaft rotation close to rated speed. It is preferred one for the higher accuracy, but it requires free uncoupled rotation of the motor shaft.

SETUP MODE  
Autotune

Enter

Select the desired option (scroll  or ):

Complete still  
Start?

OR

Complete rot  
Start?

Enter

As standard example with motor and machine installed on system, **Complete still** are used. Connect terminal 12 (Enable) to terminal 19 (+24VDC) through relays or local switch, switch on the output contactors and leave the brake closed.

Complete still  
Start?

Enter

Complete still  
Press I Key

press  to start

**NOTE!** Autotune can be aborted at any time by pressing .

The Autotune procedure will start; the drive will display:

from

Complete still 1  
0 %

to

Complete still 1  
100 %

then

Complete still 2  
0 %

to

Complete still 2  
100 %


after





```
End
Autotune
```

blinking

Press  2 times to exit from the procedure:

```
SETUP MODE
Autotune
```

Switch off the output contactors and disconnect terminal 12 (Enable).

**Note!** Autotune procedure can take up to different minutes to be completed.

---

If the operation generates any error messages, for example when the drive is disabled during procedure execution:

```
Autotune err#1:
Abort
```

and red LED alarm blinking

press  to exit 2 times,

then try to repeat the autotune procedure. For more information about error messages and alarms, please refer to section 10, Troubleshooting.

---

Press  to Exit from **SETUP MODE** menu.

Wait few seconds, message sequence will follow:

```
Busy
Please wait ...
```

then

```
Restart
Please wait ...
```

then

```
R:      S:
MONITOR
```

then

```
Load setup?
Yes->Ent  No->Esc
```

Press  to load Autotune data.

```
Busy
Please wait ...
```

then

```
Load setup?
Yes->Ent  No->Esc
```




**5**  
**Mechanical data**

Press  to exit from menu:

**Startup config**  
**Load setup**

Scroll  till:

**Startup config**  
**Mechanical data**



Press  to set “Gearbox ratio”, “Pulley diameter” and “Full scale speed” of the system:

**Travel unit sel**  
**Revolution**



“Travel unit sel” parameter determines all Speed and Ramp profile parameters units:

- Revolution = rpm, rpm/s and rpm/s<sup>2</sup>
- Millimeters = mm/s, mm/s<sup>2</sup> and mm/s<sup>3</sup>.



  
**Gearbox ratio**  
**35.00**

Press  and set gearbox ratio of the system, press  to confirm.

  
**Pulley diameter**  
**500 mm**

Press  and set pulley diameter of the system, press  to confirm.

  
**Full scale speed**  
**1460 rpm**

Press  to edit max speed (in lift application set this parameter to rated motor speed), press  to confirm .

**NOTE!** It defines the 100% of the application speed referenced. The absolute speed handling range is  $\pm 200\%$  Full scale speed.

Press  to exit from **Mechanical data** menu:

**Busy**  
**Please wait ...**

then

**Startup config**  
**Mechanical data**



**6.1**  
Encoder type configuration  
**(Encoder config)**  
  
Feedback from encoder connected to **XE** connector on Regulation card



Now go to step **6**  
up to step **9** of  
chapter 7.1.3.

---

For encoder type configuration go to step:

- **6.1** Feedback from encoder connected to **XE** connector on Regulation card

or

- **6.2** Feedback from encoder connected to XFI connector on EXP-... optional card

---

Scroll  to **Encoders config** menu:

Startup config  
Encoders config



Speed fbk sel  
Std encoder



Std enc type  
Digital

Press  to set from Digital to Sinusoidal, press  to confirm:

Std enc type  
Sinusoidal

Scroll  to set encoder pulses per revolution (factory setting = 1024ppr):

Std enc pulses  
1024 ppr

Press  and set the new encoder pulses, press  to confirm.

Press  to exit from **Encoders config** menu.

## 6.2

### Encoder type configuration (Encoder config)

Feedback from encoder connected to XFI connector on EXP... optional card



Now go to step **6**  
up to step **9** of  
chapter 7.1.3.

Scroll  to **Encoders config** menu:

Startup config  
Encoders config



Speed fbk sel  
Std encoder



Speed fbk sel  
Std encoder



Speed fbk sel  
Exp encoder



Speed fbk sel  
Exp encoder

Press  seven times.

Exp enc pulses  
1024 ppr

Press  and set the new encoder pulses, press  to confirm.

Press  to exit from **Encoders config** menu.

## 7.1.2 Sensorless vector mode

1

### Sensorless vector mode set up

Power up the drive. This operation will take about 10 seconds and the drive will display (LEDs blink for test):

AC Drive Lift  
Startup...

after 10 seconds

R: 0 S: 0  
MONITOR



R: 0 S: 0  
STARTUP



**NOTE!** Upon opening the STARTUP menu, the drive enters in the parametrization mode.

STARTUP  
Startup config



STARTUP  
Regulation mode




Regulation mode  
V/f control




Select new mode  
V/f control

Press  two times.

Select new mode  
Sensorless vect

Press  to confirm Regulation mode database selected.

Transfer param ?  
Yes->Ent No->Esc

Press  to transfer parameters from previous regulation mode to a newly selected regulation mode.

This operation is convenient only if some parameters have been set in previous regulation mode. Otherwise press Esc to not transfer parameters.

The drive will restart in the new regulation mode, this will take around 5 seconds:

Restart  
Please wait



Now go to step **2**  
up to step **9** of  
chapter 7.1.3.

then

**STARTUP  
Regulation mode**

Press to exit from **STARTUP** menu.

### 7.1.3 V/f Control mode

Power up the drive. This operation will take about 10 seconds and the drive will display (LEDs blink for test):

**1**  
**V/f Control  
switch-on**

**AC Drive Lift  
Startup...**

after 10 seconds

R: 0 S: 0  
**MONITOR**



**2**  
**V/f Control  
mode set up**

R: 0 S: 0  
**STARTUP**



**NOTE!** Upon opening the **STARTUP** menu, the drive enters in the parametrization mode.

**STARTUP  
Startup config**



**STARTUP CONFIG  
Enter setup mode**

, wait few seconds:

**SETUP MODE  
Drive data**



**Mains voltage  
400 V**



Press or to select AC input voltage from the following list:

**460 - 440 - 415 - 400 - 380 - 230V**, press to confirm.

If necessary, it is also possible to change : Ambient temperature and Switching frequency.

**3**  
Set **Motor data**

▼  
Ambient temp  
40° C

▼  
Switching freq  
8 KHz

Press ◀, the drive will show:

Busy  
Please wait ...

then

▼  
SETUP MODE  
Drive data

Set **Motor nameplate** parameters in Motor data menu (values accepted depend on drive size):

▼  
SETUP MODE  
Motor data

Enter  
Rated voltage  
380.00 V

Enter to edit motor voltage. To confirm the new value press Enter, to cancel

edit press Shift + ◀ or scroll ▼ to:

Rated frequency  
50.00 Hz

Enter to edit motor frequency, to confirm the new value press Enter

▼  
Rated current  
43 A


Enter to edit motor current, to confirm the new value press Enter.

**Note!** The value should not be less than approx 0.3 times the drive rated current, output current class 1 @400V on the drive nameplate.

▼  
Rated speed  
1460.00 rpm

 to edit motor speed, to confirm the new value press .


**NOTE!** The value is intended to be the motor full load speed at the rated frequency. If Slip value is available on the motor nameplate data, set “Rated speed” parameter as following:  
**Rated speed** = Synchronous speed - Slip



|                      |
|----------------------|
| Rated power<br>22 kW |
|----------------------|

 to edit motor power, to confirm the new value press .


**NOTE!** For a motor nameplate rated in HP, set  
**Rated power kW** = 0.736 x motor **Hp** rating.



|              |
|--------------|
| Cosφ<br>0.85 |
|--------------|

 to edit motor cos φ (power factor), to confirm the new value press .


**NOTE!** Leave default value for Cos φ if the data is not available from the nameplate.

|                       |
|-----------------------|
| Efficiency<br>91.20 % |
|-----------------------|

 to edit motor efficiency, to confirm the new value press .

**NOTE!** Leave default value for efficiency if the data is not available from the nameplate.

Press  to exit from **Motor data**; for some seconds the drive will show:

|                         |
|-------------------------|
| Busy<br>Please wait ... |
|-------------------------|

  
then  

|                          |
|--------------------------|
| SETUP MODE<br>Motor data |
|--------------------------|

**NOTE!** If any changes have been made to **Motor data** menu parameters, with this operation internal drive values will be calculated and autotune results will be initialized.  
If the operation generates any error messages or alarm led comes


  

|                      |
|----------------------|
| <b>4</b><br>Autotune |
|----------------------|





on, please check consistency of motor parameters and try again or refer to section 10, Troubleshooting.

Scroll  to perform Autotune procedure; two options can be used for this procedure: “**Complete still**” or “**Complete rot**”.


**Note!** When motor is coupled to gearbox and lift is installed, use “**Complete still**”(motor still).  
When motor is uncoupled or gearbox does not represent more than 5% of load and lift car is not installed, use “**Complete rot**”(motor on rotation).

**WARNING !** Option “**Complete still**” may also cause limited shaft rotation.

**WARNING !** Option “**Complete rot**” causes motor shaft rotation close to rated speed. It is preferred one for the higher accuracy, but it requires free uncoupled rotation of the motor shaft.



As standard example with motor and machine installed on system, **Complete still** are used. Connect terminal 12 (Enable) to terminal 19 (+24VDC) through relays or local switch, switch on the output contactors and leave the brake closed.



press  to start

**Note!** Autotune can be aborted at any time by pressing .

The Autotune procedure will start through which the drive will display:

from  
**Complete still 1**  
**0 %**

to

**Complete still 1**  
**100 %**

then

**Complete still 2**  
**0 %**


to

**Complete still 2**  
**100 %**

after

**End**  
**Autotune**

blinking

Press  2 times to exit from the procedure:

**SETUP MODE**  
**Autotune**

Switch off the output contactors and disconnect terminal 12 (Enable).

**NOTE!** Autotune procedure can take up to different minutes to be completed.

---

If the operation generates any error messages, for example when the drive is disabled during procedure execution:

**Autotune err#1:**  
**Abort**

and red LED alarm blinking

press  to exit 2 times,

then try to repeat the autotune procedure. For more information about error messages and alarms, please refer to section 10, Troubleshooting.

---

Press  to Exit from **SETUP MODE** menu.

Wait few seconds, message sequence will follow:

**Busy**  
**Please wait ...**

then

**Restart**  
**Please wait ...**

then

**5**  
**Mechanical data**

R: S:  
MONITOR

then


Load setup?  
Yes->Ent No->Esc

Press  to load Autotune data.

Busy  
Please wait ...

then

Load setup?  
Yes->Ent No->Esc

Press  to exit from menu:

Startup config  
Load setup

Scroll  till:


Startup config  
Mechanical data



Press  to set “Gearbox ratio”, “Pulley diameter” and “Full scale speed” of the system:

Travel unit sel  
Revolution



“Travel unit sel” parameter determines all Speed and Ramp profile parameters units:


- Revolution = rpm, rpm/s and rpm/s<sup>2</sup>
- Millimeters = mm/s, mm/s<sup>2</sup> and mm/s<sup>3</sup>.

  
Gearbox ratio  
35.00

Press  and set gearbox ratio of the system, press  to confirm.

  
Pulley diameter  
500 mm

Press  and set pulley diameter of the system, press  to confirm.

  
Full scale speed  
1460 rpm

Press  to edit max speed (in lift application set this parameter to rated

motor speed), press **Enter** to confirm.

**NOTE!** It defines the 100% of the application speed referenced. The absolute speed handling range is  $\pm 200\%$  Full scale speed.


Press **◀** to exit from **Mechanical data** menu:

**Busy  
Please wait ...**

then

**Startup config  
Mechanical data**

**6  
Weight**



Scroll **▼** to Weights menu:

**Startup config  
Weights**

Press **Enter** to set Car weight (weight of the lift car), Counter weight, Load weight, Rope weight, Motor and Gearbox inertia parameter:


**Car weight  
0 Kg**

Press **Enter** and edit the value of Car weight, press **Enter** to confirm.





**Counter weight  
0 Kg**

Press **Enter** and the value of Counter weight (car weight to achieve balance

system) parameter, press  to confirm.





**Load weight**  
0 Kg

Press  and edit the value of Load weight (maximum lift load weight) parameter, press  to confirm.





**Rope weight**  
0 Kg

Press  and edit the value of Rope weight (total inertia of cabin rope) parameter, press  to confirm.





**Motor inertia**  
0.00 Kg\*m<sup>2</sup>

Press  and edit the value of Motor inertia (if not available, leave to default), press  to confirm.



**Gearbox inertia**  
0.00 Kg\*m<sup>2</sup>

Press  and edit the value of Gearbox inertia (if not available, leave to default), press  to confirm.

**Note!** “Gearbox inertia” is intended as inertia of all rotating masses on slow side of gearbox, ex. pulley inertia, etc...

Press  to exit from **Weight menu**.

Press  2 times.

Follow the points below to set the BU resistance parameters:

**Startup config**  
**BU protection**



**7**

**Braking unit setting**  
**[BU protection]**



BU control  
Internal



BU resistance  
15.40 ohm

Press  and edit the resistance value, press  to confirm.



**NOTE!** See section 4.9.2 for the minimum permissible value of the resistor.

For the thermal protection of the braking resistance, a time reverse characteristic is defined. This requires definition of resistor power in continuous service, *BU res cont pwr*.

**NOTE!** Refer to chapter 9.2 for details on BU protection



BU res cont pwr  
4.00 kW

Press  to edit the power value, press  to confirm.

Press  to exit from Encoder Config menu.

Startup config  
BU protection



Busy  
Please wait ...

to

STARTUP  
Save config?

The prompt displays “Save config ?” (Recommended).  
For this operation the drive will take around 5 seconds.


Press  to execute the procedure:

STARTUP  
Save config?



R: S:  
STARTUP

**NOTE!** Upon closing the **STARTUP** menu, the drive exits from parametrization mode and becomes operational.



**Note!** The drive cannot be enabled when STARTUP menu is open.

AVyL drive allows to set a Speed profile trough 8 different speed point: “Multi speed 0” ... “Multi speed 7”

R: S:  
STARTUP



R: S:  
TRAVEL



TRAVEL  
Speed profile



Smooth start spd  
0 rpm



Multi speed 0  
0 rpm

Press to set “Multi speed 0” set point:

Multi speed 0  
+0000000Q rpm

Edit the value requested by the system and press to confirm.

Scroll to set “Multi speed 1” set point:

Multi speed 1  
0 rpm

Press and repeat the procedure as for “Multi speed 0”. Scroll to set all the others Multi speed required by the system.

**ATTENTION !** Through the combination of “Mlt spd s0 src” (equal Digital input 4), “Mlt spd s1 src” (equal Digital input 5) and “Mlt spd s2 src” (equal Digital input 6), is possible to select Multi speed desired, according to next table:



| Mtl spd sel<br>2 src | Mtl spd sel<br>1 src | Mtl spd sel<br>0 src | ACTIVE SPEED  |
|----------------------|----------------------|----------------------|---------------|
| 0                    | 0                    | 0                    | Multi speed 0 |
| 0                    | 0                    | 1                    | Multi speed 1 |
| 0                    | 1                    | 0                    | Multi speed 2 |
| 0                    | 1                    | 1                    | Multi speed 3 |
| 1                    | 0                    | 0                    | Multi speed 4 |
| 1                    | 0                    | 1                    | Multi speed 5 |
| 1                    | 1                    | 0                    | Multi speed 6 |
| 1                    | 1                    | 1                    | Multi speed 7 |

TAV3I011

Press  to exit from Speed profile menu.

AVyL drive allows to set a Ramp profile as the picture shows below:

**9**  
Ramp setting  
[Ramp profile]



**TRAVEL  
Speed profile**



**TRAVEL  
Ramp profile**







**MRO acc ini jerk**  
1000 rpm/s<sup>2</sup>

Press **Enter** to set “MRO acc ini jerk” parameter, press **Enter** to confirm:



**MRO acceleration**  
500 rpm/s

Press **Enter** to set “MRO acceleration” parameter, press **Enter** to confirm:



**MRO acc end jerk**  
1000 rpm/s<sup>2</sup>

Press **Enter** to set “MRO acc end jerk” parameter, press **Enter** to confirm:



**MRO dec ini jerk**  
1000 rpm/s<sup>2</sup>

Press **Enter** to set “MRO dec ini jerk” parameter, press **Enter** to confirm.



**MRO deceleration**  
500 rpm/s

Press **Enter** to set “MRO deceleration” parameter, press **Enter** to confirm.



**MRO dec end jerk**  
1000 rpm/s<sup>2</sup>

Press **Enter** to set “MRO dec end jerk” parameter, press **Enter** to confirm.



**MRO end decel**  
1000 rpm/s

Press **Enter** to set “MRO end decel” parameter, press **Enter** to confirm.



**TRAVEL**  
Ramp profile

Press **Down Arrow** 9 times to open the saving procedure

**TRAVEL**  
SAVE PARAMETERS

Press  to execute the procedure:

**Busy  
Please wait ...**

to

**TRAVEL  
SAVE PARAMETERS**



Press  + .

**R: 0 S: 0  
MONITOR**



**Now the drive is  
set with  
commands for  
standard  
sequence.**

## 7.2 Commissioning for AVy...BR / BR4 (Brushless Motors)

### Commissioning Set-up Procedure

| Step | Function                                | Description   |
|------|---|---|
| 1    | Set Drive data                          | Drive Data parameters: Mains voltage, Ambient temp, Switching freq, Speed reference resolution  |
| 2    | Set Motor data                          | Motor Data parameters: Rated voltage, Rated current, Rated speed, Pole pairs, Torque constant, EMF constant, Stator resistance and LsS inductance.  |
| 3    | Run current Regulator Autotune          | Autotune procedure measures a real motor parameters:<br>- “Curr Reg autotune” can be used when motor is coupled to gearbox and lift car is installed. <b>It could cause limited shaft rotation.</b> |
| 4    | Escape setup mode                       | During this operation a “Load setup” is required to load all datas changes into SETUP MODE.   |
| 5    | Set all system mechanical data          | System mechanical data:<br>Gearbox ratio, Pulley diameter, Full scale speed.  |
| 6    | Set all system weight data              | System weights data:<br>Cabin weight, Counter weight, Load weight, Rope weight, Motor inertia, Gearbox inertia  |
| 7    | Encoder configuration                   | Feedback source type selection: Sinusoidal Hall, Sinusoidal SinCos, Sinusoidal Extern, Digital Hall, DigitalExtern, SinCos, Resolver and Hyperface.   |
| 8    | Set braking unit parameters             | Braking Unit parameters: Braking unit type (internal / external), Braking unit resistance, Braking unit power   |
| 9    | Save configuration made in startup menu | Use “Save Config ?” to save all the changes made in the Startup menu.   |
| 10   | Set speed profile                       | A binary combination of three digital input allows to select up to 8 different speed setpoints  |
| 11   | Set ramp profile                        | Accelerations jerk and decelerations jerk can be set in the ramp profile  |
| 12   | Encoder phasing                         | Two options are available:<br>- motor rotating or still.  |
| 13   | Save all the parameters                 |   |

**NOTE!** Drive Startup procedure below take as example an AVyL 4220 BR4 drive (software revision 3.300).

Power up the drive, after few seconds the drive will display the main menu:

**1**  
Set drive parameters  
(Drive data)

R: S:  
MONITOR



R: 0 S: 0  
STARTUP



**NOTE!** Upon opening the STARTUP menu, the drive enters in the parametrization mode.

STARTUP  
Startup config



Startup config  
Enter setup mode



SETUP MODE  
Drive data



SETUP MODE  
Drive data



Mains voltage  
400 V



Press or to select AC input voltage from the following list:

460 - 440 - 415 - 400 - 380 - 230V, press to confirm.

If necessary, it is also possible to change : Ambient temperature, Switching frequency and Speed resolution.

Ambient temp  
40° C



Switching freq  
8 KHz



Spd ref/fbk res  
0.250 rpm

Enter

Press  or  to select a speed resolution value based on max motor speed.

E.g.: if rated speed is 144 rpm, set 0.03125 rpm (see table)


| Speed resolution<br>(Spd ref/fbk res) | Max speed value |
|---------------------------------------|-----------------|
| 0.125 rpm                             | 2048 rpm        |
| 0.25 rpm                              | 4096 rpm        |
| 0.5 rpm                               | 8192 rpm        |
| 1 rpm                                 | 16384rpm        |
| 0.03125 rpm                           | 512 rpm         |

Spd ref/fbk res  
0.03125 rpm

Enter

Press  to confirm the selection.



Press , the drive will show:

Busy  
Please wait ...

then

SETUP MODE  
Drive data




Set **Motor nameplate** parameters in Motor data menu (values accepted depend on drive size):


Enter

Rated voltage  
330.00 V

Enter

Press  to edit rated motor voltage.

Enter

Press again  to confirm the new value.




Rated current  
35 A



Enter

Press  to edit rated motor current. Press again  to confirm.





Rated speed  
2000.00 rpm

Press  to edit rated synchronous motor speed. Press again  to confirm the value.



Pole pairs  
4

Press  to edit motor pole pairs. Press again  to confirm the value.



Torque Constant  
2.480 Nm/A

Press  to edit motor torque value. Press again  to confirm the value.

**NOTE!** If Torque Constant is not available, it should be calculated with the following:

$$K_{T1} = \frac{P_n}{\left(\frac{2\pi S_n}{60}\right) I_n}$$

Where:

$P_n$  = Rated power [W]

$I_n$  = Rated current [A]

$S_n$  = Rated speed [rpm]

$$K_{T1} = \frac{T_n}{I_n}$$

Where:

$T_n$  = Rated torque [Nm]

$I_n$  = Rated current [A]



EMF constant  
1.430 V\*s

Press  to edit motor back EMF constant from motor type plate (\*).

Press  to confirm.






Stator resist  
0.135 ohm

Press  to edit motor stator resistance value (\*). Press  to confirm.



LsS inductance  
0.00237 H

Press  to edit motor stator value (\*). Press  to confirm.



**(\*) NOTE!** If “EMF constant”, “Stator resistance” and “LsSinductance” values are unknown, set them to zero before running current self-tuning procedure.

Press  to exit from **Motor data**; for few seconds the drive will show:

**Busy**  
**Please wait ...**

then

**SETUP MODE**  
**Motor data**


**NOTE!** If any changes have been made to **Motor data** menu parameters, with this operation internal drive values will be calculated and autotune results will be initialized.  
 If the operation generates any error messages or alarm led comes on, please check consistency of motor parameters and try again or see specific directions in section 10, Troubleshooting.

Scroll  to perform Current Regulator Autotune procedure.




This operation may cause limited shaft rotation.

**SETUP MODE**  
**Autotune**




**CurrReg**  
**Start?**




Connect terminal 12 (Enable) to terminal 19 (+24VDC) through relays or local switch, then switch on the output contactors. It is suggested to open the brake (the rope must be removed), if not possible leave the brake closed.

**CurrReg**  
**Press I Key**

Press  to start the Autotune procedure.

**NOTE!** Autotune procedure can take different minutes to be completed.  
 Autotune can be aborted at any time by pressing .



The drive will display from:

**CurrReg**  
0 %


to

**CurrReg**  
100 %

after


**End**  
**Autotune**

blinking to show the end of procedure.

Press  2 times to exit from the procedure:

**SETUP MODE**  
**Autotune**

Switch off the output contactors and disconnect terminal 12 (Enable).

Press  and wait few seconds

**Load setup?**  
Yes->Ent No->Esc



**Busy**  
Please wait ...

then


**Load setup?**  
Yes->Ent No->Esc

Press  to exit from menu:

**Startup config**  
**Load setup**

Scroll  till:

**Startup config**  
**Mechanical data**

Press  to set “Gearbox ratio”, “Pulley diameter” and “Full scale speed” of the system:

**Travel unit sel**  
**Revolution**

“Travel unit sel” parameter determines all Speed and Ramp profile parameters units:

- Revolution = rpm, rpm/s and rpm/s<sup>2</sup>
- Millimeters = mm/s, mm/s<sup>2</sup> and mm/s<sup>3</sup>.



Press **Enter** and **▼** or **▲** to select the units, press **Enter** to confirm.

**▼**

**Gearbox ratio**  
35.00

Press **Enter** to set gearbox ratio of the system, press **Enter** to confirm.

**▼**

**Pulley diameter**  
500 mm

Press **Enter** and edit the pulley diameter of the system, press **Enter** to confirm.

**Pulley diameter**  
+0000500 mm

**▼** to **Full scale speed** parameter

**Full scale speed**  
2000 rpm


Press **Enter** and edit the value of max speed (in lift application set this parameter to rated motor speed), press **Enter** to confirm. Press **◀** to exit from **Mechanical data** menu.

Scroll **▼** to Weights menu:

**Startup config**  
**Weights**



**6**  
**Weights**





Press **Enter** to set Car weight (weight of the lift car), Counter weight, Load weight, Rope weight, Motor and Gearbox inertia parameter:

Car weight  
0 Kg

Press  and edit the value of Car weight, press  to confirm.





Counter weight  
0 Kg

Press  and the value of Counter weight (car weight to achieve balance system) parameter, press  to confirm.





Load weight  
0 Kg

Press  and edit the value of Load weight (maximum weight of lift load) parameter, press  to confirm.





Rope weight  
0 Kg

Press  and edit the value of Rope weight (total inertia of cabin rope) parameter, press  to confirm.





Motor inertia  
0.00 Kg\*m<sup>2</sup>

Press  and edit the value of Motor inertia (if it is not available, leave to default), press  to confirm.





Gearbox inertia  
0.00 Kg\*m<sup>2</sup>

Press  and edit the value of Gearbox inertia (if it is not available, leave to default), press  to confirm.

**NOTE!** “Gearbox inertia” is intended as inertia of all rotating masses on slow rotating side of gearbox, e.g. pulley inertia, etc...

Press  to exit from **Weight menu**.

**7**Encoder type configuration  
(Encoder config)Press  2 times.Startup config  
Encoders configSpeed fbk sel  
Std encoderStd enc type  
Sinusoidal HallPress  to select the parameter (see following list) according to the encoder type, press  to confirm.

| <i>Parameter</i>           | <i>Description</i>   |
|----------------------------|--|
| <b>SinusoidalHall</b>      | is a sinusoidal incremental encoder with A+/A-,B+/B-,C+/C- traces and three digital “Hall sensor” absolute position traces for initial synchronization ( <b>XE</b> connector)                                |
| <b>SinusoidalSinCos</b>    | is a sinusoidal incremental encoder with A+/A-,B+/B-,C+/C- traces and two analog Sin Cos absolute position traces for initial synchronization ( <b>XE</b> connector).  |
| <b>SinusoidalExtern</b>    | is a sinusoidal incremental encoder with A+/A-,B+/B- traces and absolute position information through SSI serial interface for initial synchronization ( <b>XE</b> connector, requires <b>APC100y</b> card). |
| <b>DigitalHall</b>         | is a digital incremental encoder with A+/A-,B+/B-,C+/C- traces and three digital “Hall sensor” absolute position traces for initial synchronization ( <b>XE</b> connector).                                  |
| <b>DigitalExtern</b>       | is a digital incremental encoder with A+/A-,B+/B- traces and absolute position information through SSI serial interface for initial synchronization ( <b>XE</b> connector, requires <b>APC100y</b> card).    |
| <b>SinCos Resolver</b>     | is a sinusoidal absolute encoder with SinCos traces. is resolver feedback, using option cards: EXP-RES, refer its manual for details ( <b>XFR</b> connector on EXP-RES card).                                |
| <b>SinusoidalHiperface</b> | Absolute encoder with Hiperface protocol ( <b>XE</b> connector).   |
| <b>Sinusoidal Intern</b>   | sinusoidal incremental encoder with A+/A-,B+/B-,C+/C- traces, absolute position traces are not necessary because phasing is performed automatically at every start.  |
| <b>Digital Intern</b>      | digital incremental encoder with A+/A-,B+/B-,C+/C- traces, absolute position traces are not necessary because phasing is performed automatically at every start.   |

**8**  
Braking unit setting  
[BU protection]

**CAUTION!** For each encoder feedback, set the correct jumpers configuration on the regulation card RV33.

Std enc type  
SinusoidalSinCos

▽

Std enc pulses  
1024 ppr

Press **Enter** to edit the number according to encoder data, press **Enter** to confirm.

**NOTE!** It is possible to use only encoder having pulses per revolution equal to a multiple of 2.  
Example: 512 ppr, 1024 ppr, 2048 ppr, etc.

Press **◀** to exit from Encoder Config menu.

Press **◀** 2 times.

Follow the points below to set the BU resistance parameters:

Startup config  
BU protection

**Enter**

BU control  
Internal

▽

BU resistance  
15.40 ohm

Press **Enter** and edit the resistance value, press **Enter** to confirm.

**NOTE!** See section 4.9.2 for the minimum permissible value of the resistor.

For the thermal protection of the braking resistance, a time reverse characteristic is defined. This requires definition of resistor power in continuous service, **BU res cont pwr**.

**NOTE!** Refer to chapter 9.2 for details on BU protection

▽

BU res cont pwr  
4.00 kW

Press **Enter** to edit the power value, press **Enter** to confirm.

**9**  
Save configuration

Press  to exit from Encoder Config menu.

Press  to exit from Startup Config menu.

**STARTUP**  
Save config?

The prompt displays “Save config ?” (Recommended).  
For this operation the drive will take around 5 seconds.

Press  to execute the procedure:

**Busy**  
Please wait ...

to

**STARTUP**  
Save config?

Press  to exit from STARTUP menu:

R: 0 S: 0  
STARTUP

**10**  
Speed setting  
[Speed profile]

AVyL drive allows to set a Speed profile through 8 different speed point:  
“Multi speed 0” ... “Multi speed 7”

R: S:  
STARTUP



R: S:  
TRAVEL



TRAVEL  
Speed profile




Smooth start spd  
0 rpm



Multi speed 0  
0 rpm

Press  to set “Multi speed 0” set point:

Multi speed 0  
+00000000 rpm

Edit the value requested by the system and press  to confirm.

Scroll  to set “Multi speed 1” set point:

Multi speed 1  
0 rpm

Press **Enter** and repeat the procedure as for “Multi speed 0”. Scroll **▼** to set all the others Multi speed required by the system.


**ATTENTION !** Through the combination of “Mlt spd s0 src” (equal Digital input 4), “Mlt spd s1 src” (equal Digital input 5) and “Mlt spd s2 src” (equal Digital input 6), is possible to select Multi speed desired, according to next table:

| Mlt spd sel<br>2 src | Mlt spd sel<br>1 src | Mlt spd sel<br>0 src | ACTIVE SPEED  |
|----------------------|----------------------|----------------------|---------------|
| 0                    | 0                    | 0                    | Multi speed 0 |
| 0                    | 0                    | 1                    | Multi speed 1 |
| 0                    | 1                    | 0                    | Multi speed 2 |
| 0                    | 1                    | 1                    | Multi speed 3 |
| 1                    | 0                    | 0                    | Multi speed 4 |
| 1                    | 0                    | 1                    | Multi speed 5 |
| 1                    | 1                    | 0                    | Multi speed 6 |
| 1                    | 1                    | 1                    | Multi speed 7 |

TAV31011

Press **◀** to exit from Speed profile menu.

AVyL drive allows to set a Ramp profile as the picture shows below:



11  
Ramp setting  
[Ramp profile]



TRAVEL  
Speed profile



TRAVEL  
Ramp profile





MR0 acc ini jerk  
1000 rpm/s<sup>2</sup>

Press  to set “MR0 acc ini jerk” parameter, press  to confirm:





MR0 acceleration  
500 rpm/s

Press  to set “MR0 acceleration” parameter, press  to confirm:




MR0 acc end jerk  
1000 rpm/s<sup>2</sup>

Press  to set “MR0 acc end jerk” parameter, press  to confirm:



MR0 dec ini jerk  
1000 rpm/s<sup>2</sup>

Press  to set “MR0 dec ini jerk” parameter, press  to confirm.



MR0 deceleration  
500 rpm/s

Press  to set “MR0 deceleration” parameter, press  to confirm.






MR0 dec end jerk  
1000 rpm/s<sup>2</sup>

Press  to set “MR0 dec end jerk” parameter, press  to confirm.



MR0 end decel  
1000 rpm/s

Press  to set “MR0 end decel” parameter, press  to confirm.



**12**  
Encoder phasing  
[Autophase]  
  
Required only if  
encoder / motor  
are not aligned in  
factory !

TRAVEL  
Ramp profile

Press  9 times to open the saving procedure

TRAVEL  
SAVE PARAMETERS

Press  to execute the procedure:

Busy  
Please wait ...

to

TRAVEL  
SAVE PARAMETERS



Press  + .

R: 0 S: 0  
MONITOR

Now the drive is set with commands for standard sequence.



R: 0 S: 0  
SERVICE



SERVICE  
Insert password

Press  twice.

Insert password  
+00000

the last digit will blinking



Insert password  
+12345

Insert the "12345" password and press .

Insert password  
+00000

Press  twice

R: 0 S: 0  
SERVICE

Press  four times.



R: 0 S: 0  
REGULATION PARAM

Enter

Press  four times.

REGULATION PARAM  
Flux config

Enter

Flux config  
Magnetiz config

Enter

Now it is possible to select two different modes of phasing procedure:  
rotation (brake opened) or still (brake closed)

Autophase rot  
Start ?

OR 

Autophase still  
Start ?

Switch on the output contactors and press .

Autophase  
Waiting start ...

When the drive will display “Waiting start ...”, give Enable and Start commands, then wait until the end of phasing procedure.

Autotune  
End


When the drive will display “Autotune End”, close the brake, remove the Enable and Start commands, switch off the output contactors.

Press  three times.

REGULATION PARAM  
Flux config

Press  twice

REGULATION PARAM  
SAVE PARAMETERS

Press  to save the changes.

**13**

**Save all changes**



## Chapter 8 - Lift Sequencies

### External contactor control

It is possible to delegate output contactor control to external devices like PLC etc. In this case it must be ensured that contactor is closed prior drive enable and is open only after drive disable signal has been issued. Contactor mechanical opening and closing times must be taken into consideration.

### External brake control

Also brake control can be accomplished by an external means. In this case, brake can be opened only when Drive ready signal is asserted. Brake must be closed after Start fwd/rev command is removed and Ref is zero or Ref is zero dly signal programmed on digital output becomes active. In FOC and BRS modes it is possible to refer to Ref is zero dly signal and adjust with parameter **Spd 0 ref delay** time for signal activation when motor has come to a complete stop, such that stopping shock is avoided. In case of SLS and VF control since it is not possible to guarantee required torque at low frequencies it is better to refer to signal Ref is zero. Threshold for signal activation can be set by parameter **Spd 0 ref thr**. Brake opening time and closing time must also be considered.

When output contactor or brake are not controlled by the drive it is possible to set corresponding delay times to zero and implement required delay intervals in external control.

### Contactor & Brake drive control

Standard command sequence diagram shows most complete sequence in which output contactor and brake are controlled by the drive.

Start of contactor control sequence in case that contactor is controlled by the drive depends on parameter **Seq start mode**. In case that it is set as Start fwd/rev contactor is closed when asserting the Start fwd or Start rev command. Enable command is not required for closing contactors! It is required only to start sequence of motor magnetization and therefore it can be provided for example using auxiliary contact of output contactor. Drive will wait until Enable command is given. In case that selection Enable is made contactors sequence starts when Enable command is asserted. Start fwd/rev commands are not required and one of them must be connected to 24V or more easily set corresponding source to ONE. Since Start command is not used, zero speed in this configuration must be obtained through multi speed selection. Change of direction must be accomplished by multi speed selection where some parameters are set to negative values or through **Ramp ref inv src** parameter pointing to an digital input controlling direction.

In case that selection **Seq start mode** = Mlt spd out!=0 is made, sequence is started by selecting any multispeed value different from zero. When output of multispeed selection is zero, it is equivalent to a stop command.

Start fwd/rev commands are not required and for their management is valid what is written for selection Enable .

In general, direction is controlled by Start fwd/rev commands, but it is preferred only one of these commands can be used and delegate direction control to a simple multispeed selection. Another possibility is to use digital input controlling parameter **Ramp ref inv src**.

Figure 8.1: Standard Commands Sequence




Figure 8.2: Detail Starting




Figure 8.3: Detail Stopping






Figure 8.4: Relation between Direction Commands and Contactor Control Signals



**Note!** To invert the sign of Speed ref corresponding to Start fwd and Start rev commands set parameter in TRAVEL \ Ramp rev inv src = UP cont mon.







# Chapter 9 - Parameter

## 9.1 Parameter Legend

**Access mode parameter**

**R** read only  
**W** write type  
**S** saved in flash  
**Z** accessible with drive disabled

**Parameter value**

**D.Size** value determined by drive size  
**Calc** value calculated in function of other parameter  
**DrvVer** value dependent on drive fw version  
**Motr** value dependent on motor  
**List X** signal list

Parameter number

Parameter name

Parameter unit of measure

| IPA                        | Description   | [Unit] | Access | Default        | Min | Max | Format  | Reg. Mode                   |
|----------------------------|---|--------|--------|----------------|-----|-----|---------|-----------------------------|
| <b>TRAVEL</b>              |   |        |        |                |     |     |         | <b>Main menu</b>            |
| <b>TRAVEL / DC braking</b> |   |        |        |                |     |     |         | <b>2<sup>nd</sup> level</b> |
| 1836                       | DCbrake cmd src<br>IPA 7125 Lift DC Brake mon = Default<br>It allows to select the origin of the signal to command DC braking function<br>(refer to signals List 3 of Pick List manual) | N/A    | RWS    | IPA 7125List 3 |     | PIN | V-F-S-B |                             |

The Pick List manual is available (pdf format) on the supplied "CONF 99" cd-rom.

**Validity DB**

The reading keys are:

- F** Field oriented
- S** Sensorless
- V** V/f
- A** Autotuning (Setup mode)
- B** Brushless

**Point type**

**AB**

- A** can to be > **F** float type
- > **P** float type
- > **D** digital type (Integer with 16 bits)
- B** can to be > **P** parameter
- > **V** variable
- > **K** constant

**PIN** The parameter type is enumerative.  
It has, therefore, a list of possible values (for example it is a source)

## 9.2 Parameter Description

| IPA | Description | [Unit] | Access | Default | Min | Max | Format | Reg. Mode |
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|

### MONITOR

This menu displays a series of variables useful to check the Drive state. The variable function is clearly explained by the variable name.

| Monitor              |  |       |   |      |      |      |    |         |
|----------------------|--|-------|---|------|------|------|----|---------|
| 3060                 | <b>Output voltage</b><br>Voltage on the drive output terminals   | [V]   | R | 0.00 | 0.00 | 0.00 | PV | V-F-S-B |
| 3070                 | <b>Output current</b><br>Current on the drive output terminals   | [A]   | R | 0.00 | 0.00 | 0.00 | PV | V-F-S-B |
| 3080                 | <b>Output frequency</b><br>Drive output frequency  | [Hz]  | R | 0.00 | 0.00 | 0.00 | PV | V-F-S-B |
| 3090                 | <b>Output power</b><br>Drive output power. UNIT: [kW] for AVy ... AC/AC4, [kVA] for AVy ... BR/BR4.  |       | R | 0.00 | 0.00 | 0.00 | PV | V-F-S-B |
| 9405                 | <b>Norm Speed</b><br>Speed of the motor  | [rpm] | R | 0.00 | 0.00 | 0.00 | PV | V-F-S-B |
| 3210                 | <b>Speed ref</b><br>Drive speed reference  | [rpm] | R | 0.00 | 0.00 | 0.00 | PV | V-F-S-B |
| 3200                 | <b>Ramp ref</b><br>Drive ramp reference  | [rpm] | R | 0.00 | 0.00 | 0.00 | PV | V-F-S-B |
| 162                  | <b>Enable SM mon</b><br>It shows the drive Enable state  | N/A   | R | 0    | 0    | 1    | DV | V-F-S-B |
| 163                  | <b>Start SM mon</b><br>It shows the drive Start state<br>0 OFF<br>1 ON   | N/A   | R | 0    | 0    | 1    | DV | V-F-S-B |
| 164                  | <b>FastStop SM mon</b><br>It shows the drive FastStop state<br>0 OFF<br>1 ON   | N/A   | R | 0    | 0    | 1    | DV | V-F-S-B |
| MONITOR / I/O status |  |       |   |      |      |      |    |         |
| 4028                 | <b>DI 7654321E</b><br>Standard digital inputs status, from 0 to 7; E (Enable) = Digital Input 0  | N/A   | R | 0    | 0    | 1    | DP | V-F-S-B |
| 4064                 | <b>DO 3210</b><br>Standard digital outputs status, from 0 to 3   | N/A   | R | 0    | 0    | 1    | DP | V-F-S-B |
| 4057                 | <b>DIX BA9876543210</b><br>Expanded digital inputs status, from 0 to 11;<br>A = Digital InputX 10, B = Digital InputX 11 (X suffix means expanded) | N/A   | R | 0    | 0    | 1    | DP | V-F-S-B |
| 4078                 | <b>DOX 76543210</b><br>Expanded digital outputs status, from 0 to 7 (X suffix means expanded)  | N/A   | R | 0    | 0    | 1    | DP | V-F-S-B |

| IPA                              | Description   | [Unit] | Access | Default | Min  | Max   | Format  | Reg. Mode |
|----------------------------------|---|--------|--------|---------|------|-------|---------|-----------|
| <b>MONITOR / Advanced Status</b> |   |        |        |         |      |       |         |           |
| 3100                             | <b>DC link voltage</b><br>Drive DC link voltage   | [V]    | R      | 0.00    | 0.00 | 0.00  | PV      | V-F-S-B   |
| 3110                             | <b>Magnetizing curr</b><br>Drive magnetizing current  | [A]    | R      | 0.00    | 0.00 | 0.00  | PV      | V-F-S-B   |
| 3120                             | <b>Torque curr</b><br>Drive torque current  | [A]    | R      | 0.00    | 0.00 | 0.00  | PV      | V-F-S-B   |
| 3130                             | <b>Magn curr ref</b><br>Drive magnetizing current reference   | [A]    | R      | 0.00    | 0.00 | 0.00  | PV      | F-S-B     |
| 3140                             | <b>Torque curr ref</b><br>Drive torque current reference  | [A]    | R      | 0.00    | 0.00 | 0.00  | PV      | F-S-B     |
| 3180                             | <b>Flux ref</b><br>Drive flux reference   | [Wb]   | R      | 0.00    | 0.00 | 0.00  | PV      | F-S-B     |
| 3190                             | <b>Flux</b><br>Drive flux   | [Wb]   | R      | 0.00    | 0.00 | 0.00  | PV      | F-S-B     |
| 1670                             | <b>Mot OL accum %</b><br>Motor I2t overload accumulator. When 100% is reached Mot overload alarm is generated and output inverter current is reduced to motor continuous current  | [%]    | R      | 0.00    | 0.00 | 0.00  | PV      | V-F-S-B   |
| 1781                             | <b>BU OL accum %</b><br>Braking Unit I2t overload accumulator. When 100% is reached BU overload alarm is generated.   | [%]    | R      | 0.00    | 0.00 | 0.00  | PV      | V-F-S-B   |
| 1540                             | <b>Drv OL accum %</b><br>Drive Unit I2t overload accumulator. When 100% is reached Drv overload alarm is generated and output inverter current is reduced to drive continuous current. .  | [%]    | R      | 0.00    | 0.00 | 0.00  | PV      | V-F-S-B   |
| 3222                             | <b>Norm Std enc spd[rpm]</b><br>Encoder speed of standard feedback (connector "XE" on RV33 regulation board)  | R      | 0.00   | 0.00    | 0.00 | PV    | V-F-S-B |           |
| 3223                             | <b>Norm Exp enc spd</b><br>Encoder speed of expanded feedback (encoder connector on expansion optional boards)  | [rpm]  | R      | 0.00    | 0.00 | 0.00  | PV      | V-F-S-B   |
| 9553                             | <b>Std enc position</b><br>Raw accumulated encoder pulses of the standard encoder, measured in ppr x 4  | [cnt]  | R      | 0.00    | 0.00 | 0.00  | PV      | F-B       |
| 9554                             | <b>Exp enc position</b><br>Raw accumulated encoder pulses of the expanded encoder, measured in ppr x 4  | [cnt]  | R      | 0.00    | 0.00 | 0.00  | PV      | F-B       |
| 9555                             | <b>Std sin enc mod</b><br>Module of "A" and "B" trace of sinusoidal encoder on std port. Encoder peak voltage is constantly monitored and the alarm Speed feedback loss is generated if it is outside the range:<br>min=IPA 1902/5, max=IPA 1902 * 2. | [cnt]  | R      | 0.00    | 0.00 | 0.00  | PV      | F-B       |
| 9072                             | <b>HT sensor temp</b><br>Drive Heatsink temperature   | [°C]   | R      | 0.00    | 0.00 | 0.00  | PV      | V-F-S-B   |
| 9073                             | <b>RG sensor temp</b><br>Temperature on the regulation card RV33  | [°C]   | R      | 0.00    | 0.00 | 0.00  | PV      | V-F-S-B   |
| 9095                             | <b>IA sensor temp</b><br>Temperature of the heatsink incoming air temperature (available from 18.5kW up to 160kW)   | [°C]   | R      | 0.00    | 0.00 | 0.00  | PV      | V-F-S-B   |
| 9090                             | <b>Sequencer status</b><br>Sequencer status of drive State Machine. It controls the drive running and starting, accounting for protection & alarming, command sequence, and reset status.   | N/A    | R      | 0.00    | 0.00 | - - - | DV      | V-F-S-B   |

| IPA                              | Description   | [Unit]                                   | Access    | Default       | Min         | Max         | Format    | Reg. Mode      |
|----------------------------------|---|--|-----------|---------------|-------------|-------------|-----------|----------------|
| <b>State Sequencer status</b>    |   |  |           |               |             |             |           |                |
| 1                                | Magnetization running   |  |           |               |             |             |           |                |
| 2                                | Magnetization completed, Stop   |  |           |               |             |             |           |                |
| 3                                | Start   |  |           |               |             |             |           |                |
| 4                                | Fast stop, Stop   |  |           |               |             |             |           |                |
| 5                                | Fast stop, Start  |  |           |               |             |             |           |                |
| 9                                | No alarm, drive is ready to accept all commands   |  |           |               |             |             |           |                |
| 10                               | Magnetization running and Start command already present   |  |           |               |             |             |           |                |
| 12                               | Alarm active  |  |           |               |             |             |           |                |
| 16                               | Alarm not active, waiting for reset   |  |           |               |             |             |           |                |
| <b>3230</b>                      | <b>CPU1 runtime</b>   | <b>[%]</b>                               | <b>R</b>  | <b>0.00</b>   | <b>0.00</b> | <b>0.00</b> | <b>PV</b> | <b>V-F-S-B</b> |
|                                  | Time needed by the CPU1 (microprocessor)  |  |           |               |             |             |           |                |
| <b>3240</b>                      | <b>CPU2 runtime</b>   | <b>[%]</b>                               | <b>R</b>  | <b>0.00</b>   | <b>0.00</b> | <b>0.00</b> | <b>PP</b> | <b>V-F-S-B</b> |
|                                  | Time needed by the CPU2 (microprocessor)  |  |           |               |             |             |           |                |
| <b>MONITOR - Drive ID Status</b> |   |  |           |               |             |             |           |                |
| <b>1460</b>                      | <b>Drive cont curr</b>  | <b>[A]</b>                               | <b>RW</b> | <b>CALC</b>   | <b>0.00</b> | <b>0.00</b> | <b>FK</b> | <b>V-F-S-B</b> |
|                                  | Drive maximum continuous current rating; its default value depends by the drive size and applicable derating factors. |  |           |               |             |             |           |                |
| <b>114</b>                       | <b>Drive size</b>   | <b>N/A</b>                               | <b>R</b>  | <b>D.Size</b> | <b>0</b>    | <b>20</b>   | <b>DK</b> | <b>V-F-S-B</b> |
|                                  | Drive size rating in kW (ULN = 400VAC, IEC 146 Class 1) of Hp (ULN = 460VAC, IEC 146 Class 2):                        |  |           |               |             |             |           |                |
| 0                                | 0.75 kW - 0.75 Hp   |  |           |               |             |             |           |                |
| 1                                | 1.5 kW - 1.5 Hp   |  |           |               |             |             |           |                |
| 2                                | 2.2 kW - 2.0 Hp   |  |           |               |             |             |           |                |
| 3                                | 3.0 kW - 3.0 Hp   |  |           |               |             |             |           |                |
| 4                                | 4.0 kW - 5.0 Hp   |  |           |               |             |             |           |                |
| 5                                | 5.5 kW - 7.5 Hp   |  |           |               |             |             |           |                |
| 6                                | 7.5 kW - 10 Hp  |  |           |               |             |             |           |                |
| 7                                | 11 kW - 15 Hp   |  |           |               |             |             |           |                |
| 8                                | 15 kW - 20 Hp   |  |           |               |             |             |           |                |
| 9                                | 22 kW - 25 Hp   |  |           |               |             |             |           |                |
| 10                               | 30 kW - 30 Hp   |  |           |               |             |             |           |                |
| 11                               | 37 kW - 40 Hp   |  |           |               |             |             |           |                |
| 12                               | 45 kW - 50 Hp   |  |           |               |             |             |           |                |
| 13                               | 55 kW - 60 Hp   |  |           |               |             |             |           |                |
| 14                               | 75 kW - 75 Hp   |  |           |               |             |             |           |                |
| 15                               | 90 kW - 100 Hp  |  |           |               |             |             |           |                |
| 16                               | 110 kW - 125 Hp   |  |           |               |             |             |           |                |
| 17                               | 132 kW - 150 Hp   |  |           |               |             |             |           |                |
| 18                               | 160 kW - 200 Hp   |  |           |               |             |             |           |                |
| 19                               | 250 kW - 300 Hp   |  |           |               |             |             |           |                |
| 20                               | 315 kW - 450 Hp   |  |           |               |             |             |           |                |
| 21                               | 18.5kW - 22.5 Hp  |  |           |               |             |             |           |                |
| <b>300</b>                       | <b>Drive type</b>   | <b>N/A</b>                               | <b>R</b>  | <b>288</b>    | <b>0</b>    | <b>0</b>    | <b>DK</b> | <b>V-F-S-B</b> |
|                                  | 288   | 460V default settings for AVy ... AC/AC4 |           |               |             |             |           |                |
|                                  | 289   | 460V default settings for AVy ... BR/BR4 |           |               |             |             |           |                |
|                                  | 34  | 400V default settings for AVy ... AC/AC4 |           |               |             |             |           |                |
|                                  | 35  | 400V default settings for AVy ... BR/BR4 |           |               |             |             |           |                |

| IPA | Description  | [Unit]  | Access | Default | Min  | Max  | Format | Reg. Mode |
|-----|--|---------|--------|---------|------|------|--------|-----------|
| 115 | <b>Drive name</b><br>ACDRV<br>ACDRVM   | N/A     | RWS    | 0.00    | 0.00 | 0.00 | FK     | V-F-S-B   |
|     | asynchronous firmware<br>brushless drive firmware  |         |        |         |      |      |        |           |
| 810 | <b>Actual setup</b><br>Setup motor file in use (reserved)  | N/A     | R      | 0       | 0    | 0    | DK     | V-F-S-B   |
| 107 | <b>Software version</b><br>Drive software version (factory installed), example: V 3. 0. 0  |         |        |         |      |      |        |           |
| 110 | <b>Software type</b><br>Software type factory use  | N/A     | R      | DrvVer  | 0    | 0    | DV     | V-F-S-B   |
| 111 | <b>Software status</b><br>Software state factory use   | N/A     | R      | DrvVer  | 0    | 0    | DV     | V-F-S-B   |
| 99  | <b>Life time</b><br>Drive life time accumulated with power on  | [hrs]   | R      | 0.00    | 0.00 | 0.00 | PV     | V-F-S-B   |
| 98  | <b>Sys time-ddmmyy</b><br>Time and date setting from PC configurator or serial communications.<br>Clock is active only when the Drive is powered on<br><i>Note!</i> On a new regulation card the variable takes value: 00:00:00 (time) 010170 (date) | [h/m/s] | R      | 0.00    | 0.00 | 0.00 | PV     | V-F-S-B   |

### MONITOR / Alarm log

This function provides a list of last 30 drive trips or various system error messages. with cause indications also time and data informations is provided. message is referred to "Sys time - dd mm yy" variable.

Together  
Alarm log

**Example:**

01:02:36 01 02 00

Undervoltage

|              |                   |
|--------------|-------------------|
| 01:02:36     | time of alarm     |
| 02 02 00     | date of alarm     |
| Undervoltage | alarm description |

### MONITOR / Alarm log clear?

It deletes all the alarms listed in the Alarm log.

| IPA | Description | [Unit] | Access | Default | Min | Max | Format | Reg. Mode |
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|

## STARTUP

### STARTUP / Startup config / Enter setup mode

Enter setup mode command allows the access to SETUP MODE to set drive basic parameters and motor plate data. Drive will reboot and few seconds are required. All changes and operations done in the SETUP MODE will be automatically saved, every time the user executes exits setup mode.

### SETUP MODE / Drive data

|             |  |              |           |                                 |          |          |           |                |
|-------------|--|--------------|-----------|---------------------------------|----------|----------|-----------|----------------|
| <b>380</b>  | <b>Mains voltage</b>   | <b>[V]</b>   | <b>RW</b> | <b>2</b>                        | <b>0</b> | <b>5</b> | <b>DK</b> | <b>V-F-S-B</b> |
|             | Drive power supply voltage. Select supply voltage parameter accurately, according to actual drive supply voltage. After changing this parameter, selftune data are initialized to default, self-tuning must be repeated !  |              |           |                                 |          |          |           |                |
|             | 0  | 230 V        |           |                                 |          |          |           |                |
|             | 1  | 380 V        |           |                                 |          |          |           |                |
|             | 2  | 400 V        |           |                                 |          |          |           |                |
|             | 3  | 415 V        |           |                                 |          |          |           |                |
|             | 4  | 440 V        |           |                                 |          |          |           |                |
|             | 5  | 460 V        |           |                                 |          |          |           |                |
| <b>1350</b> | <b>Ambient temp</b>  | <b>[°C]</b>  | <b>RW</b> | <b>0</b>                        | <b>0</b> | <b>1</b> | <b>DK</b> | <b>V-F-S-B</b> |
|             | Drive ambient temperature. Selecting 50°C will result in drive derating, see chapter 2.3. After changing this parameter selftune data are initialized to default, self-tuning must be repeated !   |              |           |                                 |          |          |           |                |
|             | 0  | 40°C         |           |                                 |          |          |           |                |
|             | 1  | 50°C         |           |                                 |          |          |           |                |
| <b>170</b>  | <b>Switching freq</b>  | <b>[kHz]</b> | <b>RW</b> | <b>D.Size</b>                   | <b>0</b> | <b>3</b> | <b>DK</b> | <b>V-F-S-B</b> |
|             | Drive PWM switching frequency. Selecting higher switching frequency then default, results in drive derating, see table 2.3.4.1. Selecting lower value results in higher continuous output current. After changing this parameter, selftune data are initialized to default, self-tuning must be repeated ! |              |           |                                 |          |          |           |                |
|             | 0  | 2 kHz        |           |                                 |          |          |           |                |
|             | 1  | 4 kHz        |           |                                 |          |          |           |                |
|             | 2  | 8 kHz        |           |                                 |          |          |           |                |
|             | 3  | 16 kHz       |           |                                 |          |          |           |                |
|             | 4  | 12 kHz       |           |                                 |          |          |           |                |
| <b>1880</b> | <b>Spd ref/fbk res</b>   | <b>[rpm]</b> | <b>RW</b> | <b>1</b>                        | <b>0</b> | <b>5</b> | <b>DK</b> | <b>V-F-S-B</b> |
|             | Resolution of the speed references referred to the maximum process speed (1885. "Full scale speed" parameter). After changing this parameter, selftune data are initialized to default, self-tuning must be repeated !   |              |           |                                 |          |          |           |                |
|             | 0  | 0.125 rpm    | ->        | 2048 rpm maximum process speed  |          |          |           |                |
|             | 1  | 0.250 rpm    | ->        | 4096 rpm maximum process speed  |          |          |           |                |
|             | 2  | 0.500 rpm    | ->        | 8192 rpm maximum process speed  |          |          |           |                |
|             | 3  | 1.000 rpm    | ->        | 16384 rpm maximum process speed |          |          |           |                |
|             | 4  | 0.03125 rpm  | ->        | 512 rpm maximum process speed   |          |          |           |                |

### SETUP MODE / Motor data

(for AVy . AC series)

|            |                        |             |           |               |             |             |           |                |
|------------|------------------------|-------------|-----------|---------------|-------------|-------------|-----------|----------------|
| <b>670</b> | <b>Rated voltage</b>   | <b>[V]</b>  | <b>RW</b> | <b>D.Size</b> | <b>Calc</b> | <b>Calc</b> | <b>FK</b> | <b>V-F-S-B</b> |
|            | Motor rated voltage    |             |           |               |             |             |           |                |
| <b>680</b> | <b>Rated frequency</b> | <b>[Hz]</b> | <b>RW</b> | <b>D.Size</b> | <b>Calc</b> | <b>Calc</b> | <b>FK</b> | <b>V-F-S</b>   |
|            | Motor rated frequency  |             |           |               |             |             |           |                |
| <b>690</b> | <b>Rated current</b>   | <b>[A]</b>  | <b>RW</b> | <b>D.Size</b> | <b>Calc</b> | <b>Calc</b> | <b>FK</b> | <b>V-F-S-B</b> |
|            | Motor rated current    |             |           |               |             |             |           |                |

| IPA | Description  | [Unit]   | Access | Default | Min  | Max  | Format | Reg. Mode |
|-----|--|--|--------|---------|------|------|--------|-----------|
|     | <b>Note!</b>   | The value should be not less then approx 0.3 times the drive rated current (output current Class 1 @ 400V on the motor nameplate). |        |         |      |      |        |           |
| 700 | <b>Rated speed</b><br>Motor full load speed at the rated frequency. If Slip is available on the motor nameplate data, set "Rated speed" parameter as following: Rated speed = Synchronous speed - Slip | [rpm]  | RW     | D.Size  | Calc | Calc | FK     | V-F-S-B   |
| 710 | <b>Rated power</b><br>Motor rated power  | [kW]   | RW     | D.Size  | Calc | Calc | FK     | V-F-S     |
|     | <b>Note!</b>   | For a motor nameplate rated in Hp, set Rated power kW = motor Hp rating * 0.736  |        |         |      |      |        |           |
| 720 | <b>Cosfi</b><br>Motor rated power factor   | N/A  | RW     | D.Size  | Calc | Calc | FK     | V-F-S     |
| 730 | <b>Efficiency</b><br>Motor Efficiency (if not available, leave the default data)   | N/A  | RW     | D.Size  | Calc | Calc | FK     | V-F-S     |

#### Load default mot

It selects and loads the motor standard parameters:

- 0 Standard 400V
- 1 Standard 460V

**Note!** By selecting one of the two options, the motor standard parameters with 400V (or 460V) are loaded making reference to the used Drive size. Through this process, motor data is overwritten.

| SETUP MODE / Motor data |   |  |    |        |      |      |    | (for AVy . BR series) |
|-------------------------|---|--|----|--------|------|------|----|-----------------------|
| 670                     | <b>Rated voltage</b><br>Motor rated voltage   | [V]  | RW | D.Size | Calc | Calc | FK | V-F-S-B               |
| 690                     | <b>Rated current</b><br>Motor rated current   | [A]  | RW | D.Size | Calc | Calc | FK | V-F-S-B               |
|                         | <b>Note!</b>  | The value should be not less then approx 0.3 times the drive rated current (output current Class 1 @ 400V on the drive nameplate). |    |        |      |      |    |                       |
| 700                     | <b>Rated speed</b><br>Motor synchronous speed   | [rpm]  | RW | D.Size | Calc | Calc | FK | V-F-S-B               |
| 930                     | <b>Pole pairs</b><br>Must be integer number.  | N/A  | RW | 4.0    | 0.0  | 0.0  | FK | B                     |
| 990                     | <b>Torque constant</b><br>Motor torque constant. This parameter is usually stated by the motor manufacturer. If not, it can be calculated from motor rated power, speed and current as: | [Nm/A]   | RW | D.Size | 0.0  | 0.0  | FK | B                     |
|                         | $\text{Torque Constant} = \frac{P [W]}{2\pi \cdot S [\text{rpm}] \cdot I [A]}$  |  |    |        |      |      |    |                       |
|                         | Current in torque constant unit [Nm/A is RMS current].  |  |    |        |      |      |    |                       |
| 775                     | <b>EMF constant</b><br>If the number is unknown, set the parameter to zero: the drive will automatically calculate an approximate value.  | [V.s]  | RW | D.Size | 0.0  | 0.0  | FK | B                     |
| 970                     | <b>Stator resistance</b><br>Motor stator resistance value.  | [ohm]  | RW | D.Size | 0.0  | 0.0  | FK | B                     |
| 980                     | <b>LsS inductance</b><br>Motor stator inductance value  | [H]  | RW | D.Size | 0.0  | 0.0  | FK | B                     |

| IPA   | Description  | [Unit] | Access | Default | Min  | Max   | Format | Reg. Mode |
|---|--|--------|--------|---------|------|-------|--------|-----------|
|   | <b>Note!</b> If “EMF constant”, “Stator resistance” and “LsInductance” values are unknown, set them to zero before running the current self-tuning procedure.                                |        |        |         |      |       |        |           |
| <b>Load default mot</b>   |  |        |        |         |      |       |        |           |
|   | It selects and loads the motor standard parameters:  |        |        |         |      |       |        |           |
|   | 0  | Set 0  |        |         |      |       |        |           |
|   | 1  | Set 1  |        |         |      |       |        |           |
|   | <b>Note!</b> By this selection, the motor standard parameters with “Set 1” (or “Set 2”) are loaded making reference to the used Drive size. Through this process, motor data is overwritten. |        |        |         |      |       |        |           |
| <b>SETUP MODE / Autotune</b>  |  |        |        |         |      |       |        |           |
| <b>Complete still</b> <span style="float: right;"><i>(for AVy . AC series)</i></span> |  |        |        |         |      |       |        |           |
|   | Complete self-tuning of current and flux loop with a <b>stopped</b> rotor  |        |        |         |      |       |        |           |
|   | “Start ?” enable data detection command (12 drive terminal must be cycle to +24Vdc)  |        |        |         |      |       |        |           |
| <b>Complete rot</b> <span style="float: right;"><i>(for AVy . AC series)</i></span>   |  |        |        |         |      |       |        |           |
|   | Complete self -tuning of current and flux loop with a <b>moving</b> rotor  |        |        |         |      |       |        |           |
|   | “Start ?” enable data detection command (12 drive terminal must be cycle to +24Vdc)  |        |        |         |      |       |        |           |
| <b>CurrReg</b> <span style="float: right;"><i>(for AVy . AC and BR series)</i></span> |  |        |        |         |      |       |        |           |
|   | Self-tuning of current loop only with stopped motor  |        |        |         |      |       |        |           |
|   | “Start ?” enable data detection command (12 drive terminal must be cycle to +24Vdc)  |        |        |         |      |       |        |           |
| <b>FluxReg rot</b> <span style="float: right;"><i>(for AVy . AC series)</i></span>    |  |        |        |         |      |       |        |           |
|   | Self-tuning of flux loop with a <b>moving</b> rotor only   |        |        |         |      |       |        |           |
|   | “Start ?” enable data detection command (12 drive terminal must be cycle to +24Vdc)  |        |        |         |      |       |        |           |
| <b>FluxReg still</b> <span style="float: right;"><i>(for AVy . AC series)</i></span>  |  |        |        |         |      |       |        |           |
|   | Self-tuning of flux loop with a <b>stopped</b> rotor only  |        |        |         |      |       |        |           |
|   | “Start ?” enable data detection command (12 drive terminal must be cycle to +24Vdc)  |        |        |         |      |       |        |           |
| <b>SETUP MODE / Autotune / Results</b>  |  |        |        |         |      |       |        |           |
| 2780  | <b>Measured Rs</b>   | [ohm]  | RW     | Calc    | Calc | Calc  | FK     | V-F-S-B   |
|   | Value of the phase resistance detected on the stator of the motor  |        |        |         |      |       |        |           |
| 2790  | <b>Measured DTL</b>  | [V]    | RW     | Calc    | 0    | Calc  | FK     | V-F-S-B   |
|   | IGBT dead time limit   |        |        |         |      |       |        |           |
| 2800  | <b>Measured DTS</b>  | [ohm]  | RW     | Calc    | 0    | Calc  | FK     | V-F-S-B   |
|   | IGBT dead time slope   |        |        |         |      |       |        |           |
| 2810  | <b>Measured LsSigma</b>  | [H]    | RW     | Calc    | Calc | Calc  | FK     | V-F-S-B   |
|   | Value of inductance detected on the stator of the motor  |        |        |         |      |       |        |           |
| 2820  | <b>Measured Rr</b>   | [ohm]  | RW     | Calc    | Calc | Calc  | FK     | V-F-S     |
|   | Value of resistance detected on the rotor of the motor   |        |        |         |      |       |        |           |
| 2830  | <b>Measured Rr2</b>  | [ohm]  | RW     | Calc    | Calc | Calc  | FK     | V-F-S     |
|   | Value of resistance 2 detected on the rotor of the motor   |        |        |         |      |       |        |           |
| 2840  | <b>Measured P1 flux</b>  | N/A    | RW     | Calc    | 0.00 | 1.000 | FK     | V-F-S     |
|   | P1 coefficient of the Flux curve measured  |        |        |         |      |       |        |           |
| 2850  | <b>Measured P2 flux</b>  | N/A    | RW     | Calc    | 3    | 18    | FK     | V-F-S     |
|   | P2 coefficient of the Flux curve measured  |        |        |         |      |       |        |           |
| 2860  | <b>Measured P3 flux</b>  | N/A    | RW     | Calc    | 0.00 | 1.00  | FK     | V-F-S     |
|   | P3 coefficient of the Flux curve measured  |        |        |         |      |       |        |           |
| 2870  | <b>Measured Im Nom</b>   | [A]    | RW     | Calc    | 0.00 | 0.00  | FK     | V-F-S     |
|   | Value of the rated magnetizing current   |        |        |         |      |       |        |           |



| IPA  | Description  | [Unit] | Access | Default | Min  | Max  | Format | Reg. Mode |
|------|--|--------|--------|---------|------|------|--------|-----------|
| 2880 | <b>Measured Im Max</b><br>Value of the maximum magnetizing current | [A]    | RW     | Calc    | 0.00 | 0.00 | FK     | V-F-S     |
| 2890 | <b>Measured Flux Nom</b><br>Value of the rated Flux                | [Wb]   | RW     | Calc    | 0.00 | 0.00 | FK     | V-F-S     |
| 2900 | <b>Measured Flux Max</b><br>Value of the maximum Flux              | [Wb]   | RW     | Calc    | 0.00 | 0.00 | FK     | V-F-S     |

### STARTUP / Startup config / Load setup

#### Load setup

Load setup command is required to load all SETUP MODE settings into the regulation mode selected. Entering this parameter, on the display will appear:

Load setup?

Yes -> Ent No -> Esc

- Press Enter to load the SETUP MODE settings.
- Press Escape if you do not want to load the SETUP MODE settings

**Note!** The operation is required for every Regulation mode (V, F, S and B)  
It is also required for every new setting made in the SETUP MODE.

If any changes / settings in **Motor data** and **Drive data** are detected, Load setup command is presented automatically to the user, respond Yes to load data.


### STARTUP / Startup config / Mechanical data

|      |   |       |     |      |      |      |    |         |
|------|---|-------|-----|------|------|------|----|---------|
| 1015 | <b>Travel units sel</b><br>0 Revolutions<br>1 Millimeters<br>It determines the units of "TRAVEL / Speed profile" and "TRAVEL / Ramp profile" menu parameters:<br>Revolutions = rpm, rpm/s and rpm/s <sup>2</sup> - Millimeters = mm/s, mm/s <sup>2</sup> and mm/s <sup>3</sup>  | N/A   | RWZ | 0    | 0    | 1    | DK | V-F-S-B |
| 1002 | <b>Gearbox ratio</b><br>Ratio between motor shaft speed and pulley speed. Eventual roping ratio must also be included.  | N/A   | RWZ | 35   | 1    | 100  | FK | V-F-S-B |
| 1003 | <b>Pulley diameter</b><br>Diameter of the pulley  | [mm]  | RWZ | 500  | 100  | 2000 | FK | V-F-S-B |
| 1885 | <b>Full scale speed</b><br>It defines the 100% of the application speed referenced. The absolute speed handling range is ± 200% Full scale speed.<br>For lift application set this parameter to maximum allowed motor speed, typically rated speed of the motor. This parameter will also set the limit on all multispeed values IPA 7060 - 7067. | [rpm] | RW  | 1500 | Calc | Calc | PV | V-F-S-B |

### STARTUP / Startup config / Weights

|      |  |                     |     |       |       |       |    |         |
|------|--|---------------------|-----|-------|-------|-------|----|---------|
| 1004 | <b>Car weight</b><br>Weight of the Lift car  | [kg]                | RWZ | 0.00  | 0.00  | 0.00  | FK | V-F-S-B |
| 1005 | <b>Counter weight</b><br>Weight of the counter mass to achieve balanced system                                       | [kg]                | RWZ | 0.00  | 0.00  | 0.00  | FK | V-F-S-B |
| 1006 | <b>Load weight</b><br>Maximum weight of Lift load (total persons weight)   | [kg]                | RWZ | 0.00  | 0.00  | 0.00  | FK | V-F-S-B |
| 1007 | <b>Rope weight</b><br>Total weight of Rope   | [kg]                | RWZ | 0.00  | 0.00  | 0.00  | FK | V-F-S-B |
| 1011 | <b>Motor inertia</b><br>Inertia of the motor, refer to motor manufacturer (if it is not available, leave to default) | [kgm <sup>2</sup> ] | RWZ | 0.000 | 0.000 | 0.000 | FK | V-F-S-B |


| IPA  | Description   | [Unit]              | Access | Default | Min   | Max   | Format | Reg. Mode |
|------|---|---------------------|--------|---------|-------|-------|--------|-----------|
| 1012 | <b>Gearbox inertia</b>  | [kgm <sup>2</sup> ] | RWZ    | 0.000   | 0.000 | 0.000 | FK     | V-F-S-B   |
|      | Inertia of the gearbox, refer to manufacturer (if it is not available, leave to default).<br>Can be set here the inertia of all mechanical parts at slow side of gearbox (ex. pulley, etc...) |                     |        |         |       |       |        |           |




| <b>STARTUP / Startup config / Landing zone</b> |   |      |      |          |    |        |     |     |
|--|---|------|------|----------|----|--------|-----|-----|
| 9411   | <b>Landing control</b>  | N/A  | RWZ  | 0        | 0  | 1      | DP  | F-B |
|  | 0 Disabled  |      |      |          |    |        |     |     |
|  | 1 Enabled   |      |      |          |    |        |     |     |
|  | Enable/Disable of accurate position control in landing zone   |      |      |          |    |        |     |     |
| 9419   | <b>Landing init src</b>   | N/A  | RWSZ | IPA 7124 |    | List 3 | PIN | F-B |
|  | IPA 7124 Lift Landing mon = Default<br>It allows to select the signal to initialize the close loop position control in the Landing Zone (leave to default if landing should be managed by internal lift control sequence; refer to signals List 3 of Pick List manual)) |      |      |          |    |        |     |     |
| 9412   | <b>Landing distance</b>   | [mm] | RWZ  | 100      | 10 | 1000   | PP  | F-B |
|  | Total distance between landing zone signal and floor position. Higher value allows faster positioning.  |      |      |          |    |        |     |     |
| 9420   | <b>Landing ratio</b>  | [%]  | RWZ  | 50       | 0  | 90     | PP  | F-B |
|  | Percentage of landing distance during which car runs at constant speed  |      |      |          |    |        |     |     |
| 9417   | <b>Pos P gain</b>   | [%]  | RWZ  | 1        | 0  | 100    | PP  | F-B |
|  | Proportional gain of position regulator   |      |      |          |    |        |     |     |

| IPA  | Description     | [Unit] | Access | Default | Min | Max  | Format | Reg. Mode |
|------|-----------------|--------|--------|---------|-----|------|--------|-----------|
| 9410 | Pos speed limit | [rpm]  | RWZ    | 200     | 0   | Calc | PP     | F-B       |

Maximum speed allowed to use by position controller



Landing sensor output can be interfaced to the drive through digital input which can become command to initialize landing control.



### STARTUP / Startup config / Encoders config

|      |               |             |    |   |   |   |    |       |
|------|---------------|-------------|----|---|---|---|----|-------|
| 1940 | Speed fbk sel | N/A         | RW | 0 | 0 | 1 | DV | V-F-B |
|      | 0             | Std encoder |    |   |   |   |    |       |
|      | 1             | Exp encoder |    |   |   |   |    |       |

It allows to switch the feedback between the encoder standard port "XE" (on RV33 regulation card) and the encoder expanded (from encoder optional cards: EXP-F2E and EXP-D14A4F)

**Note!** Expansion encoder cannot be used for speed feedback in Brushless mode.  
It can be used only for setting speed reference.

|      |              |     |     |   |    |    |       |
|------|--------------|-----|-----|---|----|----|-------|
| 1925 | Std enc type | N/A | RWZ | 0 | 12 | DK | V-F-B |
|------|--------------|-----|-----|---|----|----|-------|

Encoder type connected to the standard input. **Default: 1** for AVy ... AC/AC4, **4** for AVy ... BR/BR4  
Set allowed for AVy ... AC/AC4:

|   |                 |  |
|---|-----------------|--|
| 0 | Sinusoidal      | sinusoidal encoder, select the correct jumper settings on the reg. card, RV33                                      |
| 1 | Digital         | digital encoder  |
| 2 | Frequency input | digital single channel frequency input: channel A. Signal +5V must be connected between A and power supply common. |

Set allowed for AVy ... BR/BR4:

|   |                   |   |
|---|-------------------|---|
| 3 | Sinusoidal Hall   | sinusoidal incremental encoder with A+ / A-, B+ / B-, C+ / C- traces and three digital "Hall sensor" absolute position traces for initial synchronisation (factory setting) |
| 4 | Sinusoidal SinCos | sinusoidal incremental encoder with A+ / A-, B+ / B-, C+ / C- traces and two Sin/Cos absolute position traces for initial synchronisation                                   |
| 5 | Sinusoidal Extern | sinusoidal incremental encoder with A+ / A-, B+ / B- traces and   |

| IPA         | Description   | [Unit]   | Access  | Default     | Min         | Max         | Format    | Reg. Mode      |
|-------------|---|--|---|-------------|-------------|-------------|-----------|----------------|
|             |   |  | absolute position information through SSI serial interface for initial synchronisation (requires APC card)  |             |             |             |           |                |
| 6           | Digital Hall  |  | digital incremental encoder with A+ / A-, B+ / B-, C+ / C- traces and three digital "Hall sensor" absolute position traces for initial synchronisation (factory setting)                                |             |             |             |           |                |
| 7           | DigitalExtern   |  | digital incremental encoder with A+ / A-, B+ / B- traces and absolute position information through SSI serial interface for initial synchronisation (requires APC card)                                 |             |             |             |           |                |
| 8           | SinCos  |  | Sin / Cos absolute position traces for initial synchronisation, incremental information is not used.  |             |             |             |           |                |
| 9           | Resolver  |  | resolver using option cards: EXP-RES (refer its manual for jumpers 0 configurations)  |             |             |             |           |                |
| 10          | Sinusoidal Hiperface  |  | absolute encoder with Hiperface protocol ( <i>from software rel. 3.300</i> )  |             |             |             |           |                |
| 11          | Sinusoidal Intern   |  | sinusoidal incremental encoder with A+/A-,B+/B-, C+/C- traces, absolute position traces are not necessary because phasing is performed automatically at every start ( <i>from software rel. 3.500</i> ) |             |             |             |           |                |
| 12          | Digital Intern  |  | digital incremental encoder with A+/A-,B+/B-, C+/C- traces, absolute position traces are not necessary because phasing is performed automatically at every start ( <i>from software rel. 3.500</i> )    |             |             |             |           |                |
| <b>1890</b> | <b>Std enc pulses</b>   | <b>[ppr]</b>   | <b>RWZ</b>  | <b>1024</b> | <b>Calc</b> | <b>Calc</b> | <b>FK</b> | <b>V-F-S-B</b> |
|             | Encoder pulses per revolution (ppr) value of the standard input.<br>For brushless motors it is possible to use only the following values: 512, 1024, 2048, 4096, 8192.    |  |   |             |             |             |           |                |
| <b>1931</b> | <b>Std dig enc mode</b>   | <b>N/A</b>   | <b>RWZ</b>  | <b>0</b>    | <b>0</b>    | <b>1</b>    | <b>DP</b> | <b>V-F-S-B</b> |
|             | 0   | FP   | mode frequency and period measuring   |             |             |             |           |                |
|             | 1   | F  | mode frequency measuring  |             |             |             |           |                |
|             | Measuring method of the digital encoder speed connected to the standard input   |  |   |             |             |             |           |                |
| <b>1927</b> | <b>Std enc supply</b>   | <b>N/A</b>   | <b>RWZ</b>  | <b>0</b>    | <b>0</b>    | <b>3</b>    | <b>DP</b> | <b>V-F-S-B</b> |
|             | 0   | 5.41 / 8.16 V  |   |             |             |             |           |                |
|             | 1   | 5.68 / 8.62 V  |   |             |             |             |           |                |
|             | 2   | 5.91 / 9.00 V  |   |             |             |             |           |                |
|             | 3   | 6.16 / 9.46 V  |   |             |             |             |           |                |
|             | Selection between 5V / 8V range is done through dip-switch S28.<br>Power supply voltage of the standard Encoder input. Increase this value in case of long encoder cable. |  |   |             |             |             |           |                |
| <b>1902</b> | <b>Std sin enc Vp</b>   | <b>[V]</b>   | <b>RW</b>   | <b>0.5</b>  | <b>0</b>    | <b>1.5</b>  | <b>FK</b> | <b>V-F-B</b>   |
|             | Peak voltage value of the sinusoidal encoder connected to the standard input  |  |   |             |             |             |           |                |
| <b>1300</b> | <b>Std enc cnt dir</b>  | <b>N/A</b>   | <b>RWSZ</b>   | <b>0</b>    | <b>0</b>    | <b>1</b>    | <b>DP</b> | <b>V-F-S-B</b> |
|             | 0   | Not inverted   |   |             |             |             |           |                |
|             | 1   | Inverted   |   |             |             |             |           |                |
|             | Selection of standard encoder counting direction. It allows to change sign of measured speed, it is equivalent of swaping encoder channels AA- <-> BB-.                   |  |   |             |             |             |           |                |
| <b>1926</b> | <b>Exp enc type</b>   | <b>N/A</b>   | <b>RW</b>   | <b>1</b>    | <b>1</b>    | <b>2</b>    | <b>DK</b> | <b>V-F-B</b>   |
|             | Encoder type connected to the expanded input  |  |   |             |             |             |           |                |
|             | 1   | Digital digital encoder  |   |             |             |             |           |                |
|             | 2   | Frequency input digital single channel frequency input: channel A. Signal +5V must be connected between A and power supply common. |   |             |             |             |           |                |
|             | <b>NOTE!</b> For brushless motors expanded encoder cannot be used for speed feedback.<br>It can be used only for setting speed reference.                                 |  |   |             |             |             |           |                |

| IPA  | Description   | [Unit] | Access | Default | Min  | Max  | Format | Reg. Mode |
|------|---|--------|--------|---------|------|------|--------|-----------|
| 1900 | <b>Exp enc pulses</b><br>Encoder pulses per revolution (ppr) value of the expanded input.   | [ppr]  | RWZ    | 1024    | Calc | Calc | FK     | V-F-B     |
| 1301 | <b>Exp enc cnt dir</b><br>0 Not inverted<br>1 Inverted<br>Selection of expansion encoder counting direction. It allows to change sign of measured speed, it is equivalent of swapping encoder channels AA- <-> BB-. | N/A    | RWSZ   | 0       | 0    | 1    | DP     | V-F-B     |

### STARTUP / Startup config / Encoders config / Rep/Sim encoder

|      |   |     |     |      |   |      |    |     |
|------|---|-----|-----|------|---|------|----|-----|
| 1962 | <b>Rep/Sim enc sel</b><br>Selection of the encoder to be repeated using the optional card EXP-F2E.<br>0 Repeat std enc repeat standard encoder<br>1 Repeat exp enc repeat expanded encoder<br>2 Simulate std simulate digital incremental encoder in case of SinCos or Resolver selections as feedback devices in Std enc type parameter. | N/A | RWZ | 0    | 0 | 1    | DK | V-F |
| 1952 | <b>Sim enc pulses</b><br>Simulated encoder pulses per revolution (ppr) value (factory setting = 1024 ppr)   | N/A | RWZ | 1024 | 1 | Calc | FK | B   |

### STARTUP / Startup config / Encoders config / Index storing

|      |   |     |      |          |   |         |     |     |
|------|---|-----|------|----------|---|---------|-----|-----|
| 9550 | <b>Index storing en</b><br>Index storing function.<br>The encoder counts can be latched allowing the user to determine the position of the encoder relative to an absolute position.<br>0 Off<br>1 Storing enabled enables the capturing of the encoder count as described by the setting of the control word. The control word is the value of "Int IS ctrl" or the word selected by "IS ctrl src"<br>2 Control std enc it constantly reads all the generated pulses on the std encoder<br>3 Control exp enc it constantly reads all the generated pulses on the exp encoder | N/A | RWSZ | 0        | 0 | 3       | DV  | F-B |
| 9551 | <b>Int IS ctrl</b><br>Fixed programming at Index Storing Function according to following table.   | N/A | RWS  | 0        | 0 | 0X0000  | DV  | F-B |
| 9557 | <b>IS ctrl src</b><br>IPA 9551 Int IS ctrl = Default<br>It allows to select the origin of the signal for "Index storing function" command.<br>For example a SBI word or DGFC word (refer to signals List 39 of Pick List manual)  | N/A | RWSZ | IPA 9551 |   | List 39 | PIN | F-B |

**Note!** Digital inputs 6 and 7 (terminals 38 and 39) are dedicated to the use of the "Index Qualifier" (home position switch) when Index storing is enabled.

In the next table are showed the values of **IS ctrl src** from SBI word, DGFC word or *Int IS ctrl* if:  
**IS ctrl src** = *Int IS ctrl*

| IPA | Description    | [Unit]         | Access  | Default | Min | Max | Format                     | Reg. Mode      |
|-----|----------------|----------------|---|---------|-----|-----|----------------------------|----------------|
|     | <b>No. bit</b> | <b>Name</b>    | <b>Description</b>  |         |     |     | <b>Access (Read/Write)</b> | <b>Default</b> |
|     | 0-1            | -              | Not used  |         |     |     | -                          | -              |
|     | 2              | POLNLT         | It indicates the encoder index edge polarity:<br>0= rising edge<br>1= falling edge  |         |     |     | R/W                        | 0              |
|     | 3              | -              | Not used  |         |     |     | -                          | -              |
|     | 4-5            | ENNQUAL        | It sets the qualifier input state to activate the encoder index reading:<br>=0, switched off when dig.input 7 = 0<br>=1, switched off when dig.input 7 = 1<br>=2, through signal = 0<br>=3, through signal = 1        |         |     |     | W                          | 0              |
|     | 6              | Target Enc Num | It points out for which encoder the values of this parameter are reported:<br>=0, operations requested on the Std Encoder input<br>=1, operations requested on the Exp Encoder input                                  |         |     |     | R/W                        | 0              |
|     | 7              | -              | Not used  |         |     |     | -                          | -              |
|     | 8-9            | ENNLT          | Control function of the encoder index reading<br>=0, switched off, function disabled<br>=1, once, enables the reading of the first index signal edge only.<br>=2, continuous, enables the reading of the index signal |         |     |     | R/W                        | 0              |

TAV13241

For the Index storing function, **the status Registers are not available via keypad** and are to be used for the configuration and the data reading. These are:

L index register IPA9556

H index register IPA9555

In the next table are showed the registers values:

| Ipa  | No. bit | Name           | Description   | Access (Read/Write) | Default |
|------|---------|----------------|---|---------------------|---------|
| 9556 | 0       | Source Enc Num | It indicates which encoder is used for index storing:<br>=0, register data are referred to the Std Encoder input<br>=1, register data are referred to the Exp Encoder input | R                   | 0       |
|      | 1       | MP_IN          | Actual Qualifier input value (digital input 7):<br>=0, qualifier input level is low<br>=1, qualifier input level is high  | R                   | 0       |
|      | 2-3     | STATNLT        | Status of the acquisition function; as:<br>0=OFF<br>1=Once, storing is not executed yet<br>2=Once, storing is already executed<br>3=Continuous                              | R                   | 0       |
| 9555 | 0-15    | CNTNLT         | Position counter value corresponding to the index.<br>Value is only valid when STANLT is equal to 2 or 3  | R                   | 0       |

indexstorpar

|             |                         |            |           |             |             |           |           |          |
|-------------|-------------------------|------------|-----------|-------------|-------------|-----------|-----------|----------|
| <b>1936</b> | <b>Motor pp/sens pp</b> | <b>N/A</b> | <b>RW</b> | <b>Calc</b> | <b>Calc</b> | <b>32</b> | <b>PP</b> | <b>B</b> |
|-------------|-------------------------|------------|-----------|-------------|-------------|-----------|-----------|----------|

Ratio between motor pole pairs and feedback sensor pole pairs, typically used for resolver.

### STARTUP / Startup config / SpdReg gain calc

|             |                    |            |            |          |          |          |           |              |
|-------------|--------------------|------------|------------|----------|----------|----------|-----------|--------------|
| <b>2048</b> | <b>Calc method</b> | <b>N/A</b> | <b>RWZ</b> | <b>0</b> | <b>0</b> | <b>1</b> | <b>DK</b> | <b>F-S-B</b> |
|-------------|--------------------|------------|------------|----------|----------|----------|-----------|--------------|

With "Calc method" two gain calculation methods can be selected:

0 Variable bandw speed regulation bandwidth is internally selected according to the principle that bandwidth is decreased as inertia is increased


1 Fixed bandw speed regulation bandwidth is specified by parameter "Bandwidth"

It allows to perform the speed regulator gain calculation. Inertia must be entered through the "Calc Inertia" parameter or specifying parameters in Weights menu.

| IPA  | Description   | [Unit]              | Access | Default | Min | Max | Format | Reg. Mode |
|------|---|---------------------|--------|---------|-----|-----|--------|-----------|
| 2610 | <b>Calc Inertia</b><br>Inertia of the load. When parameters in Weights menu have been set, the result of system inertia referred to the motor shaft is set in this parameter. | [kgm <sup>2</sup> ] | RWZ    | D.Size  | 0   | 0   | FK     | F-S-B     |
| 2049 | <b>Bandwidth</b><br>Speed regulator bandwidth. Higher bandwidth value makes motor respond faster and overall result is more stiff control.                                    | [rad/s]             | RWZ    | 50      | 1   | 400 | FK     | F-S-B     |

### STARTUP / Startup config / V/f config

|      |   |      |     |      |      |      |    |   |
|------|---|------|-----|------|------|------|----|---|
| 3420 | <b>V/f voltage</b><br>Base voltage for the V/f mode. This parameter is set according to motor nominal voltage, but can be changed to modify V/f characteristic.       | [V]  | RWZ | Motr | Calc | Calc | FK | V |
| 3430 | <b>V/f frequency</b><br>Base frequency for the V/f mode. This parameter is set according to motor nominal frequency, but can be changed to modify V/f characteristic. | [Hz] | RWZ | Motr | 5    | Calc | FK | V |



### STARTUP / Startup config / Motor protection


I2t function is similar to the protection of the motor by the thermal relay. It states the I2t typical behavior. The integrator state is given by **Mot OL accum %**, it gives the percentage state of the Rms current integration, 100 % = I2t alarm level. **Mot OL trip** signal is available in the pick-list selections. It states that the trip condition of I2t has been reached and overload is not allowed. The intervention time depends on the value of the motor current as follows:

$$\text{Overload time} = \frac{(\text{Motor Rated current} * \text{Service factor} * \text{Motor OL factor})^2 * \text{Motor OL time}}{(\text{Motor current})^2}$$

It is possible to generate an alarm condition or reduce eventual overload current to nominal current of the motor. For various options of alarm configuration see menu ALARM CONFIG / Motor overload.

|      |  |       |    |    |     |      |    |         |
|------|--|-------|----|----|-----|------|----|---------|
| 1612 | <b>Motor OL control</b><br>0 Disabled<br>1 Enabled<br>Enable / disable motor current limit control and overload I2t protection function<br>(from software rel. 3.300).               | N/A   | RW | 0  | 0   | 1    | DK | V-F-S-B |
| 1611 | <b>Service factor</b><br>Service factor. Some motors have a motor continuous current (Ic) higher than the rated current (In). The service factor makes reference to the Ic/In ratio. | N/A   | RW | 1  | 0.5 | 1.5  | FK | V-F-S-B |
| 1610 | <b>Motor OL factor</b><br>Allowed motor overload factor referring to the Motor rated current * Service factor  | N/A   | RW | 2  | 1.2 | Calc | FK | V-F-S-B |
| 1650 | <b>Motor OL time</b><br>Allowed overload time with overload level equal to Motor OL factor.  | [sec] | RW | 30 | 10  | Calc | FK | V-F-S-B |

| IPA | Description | [Unit] | Access | Default | Min | Max | Format | Reg. Mode |
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|




- (1) Rated current • Service factor = 100%
- (2) Motor OL factor
- (3) Motor OL time

### STARTUP / Startup config / BU protection

The function protects braking resistor by monitoring current in the resistor according to I<sup>2</sup>t characteristic. When the protection becomes active, it is possible to generate an alarm condition. According to the different cases it is possible to use the device internal IGBT (or external braking unit).

|             |  |              |            |               |             |              |           |   |
|-------------|--|--------------|------------|---------------|-------------|--------------|-----------|---|
| <b>1700</b> | <b>BU control</b>  | <b>[N/A]</b> | <b>RWZ</b> | <b>1</b>      | <b>0</b>    | <b>2</b>     | <b>DP</b> | <b>V-F-S-B</b>                                |
|             | 0 Off  |              |            |               |             |              |           | Function disabled                             |
|             | 1 Internal   |              |            |               |             |              |           | Enable Braking Unit internal device (Default) |
|             | 2 External   |              |            |               |             |              |           | Enable Braking Unit external BUy device       |
|             | The parameter enables the Braking Unit function.   |              |            |               |             |              |           |   |
| <b>1740</b> | <b>BU resistance</b>   | <b>[ohm]</b> | <b>RWZ</b> | <b>D.Size</b> | <b>Calc</b> | <b>10000</b> | <b>FK</b> | <b>V-F-S-B</b>                                |
|             | Braking Unit resistance value, mounted optional on the power section terminals or external (C & BR1)   |              |            |               |             |              |           |   |
| <b>1710</b> | <b>BU res cont pwr</b>   | <b>[kW]</b>  | <b>RWZ</b> | <b>D.Size</b> | <b>0</b>    | <b>0</b>     | <b>FK</b> | <b>V-F-S-B</b>                                |
|             | Braking Unit resistance continuous power   |              |            |               |             |              |           |   |
| <b>1720</b> | <b>BU res OL time</b>  | <b>[sec]</b> | <b>RWZ</b> | <b>D.Size</b> | <b>1</b>    | <b>1000</b>  | <b>FK</b> | <b>V-F-S-B</b>                                |
|             | Resistance allowed overload time referring to the overload power. The control of the external braking unit and of the resistance I <sup>2</sup> t protection is independent of BU type (BU digital output command, is available, on the regulation card terminals ). |              |            |               |             |              |           |   |
| <b>1730</b> | <b>BU res OL factor</b>  | <b>[N/A]</b> | <b>RWZ</b> | <b>D.Size</b> | <b>1.2</b>  | <b>20</b>    | <b>FK</b> | <b>V-F-S-B</b>                                |
|             | Allowed overload factor referring to the overload power of the braking resistance. Overload factor = overload Power/ rated Power   |              |            |               |             |              |           |   |



- (1) BU res cont power
- (2) BU res OL factor
- (3) BU res OL time



| IPA | Description | [Unit] | Access | Default | Min | Max | Format | Reg. Mode |
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|

## STARTUP / Startup config / Load default ?

### Load default ?

Drive reset with default parameter values in the selected regulation mode only.  
Each regulation mode has its own “Load default ?” command.

**Note!** “Load default ?” command does not reset SETUP MODE with default parameter values; Drive, Motor data and Autotune values are maintained.

Use Save config command to save default parameter values such that are preserved for next power up.

## STARTUP / Startup config / Load saved ?

### Load saved ?

Reload of the last saved database selected.

## STARTUP / Regulation mode

| 100 | Regulation mode   | N/A                              | R | 0 | 0 | 5 | DK | V-F-S-B |
|-----|---|----------------------------------|---|---|---|---|----|---------|
|     | It allows to select the desired regulation mode. When the Regulation mode parameter is selected, the active regulation mode is displayed; in order to change it to a new mode press “Enter”; Select new mode will be displayed, then scroll the list: |                                  |   |   |   |   |    |         |
|     | 0   | V/f control                      |   |   |   |   |    |         |
|     | 1   | Field oriented                   |   |   |   |   |    |         |
|     | 2   | Sensorless                       |   |   |   |   |    |         |
|     | 3   | Setup mode (asynchronous motors) |   |   |   |   |    |         |
|     | 4   | Brushless                        |   |   |   |   |    |         |
|     | 5   | Setup mode (brushless motors)    |   |   |   |   |    |         |
|     | After new regulation mode is selected, it is possible to copy (transfer) parameters from previous regulation mode. This operation is convenient if drive has been parametrized in previous regulation mode ( <i>from software rel. 3.500</i> ).       |                                  |   |   |   |   |    |         |
|     | <b>Note!</b> Appropriate firmware is required using the drive in Brushless mode   |                                  |   |   |   |   |    |         |

## STARTUP / Import recipe

In recipe user can store its configuration of parameters for a given application. By re-calling appropriate recipe file all the necessary application parameters are set by a single command. Recipe files must be filled with parameters in the factory (please contact drive manufacturer). Available are 7 recipe files that are empty in default configuration. Only parameters outside STARTUP menu can be put to recipe files.

Select recipe:

|   |        |
|---|--------|
| 1 | User 1 |
| 2 | User 2 |
| 3 | User 3 |
| 4 | User 4 |
| 5 | User 5 |
| 6 | User 6 |
| 7 | User 7 |

## STARTUP / Save config ?

AVyL drive allows two different commands to save the parameters modified in the regulation mode selected:

- by STARTUP menu, “Save Config?” command
- by all other menus, “SAVE PARAMETERS” command

Any changes made in STARTUP menu require “Save Config?” command, which saves all entire regulation mode selected. It is recommended every time the user made any changes into STARTUP menu.

“SAVE PARAMETERS” command saves all the changes made out of STARTUP menu only.

When on the keypad display appears blinking message “Use Save Config”, use “Save Config?” command.

| IPA | Description | [Unit] | Access | Default | Min | Max | Format | Reg. Mode |
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|


## TRAVEL

### TRAVEL / Speed profile

The parameters unit is defined by IPA 1015 in “STARTUP / Startup config / Mechanical data” menu, changing the IPA 1015 setting from [0] Revolutions (default) to [1] Millimeters, the units in this menu change as follows: [rpm] becomes [mm/s], [rpm/s] becomes [mm/s<sup>2</sup>], [rpm/s<sup>2</sup>] becomes [mm/s<sup>3</sup>].

**7110 Smooth start spd** [rpm] RWS 0 Calc Calc PP V-F-S-B

Smooth start speed is selected automatically after start command independently from multispeed value. Duration of this special speed depends on Smooth start dly parameter. If this parameter is zero, Smooth start spd is not selected and multispeed values prevails. Smooth start speed can be used to optimise feeling at starting in some types of installations.



**Note!** “Smooth start dly” can be set in TRAVEL / Lift sequence menu.

|             |                                       |        |     |      |      |      |    |         |
|-------------|---------------------------------------|--------|-----|------|------|------|----|---------|
| <b>7060</b> | <b>Multi speed 0</b><br>Speed 0 value | [rpm]  | RWS | 0    | Calc | Calc | PV | V-F-S-B |
| <b>7061</b> | <b>Multi speed 1</b><br>Speed 1 value | [rpm]  | RWS | 0    | Calc | Calc | PP | V-F-S-B |
| <b>7062</b> | <b>Multi speed 2</b><br>Speed 2 value | [rpm]  | RWS | 0    | Calc | Calc | PP | V-F-S-B |
| <b>7063</b> | <b>Multi speed 3</b><br>Speed 3 value | [rpm]  | RWS | 0    | Calc | Calc | PP | V-F-S-B |
| <b>7064</b> | <b>Multi speed 4</b><br>Speed 4 value | [rpm]  | RWS | 0    | Calc | Calc | PP | V-F-S-B |
| <b>7065</b> | <b>Multi speed 5</b><br>Speed 5 value | [rpm]  | RWS | 0    | Calc | Calc | PP | V-F-S-B |
| <b>7066</b> | <b>Multi speed 6</b><br>Speed 6 value | [rpm]  | RWS | 0    | Calc | Calc | PP | V-F-S-B |
| <b>7067</b> | <b>Multi speed 7</b><br>Speed 7 value | [rpm]  | RWS | 0    | Calc | Calc | PP | V-F-S-B |
| <b>7134</b> | <b>Max linear speed</b>               | [mm/s] | R   | Calc | 0    | 0    | FK | V-F-S-B |

### TRAVEL / Ramp profile

The parameters unit is defined by IPA 1015 in “STARTUP / Startup config / Mechanical data” menu, changing the


| IPA | Description | [Unit] | Access | Default | Min | Max | Format | Reg. Mode |
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|

IPA 1015 setting from [0] Revolutions (default) to [1] Millimeters, the units in this menu change as follows:

[rpm] becomes [mm/s], [rpm/s] becomes [mm/s<sup>2</sup>], [rpm/s<sup>2</sup>] becomes [mm/s<sup>3</sup>].

Two different sets of ramp profiles (MRO ... and MR1 ...) are available; the selection is done by parameter

Mlt ramp sel src (IPA 8090) into "TRAVEL / Lift sequence" menu. Default is MRO ...



|      |   |                       |     |      |       |         |    |         |
|------|---|-----------------------|-----|------|-------|---------|----|---------|
| 8046 | <b>MRO acc ini jerk</b><br>Acceleration initial jerk, set 0                                 | [rpm/s <sup>2</sup> ] | RWS | 1000 | 0.349 | 750*100 | PP | V-F-S-B |
| 8040 | <b>MRO acceleration</b><br>Acceleration ramp, set 0   | [rpm/s]               | RWS | 500  | 1     | 1.5*106 | PP | V-F-S-B |
| 8041 | <b>MRO acc end jerk</b><br>Acceleration end jerk, set 0                                     | [rpm/s <sup>2</sup> ] | RWS | 1000 | 0.349 | 750*106 | PP | V-F-S-B |
| 8047 | <b>MRO dec ini jerk</b><br>Deceleration initial jerk, set 0                                 | [rpm/s <sup>2</sup> ] | RWS | 1000 | 0.349 | 750*106 | PP | V-F-S-B |
| 8042 | <b>MRO deceleration</b><br>Deceleration ramp, set 0   | [rpm/s]               | RWS | 500  | 1     | 1.5*106 | PP | V-F-S-B |
| 8043 | <b>MRO dec end jerk</b><br>Deceleration end jerk, set 0                                     | [rpm/s <sup>2</sup> ] | RWS | 1000 | 0.349 | 750*106 | PP | V-F-S-B |
| 8044 | <b>MRO end decel</b><br>Final deceleration slope corresponding to removal of START command. | [rpm/s]               | RWS | 1000 | 1     | 1.5*106 | PP | V-F-S-B |
| 8056 | <b>MR1 acc ini jerk</b><br>Acceleration initial jerk, set 1                                 | [rpm/s <sup>2</sup> ] | RWS | 1000 | 0.349 | 750*106 | PP | V-F-S-B |
| 8050 | <b>MR1 acceleration</b><br>Acceleration ramp, set 1   | [rpm/s]               | RWS | 500  | 1     | 1.5*106 | PP | V-F-S-B |
| 8051 | <b>MR1 acc end jerk</b><br>Acceleration end jerk, set 1                                     | [rpm/s <sup>2</sup> ] | RWS | 1000 | 0.349 | 750*106 | PP | V-F-S-B |

| IPA  | Description   | [Unit]                | Access | Default | Min   | Max     | Format | Reg. Mode |
|------|---|-----------------------|--------|---------|-------|---------|--------|-----------|
| 8057 | <b>MR1 dec ini jerk</b><br>Deceleration initial jerk, set 1   | [rpm/s <sup>2</sup> ] | RWS    | 1000    | 0.349 | 750*106 | PP     | V-F-S-B   |
| 8052 | <b>MR1 deceleration</b><br>Deceleration ramp, set 1   | [rpm/s]               | RWS    | 500     | 1     | 1.5*106 | PP     | V-F-S-B   |
| 8053 | <b>MR1 dec end jerk</b><br>Deceleration end jerk, set 1   | [rpm/s <sup>2</sup> ] | RWS    | 1000    | 0.349 | 750*106 | PP     | V-F-S-B   |
| 8054 | <b>MR1 end decel</b><br>Final deceleration slope corresponding to removal of START command.   | [rpm/s]               | RWS    | 1000    | 1     | 1.5*106 | PP     | V-F-S-B   |
| 9421 | <b>SlowDown dist</b><br>It allows to calculate the distance from running speed to approach speed if for running speed and approach speed Multispeed 1 and Multispeed 0 are used respectively. | [mm]                  | RW     | 0.00    | 0.00  | 0.00    | FK     | V-F-S-B   |

#### SlowDown dist Calculate ?

Executing "Calculate ?" using Enter key, will be calculate the distance from running speed to approach speed.

**NOTE!** It is available only if IPA 1015 Travel units sel parameter is set to Millimeters.

| TRAVEL / Lift sequence |  |      |     |          |      |        |     |         |
|------------------------|--|------|-----|----------|------|--------|-----|---------|
| 7100                   | <b>Cont close delay</b><br>Output contactor close delay. See Chapter 8 - Lift Sequencies   | [ms] | RWS | 200      | 0.00 | 65535  | PP  | V-F-S-B |
| 7101                   | <b>Brake open delay</b><br>See Chapter 8 - Lift Sequencies   | [ms] | RWS | 0.00     | 0.00 | 65535  | PP  | V-F-S-B |
| 7102                   | <b>Smooth start dly</b><br>See IPA 7110 into "TRAVEL / Speed profile" menu.  | [ms] | RWS | 0.00     | 0.00 | 65535  | PP  | V-F-S-B |
| 7103                   | <b>Brake close dly</b><br>See Chapter 8 - Lift Sequencies  | [ms] | RWS | 200      | 0.00 | 65535  | PP  | V-F-S-B |
| 7104                   | <b>Cont open delay</b><br>Output contactors open delay. See Chapter 8 - Lift Sequencies  | [ms] | RWS | 200      | 0.00 | 65535  | PP  | V-F-S-B |
| 7105                   | <b>Seq start mode</b><br>0 Start fwd/rev<br>1 Enable<br>2 Mlt spd out !=0<br><i>(from software rel. 3.500).</i><br>It changes the way how contactor sequence starts:<br>"Start fwd/rev" selection allows to start contactor sequence without Enable command (Enable is required only to run the motor). Enable signal can be given by an auxiliary contact of output contactors "Enable" selection allows to start contactor sequences only with Enable command.<br>"Mlt spd out !=0" selection allows to start contactor sequences with multispeed selection.<br>Non zero multi speed value will cause sequence start. Start command must be also asserted. | N/A  | RWS | 0        | 0    | 2      | DP  | V-F-S-B |
| 7106                   | <b>Seq start sel</b><br>0 Standard inp Using Start fwd / rev src input<br>1 Alternative inp Using Start alt src input  | N/A  | RWS | 0        | 0    | 1      | DP  | V-F-S-B |
| 7115                   | <b>Start fwd src</b><br>IPA 4021 DI 1 monitor = Default (refer to signals List 3 of Pick List manual)  | N/A  | RWS | IPA 4021 |      | List 3 | PIN | V-F-S-B |
| 7116                   | <b>Start rev src</b><br>IPA 4022 DI 2 monitor = Default (refer to signals List 3 of Pick List manual)  | N/A  | RWS | IPA 4022 |      | List 3 | PIN | V-F-S-B |
| 7117                   | <b>Start alt src</b><br>IPA 4000 NULL = Default  | N/A  | RWS | IPA 4000 |      | List 3 | PIN | V-F-S-B |
| 7072                   | <b>Mlt spd s 0 src</b><br>DI 4 monitor = Default<br>It allows to select the origin of the signals stating the input combination of multispeed function.  | N/A  | RWS | IPA 4024 |      | List 3 | PIN | V-F-S-B |

| IPA         | Description   | [Unit]            | Access     | Default           | Min         | Max           | Format          | Reg. Mode      |
|-------------|---|-------------------|------------|-------------------|-------------|---------------|-----------------|----------------|
|             | (Mlt spd s 0 - 1 - 2 sources; refer to signals List 3 of Pick List manual)  |                   |            |                   |             |               |                 |                |
| <b>7073</b> | <b>Mlt spd s 1 src</b><br>DI 5 monitor = Default<br>It allows to select the origin of the signals stating the input combination of multispeed function.<br>(Mlt spd s 0 - 1 - 2 sources; refer to signals List 3 of Pick List manual) | <b>N/A</b>        | <b>RWS</b> | <b>IPA 4025</b>   |             | <b>List 3</b> | <b>PIN</b>      | <b>V-F-S-B</b> |
| <b>7074</b> | <b>Mlt spd s 2 src</b><br>DI 6 monitor = Default<br>It allows to select the origin of the signals stating the input combination of multispeed function.<br>(Mlt spd s 0 - 1 - 2 sources; refer to signals List 3 of Pick List manual) | <b>N/A</b>        | <b>RWS</b> | <b>IPA 4025</b>   |             | <b>List 3</b> | <b>PIN</b>      | <b>V-F-S-B</b> |
|             | Mtl spd sel 2 src   | Mtl spd sel 1 src |            | Mtl spd sel 0 src |             |               | ACTIVE RAMP REF |                |
|             | 0   | 0                 |            | 0                 |             |               | Multi speed 0   |                |
|             | 0   | 0                 |            | 1                 |             |               | Multi speed 1   |                |
|             | 0   | 1                 |            | 0                 |             |               | Multi speed 2   |                |
|             | 0   | 1                 |            | 1                 |             |               | Multi speed 3   |                |
|             | 1   | 0                 |            | 0                 |             |               | Multi speed 4   |                |
|             | 1   | 0                 |            | 1                 |             |               | Multi speed 5   |                |
|             | 1   | 1                 |            | 0                 |             |               | Multi speed 6   |                |
|             | 1   | 1                 |            | 1                 |             |               | Multi speed 7   |                |
| <b>7069</b> | <b>Mlt spd sel mon</b><br>Active selection displaying (Multispeed 0, Multispeed 1, etc.)  | <b>N/A</b>        | <b>R</b>   | <b>0</b>          | <b>0</b>    | <b>7</b>      | <b>DP</b>       | <b>V-F-S-B</b> |
| <b>7070</b> | <b>Mlt spd out mon</b><br>It displays multispeed block output signal  | <b>[rpm]</b>      | <b>R</b>   | <b>0.00</b>       | <b>0.00</b> | <b>0.00</b>   | <b>PV</b>       | <b>V-F-S-B</b> |
| <b>8090</b> | <b>Mlt ramp sel src</b><br>IPA 4000 NULL = Default<br>It allows to select the origin of the signals stating Multi ramp input combination (Mlt ramp s0-1 src; refer to signals List 3 of Pick List manual)                             | <b>N/A</b>        | <b>RWS</b> | <b>IPA 4000</b>   |             | <b>List 3</b> | <b>PIN</b>      | <b>V-F-S-B</b> |
|             | Multi Ramp sel src  |                   |            | Active set        |             |               |                 |                |
|             | 0   |                   |            | MRO               |             |               |                 |                |
|             | 1   |                   |            | MR1               |             |               |                 |                |
| <b>8078</b> | <b>Mlt ramp sel mon</b><br>Displaying of the selected ramp set  | <b>N/A</b>        | <b>R</b>   | <b>0</b>          | <b>0</b>    | <b>3</b>      | <b>DP</b>       | <b>V-F-S-B</b> |
| <b>7143</b> | <b>Door open src</b><br>IPA 4000 NULL = Default (refer to signals List 3 of Pick List manual)<br>Source to Enable the function through the digital input.   | <b>N/A</b>        | <b>RWS</b> | <b>IPA 4000</b>   |             | <b>List 3</b> | <b>PIN</b>      | <b>V-F-S-B</b> |
| <b>7138</b> | <b>Door open speed</b><br>Door open speed threshold.  | <b>[rpm]</b>      | <b>RWS</b> | <b>0.00</b>       | <b>0.00</b> | <b>Calc</b>   | <b>PP</b>       | <b>V-F-S-B</b> |



### Door open control function.

This function allows anticipated door open control before the car arrival at the floor level. Door open signal can be given on digital output when speed drops below settable threshold. The function must be enabled by the digital input. Status of the speed checking command execution to open the door can be checked by providing the feedback from door open mechanism to drive digital input.

Alarm can be generated if command and feedback don't match.

| IPA  | Description  | [Unit] | Access | Default  | Min | Max    | Format | Reg. Mode |
|------|--|--------|--------|----------|-----|--------|--------|-----------|
| 7118 | <b>Brake open src</b>  | N/A    | RWS    | IPA 4001 |     | List 3 | PIN    | V-F-S-B   |
|      | Source to enable brake release through the digital input. In standard sequence brake release is controlled by the drive and therefore this parameter is set to ONE. In case that brake release should be conditioned by some external control (e.g. PLC), set this parameter to digital input controlled by PLC. |        |        |          |     |        |        |           |
|      | Internal sequence for brake release will wait until this input is asserted.  |        |        |          |     |        |        |           |
|      | During run brake will be closed whenever this input becomes not asserted.  |        |        |          |     |        |        |           |


### TRAVEL / Speed reg gains

Allows to change speed regulation gain according to speed reference. Typically at low speed high gains are required to have good starting behavior. At high speed lower gains are preferred to suppress eventual vibrations due to mechanical imperfections. In case that values above 100% are required to achieve desired speed response increase gains base values in menu “REGULATION PARAM / Spd regulator / Base values”, IPA 2075 and 2077. When base values are increased percentage values are reduced such that resulting gain used by regulator preserves original value. At this point percentage values can be increased.

**NOTE!** “Bands %” and “Thr%” can be set in TRAVEL/Speed threshold menu.

#### Default configuration (Spd 0 enable = Disable, only parameters 21 are set):


Gains #1 are used for middle (accel / decel) and high speed  
 Gains #2 are used at low speed (starting and approach speed)



| IPA | Description | [Unit] | Access | Default | Min | Max | Format | Reg. Mode |
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|


**Possible configuration (\$pd 0 enable = Disable, also parameters 32 are set):**

Gains #1 are used for high speed (running)  
 Gains #2 are used for middle (accel / decel) speed  
 Gains #3 are used for low speed (starting / stopping)



**Possible configuration (\$pd 0 enable = Enable as spd 0, only parameters 21 are set):**

Gains #1 are used for high speed (running)  
 Gains #2 are used for middle (accel / decel) speed  
 Gains #0 are used for low speed (starting / stopping)



| IPA | Description | [Unit] | Access | Default | Min | Max | Format | Reg. Mode |
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|


**Possible configuration (Spd 0 enable = Enable as start, also parameters 32 are set):**

Gains #1 are used for high speed (running)

Gains #2 are used for middle (accel / decel) speed

Gains #3 are used for stopping


Gains #0 are used for starting



|             |   |   |      |      |   |     |    |       |
|-------------|---|---|------|------|---|-----|----|-------|
| <b>3700</b> | <b>SpdP1 gain %</b>   | [%]   | RWS  | 10   | 0 | 100 | PP | F-S-B |
|             | Proportional speed 1 regulator gain at high speed   |   |      |      |   |     |    |       |
| <b>3701</b> | <b>SpdI1 gain %</b>   | [%]   | RWS  | 10   | 0 | 100 | PP | F-S-B |
|             | Integral speed 1 regulator gain at high speed   |   |      |      |   |     |    |       |
| <b>3702</b> | <b>SpdP2 gain %</b>   | [%]   | RWS  | 10   | 0 | 100 | PP | F-S-B |
|             | Proportional speed 2 regulator gain at medium speed   |   |      |      |   |     |    |       |
| <b>3703</b> | <b>SpdI2 gain %</b>   | [%]   | RWS  | 10   | 0 | 100 | PP | F-S-B |
|             | Integral speed 2 regulator gain at medium speed   |   |      |      |   |     |    |       |
| <b>3704</b> | <b>SpdP3 gain %</b>   | [%]   | RWS  | 10   | 0 | 100 | PP | F-S-B |
|             | Proportional speed 3 regulator gain at low speed  |   |      |      |   |     |    |       |
| <b>3705</b> | <b>SpdI3 gain %</b>   | [%]   | RWS  | 10   | 0 | 100 | PP | F-S-B |
|             | Integral speed 3 regulator gain at low speed  |   |      |      |   |     |    |       |
| <b>3720</b> | <b>Spd 0 enable</b>   | N/A   | RWS  | 0    | 0 | 1   | DP | F-S-B |
|             | Apart from gain adaptive function, it is possible to have another set of gains when speed reference is below Speed 0 reference threshold parameter. Function must be enabled by this parameter. |   |      |      |   |     |    |       |
|             | 0   | Disable                                     |      |      |   |     |    |       |
|             | 1   | Enable as spd 0                             |      |      |   |     |    |       |
|             | 2   | Enable as start (from software rel. 3.300). |      |      |   |     |    |       |
| <b>3722</b> | <b>Spd 0 P gain %</b>   | [%]   | RWS  | Calc | 0 | 100 | PP | F-S-B |
|             | Proportional speed 0 regulator gain at zero speed   |   |      |      |   |     |    |       |
| <b>3723</b> | <b>Spd 0 I gain %</b>   | [%]   | RWS  | Calc | 0 | 100 | PP | F-S-B |
|             | Integral speed 0 regulator gain at zero speed   |   |      |      |   |     |    |       |
| <b>2530</b> | <b>Sfbk der enable</b>  | N/A   | RWSZ | 0    | 0 | 1   | DV | F-S-B |
|             | Speed feedback derivative function enable / disable.  |   |      |      |   |     |    |       |




| IPA | Description | [Unit] | Access | Default | Min | Max | Format | Reg. Mode |
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|
| 0   | Disable     |        |        |         |     |     |        |           |
| 1   | Enable      |        |        |         |     |     |        |           |



|      |   |      |     |       |      |       |    |       |
|------|---|------|-----|-------|------|-------|----|-------|
| 2540 | <b>Sfbk der gain</b><br>Speed feedback derivative gain.   | [%]  | RWS | 0     | -100 | 100   | PV | F-S-B |
| 2550 | <b>Sfbk der base</b><br>Base feedback derivative gain.  | [ms] | RWS | 10000 | 0    | 10000 | FK | F-S-B |
| 2560 | <b>Sfbk der filter</b><br>Speed feedback derivative filter  | [ms] | RWS | 5     | 0    | 1000  | PP | F-S-B |
| 2380 | <b>Prop filter</b><br>Filter on the proportional part of torque reference. Can be used to suppress the noise. | [ms] | RWS | 1.5   | 0.15 | 1000  | PP | F-S-B |

### TRAVEL / Speed threshold


|      |   |       |     |     |   |       |    |         |
|------|---|-------|-----|-----|---|-------|----|---------|
| 3726 | <b>Spd 0 ref thr</b><br>Speed 0 reference threshold | [rpm] | RWS | 30  | 0 | 0     | PP | V-F-S-B |
| 3727 | <b>Spd 0 ref delay</b><br>Speed 0 reference delay   | [ms]  | RWS | 500 | 0 | 30000 | PP | V-F-S-B |



**NOTE!** “Ref is zero” and “Ref is zero dly” signals are available in the pick-lists of the digital outputs. “Brake cont mon” signal is available a digital relay output (83-85 terminals).

|      |  |       |     |      |   |       |    |         |
|------|--|-------|-----|------|---|-------|----|---------|
| 3724 | <b>Spd 0 speed thr</b><br>Speed 0 speed threshold. | [rpm] | RWS | 30   | 0 | 0     | PP | V-F-S-B |
| 3725 | <b>Spd 0 spd delay</b><br>Speed 0 speed delay      | [ms]  | RWS | 1000 | 0 | 30000 | PP | V-F-S-B |

| IPA | Description | [Unit] | Access | Default | Min | Max | Format | Reg. Mode |
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|




**Note!** “Spd is zero” and “Spd is zero dly” signals are available in the pick-lists of the digital and analog outputs.

|  |                         |     |     |    |   |     |    |       |
|--|-------------------------|-----|-----|----|---|-----|----|-------|
| 3706   | <b>SGP tran21 h thr</b> | [%] | RWS | 15 | 0 | 100 | PP | F-S-B |
| See “Possible/Default configuration” figures on “TRAVEL / Speed reg gains” menu. |                         |     |     |    |   |     |    |       |
| 3707   | <b>SGP tran32 l thr</b> | [%] | RWS | 0  | 0 | 100 | PP | F-S-B |
| See “Possible/Default configuration” figures on “TRAVEL / Speed reg gains” menu. |                         |     |     |    |   |     |    |       |
| 3708   | <b>SGP tran21 band</b>  | [%] | RWS | 10 | 0 | 100 | PP | F-S-B |
| See “Possible/Default configuration” figures on “TRAVEL / Speed reg gains” menu. |                         |     |     |    |   |     |    |       |
| 3709   | <b>SGP tran32 band</b>  | [%] | RWS | 0  | 0 | 100 | PP | F-S-B |
| See “Possible/Default configuration” figures on “TRAVEL / Speed reg gains” menu. |                         |     |     |    |   |     |    |       |

### TRAVEL / Pre-torque

Pre torque function helps to ensure smooth starting without initial jerk. This is achieved by setting the torque prior to open the brake to a value that corresponds to the load. Pre torque value applied to the motor as well as direction of applied torque can be provided by mounting load cell on the lift car. Load cell signal is acquired through analog input and scaled appropriately, if pre-torque function is used.

If load cell is not available it is possible to work with fixed value of torque and provide only torque direction. In this case fixed value is optimized only for one load condition.




|  |                        |       |     |     |      |     |    |       |
|--|------------------------|-------|-----|-----|------|-----|----|-------|
| 9431   | <b>Int Pre-torque</b>  | [%]   | RWS | 0   | 0    | 100 | PV | F-S-B |
| Internal (fixed) motor pre-torque value                        |                        |       |     |     |      |     |    |       |
| 9432   | <b>Pre-torque time</b> | [sec] | RWS | 1.0 | 0.01 | 5   | PP | F-S-B |
| Pre-torque duration in case that IPA 9439 is selected as ramp. |                        |       |     |     |      |     |    |       |

| IPA  | Description   | [Unit] | Access | Default  | Min | Max    | Format | Reg. Mode |
|------|---|--------|--------|----------|-----|--------|--------|-----------|
| 9438 | <b>Pre-torque gain</b><br>Gain factor of the Pre-torque function to scale value from load sensor.<br>Pre-torque gain value is automatically calculated after mechanical and weights data have been entered.   | [%]    | RWS    | 1.0      | 0   | 4.0    | PP     | F-S-B     |
| 9439 | <b>Pre-torque type</b><br>0 Ramp<br>1 Costant<br>Pre-torque type control  | N/A    | WSZ    | 0        | 0   | 1      | DV     | F-S-B     |
| 9434 | <b>Pre-torque src</b><br>IPA 9431 Int Pre-torque = Default<br>It allows to select an analog input to provide motor pre-torque value<br>(refer to signals List 2 of Pick List manual)  | N/A    | RWSZ   | IPA 9431 |     | List 2 | PIN    | F-S-B     |
| 9435 | <b>Pre-trq sign src</b><br>IPA 4000 NULL = Default<br>It connects the selected signal to the selector of the multiplier input: if the signal is 0, multiply by +1, or if the signal is 1, multiply by -1 (refer to signals List 3 of Pick List manual). | N/A    | RWSZ   | IPA 4000 |     | List 3 | PIN    | F-S-B     |

### TRAVEL / Inertia comp

Inertia compensation function can be used to compensate the inertia caused by the load of the motor during acceleration / deceleration phase. It avoids also speed overshoot at the end of ramp.


|      |  |                     |     |      |      |      |    |       |
|------|--|---------------------|-----|------|------|------|----|-------|
| 2580 | <b>Inertia comp en</b><br>0 OFF<br>1 Internal<br>2 External<br>It enables inertia compensation function  | N/A                 | RWS | 1    | 0    | 1    | DV | F-S-B |
| 2054 | <b>Int Inertia</b><br>Internal value of the moment of Inertia.<br>Inertia value is automatically calculated after mechanical and weights data have been entered. | [kgm <sup>2</sup> ] | RWS | 0    | 0    | Calc | PV | F-S-B |
| 2590 | <b>Inertia comp fit</b><br>Filter on the compensation  | [ms]                | RWS | 30   | 0    | 1000 | PP | F-S-B |
| 2625 | <b>Inertia comp mon</b><br>It displays Inertia compensation torque contribution.   | [Nm]                | R   | 0.00 | 0.00 | 0.00 | DV | F-S-B |



**Note!** “Inertia comp mon” signals is available in the pick-lists of the analog outputs.

| IPA   | Description             | [Unit] | Access | Default  | Min    | Max | Format  | Reg. Mode |
|---|-------------------------|--------|--------|----------|--------|-----|---------|-----------|
| <b>TRAVEL / DC braking</b>  |                         |        |        |          |        |     |         |           |
| DC current injection can help to stop the motor and ensure that lift car arrives exactly at floor level.  |                         |        |        |          |        |     |         |           |
| <b>1836</b>   | <b>DCbrake cmd src</b>  | N/A    | RWS    | IPA 7125 | List 3 | PIN | V-F-S-B |           |
| IPA 7125 Lift DC Brake mon = Default<br>It allows to select the origin of the signal to command DC braking function, normally if is controled by lift sequence. (refer to signals List 3 of Pick List manual) |                         |        |        |          |        |     |         |           |
| <b>1833</b>   | <b>DCbrake delay</b>    | [sec]  | RWS    | 0.1      | 0.01   | 30  | PP      | V-F-S-B   |
| Delay between the injection command and the injection of the current itself   |                         |        |        |          |        |     |         |           |
| <b>1834</b>   | <b>DCbrake duration</b> | [sec]  | RWS    | 1        | 0.01   | 30  | PP      | V-F-S-B   |
| Duration of the current injection   |                         |        |        |          |        |     |         |           |
| <b>1835</b>   | <b>DCbrake current</b>  | [%]    | RWS    | 100      | 0      | 100 | PP      | V-F-S-B   |
| Braking current as a percentage of <b>Drive continuous current</b>  |                         |        |        |          |        |     |         |           |
| <b>1837</b>   | <b>DCBrake state</b>    | N/A    | R      | 0        | 0      | 1   | DV      | V-F-S-B   |
| 0 non-active<br>1 active<br>State of DC Brake functon.  |                         |        |        |          |        |     |         |           |

**Note!** Sequence available only when IPA 7105 set as Start fwd/rev.  
Lift DC brake mon signal that controls DC current braking is not available.



- A = DC brake delay + DC brake duration > Spd 0 ref dly + Brake close dly  
 B = DC brake delay + DC brake duration < Spd 0 ref dly + Brake close dly

| IPA                           | Description  | [Unit] | Access | Default | Min | Max | Format | Reg. Mode |
|-------------------------------|--|--------|--------|---------|-----|-----|--------|-----------|
| <b>TRAVEL / Ramp function</b> |  |        |        |         |     |     |        |           |
| 8031                          | <b>Ramp out enable</b><br>0 Disabled<br>1 Enabled<br>Ramp function enabling            | N/A    | WSZ    | 1       | 0   | 1   | DP     | V-F-S-B   |
| 8021                          | <b>Ramp shape</b><br>0 Linear<br>1 S-Shaped<br>Ramp selection. Linear or S-shaped ramp | N/A    | RWS    | 1       | 0   | 1   | DV     | V-F-S-B   |

### TRAVEL / Ramp setpoint

The Function of this block is to generate the Set point for the ramp. Set reference by algebraically adding its inputs. All parameters in this menu have default values set for lift application.

### TRAVEL / Ramp setpoint / Ramp ref src

|      |  |     |     |          |         |     |         |
|------|--|-----|-----|----------|---------|-----|---------|
| 7035 | <b>Ramp ref 1 src</b><br>IPA 7130 Lift out spd mon = Default<br>It select the origin of the signal of Ramp ref 1<br>(refer to signals List 7 of Pick List manual)  | N/A | RWS | IPA 7130 | List 7  | PIN | V-F-S-B |
| 7036 | <b>Ramp ref 2 src</b><br>IPA 7031 Int ramp ref 2 = Default<br>It select the origin of the signal of Ramp ref 2<br>(refer to signals List 8 of Pick List manual)  | N/A | RWS | IPA 7031 | List 8  | PIN | V-F-S-B |
| 7029 | <b>Ramp ref 3 src</b><br>IPA 7038 Int ramp ref 3 = Default<br>It select the origin of the signal of Ramp ref 3   | N/A | RWS | IPA 7038 | List 45 | PIN | V-F-S-B |
| 7037 | <b>Ramp ref inv src</b><br>IPA 7121 DOWN Count mon = Default<br>It connects the selected signal to the selector of the multiplier input:if the signal is 0, multiply by +1, or if the signal is 1, multiply by -1. The multiplier allows to invert Ramp reference signal (refer to signals List 3 of Pick List manual). By using DOWN cont mon / Up cont mon it is possible to invert lift movement direction that corresponds to commands <b>Start fwd src</b> (IPA 7115), <b>Start rev src</b> (IPA 7116). | N/A | RWS | IPA 4000 | List 3  | PIN | V-F-S-B |


### TRAVEL / Ramp setpoint / Ramp ref cfg

|      |   |       |     |   |      |      |    |         |
|------|---|-------|-----|---|------|------|----|---------|
| 7030 | <b>Int ramp ref 1</b><br>Value of the Int ramp ref 1 variable | [rpm] | RWS | 0 | Calc | Calc | PV | V-F-S-B |
| 7031 | <b>Int ramp ref 2</b><br>Value of the Int ramp ref 2 variable | [rpm] | RWS | 0 | Calc | Calc | PV | V-F-S-B |
| 7038 | <b>Int ramp ref 3</b><br>Value of the Int ramp ref 3 variable | [rpm] | RWS | 0 | Calc | Calc | PV | V-F-S-B |

### TRAVEL / Ramp setpoint / Ramp ref mon

|      |   |       |   |      |      |      |    |         |
|------|---|-------|---|------|------|------|----|---------|
| 7032 | <b>Ramp ref 1 mon</b><br>Displaying of the Ramp ref 1 signal          | [rpm] | R | 0.00 | 0.00 | 0.00 | PP | V-F-S-B |
| 7033 | <b>Ramp ref 2 mon</b><br>Displaying of the Ramp ref 2 signal          | [rpm] | R | 0.00 | 0.00 | 0.00 | PP | V-F-S-B |
| 7039 | <b>Ramp ref 3 mon</b><br>Displaying of the Ramp ref 3 signal          | [rpm] | R | 0.00 | 0.00 | 0.00 | PP | V-F-S-B |
| 7034 | <b>Ramp setpoint</b><br>Displaying of the Ramp setpoint output signal | [rpm] | R | 0.00 | 0.00 | 0.00 | PV | V-F-S-B |

| IPA | Description | [Unit] | Access | Default | Min | Max | Format | Reg. Mode |
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|



1. Switch is closed if Ramp out enable = Enabled & Start. Switch is opened if Ramp out enable = Enabled & Stop
  2. Switch is closed if Ramp out enable = Enabled & (!Fast stop). Switch is opened if Ramp out enable = Enabled & Fast stop
- Both switches are closed if Ramp out enable = Disabled

## TRAVEL / Speed setpoint

The function of the block is to generate the set point for the speed regulator by algebraically adding its inputs, see ramp set point. All parameters in this menu have default values set for lift application.

### TRAVEL / Speed setpoint / Speed ref src

|      |  |     |     |          |         |     |         |
|------|--|-----|-----|----------|---------|-----|---------|
| 7050 | <b>Speed ref 1 src</b><br>IPA 7040 Int speed ref 1 = Default<br>It select the origin of the signal of Speed ref 1 in V/f, SLS. LZ speed ref (IPA 9408) in FOC, BRS (refer to signals List 9 of Pick List manual)List 9)  | N/A | RWS | IPA 7040 | List 9  | PIN | V-F-S-B |
| 7051 | <b>Speed ref 2 src</b><br>IPA 7041 Int speed ref 2 = Default<br>It select the origin of the signal of Speed ref 2. (Refer to signals List 10 of Pick List manual).   | N/A | RWS | IPA 7041 | List 10 | PIN | V-F-S-B |
| 7053 | <b>Speedref inv src</b><br>IPA 4000 NULL = Default<br>It connects the selected signal to the selector of the multiplier input: if the signal is 0, multiply by +1, or if the signal is 1, multiply by -1. The multiplier allows to invert Speed reference signal (refer to signals List 3 of Pick List manual) | N/A | RWS | IPA 4000 | List 3  | PIN | V-F-S-B |


### TRAVEL / Speed setpoint / Speed ref cfg

|      |   |       |     |   |      |      |    |         |
|------|---|-------|-----|---|------|------|----|---------|
| 7040 | <b>Int speed ref 1</b><br>Value of the Int speed ref 1 variable | [rpm] | RWS | 0 | Calc | Calc | PV | V-F-S-B |
| 7041 | <b>Int speed ref 2</b><br>Value of the Int speed ref 2 variable | [rpm] | RWS | 0 | Calc | Calc | PV | V-F-S-B |

### TRAVEL / Speed setpoint / Speed ref mon

|      |  |       |   |      |      |      |    |         |
|------|--|-------|---|------|------|------|----|---------|
| 8022 | <b>Ramp out mon</b><br>Displaying of Ramp output signal        | [rpm] | R | 0.00 | 0.00 | 0.00 | PV | V-F-S-B |
| 7045 | <b>Speed ref 1 mon</b><br>Displaying of the Speed ref 1 signal | [rpm] | R | 0.00 | 0.00 | 0.00 | PP | V-F-S-B |

| IPA  | Description  | [Unit] | Access | Default | Min  | Max  | Format | Reg. Mode |
|------|--|--------|--------|---------|------|------|--------|-----------|
| 7046 | <b>Speed ref 2 mon</b><br>Displaying of the Speed ref 2 signal | [rpm]  | R      | 0.00    | 0.00 | 0.00 | PP     | V-F-S-B   |



1. Switch is closed if *Ramp out enable* = Disabled & Start  
Switch is opened if *Ramp out enable* = Disabled & Stop
  2. Switch is closed if *Ramp out enable* = Disabled &  $\alpha$   
Switch is opened if *Ramp out enable* = Disabled &  $\alpha$  fast stop
- Both switches are closed if *Ramp out enable* = Enabled

## SAVE PARAMETERS

AVyL drive allows two different commands to save the parameters modified in the regulation mode selected:

- by STARTUP menu, “Save Config?” command
- by all other menus, “SAVE PARAMETERS” command

Any changes made in STARTUP menu require “Save Config?” command, which saves all entire regulation mode selected. It is recommended every time the user made any changes into STARTUP menu.

“SAVE PARAMETERS” command saves all the changes made out of STARTUP menu only.

When on the keypad display appears blinking message “Use Save Config”, use “Save Config?” command

| IPA | Description | [Unit] | Access | Default | Min | Max | Format | Reg. Mode |
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|

## REGULATION PARAM

Most of the parameters in this menu are initialized by autotune procedure. The access to REGULATION PARAM menu is allowed by Level 1 password: 12345. It must to be set in the SERVICE menu.

### REGULATION PARAM / V/f reg param

|             |  |         |   |      |      |      |    |   |
|-------------|--|---------|---|------|------|------|----|---|
| <b>3400</b> | <b>Voltage boost</b>   | [%]     | RWS   | Calc | 0.00 | 0.00 | PV | V |
|             | Torque boost at low speed. It allows to increase the output voltage at zero Hz.<br>Initialized by autotune procedure   |         |   |      |      |      |    |   |
| <b>3531</b> | <b>Slip comp</b>   | [rpm]   | RWS   | Calc | 0.00 | Calc | PV | V |
|             | Compensation of speed drop due to load. Initialized by autotune procedure.<br>When Slip comp mode = Encoder, it acts as a limit on the amount of speed correction obtained from encoder feedback. In general parameter must be increased to about 4 times of rated motor slip.<br>Low values of Slip comp parameter may cause instability. |         |   |      |      |      |    |   |
| <b>3541</b> | <b>Slip comp filter</b>  | [sec]   | RWS   | 0.50 | Calc | 10   | PP | V |
|             | Slip compensation filter.  |         |   |      |      |      |    |   |
| <b>3411</b> | <b>Slip comp mode</b>  | N/A     | RWS   | 0    | 0    | 2    | DP | V |
|             | 0  | Normal  | Standard slip compensation using load current   |      |      |      |    |   |
|             | 1  | Encoder | Slip compensation using encoder feedback in closed loop speed control, see IPA 3531                       |      |      |      |    |   |
|             | 2  | Lift    | Slip compensation using load current, suitable for lift application<br><i>(from software rel. 3.500).</i> |      |      |      |    |   |
| <b>3412</b> | <b>Slip P gain</b>   | [%]     | RWS   | 2.0  | 0    | 100  | PP | V |
|             | Proportional gain of slip regulator. It must be adjusted according to actual load conditions (inertia).<br>In general, if there are oscillations, the proportional gain must be increased.   |         |   |      |      |      |    |   |
| <b>3413</b> | <b>Slip I gain</b>   | [%]     | RWS   | 0.5  | 0    | 100  | PP | V |
|             | Integral gain of slip regulator. It must be adjusted according to actual load conditions (inertia). In general, if there are oscillations, the integral gain must be reduced.  |         |   |      |      |      |    |   |
| <b>3585</b> | <b>Antioscill gain</b>   | [%]     | RWS   | 0    | 0    | 100  | PP | V |
|             | It allows to damp the current oscillations in the motor, which could be developed in the middle range of the rated speed   |         |   |      |      |      |    |   |
| <b>3520</b> | <b>V/f ILim P gain</b>   | [rpm_A] | RWS   | Calc | Calc | Calc | PP | V |
|             | Proportional gain of the pseudo current loop regulator in V/f mode   |         |   |      |      |      |    |   |
| <b>3530</b> | <b>V/f ILim I gain</b>   | [rpm_A] | RWS   | Calc | Calc | Calc | PP | V |
|             | Integral gain of the pseudo current loop regulator in V/f mode   |         |   |      |      |      |    |   |

### REGULATION PARAM / Spd regulator

#### REGULATION PARAM / Spd regulator / Percent values

|             |   |     |     |      |      |    |    |       |
|-------------|---|-----|-----|------|------|----|----|-------|
| <b>3700</b> | <b>SpdP1 gain %</b>                               | [%] | RWS | Calc | 0.00 | 00 | PP | F-S-B |
|             | Proportional speed 1 gain regulator at high speed |     |     |      |      |    |    |       |
| <b>3701</b> | <b>SpdI1 gain %</b>                               | [%] | RWS | Calc | 0.00 | 00 | PP | F-S-B |
|             | Integral speed 1 gain regulator at high speed     |     |     |      |      |    |    |       |

#### REGULATION PARAM / Spd regulator / Base values


|             |  |         |     |      |      |      |    |       |
|-------------|--|---------|-----|------|------|------|----|-------|
| <b>2075</b> | <b>SpdP base value</b>                     | [A/rpm] | RWS | Calc | 0.00 | 0.00 | FK | F-S-B |
|             | Basic value of the speed Proportional gain |         |     |      |      |      |    |       |
| <b>2077</b> | <b>SpdI base value</b>                     | [A/rpm] | RWS | Calc | 0.00 | Calc | FK | F-S-B |
|             | Basic value of the speed Integral gain     |         |     |      |      |      |    |       |



| IPA   | Description  | [Unit]   | Access | Default | Min  | Max  | Format | Reg. Mode |
|---|--|----------|--------|---------|------|------|--------|-----------|
| <b>REGULATION PARAM / Spd regulator / In use values</b>   |  |          |        |         |      |      |        |           |
| 2063  | InUse SpdP gain%                                     | [%]      | R      | 10      | 0    | 100  | PV     | F-S-B     |
|   | In use value of the speed Proportional gain          |          |        |         |      |      |        |           |
| 2065  | InUse SpdI gain%                                     | [%]      | R      | 10      | 0    | 100  | PV     | F-S-B     |
|   | In use value of the speed Integral gain              |          |        |         |      |      |        |           |
| <b>REGULATION PARAM / Curr regulator</b>  |  |          |        |         |      |      |        |           |
| <b>REGULATION PARAM / Curr regulator / Percent values</b>   |  |          |        |         |      |      |        |           |
| 1999  | CurrP gain %   | [%]      | RWS    | Calc    | 0.00 | 100  | PP     | V-F-S-B   |
|   | Proportional gain of current loop                    |          |        |         |      |      |        |           |
| 2000  | CurrI gain %   | [%]      | RWS    | Calc    | 0.00 | 100  | PP     | V-F-S-B   |
|   | Integral gain of current loop                        |          |        |         |      |      |        |           |
| <b>REGULATION PARAM / Curr regulator / Base values</b>  |  |          |        |         |      |      |        |           |
| 2005  | CurrP base value                                     | [V/A]    | RWS    | Calc    | 0.00 | Calc | FK     | V-F-S-B   |
|   | Basic value of the proportional gain of current loop |          |        |         |      |      |        |           |
| 2007  | CurrI base value                                     | [V/A/s]  | RWS    | Calc    | 0.00 | Calc | FK     | V-F-S-B   |
|   | Basic value of the integral gain of current loop     |          |        |         |      |      |        |           |
| <b>REGULATION PARAM / Curr regulator / Dead time comp</b>   |  |          |        |         |      |      |        |           |
| The function allows for compensation of the output voltage distortion due to IGBT voltage drop and its switching characteristics. |  |          |        |         |      |      |        |           |
| 530   | Dead time limit                                      | [V]      | RWS    | Calc    | 0.00 | 50   | PP     | V-F-S-B   |
|   | Value of the voltage compensation                    |          |        |         |      |      |        |           |
| 540   | Dead time slope                                      | [V/A]    | RWS    | Calc    | 0.00 | 100  | PP     | V-F-S-B   |
|   | Compensation Gradient                                |          |        |         |      |      |        |           |
| <b>REGULATION PARAM / Flux regulator</b>  |  |          |        |         |      |      |        |           |
| <b>REGULATION PARAM / Flux regulator / Percent values</b>   |  |          |        |         |      |      |        |           |
| 2013  | FlxP gain %  | [%]      | RWS    | Calc    | 0    | 100  | PP     | F-S       |
|   | Proportional gain of flux loop                       |          |        |         |      |      |        |           |
| 2015  | FlxI gain %  | [%]      | RWS    | Calc    | 0    | 100  | PP     | F-S       |
|   | Integral gain of flux loop                           |          |        |         |      |      |        |           |
| <b>REGULATION PARAM / Flux regulator / Base values</b>  |  |          |        |         |      |      |        |           |
| 2021  | FlxP base value                                      | [A/Wb]   | RWS    | Calc    | 0.00 | Calc | FK     | F-S       |
|   | Basic value of the proportional gain of flux loop    |          |        |         |      |      |        |           |
| 2022  | FlxI base value                                      | [A/Wb/s] | RWS    | Calc    | 0.00 | Calc | FK     | F-S       |
|   | Basic value of the integral gain of flux loop        |          |        |         |      |      |        |           |
| <b>REGULATION PARAM / Vlt regulator</b>   |  |          |        |         |      |      |        |           |
| <b>REGULATION PARAM / Vlt regulator / Percent values</b>  |  |          |        |         |      |      |        |           |
| 2031  | VltP gain %  | [%]      | RWS    | Calc    | 0.00 | 100  | PP     | F-S-B     |
|   | Proportional gain of voltage loop                    |          |        |         |      |      |        |           |
| 2033  | VltI gain %  | [%]      | RWS    | Calc    | 0.00 | 100  | PP     | F-S-B     |
|   | Integral gain of voltage loop                        |          |        |         |      |      |        |           |

| IPA   | Description  | [Unit]  | Access | Default | Min  | Max  | Format | Reg. Mode |
|---|--|---------|--------|---------|------|------|--------|-----------|
| <b>REGULATION PARAM / Vlt regulator / Base values</b> |  |         |        |         |      |      |        |           |
| 2039  | <b>VltP base value</b><br>Basic value of the proportional gain of voltage loop | [A/V]   | RWS    | Calc    | 0.00 | 0.00 | FK     | F-S-B     |
| 2041  | <b>VltI base value</b><br>Basic value of the integral gain of voltage loop     | [A/V/s] | RWS    | Calc    | 0.00 | 0.00 | FK     | F-S-B     |

### REGULATION PARAM / Torque config



### REGULATION PARAM / Torque config / Torque setpoint / T setpoint src

|      |  |     |     |          |        |     |       |
|------|--|-----|-----|----------|--------|-----|-------|
| 2441 | <b>Torque ref 2 src</b><br>IPA 9433 Pre-torque out = Default<br>It allows to select the origin of the signal for torque reference (refer to signals List 15 of Pick List manual) | N/A | RWS | IPA 9433 | List15 | PIN | F-S-B |
|------|--|-----|-----|----------|--------|-----|-------|

### REGULATION PARAM / Torque config / Torque setpoint / T setpoint cfg

|      |   |      |     |      |      |      |    |       |
|------|---|------|-----|------|------|------|----|-------|
| 2440 | <b>Int torque ref 2</b><br>It allows to set an alternative reference to connect to Torque ref 2 src | [Nm] | RWS | 0.00 | Calc | Calc | PV | F-S-B |
|------|---|------|-----|------|------|------|----|-------|

### REGULATION PARAM / Torque config / Torque setpoint / T setpoint mon

|      |   |      |   |      |      |      |    |       |
|------|---|------|---|------|------|------|----|-------|
| 2442 | <b>Torque ref 2 mon</b><br>Torque ref 2 variable displaying | [Nm] | R | 0.00 | 0.00 | 0.00 | PP | F-S-B |
| 2450 | <b>Torque ref</b><br>Overall Torque ref variable displaying | [Nm] | R | 0.00 | 0.00 | 0.00 | PV | F-S-B |

### REGULATION PARAM / Torque config / Torque curr lim / Trq curr lim src

|      |  |     |     |          |        |     |         |
|------|--|-----|-----|----------|--------|-----|---------|
| 1195 | <b>Trq curr lim src</b><br>IPA 4000 NULL = Default<br>It allows to select the origin of the signal for torque current limit (refer to signals List 15 of Pick List manual) | N/A | RWS | IPA 4000 | List15 | PIN | V-F-S-B |
|------|--|-----|-----|----------|--------|-----|---------|

*(from software rel. 3.300).*

### REGULATION PARAM / Torque config / Torque curr lim / Trq curr lim cfg

|      |  |                                    |     |      |      |      |    |                                    |
|------|--|------------------------------------|-----|------|------|------|----|------------------------------------|
| 1190 | <b>Tcurr lim sel</b><br>0 Off<br>1 T lim +/-<br>2 T lim mot/gen<br>3 T lim sym var<br>4 T lim pos var<br>5 T lim neg var<br>Selection of the torque Current limit type | N/A                                | RWS | 0    | 0    | 4    | DV | V-F-S-B                            |
|      |  | None                               |     |      |      |      |    | Limits depend on drive rating.     |
|      |  | Positive or negative limit         |     |      |      |      |    | Limits depend on IPA 1210, IPA1220 |
|      |  | Motor or Generator limit           |     |      |      |      |    | Limits depend on IPA 1210, IPA1220 |
|      |  | Limits are controlled by IPA 1195. |     |      |      |      |    | <i>(from software rel. 3.300).</i> |
|      |  | Limits are controlled by IPA 1195. |     |      |      |      |    | <i>(from software rel. 3.300).</i> |
|      |  | Limits are controlled by IPA 1195. |     |      |      |      |    | <i>(from software rel. 3.300).</i> |
| 1210 | <b>Tcurr lim +</b><br>Positive current limit or Motor (Positive power) limit.  | [A]                                | RWS | Calc | 0.00 | Calc | PV | V-F-S-B                            |

| IPA  | Description  | [Unit] | Access | Default  | Min  | Max     | Format | Reg. Mode |
|--|--|--------|--------|----------|------|---------|--------|-----------|
| 1220   | <b>Tcurr lim -</b><br>Negative current limit or Generator (Negative power) limit.  | [A]    | RWS    | Calc     | 0.00 | Calc    | PV     | V-F-S-B   |
| <b>REGULATION PARAM / Torque config / Torque curr lim / Trq curr lim mon</b>   |  |        |        |          |      |         |        |           |
| 1250   | <b>Inuse Tcurr lim+</b><br>Monitor of the positive current limit in use  | [A]    | R      | 0.00     | 0.00 | 0.00    | PV     | V-F-S-B   |
| 1260   | <b>Inuse Tcurr lim-</b><br>Monitor for the negative current limit in use   | [A]    | R      | 0.00     | 0.00 | 0.00    | PV     | V-F-S-B   |
| 2445   | <b>Tcurr lim state</b><br>Current limit state<br>0 Not-reached<br>1 Reached  | N/A    | R      | 0        | 0    | 1       | DV     | V-F-S-B   |
| <b>REGULATION PARAM / Flux config</b>  |  |        |        |          |      |         |        |           |
| <b>REGULATION PARAM / Flux config / Magnetiz config</b>  |  |        |        |          |      |         |        |           |
| <b>Autophase rot / Start ?</b>   |  |        |        |          |      |         |        |           |
| Autophasing command to phase brushless motors. After pressing Start, give the Enable and Start command to drive. Motor must be free of any load, brake must be released.<br>Motor will first align and then rotate slightly at very low speed.   |  |        |        |          |      |         |        |           |
| <b>Autophase still / Start ?</b>   |  |        |        |          |      |         |        |           |
| Autophasing command to phase brushless motors. After pressing Start, give the Enable and Start command to drive. Drive will perform phasing procedure without rotation. Brake can be locked<br><i>(from software rel. 3.500).</i>  |  |        |        |          |      |         |        |           |
| 1810   | <b>Magn ramp time</b><br>Set of the ramp time of the magnetizing current   | [sec]  | RWS    | D.Size   | 0.01 | 5       | PP     | F-S       |
| 1815   | <b>Lock flux pos</b><br>0 Off<br>1 At magnetization<br>2 At Spd = 0<br>3 At Magn & Spd = 0<br>4 At magn & Ref=0<br>Flux position is locked during magnetization or when stop command has been issued and signal "Speed is zero delayed" becomes TRUE<br>Flux position is locked during magnetization or when stop command has been issued and signal "Speed is zero delayed" becomes TRUE<br>Flux position is locked during magnetization or when both signals "Speed reference is zero delayed" and "Speed is zero delayed" become TRUE | N/A    | RWSZ   | 0        | 0    | 1       | DP     | F-S-B     |
| The function is useful for undesired motor shaft rotation. It allows to lock the Flux position.  |  |        |        |          |      |         |        |           |
| <b>REGULATION PARAM / Flux config / Flux max limit / Flux max lim src</b>  |  |        |        |          |      |         |        |           |
| This Function allows the user to control the maximum value of the Flux current.<br>It is linked to the control of the voltage loop. In a condition where the Flux is = 100%, the voltage regulator prevails by controlling the motor. It means that it is only possible to further limit the requirement of the voltage loop. In case the Drive is active in the constant torque area, it is possible to set an overflux up to 115% of the rated flux. Such control is possible, obviously, only if the motor/drive combination is in a position to supply a sufficient magnetizing current. |  |        |        |          |      |         |        |           |
| 1121   | <b>Flux level src</b><br>IPA 1120 Int fix maxlim = Default<br>It allows to select the origin of the signal to control the function<br>(refer to signals List 24 of Pick List manual)   | N/A    | RWS    | IPA 1120 |      | List 24 | PIN    | F-S-B     |

| IPA  | Description   | [Unit] | Access | Default  | Min     | Max  | Format | Reg. Mode |
|--|---|--------|--------|----------|---------|------|--------|-----------|
| <b>REGULATION PARAM / Flux config / Flux max limit / Flux max lim cfg</b>  |   |        |        |          |         |      |        |           |
| 1120   | <b>Int flx maxim</b>  | [%]    | RWS    | 0.00     | 0.00    | 0.00 | PV     | F-S-B     |
|  | It allows to set an alternative signal to connect to Flux level src   |        |        |          |         |      |        |           |
| <b>REGULATION PARAM / Flux config / Flux max limit / Flux max lim mon</b>  |   |        |        |          |         |      |        |           |
| 1150   | <b>Inuse flx maxim</b>  | [%]    | R      | 0.00     | 0.00    | 0.00 | PV     | F-S-B     |
|  | Monitor of flux limit value in use  |        |        |          |         |      |        |           |
| <b>REGULATION PARAM / Flux config / Output vlt ref</b>   |   |        |        |          |         |      |        |           |
| The Function allows the regulation of the flux in the constant power area where a voltage margin must be available for the regulation. This value is usually equal to 2% of the maximum output voltage.<br>A higher value allows a faster response of the voltage regulator but with a lower amount of available voltage on the output. A lower value allows a higher output voltage with a decrease of the dynamic performances |   |        |        |          |         |      |        |           |
| <b>REGULATION PARAM / Flux config / Output vlt ref / Out vlt ref src</b>   |   |        |        |          |         |      |        |           |
| 1141   | <b>Outvlt lim src</b>   | N/A    | RWS    | IPA 1140 | List 42 | PIN  | F-S-B  |           |
|  | IPA 1140 Int Outvlt lim = Default<br>It allows to select the origin of the signal to control the function<br>(refer to signals List 42 of Pick List manual) |        |        |          |         |      |        |           |
| <b>REGULATION PARAM / Flux config / Output vlt ref / Out vlt ref cfg</b>   |   |        |        |          |         |      |        |           |
| 1130   | <b>Dyn vlt margin</b>   | [%]    | RWS    | 2        | 1       | 10   | PV     | F-S-B     |
|  | Voltage margin for the flux regulation  |        |        |          |         |      |        |           |
| 1140   | <b>Int Outvlt lim</b>   | [V]    | RWS    | Calc     | Calc    | Calc | PV     | F-S-B     |
|  | Internal output voltage limit. initialized from motor rated voltage.<br>This parameter determines the start of flux weakening. Connected to Outvlt lim src  |        |        |          |         |      |        |           |
| <b>REGULATION PARAM / Flux config / Output vlt ref / Out vlt ref mon</b>   |   |        |        |          |         |      |        |           |
| 1170   | <b>Available Outvlt</b>   | [V]    | R      | 0.00     | 0.00    | 0.00 | PV     | F-S-B     |
|  | Monitor for the maximum available output voltage.<br>It is calculated directly starting from the DC link voltage  |        |        |          |         |      |        |           |
| 1180   | <b>Inuse Outvlt ref</b>   | [V]    | R      | 0.00     | 0.00    | 0.00 | PV     | F-S-B     |
|  | Limit in use on the output voltage  |        |        |          |         |      |        |           |
| <b>REGULATION PARAM / Sls SpdFbk gains</b>   |   |        |        |          |         |      |        |           |
| In the Sensorless regulation mode the motor speed is estimated through an observer algorithm based on a speed gains profile. The procedure below allows the user to improve the gains profile of the observer circuit at low, medium and high Motoring/Regen speed.  |   |        |        |          |         |      |        |           |
| <b>REGULATION PARAM / Sls SpdFbk gains / Motoring gains</b>  |   |        |        |          |         |      |        |           |
| 1090   | <b>SLS mot HPgain</b>   | [%]    | RWS    | 5        | 0       | 100  | PP     | S         |
|  | Motor Proportional High gain  |        |        |          |         |      |        |           |
| 1091   | <b>SLS mot Hlgain</b>   | [%]    | RWS    | 5        | 0       | 100  | PP     | S         |
|  | Motor Integral High gain  |        |        |          |         |      |        |           |
| 1092   | <b>SLS mot MPgain</b>   | [%]    | RWS    | 5        | 0       | 100  | PP     | S         |
|  | Motor Proportional Medium gain  |        |        |          |         |      |        |           |
| 1093   | <b>SLS mot Mlgain</b>   | [%]    | RWS    | 5        | 0       | 100  | PP     | S         |
|  | Motor Integral Medium gain  |        |        |          |         |      |        |           |
| 1094   | <b>SLS mot LPgain</b>   | [%]    | RWS    | 1        | 0       | 100  | PP     | S         |
|  | Motor Proportional Low gain   |        |        |          |         |      |        |           |

| IPA  | Description                                      | [Unit] | Access | Default | Min | Max | Format | Reg. Mode |
|------|--|--------|--------|---------|-----|-----|--------|-----------|
| 1095 | <b>SLS mot LIgain</b><br>Motor Integral Low gain | [%]    | RWS    | 0       | 0   | 100 | PP     | S         |

#### REGULATION PARAM / SIs SpdFbk gains / Regen gains

|      |   |     |     |   |   |     |    |   |
|------|---|-----|-----|---|---|-----|----|---|
| 1101 | <b>SLS regen HPgain</b><br>Regen Proportional High gain   | [%] | RWS | 5 | 0 | 100 | PP | S |
| 1102 | <b>SLS regen Hlgain</b><br>Regen Integral High gain       | [%] | RWS | 5 | 0 | 100 | PP | S |
| 1103 | <b>SLS regen MPgain</b><br>Regen Proportional Medium gain | [%] | RWS | 5 | 0 | 100 | PP | S |
| 1104 | <b>SLS regen Mlgain</b><br>Regen Integral Medium gain     | [%] | RWS | 5 | 0 | 100 | PP | S |
| 1105 | <b>SLS regen LPgain</b><br>Regen Proportional Low gain    | [%] | RWS | 1 | 0 | 100 | PP | S |
| 1106 | <b>SLS regen LIgain</b><br>Regen Integral Low gain        | [%] | RWS | 0 | 0 | 100 | PP | S |

#### REGULATION PARAM / SIs SpdFbk gains / Gain transitions

|      |   |       |      |      |      |      |    |   |
|------|---|-------|------|------|------|------|----|---|
| 1096 | <b>SLS H/M tran level</b><br>Transition level from High to Medium profile               | [rpm] | RWS  | Calc | 0.00 | Calc | PP | S |
| 1097 | <b>SLS M/L tran level</b><br>Transition level from Medium to Low profile                | [rpm] | RWS  | Calc | 0.00 | Calc | PP | S |
| 1098 | <b>SLS H/M tran bnd[rpm]</b><br>Transition band from High to Medium profile             | RWS   | Calc | 0.00 | Calc | PP   | S  |   |
| 1099 | <b>SLS M/L tran bnd</b><br>Transition band from Medium to Low profile                   | [rpm] | RWS  | Calc | 0.00 | Calc | PP | S |
| 1107 | <b>SLS 0 tran bnd</b><br>Speed 0 transition band (Motoring/Regen/Motoring)              | [rpm] | RWS  | Calc | 0.00 | Calc | PP | S |
| 1111 | <b>Observer filter</b><br>Time constant of the first-order Filter on both gains profile | [ms]  | RWS  | 100  | Calc | Calc | PP | S |

#### REGULATION PARAM / SIs SpdFbk gains / Gain monitor

|      |   |     |   |      |      |      |    |   |
|------|---|-----|---|------|------|------|----|---|
| 1085 | <b>Inuse S P gain</b><br>In use Proportional gains of speed observer. | [%] | R | 0.00 | 0.00 | 0.00 | PV | S |
| 1086 | <b>Inuse S I gain</b><br>In use Integral gains of speed observer.     | [%] | R | 0.00 | 0.00 | 0.00 | PV | S |
| 1112 | <b>Observer ref mon</b><br>Observer adapt gain reference monitor.     | [%] | R | 0.00 | 0.00 | 0.00 | PP | S |

#### REGULATION PARAM / Test generator


The tuning of the regulators can be done using an internal test signal generator in order to evaluate the regulator response. This operation requires the use of a digital oscilloscope. The "Test generator" generates signal shaped as a rectangular wave with a programmable frequency and amplitude. Using the Test generator function it is possible to carry out the manual tunings of Current regulator, Flux regulator Voltage regulator and Speed regulator.

| IPA  | Description          | [Unit]        | Access                        | Default | Min | Max | Format | Reg. Mode |
|--|----------------------|---------------|-------------------------------|---------|-----|-----|--------|-----------|
| <b>REGULATION PARAM / Test generator / Test gen mode</b> |                      |               |                               |         |     |     |        |           |
| 2756   | <b>Test gen mode</b> | N/A           | RWS                           | 0       | 0   | 6   | DK     | V-F-S-B   |
|  | 0                    | Off           |                               |         |     |     |        |           |
|  | 1                    | Ramp ref 1    | Ramp reference 1              |         |     |     |        |           |
|  | 2                    | Speed ref 1   | Speed reference 1             |         |     |     |        |           |
|  | 3                    | Torque ref 2  | Torque reference 2            |         |     |     |        |           |
|  | 4                    | Magn curr ref | Magnetizing current reference |         |     |     |        |           |
|  | 5                    | Flux ref      | Flux reference                |         |     |     |        |           |
|  | 6                    | Outvit lim    | Voltage reference             |         |     |     |        |           |

This parameter defines where the test signal is connected in the control scheme.

|   |   |       |     |    |       |        |    |         |
|---|---|-------|-----|----|-------|--------|----|---------|
| <b>REGULATION PARAM / Test generator / Test gen cfg</b> |   |       |     |    |       |        |    |         |
| 2745  | <b>Gen Hi ref</b>                                   | [cnt] | RWS | 0  | 32767 | -32767 | PV | V-F-S-B |
|   | Value in count of the higher amplitude signal value |       |     |    |       |        |    |         |
| 2750  | <b>Gen Low ref</b>                                  | [cnt] | RWS | 0  | 32767 | -32767 | PV | V-F-S-B |
|   | Value in count of the lower amplitude signal value  |       |     |    |       |        |    |         |
| 2755  | <b>Gen Period</b>                                   | [sec] | RWS | 10 | 0     | 10000  | PV | V-F-S-B |
|   | Period of the square wave                           |       |     |    |       |        |    |         |

|   |  |       |   |      |      |      |    |         |
|---|--|-------|---|------|------|------|----|---------|
| <b>REGULATION PARAM / Test generator / Test gen mon</b> |  |       |   |      |      |      |    |         |
| 2760  | <b>Gen output</b>                            | [cnt] | R | 0.00 | 0.00 | 0.00 | PV | V-F-S-B |
|   | Monitoring the test generator output signal. |       |   |      |      |      |    |         |



## SAVE PARAMETERS

AVyL drive allows two different commands to save the parameters modified in the regulation mode selected:

- by STARTUP menu, “Save Config?” command
- by all other menus, “SAVE PARAMETERS” command

Any changes made in STARTUP menu require “Save Config?” command, which saves all entire regulation mode selected.

It is recommended every time the user made any changes into STARTUP menu.

“SAVE PARAMETERS” command saves all the changes made out of STARTUP menu only.

When on the keypad display appears blinking message “Use Save Config?”, use “Save Config?” command

| IPA | Description | [Unit] | Access | Default | Min | Max | Format | Reg. Mode |
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|

## I/O CONFIG

The access to I/O CONFIG menu is allowed by Level 1 password: 12345. It must all be set in the SERVICE menu.

### I/O CONFIG / Commands

Configuration of Enable, Start commands. All parameters in this menu have default values set for lift application.

#### I/O CONFIG / Commands / Commands src

|      |  |     |     |          |         |     |         |
|------|--|-----|-----|----------|---------|-----|---------|
| 153  | <b>Term StrStp src</b><br>IPA 4001 ONE = Default<br>It allows to select the signal to generate the Start (1) command and of the terminal strip Stop (0) command (refer to signals List 16 of Pick List manual)         | N/A | RWS | IPA 4001 | List 16 | PIN | V-F-S-B |
| 9210 | <b>Term Start src</b><br>IPA 4000 NULL = Default<br>It allows to select the signal to generate the terminal strip Start command (refer to signals List 16 of Pick List manual)   | N/A | RWS | IPA 4000 | List 16 | PIN | V-F-S-B |
| 9211 | <b>Term Stop src</b><br>IPA 4000 NULL = Default<br>It allows to select the signal to generate the terminal strip Stop command (refer to signals List 16 of Pick List manual)   | N/A | RWS | IPA 4000 | List 16 | PIN | V-F-S-B |
| 156  | <b>Dig Enable src</b><br>IPA 7128 Lift Enable mon= Default<br>It allows to select the signal to generate a digital Enable command (refer to signals List 17 of Pick List manual)                                       | N/A | RWS | IPA 7128 | List 17 | PIN | V-F-S-B |
| 157  | <b>Dig StrStp src</b><br>IPA 7129 Lift Start mon = Default<br>It allows to select the signal to generate the a digital Start (1) command and a digital Stop (0) command (refer to signals List 17 of Pick List manual) | N/A | RWS | IPA 7129 | List 17 | PIN | V-F-S-B |
| 154  | <b>FastStop src</b><br>IPA 4000 NULL = Default<br>It allows to select the signal to generate the FastStop command (refer to signals List 18 of Pick List manual)   | N/A | RWS | IPA 4000 | List 18 | PIN | V-F-S-B |

#### I/O CONFIG / Commands / Commands cfg

"Commands select" parameter determines the logic for the Start/Stop Edge sensitive signal or Level sensitive signal or I O keys keypad commands control

|      |   |     |     |   |   |   |    |         |
|------|---|-----|-----|---|---|---|----|---------|
| 4002 | <b>Commands select</b><br>0 Terminals Level<br>1 Terminals Edge<br>2 Digital Level<br>3 Digital Edge<br>4 I O keys<br>Setting of this parameter is not allowed while terminal enable is active.                           | N/A | RWS | 2 | 0 | 4 | DV | V-F-S-B |
| 4004 | <b>En/Disable mode</b><br>0 Off<br>1 Stop/FS & Spd=0<br>2 Stop & Spd=0<br>3 FS & Spd=0<br>It controls the action time of the stop condition.<br>Setting of this parameter is not allowed while terminal enable is active. | N/A | RWS | 0 | 0 | 3 | DP | V-F-S-B |

| IPA  | Description   | [Unit] | Access | Default | Min | Max   | Format | Reg. Mode |
|------|---------------|--------|--------|---------|-----|-------|--------|-----------|
| 4006 | Spd 0 dis dly | [ms]   | RWS    | 1000    | 16  | 10000 | PP     | V-F-S-B   |

Delay time between the zero speed and the disabling procedure


### I/O CONFIG / Commands / Commands mon

|  |                  |     |   |   |   |   |    |         |
|--|------------------|-----|---|---|---|---|----|---------|
| 150                                    | Enable cmd mon   | N/A | R | 0 | 0 | 1 | DV | V-F-S-B |
| It displays the Enable command state   |                  |     |   |   |   |   |    |         |
| 151                                    | Start cmd mon    | N/A | R | 0 | 0 | 1 | DV | V-F-S-B |
| It displays the Start command state    |                  |     |   |   |   |   |    |         |
| 152                                    | FastStop cmd mon | N/A | R | 0 | 0 | 1 | DV | V-F-S-B |
| It displays the FastStop command state |                  |     |   |   |   |   |    |         |

### I/O CONFIG / Analog inputs

Drive has 3 standard and 2 expanded analog inputs. Each AI block has the following structure.

Analog inputs can also be used as non isolated digital inputs by using An inp X<thr as output and setting appropriately parameter Anp inp X thr.



#### HARDWARE JUMPER

S8 : Off --> AI1 +/- 10V  
 : On --> AI1 0-20mA ; 4 - 20mA

### Analog inputs / Std analog inps / Analog input 1 / An inp 1 src

|   |                  |     |     |          |        |     |         |  |
|---|------------------|-----|-----|----------|--------|-----|---------|--|
| 5011  | AI 1 sgn src     | N/A | RWS | IPA 4000 | List 3 | PIN | V-F-S-B |  |
| IPA 4000 NULL = Default   |                  |     |     |          |        |     |         |  |
| It connects the selected signal to the selector of the multiplier input: if the signal is 0, multiply by +1, or if the signal is 1, multiply by -1. The multiplier allows to invert Analog Input 1 signal (refer to signals List 3 of Pick List manual) |                  |     |     |          |        |     |         |  |
| 5012  | AI 1 alt sel src | N/A | RWS | IPA 4000 | List 3 | PIN | V-F-S-B |  |
| IPA 4000 NULL = Default   |                  |     |     |          |        |     |         |  |
| It connects the selected signal to the selector of the alternative reference for An. Inp. 1 block (refer to signals List 3 of Pick List manual)   |                  |     |     |          |        |     |         |  |

### Analog inputs / Std analog inps / Analog input 1 / An inp 1 cfg

|  |               |     |     |   |   |   |    |         |
|--|---------------|-----|-----|---|---|---|----|---------|
| 5000   | An inp 1 type | N/A | RWS | 0 | 0 | 2 | DP | V-F-S-B |
| 0 -10V...+10V Input connects a signal with a maximum voltage of +/-10V. (The change in |               |     |     |   |   |   |    |         |



| IPA | Description    | [Unit] | Access | Default | Min | Max | Format | Reg. Mode   |
|-----|----------------|--------|--------|---------|-----|-----|--------|---|
| 1   | 0..20mA,0..10V |        |        |         |     |     |        |   |
|     |                |        |        |         |     |     |        | the motor rotation direction is obtained according to the signal polarity).<br>Input voltage > 10V or >-10V cause saturation of the count value.<br>On the input it's possible to connect a max voltage of +10V or a 0...20mA current signal. The signal must always have a positive sign, through which, if used as a reference, it is possible to change the motor rotation direction via "AI 1 sgn src"  |
| 2   | 4..20mA        |        |        |         |     |     |        |   |
|     |                |        |        |         |     |     |        | On the input it is possible to connect a 4... 20mA current signal. The signal must always have a positive sign through which, if used as a reference, it is possible to change the motor rotation direction via "AI 1 sgn src". Through the An inp X <thr output it is possible to state if the current signal is lower than the one of the set threshold. If the current is <= 4mA , the output supplies a signal (error signal). This, for example, can be combined with a digital output |
|     | <b>Note!</b>   |        |        |         |     |     |        | "An inp 1 type" selection requires a correct jumpers configuration of RV33 regulation card:<br>-10V...+10V & 0..10V S8=OFF – S9=OFF – S10=OFF<br>0..20mA & 4..20mA S8=ON – S9= ON – S10= ON   |

|      |  |       |     |        |        |        |    |         |
|------|--|-------|-----|--------|--------|--------|----|---------|
| 5002 | <b>AI 1 alt value</b>  | [cnt] | RWS | 0      | 32767  | -32767 | PV | V-F-S-B |
|      | Alternative reference value in count for Analog input 1                    |       |     |        |        |        |    |         |
| 5003 | <b>An inp 1 thr</b>  | [cnt] | RWS | 3277   | -16384 | 16383  | PP | V-F-S-B |
|      | Analog Input 1 threshold value in count                                    |       |     |        |        |        |    |         |
| 5004 | <b>An inp 1 scale</b>  | N/A   | RWS | 1      | -16    | 16     | PP | V-F-S-B |
|      | Analog Input 1 scale factor  |       |     |        |        |        |    |         |
| 5006 | <b>An inp 1 filter</b>   | [sec] | RWS | 0.0064 | 0.00   | 4.096  | PP | V-F-S-B |
|      | Time constant of the Analog Input 1 filter                                 |       |     |        |        |        |    |         |
| 5007 | <b>An inp 1 low lim</b>  | [cnt] | RWS | -16384 | -32768 | 32767  | PP | V-F-S-B |
|      | Lower limit of the Analog Input 1 block output in count (see figure below) |       |     |        |        |        |    |         |
| 5008 | <b>An inp 1 hi lim</b>   | [cnt] | RWS | 16383  | -32768 | 32767  | PP | V-F-S-B |
|      | Upper limit of the Analog Input 1 block output in count (see figure below) |       |     |        |        |        |    |         |

#### AI 1 offs tune / Start?

Autotune command for the Analog Input 1 offset. Input automatic fine-tuning.  
To run the autotune, put the input signal to its minimum value and execute "Start ?" command

#### AI 1 gain tune / Start?

Autotune command for the Analog Input 1 gain. Conditions containing an offset can be compensated.  
To run the autotune, put the input signal to its maximum value and execute "Start ?" command

### Analog inputs / Std analog inps / Analog input 1 / An inp 1 mon

|      |  |       |     |      |        |       |    |         |
|------|--|-------|-----|------|--------|-------|----|---------|
| 5009 | <b>An inp 1 output</b>   | [cnt] | R   | 0.00 | -32768 | 32767 | PV | V-F-S-B |
|      | Analog Input 1 output count displaying   |       |     |      |        |       |    |         |
| 5010 | <b>An inp 1 &lt; thr</b>   | N/A   | R   | 0    | 0      | 1     | DV | V-F-S-B |
|      | Display of threshold compensator state of Analog Input 1 (1 = the condition is true) |       |     |      |        |       |    |         |
| 5001 | <b>An inp 1 offset</b>   | [cnt] | RWS | 0    | -16384 | 16383 | PP | V-F-S-B |
|      | Analog Input 1 offset count value displaying   |       |     |      |        |       |    |         |
| 5005 | <b>An inp 1 gain</b>   | N/A   | RWS | 1    | -16    | 16    | PP | V-F-S-B |
|      | Analog Input 1 gain count value displaying   |       |     |      |        |       |    |         |

### Analog inputs / Std analog inps / Analog input 2 / An inp 2 src

|      |   |     |     |          |        |     |         |  |
|------|---|-----|-----|----------|--------|-----|---------|--|
| 5031 | <b>AI 2 sgn src</b>   | N/A | RWS | IPA 4000 | List 3 | PIN | V-F-S-B |  |
|      | IPA 4000 NULL = Default<br>It connects the selected signal to the selector of the multiplier input: if the signal is 0, |     |     |          |        |     |         |  |

| IPA  | Description   | [Unit] | Access | Default  | Min    | Max | Format  | Reg. Mode |
|------|---|--------|--------|----------|--------|-----|---------|-----------|
|      | multiply by +1, or if the signal is 1, multiply by -1. The multiplier allows to invert Analog Input 2 signal (refer to signals List 3 of Pick List manual)  |        |        |          |        |     |         |           |
| 5032 | <b>AI 2 alt sel src</b><br>IPA 4000 NULL = Default<br>It connects the selected signal to the selector of the alternative reference for An. Inp. 2 block (refer to signals List 3 of Pick List manual) | N/A    | RWS    | IPA 4000 | List 3 | PIN | V-F-S-B |           |

### Analog inputs / Std analog inps / Analog input 2 / An inp 2 cfg

|      |  |       |     |        |        |        |    |         |
|------|--|-------|-----|--------|--------|--------|----|---------|
| 5020 | <b>An inp 2 type</b><br>0 -10V ... +10V<br>1 0..20mA,0..10V<br>3 4..20mA<br>For "An inp 2 type" description refer to "An inp 1 type" description above | N/A   | RWS | 0      | 0      | 2      | DP | V-F-S-B |
| 5022 | <b>AI 2 alt value</b><br>Alternative reference value in count for Analog input 2   | [cnt] | RWS | 0      | 32767  | -32767 | PV | V-F-S-B |
| 5023 | <b>An inp 2 thr</b><br>Analog Input 2 threshold value in count   | [cnt] | RWS | 3277   | -16384 | 16383  | PP | V-F-S-B |
| 5024 | <b>An inp 2 scale</b><br>Analog Input 2 scale factor   | N/A   | RWS | 1      | -16    | 16     | PP | V-F-S-B |
| 5026 | <b>An inp 2 filter</b><br>Time constant of the Analog Input 2 filter   | [sec] | RWS | 0.0064 | 0.00   | 4.096  | PP | V-F-S-B |
| 5027 | <b>An inp 2 lo lim</b><br>Lower limit of the Analog Input 2 block output in count (see figure of Analog Input 1 above)                                 | [cnt] | RWS | -16384 | -32768 | 32767  | PP | V-F-S-B |
| 5028 | <b>An inp 2 hi lim</b><br>Upper limit of the Analog Input 2 block output in count (see figure of Analog Input 1 above)                                 | [cnt] | RWS | 16383  | -32768 | 32767  | PP | V-F-S-B |

#### AI 2 offs tune / Start?

Refer to "AI 1 offs tune" description above

#### AI 2 gain tune / Start?

Refer to "AI 1 gain tune" description above

### Analog inputs / Std analog inps / Analog input 2 / An inp 2 mon

|      |  |       |     |      |        |       |    |         |
|------|--|-------|-----|------|--------|-------|----|---------|
| 5029 | <b>An inp 2 output</b><br>Analog Input 2 output count displaying   | [cnt] | R   | 0.00 | -32768 | 32767 | PV | V-F-S-B |
| 5030 | <b>An inp 2 &lt; thr</b><br>Display of threshold compensator state of Analog Input 2 (1 = the condition is true) | N/A   | R   | 0    | 0      | 1     | DV | V-F-S-B |
| 5021 | <b>An inp 2 offset</b><br>Analog Input 2 offset count value displaying   | [cnt] | RWS | 0    | -16384 | 16383 | PP | V-F-S-B |
| 5025 | <b>An inp 2 gain</b><br>Analog Input 2 gain count value displaying   | N/A   | RWS | 1    | -16    | 16    | PP | V-F-S-B |

### Analog inputs / Std analog inps / Analog input 3 / An inp 3 src

|      |   |     |     |          |        |     |         |  |
|------|---|-----|-----|----------|--------|-----|---------|--|
| 5051 | <b>AI 3 sgn src</b><br>IPA 4000 NULL = Default<br>It connects the selected signal to the selector of the multiplier input: if the signal is 0, multiply by +1, or if the signal is 1, multiply by -1. The multiplier allows to invert Analog Input 3 signal (refer to signals List 3 of Pick List manual) | N/A | RWS | IPA 4000 | List 3 | PIN | V-F-S-B |  |
| 5052 | <b>AI 3 alt sel src</b><br>IPA 4000 NULL = Default  | N/A | RWS | IPA 4000 | List 3 | PIN | V-F-S-B |  |

| IPA  | Description  | [Unit] | Access | Default  | Min    | Max    | Format | Reg. Mode |
|--|--|--------|--------|----------|--------|--------|--------|-----------|
|  | It connects the selected signal to the selector of the alternative reference for An. Inp. 3 block (refer to signals List 3 of Pick List manual)  |        |        |          |        |        |        |           |
| <b>Analog inputs / Std analog inps / Analog input 3 / An inp 3 cfg</b>   |  |        |        |          |        |        |        |           |
| 5040   | <b>An inp 3 type</b>   | N/A    | RWS    | 0        | 0      | 2      | DP     | V-F-S-B   |
|  | 0 -10V ... +10V<br>1 0..20mA,0..10V<br>2 4..20mA<br>For "An inp 3 type" description refer to "An inp 1 type" description above   |        |        |          |        |        |        |           |
| 5042   | <b>AI 3 alt value</b>  | [cnt]  | RWS    | 0        | 32767  | -32767 | PV     | V-F-S-B   |
|  | Alternative reference value in count for Analog input 3  |        |        |          |        |        |        |           |
| 5043   | <b>An inp 3 thr</b>  | [cnt]  | RWS    | 3277     | -16384 | 16383  | PP     | V-F-S-B   |
|  | Analog Input 3 threshold value in count  |        |        |          |        |        |        |           |
| 5044   | <b>An inp 3 scale</b>  | N/A    | RWS    | 1        | -16    | 16     | PP     | V-F-S-B   |
|  | Analog Input 3 scale factor  |        |        |          |        |        |        |           |
| 5046   | <b>An inp 3 filter</b>   | [sec]  | RWS    | 0.0064   | 0.00   | 4.096  | PP     | V-F-S-B   |
|  | Time constant of the Analog Input 3 filter   |        |        |          |        |        |        |           |
| 5047   | <b>An inp 3 lo lim</b>   | [cnt]  | RWS    | -16384   | -32768 | 32767  | PP     | V-F-S-B   |
|  | Lower limit of the Analog Input 3 block output in count (see figure of Analog Input 1 above)   |        |        |          |        |        |        |           |
| 5048   | <b>An inp 3 hi lim</b>   | [cnt]  | RWS    | 16383    | -32768 | 32767  | PP     | V-F-S-B   |
|  | Upper limit of the Analog Input 3 block output in count (see figure of Analog Input 1 above)   |        |        |          |        |        |        |           |
| <b>AI 3 offs tune</b>  |  |        |        |          |        |        |        |           |
|  | Refer to "AI 1 offs tune" description above  |        |        |          |        |        |        |           |
| <b>AI 3 gain tune</b>  |  |        |        |          |        |        |        |           |
|  | Refer to "AI 1 gain tune" description above  |        |        |          |        |        |        |           |
| <b>Analog inputs / Std analog inps / Analog input 3 / An inp 3 mon</b>   |  |        |        |          |        |        |        |           |
| 5049   | <b>An inp 3 output</b>   | [cnt]  | R      | 0.00     | -32768 | 32767  | PV     | V-F-S-B   |
|  | Analog Input 3 output count displaying   |        |        |          |        |        |        |           |
| 5050   | <b>An inp 3 &lt; thr</b>   | N/A    | R      | 0        | 0      | 1      | DV     | V-F-S-B   |
|  | Display of threshold compensator state of Analog Input 3 (1 = the condition is true)   |        |        |          |        |        |        |           |
| 5041   | <b>An inp 3 offset</b>   | [cnt]  | RWS    | 0        | -16384 | 16383  | PP     | V-F-S-B   |
|  | Analog Input 3 offset count value displaying   |        |        |          |        |        |        |           |
| 5045   | <b>An inp 3 gain</b>   | -      | RWS    | 1        | -16    | 16     | PP     | V-F-S-B   |
|  | Analog Input 3 gain count value displaying   |        |        |          |        |        |        |           |
| <b>Analog inputs / Exp analog inps / Analog input 1X / An inp 1X src</b> |  |        |        |          |        |        |        |           |
| 5069   | <b>AI 1X sgn src</b>   | N/A    | RWS    | IPA 4000 | List 3 | PIN    |        | V-F-S-B   |
|  | IPA 4000 NULL = Default<br>It connects the selected signal to the selector of the multiplier input: if the signal is 0, multiply by +1, or if the signal is 1, multiply by -1. The multiplier allows to invert Analog Input 1X signal. (refer to signals List 3 of Pick List manual) |        |        |          |        |        |        |           |
| <b>Analog inputs / Exp analog inps / Analog input 1X / An inp 1X cfg</b> |  |        |        |          |        |        |        |           |
| 5060   | <b>An inp 1X type</b>  | N/A    | RWS    | 0        | 0      | 2      | DP     | V-F-S-B   |
|  | 0 -10V ... +10V<br>1 0..20mA,0..10V<br>3 4..20mA<br>For "An inp 1X type" description refer to "An inp 1 type" description above  |        |        |          |        |        |        |           |

| IPA  | Description  | [Unit] | Access | Default | Min    | Max   | Format | Reg. Mode |
|------|--|--------|--------|---------|--------|-------|--------|-----------|
| 5062 | <b>An inp 1X thr</b><br>Analog Input 1X threshold value in count   | [cnt]  | RWS    | 3277    | -16384 | 16383 | PP     | V-F-S-B   |
| 5063 | <b>An inp 1X scale</b><br>Analog Input 1X scale factor   | N/A    | RWS    | 1       | -16    | 16    | PP     | V-F-S-B   |
| 5065 | <b>An inp 1X lo lim</b><br>Lower limit of the Analog Input 1X block output in count (see figure of Analog Input 1 above) | [cnt]  | RWS    | -16384  | -32768 | 32767 | PP     | V-F-S-B   |
| 5066 | <b>An inp 1X hi lim</b><br>Upper limit of the Analog Input 1X block output in count (see figure of Analog Input 1 above) | [cnt]  | RWS    | 16383   | -32768 | 32767 | PP     | V-F-S-B   |

#### AI 1X offs tune

Refer to “AI 1 offs tune” description above

#### AI 1X gain tune

Refer to “AI 1 offs gain” description above

### Analog inputs / Exp analog inps / Analog input 1X / An inp 1X mon

|      |  |       |     |      |        |       |    |         |
|------|--|-------|-----|------|--------|-------|----|---------|
| 5067 | <b>An inp 1X output</b><br>Analog Input 1X output count displaying   | [cnt] | R   | 0.00 | -32768 | 32767 | PV | V-F-S-B |
| 5068 | <b>An inp 1X &lt; thr</b><br>Display of threshold compensator state of Analog Input 1X (1 = the condition is true) | N/A   | R   | 0    | 0      | 1     | DV | V-F-S-B |
| 5061 | <b>An inp 1X offset</b><br>Analog Input 1X offset count value displaying   | [cnt] | RWS | 0    | -16384 | 16383 | PP | V-F-S-B |
| 5064 | <b>An inp 1X gain</b><br>Analog Input 1X gain count value displaying   | [cnt] | RWS | 0    | -16384 | 16383 | PP | V-F-S-B |

### Analog inputs / Exp analog inps / Analog input 2X / An inp 2X src

|      |  |     |     |          |        |     |         |
|------|--|-----|-----|----------|--------|-----|---------|
| 5089 | <b>AI 2X sgn src</b><br>IPA 4000 NULL = Default<br>It connects the selected signal to the selector of the multiplier input: if the signal is 0, multiply by +1, or if the signal is 1, multiply by -1. The multiplier allows to invert Analog Input 2X signal. (refer to signals List 3 of Pick List manual) | N/A | RWS | IPA 4000 | List 3 | PIN | V-F-S-B |
|------|--|-----|-----|----------|--------|-----|---------|

### Analog inputs / Exp analog inps / Analog input 2X / An inp 2X cfg

|      |  |       |     |        |        |       |    |         |
|------|--|-------|-----|--------|--------|-------|----|---------|
| 5080 | <b>An inp 2X type</b><br>0 -10V ... +10V<br>1 0..20mA,0..10V<br>2 4..20mA<br>For “An inp 2X type” description refer to “An inp 1 type” description above | N/A   | RWS | 0      | 0      | 2     | DP | V-F-S-B |
| 5082 | <b>An inp 2X thr</b><br>Analog Input 2X threshold value in count   | [cnt] | RWS | 3277   | -16384 | 16383 | PP | V-F-S-B |
| 5083 | <b>An inp 2X scale</b><br>Analog Input 2X scale factor   | N/A   | RWS | 1      | -16    | 16    | PP | V-F-S-B |
| 5085 | <b>An inp 2X lo lim</b><br>Lower limit of the Analog Input 2X block output in count (see figure of Analog Input 1 above)                                 | [cnt] | RWS | -16384 | -32768 | 32767 | PP | V-F-S-B |
| 5086 | <b>An inp 2X hi lim</b><br>Upper limit of the Analog Input 2X block output in count (see figure of Analog Input 1 above)                                 | [cnt] | RWS | 16383  | -32768 | 32767 | PP | V-F-S-B |

#### AI 2X offs tune

Refer to “AI 1 offs tune” description above

#### AI 2X gain tune

Refer to “AI 1 offs gain” description above

| IPA  | Description  | [Unit] | Access | Default | Min    | Max   | Format | Reg. Mode |
|--|--|--------|--------|---------|--------|-------|--------|-----------|
| <b>Analog inputs / Exp analog inps / Analog input 2X / An inp 2X mon</b> |  |        |        |         |        |       |        |           |
| 5087   | <b>An inp 2X output</b><br>Analog Input 2X output count displaying   | [cnt]  | R      | 0.00    | -32768 | 32767 | PV     | V-F-S-B   |
| 5088   | <b>An inp 2X &lt; thr</b><br>Display of threshold compensator state of Analog Input 2X (1 = the condition is true) | N/A    | R      | 0.00    | 0.00   | 0.00  | DV     | V-F-S-B   |
| 5081   | <b>An inp 2X offset</b><br>Analog Input 2X offset count value displaying   | [cnt]  | RWS    | 0       | -16384 | 16383 | PP     | V-F-S-B   |
| 5084   | <b>An inp 2X gain</b><br>Analog Input 2X gain count value displaying   | [cnt]  | RWS    | 0       | -16384 | 16383 | PP     | V-F-S-B   |

### Analog inputs / Exp analog inps / Exp ana inp en

|      |   |     |     |   |   |   |    |         |
|------|---|-----|-----|---|---|---|----|---------|
| 3900 | <b>Exp ana inp en</b><br>0 Disabled<br>2 Enabled<br>It enables Expanded Analog Inputs | N/A | RWS | 0 | 0 | 1 | DV | V-F-S-B |
|------|---|-----|-----|---|---|---|----|---------|

### Analog inputs / Destinations

This read-only menu allows the user to see where the Analog inputs are connected. If more then one source is connected to an Analog Input, only one is shown. If no sources are connected the message "Not used" is displayed.

|      |   |
|------|---|
| 4500 | <b>An inp 1 dst</b><br>It displays the Analog Input 1 destination   |
| 4501 | <b>An inp 2 dst</b><br>It displays the Analog Input 2 destination   |
| 4502 | <b>An inp 3 dst</b><br>It displays the Analog Input 3 destination   |
| 4503 | <b>An inp 1X dst</b><br>It displays the Analog Input 1X destination |
| 4504 | <b>An inp 2X dst</b><br>It displays the Analog Input 2X destination |


### I/O CONFIG / Analog outputs

#### CALIBRATION TO +/-10 V OUTPUT

An out 1 mon (in counts) \* An out 1 scale = An out 1 hi lim (in counts) = 10 V


An out 1 mon (in counts) \* An out 1 scale = An out 1 lo lim (in counts) = -10 V

Software version 3.200



| IPA | Description | [Unit] | Access | Default | Min | Max | Format | Reg. Mode |
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|

Software version 3.300



Drive has 2 standard (voltage outputs) and 4 expanded analog outputs (1x and 2x = voltage outputs, 3x and 4x = current outputs). Each Analog output block has the following structure.

| Analog outputs / Std analog outs / Analog output 1 / An out 1 src  |                  |       |     |          |        |        |    |         |
|--|------------------|-------|-----|----------|--------|--------|----|---------|
| 3570   | An out 1 src     | N/A   | RWS | IPA 4000 |        | List 2 |    | V-F-S-B |
| IPA 4000 NULL = Default<br>It allows to connect the selected signal to the Analog output 1 (refer to signals List 2 of Pick List manual) |                  |       |     |          |        |        |    |         |
| 3575   | An out 1 sgn src | N/A   | RWS | IPA 4000 |        | List 2 |    | V-F-S-B |
| It allows to select the sign of the signal connected on analog output. (from software rel. 3.300)  |                  |       |     |          |        |        |    |         |
| Analog outputs / Std analog outs / Analog output 1 / An out 1 cfg  |                  |       |     |          |        |        |    |         |
| 6012   | An out 1 scale   | N/A   | RWS | 1        | -10    | 10     | PP | V-F-S-B |
| Scale or multiplicative factor of Analog output 1  |                  |       |     |          |        |        |    |         |
| 6010   | An out 1 hi lim  | [cnt] | RWS | 16383    | 0      | 32767  | PP | V-F-S-B |
| Analog output 1 count value aimed at obtaining +10V. Value must be higher than zero  |                  |       |     |          |        |        |    |         |
| 6011   | An out 1 lo lim  | [cnt] | RWS | -16384   | -32768 | 0      | PP | V-F-S-B |
| Analog output 1 count value aimed at obtaining -10V. Value must be higher than zero  |                  |       |     |          |        |        |    |         |
| Analog outputs / Std analog outs / Analog output 1 / An out 1 mon  |                  |       |     |          |        |        |    |         |
| 6013   | An out 1 mon     | [cnt] | R   | 0        | -32768 | 32767  | PP | V-F-S-B |
| Analog output 1 count value displaying   |                  |       |     |          |        |        |    |         |
| Analog outputs / Std analog outs / Analog output 2 / An out 2 src  |                  |       |     |          |        |        |    |         |
| 3580   | An out 2 src     | N/A   | RWS | IPA 4000 |        | List 2 |    | V-F-S-B |
| IPA 4000 NULL = Default<br>It allows to connect the selected signal to the Analog output 2 (refer to signals List 2 of Pick List manual) |                  |       |     |          |        |        |    |         |
| 3576   | An out 2 sgn src | N/A   | RWS | IPA 4000 |        | List 2 |    | V-F-S-B |
| It allows to select the sign of the signal connected on analog output. (from software rel. 3.300)  |                  |       |     |          |        |        |    |         |
| Analog outputs / Std analog outs / Analog output 2 / An out 2 cfg  |                  |       |     |          |        |        |    |         |
| 6017   | An out 2 scale   | N/A   | RWS | 1        | -10    | 10     | PP | V-F-S-B |
| Scale or multiplicative factor of Analog output 2  |                  |       |     |          |        |        |    |         |
| 6015   | An out 2 hi lim  | [cnt] | RWS | 16383    | 0      | 32767  | PP | V-F-S-B |
| Analog output 2 count value aimed at obtaining +10V. Value must be higher than zero  |                  |       |     |          |        |        |    |         |
| 6016   | An out 2 lo lim  | [cnt] | RWS | -16384   | -32768 | 0      | PP | V-F-S-B |
| Analog output 2 count value aimed at obtaining -10V. Value must be higher than zero  |                  |       |     |          |        |        |    |         |

| IPA  | Description  | [Unit] | Access | Default  | Min    | Max    | Format | Reg. Mode |
|--|--|--------|--------|----------|--------|--------|--------|-----------|
| <b>Analog outputs / Std analog outs / Analog output 2 / An out 2 mon</b>   |  |        |        |          |        |        |        |           |
| 6018   | <b>An out 2 mon</b><br>Analog output 2 count value displaying  | [cnt]  | R      | 0.00     | -32768 | 32676  | PP     | V-F-S-B   |
| <b>Analog outputs / Exp analog outs / Analog output 1X / An out 1X src</b> |  |        |        |          |        |        |        |           |
| 4090   | <b>An out 1X src</b><br>IPA 4000 NULL = Default<br>It allows to connect the selected signal to the Analog output 1X<br>(refer to signals List 2 of Pick List manual) | N/A    | RWS    | IPA 4000 |        | List 2 |        | V-F-S-B   |
| <b>Analog outputs / Exp analog outs / Analog output 1X / An out 1X cfg</b> |  |        |        |          |        |        |        |           |
| 6022   | <b>An out 1X scale</b><br>Scale or multiplicative factor of Analog output 1X   | N/A    | RWS    | 1        | -10    | 10     | PP     | V-F-S-B   |
| 6020   | <b>An out 1X hi lim</b><br>Analog output 1X count value aimed at obtaining +10V. Value must be higher than zero  | [cnt]  | RWS    | 16383    | 0      | 32767  | PP     | V-F-S-B   |
| 6021   | <b>An out 1X lo lim</b><br>Analog output 1X count value aimed at obtaining -10V. Value must be higher than zero  | [cnt]  | RWS    | -16384   | -32768 | 0      | PP     | V-F-S-B   |
| <b>Analog outputs / Exp analog outs / Analog output 1X / An out 1X mon</b> |  |        |        |          |        |        |        |           |
| 6023   | <b>An out 1X mon</b><br>Analog output 1X count value displaying  | [cnt]  | R      | 0.00     | -32768 | 32676  | PP     | V-F-S-B   |
| <b>Analog outputs / Exp analog outs / Analog output 2X / An out 2X src</b> |  |        |        |          |        |        |        |           |
| 4091   | <b>An out 2X src</b><br>IPA 4000 NULL = Default<br>It allows to connect the selected signal to the Analog output 2X<br>(refer to signals List 2 of Pick List manual) | N/A    | RWS    | IPA 4000 |        | List 2 |        | V-F-S-B   |
| <b>Analog outputs / Exp analog outs / Analog output 2X / An out 2X cfg</b> |  |        |        |          |        |        |        |           |
| 6027   | <b>An out 2X scale</b><br>Scale or multiplicative factor of Analog output 2X   | N/A    | RWS    | 1        | -10    | 10     | PP     | V-F-S-B   |
| 6025   | <b>An out 2X hi lim</b><br>Analog output 2X count value aimed at obtaining +10V. Value must be higher than zero  | [cnt]  | RWS    | 16383    | 0      | 32767  | PP     | V-F-S-B   |
| 6026   | <b>An out 2X lo lim</b><br>Analog output 2X count value aimed at obtaining -10V. Value must be higher than zero  | [cnt]  | RWS    | -16384   | -32768 | 0      | PP     | V-F-S-B   |
| <b>Analog outputs / Exp analog outs / Analog output 2X / An out 2X mon</b> |  |        |        |          |        |        |        |           |
| 6028   | <b>An out 2X mon</b><br>Analog output 2X count value displaying  | [cnt]  | R      | 0.00     | -32768 | 32676  | PP     | V-F-S-B   |
| <b>Analog outputs / Exp analog outs / Analog output 3X / An out 3X src</b> |  |        |        |          |        |        |        |           |
| 4092   | <b>An out 3X src</b><br>IPA 4000 NULL = Default<br>It allows to connect the selected signal to the Analog output 3X<br>(refer to signals List 2 of Pick List manual) | N/A    | RWS    | IPA 4000 |        | List 2 |        | V-F-S-B   |
| <b>Analog outputs / Exp analog outs / Analog output 3X / An out 3X cfg</b> |  |        |        |          |        |        |        |           |
| 6034   | <b>An out 3X type</b><br>0 0..20 mA<br>1 4..20 mA<br>It allows to select the Analog output 3X type (EXP-D20A6 optional card is required)                             | N/A    | RWS    | 0        | 0      | 1      | DP     | V-F-S-B   |

| IPA  | Description  | [Unit] | Access | Default  | Min    | Max    | Format | Reg. Mode |
|--|--|--------|--------|----------|--------|--------|--------|-----------|
| 6032   | <b>An out 3X scale</b><br>Scale or multiplicative factor of Analog output 3X   | N/A    | RWS    | 1        | -10    | 10     | PP     | V-F-S-B   |
| 6030   | <b>An out 3X hi lim</b><br>Analog output 3X count value aimed at obtaining +10V. Value must be higher than zero  | [cnt]  | RWS    | 16383    | 0      | 32767  | PP     | V-F-S-B   |
| 6031   | <b>An out 3X lo lim</b><br>Analog output 3X count value aimed at obtaining -10V. Value must be higher than zero  | [cnt]  | RWS    | -16384   | -32768 | 0      | PP     | V-F-S-B   |
| <b>Analog outputs / Exp analog outs / Analog output 3X / An out 3X mon</b> |  |        |        |          |        |        |        |           |
| 6033   | <b>An out 3X mon</b><br>Analog output 3X count value displaying  | [cnt]  | R      | 0.00     | -32768 | 32676  | PP     | V-F-S-B   |
| <b>Analog outputs / Exp analog outs / Analog output 4X / An out 4X src</b> |  |        |        |          |        |        |        |           |
| 4093   | <b>An out 4X src</b><br>IPA 4000 NULL = Default<br>It allows to connect the selected signal to the Analog output 4X<br>(refer to signals List 2 of Pick List manual) | N/A    | RWS    | IPA 4000 |        | List 2 |        | V-F-S-B   |
| <b>Analog outputs / Exp analog outs / Analog output 4X / An out 4X cfg</b> |  |        |        |          |        |        |        |           |
| 6039   | <b>An out 4x type</b><br>0 0..20 mA<br>1 4..20 mA<br>It allows to select the Analog output 4X type (EXP-D20A6 optional card is required)                             | N/A    | RWS    | 0        | 0      | 1      | DP     | V-F-S-B   |
| 6037   | <b>An out 4X scale</b><br>Scale or multiplicative factor of Analog output 4X   | N/A    | RWS    | 1        | -10    | 10     | PP     | V-F-S-B   |
| 6035   | <b>An out 4X hi lim</b><br>Analog output 4X count value aimed at obtaining +10V. Value must be higher than zero  | [cnt]  | RWS    | 16383    | 0      | 32767  | PP     | V-F-S-B   |
| 6036   | <b>An out 4X lo lim</b><br>Analog output 4X count value aimed at obtaining -10V. Value must be higher than zero  | [cnt]  | RWS    | -16384   | -32768 | 0      | PP     | V-F-S-B   |
| <b>Analog outputs / Exp analog outs / Analog output 4X / An out 4X mon</b> |  |        |        |          |        |        |        |           |
| 6038   | <b>An out 4X mon</b><br>Analog output 4X count value displaying  | [cnt]  | R      | 0.00     | -32768 | 32676  | PP     | V-F-S-B   |
| <b>Analog outputs / Exp analog outs / Exp ana out en</b>                   |  |        |        |          |        |        |        |           |
| 3901   | <b>Exp ana out en</b><br>0 Disabled<br>1 Enabled<br>It enables the expanded analog outputs   | N/A    | RWS    | 0        | 0      | 1      | DV     | V-F-S-B   |




### I/O CONFIG / Digital inputs

Digital Input Block function allows to invert the signal on the terminal strip.

For example, if the potential available on the terminal strip is +24V, and the inversion is disabled (not inverted) the input state is 1 (ONE), standard configuration; if the inversion is enabled (inversion) the input state is 0 (NULL). The Drive ENABLE is set on the "Digital input 0"; such condition can not be changed as it is performed via the hardware.

Its function, anyway, can be combined with a command signal in the sources of the other Blocks. "DI 0 Enable mon" signal (Digital input 0 signal) is available in the "List 3".



### I/O CONFIG / Digital inputs / Std digital inps / Std dig inp cfg

|      |   |     |     |   |   |   |    |         |
|------|---|-----|-----|---|---|---|----|---------|
| 4011 | <b>DI 1 inversion</b><br>0 Not inverted<br>1 Inverted | N/A | RWS | 0 | 0 | 1 | DP | V-F-S-B |
| 4012 | <b>DI 2 inversion</b><br>0 Not inverted<br>1 Inverted | N/A | RWS | 0 | 0 | 1 | DP | V-F-S-B |
| 4013 | <b>DI 3 inversion</b><br>0 Not inverted<br>1 Inverted | N/A | RWS | 0 | 0 | 1 | DP | V-F-S-B |
| 4014 | <b>DI 4 inversion</b><br>0 Not inverted<br>1 Inverted | N/A | RWS | 0 | 0 | 1 | DP | V-F-S-B |
| 4015 | <b>DI 5 inversion</b><br>0 Not inverted<br>1 Inverted | N/A | RWS | 0 | 0 | 1 | DP | V-F-S-B |
| 4016 | <b>DI 6 inversion</b><br>0 Not inverted<br>1 Inverted | N/A | RWS | 0 | 0 | 1 | DP | V-F-S-B |

| IPA  | Description   | [Unit] | Access | Default | Min | Max | Format | Reg. Mode |
|------|---|--------|--------|---------|-----|-----|--------|-----------|
| 4017 | <b>DI 7 inversion</b><br>0 Not inverted<br>1 Inverted | N/A    | RWS    | 0       | 0   | 1   | DP     | V-F-S-B   |

#### I/O CONFIG / Digital inputs / Std digital inps / Std dig inp mon

|      |  |     |   |   |   |   |    |         |
|------|--|-----|---|---|---|---|----|---------|
| 4020 | <b>DI 0 Enable mon</b><br>Enable terminal displaying       | N/A | R | 0 | 0 | 1 | DV | V-F-S-B |
| 4021 | <b>DI 1 monitor</b><br>Digital Input 1 terminal displaying | N/A | R | 0 | 0 | 1 | DV | V-F-S-B |
| 4022 | <b>DI 2 monitor</b><br>Digital Input 2 terminal displaying | N/A | R | 0 | 0 | 1 | DV | V-F-S-B |
| 4023 | <b>DI 3 monitor</b><br>Digital Input 3 terminal displaying | N/A | R | 0 | 0 | 1 | DV | V-F-S-B |
| 4024 | <b>DI 4 monitor</b><br>Digital Input 4 terminal displaying | N/A | R | 0 | 0 | 1 | DV | V-F-S-B |
| 4025 | <b>DI 5 monitor</b><br>Digital Input 5 terminal displaying | N/A | R | 0 | 0 | 1 | DV | V-F-S-B |
| 4026 | <b>DI 6 monitor</b><br>Digital Input 6 terminal displaying | N/A | R | 0 | 0 | 1 | DV | V-F-S-B |

#### Digital Input 6 terminal displaying

|      |  |     |   |   |   |   |    |         |
|------|--|-----|---|---|---|---|----|---------|
| 4027 | <b>DI 7 monitor</b><br>Digital Input 7 terminal displaying   | N/A | R | 0 | 0 | 1 | DV | V-F-S-B |
| 4028 | <b>DI 7654321E</b><br>Standard digital inputs displaying. Under each number the logical state of each single input is displayed. | N/A | R | 0 | 0 | - | DP | V-F-S-B |

#### I/O CONFIG / Digital inputs / Exp digital inps / Exp dig inp cfg


|      |  |     |     |   |   |   |    |         |
|------|--|-----|-----|---|---|---|----|---------|
| 4030 | <b>DI 0X inversion</b><br>0 Not inverted<br>1 Inverted | N/A | RWS | 0 | 0 | 1 | DP | V-F-S-B |
| 4031 | <b>DI 1X inversion</b><br>0 Not inverted<br>1 Inverted | N/A | RWS | 0 | 0 | 1 | DP | V-F-S-B |
| 4032 | <b>DI 2X inversion</b><br>0 Not inverted<br>1 Inverted | N/A | RWS | 0 | 0 | 1 | DP | V-F-S-B |
| 4033 | <b>DI 3X inversion</b><br>0 Not inverted<br>1 Inverted | N/A | RWS | 0 | 0 | 1 | DP | V-F-S-B |
| 4034 | <b>DI 4X inversion</b><br>0 Not inverted<br>1 Inverted | N/A | RWS | 0 | 0 | 1 | DP | V-F-S-B |
| 4035 | <b>DI 5X inversion</b><br>0 Not inverted<br>1 Inverted | N/A | RWS | 0 | 0 | 1 | DP | V-F-S-B |
| 4036 | <b>DI 6X inversion</b><br>0 Not inverted<br>1 Inverted | N/A | RWS | 0 | 0 | 1 | DP | V-F-S-B |

| IPA   | Description   | [Unit] | Access | Default | Min | Max | Format | Reg. Mode |
|---|---|--------|--------|---------|-----|-----|--------|-----------|
| 4037  | <b>DI 7X inversion</b><br>0 Not inverted<br>1 Inverted  | N/A    | RWS    | 0       | 0   | 1   | DP     | V-F-S-B   |
| 4038  | <b>DI 8X inversion</b><br>0 Not inverted<br>1 Inverted  | N/A    | RWS    | 0       | 0   | 1   | DP     | V-F-S-B   |
| 4039  | <b>DI 9X inversion</b><br>0 Not inverted<br>1 Inverted  | N/A    | RWS    | 0       | 0   | 1   | DP     | V-F-S-B   |
| 4040  | <b>DI 10X inversion</b><br>0 Not inverted<br>1 Inverted   | N/A    | RWS    | 0       | 0   | 1   | DP     | V-F-S-B   |
| 4041  | <b>DI 11X inversion</b><br>0 Not inverted<br>1 Inverted   | N/A    | RWS    | 0       | 0   | 1   | DP     | V-F-S-B   |
| <b>I/O CONFIG / Digital inputs / Exp digital inps / Exp dig inp mon</b> |   |        |        |         |     |     |        |           |
| 4045  | <b>DI 0X monitor</b><br>Digital Input 0X terminal displaying  | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |
| 4046  | <b>DI 1X monitor</b><br>Digital Input 1X terminal displaying  | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |
| 4047  | <b>DI 2X monitor</b><br>Digital Input 2X terminal displaying  | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |
| 4048  | <b>DI 3X monitor</b><br>Digital Input 3X terminal displaying  | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |
| 4049  | <b>DI 4X monitor</b><br>Digital Input 4X terminal displaying  | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |
| 4050  | <b>DI 5X monitor</b><br>Digital Input 5X terminal displaying  | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |
| 4051  | <b>DI 6X monitor</b><br>Digital Input 6X terminal displaying  | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |
| 4052  | <b>DI 7X monitor</b><br>Digital Input 7X terminal displaying  | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |
| 4053  | <b>DI 8X monitor</b><br>Digital Input 8X terminal displaying  | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |
| 4054  | <b>DI 9X monitor</b><br>Digital Input 9X terminal displaying  | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |
| 4055  | <b>DI 10X monitor</b><br>Digital Input 10X terminal displaying  | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |
| 4056  | <b>DI 11X monitor</b><br>Digital Input 11X terminal displaying  | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |
| 4057  | <b>DIX BA9876543210</b><br>Expanded digital inputs displaying. Under each number the logical state of each single input is displayed. | N/A    | R      | 0       | 0   | -   | DV     | V-F-S-B   |

| IPA   | Description                            | [Unit]   | Access | Default | Min | Max | Format | Reg. Mode |
|---|--|--|--------|---------|-----|-----|--------|-----------|
| <b>I/O CONFIG / Digital inputs / Exp dig inp en</b>   |  |  |        |         |     |     |        |           |
| 3902  | <b>Exp dig inp en</b>                  | N/A  | RWS    | 0       | 0   | 1   | DV     | V-F-S-B   |
|   | 0                                      | Disabled   |        |         |     |     |        |           |
|   | 1                                      | Enabled  |        |         |     |     |        |           |
|   | It enables the expanded digital inputs |  |        |         |     |     |        |           |
| <b>I/O CONFIG / Digital inputs / Destinations</b>   |  |  |        |         |     |     |        |           |
| This read-only menu allows the user to see where the Digital inputs are connected. If more than one source is connected to the Digital Input, only first one is shown. If no sources are connected the message "Not used" is displayed. |  |  |        |         |     |     |        |           |
| 4505  | <b>DI 0 Enable dst</b>                 | It displays the Digital Input 0 (Enable) destination |        |         |     |     |        |           |
| 4506  | <b>DI 1 dst</b>                        | It displays the Digital Input 1 destination          |        |         |     |     |        |           |
| 4507  | <b>DI 2 dst</b>                        | It displays the Digital Input 2 destination          |        |         |     |     |        |           |
| 4508  | <b>DI 3 dst</b>                        | It displays the Digital Input 3 destination          |        |         |     |     |        |           |
| 4509  | <b>DI 4 dst</b>                        | It displays the Digital Input 4 destination          |        |         |     |     |        |           |
| 4510  | <b>DI 5 dst</b>                        | It displays the Digital Input 5 destination          |        |         |     |     |        |           |
| 4511  | <b>DI 6 dst</b>                        | It displays the Digital Input 6 destination          |        |         |     |     |        |           |
| 4512  | <b>DI 7 dst</b>                        | It displays the Digital Input 7 destination          |        |         |     |     |        |           |
| 4513  | <b>DI 0X dst</b>                       | It displays the Digital Input 0X destination         |        |         |     |     |        |           |
| 4514  | <b>DI 1X dst</b>                       | It displays the Digital Input 1X destination         |        |         |     |     |        |           |
| 4515  | <b>DI 2X dst</b>                       | It displays the Digital Input 2X destination         |        |         |     |     |        |           |
| 4516  | <b>DI 3X dst</b>                       | It displays the Digital Input 3X destination         |        |         |     |     |        |           |
| 4517  | <b>DI 4X dst</b>                       | It displays the Digital Input 4X destination         |        |         |     |     |        |           |
| 4518  | <b>DI 5X dst</b>                       | It displays the Digital Input 5X destination         |        |         |     |     |        |           |
| 4519  | <b>DI 6X dst</b>                       | It displays the Digital Input 6X destination         |        |         |     |     |        |           |
| 4520  | <b>DI 7X dst</b>                       | It displays the Digital Input 7X destination         |        |         |     |     |        |           |
| 4521  | <b>DI 8X dst</b>                       | It displays the Digital Input 8X destination         |        |         |     |     |        |           |
| 4522  | <b>DI 9X dst</b>                       | It displays the Digital Input 9X destination         |        |         |     |     |        |           |
| 4523  | <b>DI 10X dst</b>                      | It displays the Digital Input 10X destination        |        |         |     |     |        |           |
| 4524  | <b>DI 11X dst</b>                      | It displays the Digital Input 11X destination        |        |         |     |     |        |           |

## I/O CONFIG / Digital outputs

The blocks of the digital outputs allow to turn an internal signal into a signal available on the terminal strip.



|                             |                            |                                 |  |
|-----------------------------|----------------------------|---------------------------------|--|
| DO 0 src<br>Drive OK        | Exp dig out en<br>Disabled |                                 |  |
| DO 1 src<br>Spd is zero dly |                            | DO 1 inversion<br>Not inverted  |  |
| DO 2 src<br>NULL            |                            | DO 2 inversion<br>Not inverted  |  |
| DO 3 src<br>NULL            |                            | DO 3 inversion<br>Not inverted  |  |
| DO 0X src<br>NULL           |                            | DO 0X inversion<br>Not inverted |  |
| DO 1X src<br>NULL           |                            | DO 1X inversion<br>Not inverted |  |
| DO 2X src<br>NULL           |                            | DO 2X inversion<br>Not inverted |  |
| DO 3X src<br>NULL           |                            | DO 3X inversion<br>Not inverted |  |
| DO 4X src<br>NULL           |                            | DO 4X inversion<br>Not inverted |  |
| DO 5X src<br>NULL           |                            | DO 5X inversion<br>Not inverted |  |
| DO 6X src<br>NULL           |                            | DO 6X inversion<br>Not inverted |  |
| DO 7X src<br>NULL           |                            | DO 7X inversion<br>Not inverted |  |

## I/O CONFIG / Digital outputs / Std digital outs / Std dig out src

**4065 DO 0 src** N/A RWS IPA 9097List 1 PIN V-F-S-B

IPA 9097 Drive OK = Default

It allows to connect the selected signal to the Digital output 0 and it can also defines the conditions that the relay contacts will close. For example:

Drive OK

The contact closes when the drive is powered up with no failure alarms.

Drive Ready

The contact closes when the following conditions are fulfilled:

- The drive is powered up
- There are no failure alarms present
- The drive is enabled. The enable operation is defined by parameters [En/disable mode] & [Commands sel]
- The magnetizing procedure has been completed (Drive is ready to deliver torque)

**NOTE!** The contact opens immediately on a drive failure, or when the drive is disabled.  
(refer to signals List 1 of Pick List manual)

| IPA  | Description   | [Unit] | Access | Default  | Min | Max    | Format | Reg. Mode |
|------|---|--------|--------|----------|-----|--------|--------|-----------|
| 4066 | <b>DO 1 src</b><br>IPA 7123 BRAKE cont mon = Default<br>It allows to connect the selected signal to the Digital output 2<br>(refer to signals List 1 of Pick List manual) | N/A    | RWS    | IPA 7123 |     | List 1 | PIN    | V-F-S-B   |
| 4067 | <b>DO 2 src</b><br>IPA 161 Drive ready = Default<br>It allows to connect the selected signal to the Digital output 3<br>(refer to signals List 1 of Pick List manual)     | N/A    | RWS    | IPA 161  |     | List 1 | PIN    | V-F-S-B   |
| 4068 | <b>DO 3 src</b><br>IPA 3728 Speed is zero = Default<br>It allows to connect the selected signal to the Digital output 2<br>(refer to signals List 1 of Pick List manual)  | N/A    | RWS    | IPA 3728 |     | List 1 | PIN    | V-F-S-B   |

#### I/O CONFIG / Digital outputs / Std digital outs / Std dig out cfg

|      |   |     |     |   |   |   |    |         |
|------|---|-----|-----|---|---|---|----|---------|
| 4060 | <b>DO 0 inversion</b><br>0 Not inverted<br>1 Inverted | N/A | RWS | 0 | 0 | 1 | DP | V-F-S-B |
| 4061 | <b>DO 1 inversion</b><br>0 Not inverted<br>1 Inverted | N/A | RWS | 0 | 0 | 1 | DP | V-F-S-B |
| 4062 | <b>DO 2 inversion</b><br>0 Not inverted<br>1 Inverted | N/A | RWS | 0 | 0 | 1 | DP | V-F-S-B |
| 4063 | <b>DO 3 inversion</b><br>0 Not inverted<br>1 Inverted | N/A | RWS | 0 | 0 | 1 | DP | V-F-S-B |

#### I/O CONFIG / Digital outputs / Std digital outs / Std dig out mon

|      |   |     |     |   |   |   |    |         |
|------|---|-----|-----|---|---|---|----|---------|
| 4064 | <b>DO 3210</b><br>The digital output logical state is displayed under each number | N/A | RWS | 0 | 0 | - | DP | V-F-S-B |
|------|---|-----|-----|---|---|---|----|---------|

#### I/O CONFIG / Digital outputs / Exp digital outs / Exp dig out src

|      |  |     |     |          |  |        |     |         |
|------|--|-----|-----|----------|--|--------|-----|---------|
| 4080 | <b>DO 0X src</b><br>IPA 7122 RUN cont mon = Default<br>It allows to connect the selected signal to the Digital output 0X<br>(refer to signals List 1 of Pick List manual)  | N/A | RWS | IPA 7122 |  | List 1 | PIN | V-F-S-B |
| 4081 | <b>DO 1X src</b><br>IPA 7120 UP cont mon = Default<br>It allows to connect the selected signal to the Digital output 1X<br>(refer to signals List 1 of Pick List manual)   | N/A | RWS | IPA 7120 |  | List 1 | PIN | V-F-S-B |
| 4082 | <b>DO 2X src</b><br>IPA 7121 DOWN cont mon = Default<br>It allows to connect the selected signal to the Digital output 2X<br>(refer to signals List 1 of Pick List manual) | N/A | RWS | IPA 7121 |  | List 1 | PIN | V-F-S-B |
| 4083 | <b>DO 3X src</b><br>IPA 7139 Door open mon = Default<br>It allows to connect the selected signal to the Digital output 2X<br>(refer to signals List 1 of Pick List manual) | N/A | RWS | IPA 7139 |  | List 1 | PIN | V-F-S-B |

| IPA  | Description   | [Unit] | Access | Default  | Min | Max    | Format | Reg. Mode |
|------|---|--------|--------|----------|-----|--------|--------|-----------|
| 4084 | <b>DO 4X src</b><br>IPA 4000 NULL = Default<br>It allows to connect the selected signal to the Digital output 4X<br>(refer to signals List 1 of Pick List manual) | N/A    | RWS    | IPA 4000 |     | List 1 | PIN    | V-F-S-B   |
| 4085 | <b>DO 5X src</b><br>IPA 4000 NULL = Default<br>It allows to connect the selected signal to the Digital output 5X<br>(refer to signals List 1 of Pick List manual) | N/A    | RWS    | IPA 4000 |     | List 1 | PIN    | V-F-S-B   |
| 4086 | <b>DO 6X src</b><br>IPA 4000 NULL = Default<br>It allows to connect the selected signal to the Digital output 6X<br>(refer to signals List 1 of Pick List manual) | N/A    | RWS    | IPA 4000 |     | List 1 | PIN    | V-F-S-B   |
| 4087 | <b>DO 7X src</b><br>IPA 4000 NULL = Default<br>It allows to connect the selected signal to the Digital output 7X<br>(refer to signals List 1 of Pick List manual) | N/A    | RWS    | IPA 4000 |     | List 1 | PIN    | V-F-S-B   |

#### I/O CONFIG / Digital outputs / Exp digital outs / Exp dig out cfg

|      |  |     |     |   |   |   |    |         |
|------|--|-----|-----|---|---|---|----|---------|
| 4070 | <b>DO 0X inversion</b><br>0 Not inverted<br>1 Inverted | N/A | RWS | 0 | 0 | 1 | DP | V-F-S-B |
| 4071 | <b>DO 1X inversion</b><br>0 Not inverted<br>1 Inverted | N/A | RWS | 0 | 0 | 1 | DP | V-F-S-B |
| 4072 | <b>DO 2X inversion</b><br>0 Not inverted<br>1 Inverted | N/A | RWS | 0 | 0 | 1 | DP | V-F-S-B |
| 4073 | <b>DO 3X inversion</b><br>0 Not inverted<br>1 Inverted | N/A | RWS | 0 | 0 | 1 | DP | V-F-S-B |
| 4074 | <b>DO 4X inversion</b><br>0 Not inverted<br>1 Inverted | N/A | RWS | 0 | 0 | 1 | DP | V-F-S-B |
| 4075 | <b>DO 5X inversion</b><br>0 Not inverted<br>1 Inverted | N/A | RWS | 0 | 0 | 1 | DP | V-F-S-B |
| 4076 | <b>DO 6X inversion</b><br>0 Not inverted<br>1 Inverted | N/A | RWS | 0 | 0 | 1 | DP | V-F-S-B |
| 4077 | <b>DO 7X inversion</b><br>0 Not inverted<br>1 Inverted | N/A | RWS | 0 | 0 | 1 | DP | V-F-S-B |

#### I/O CONFIG / Digital outputs / Exp digital outs / Exp dig out mon

|      |                     |     |   |   |   |   |    |         |
|------|---------------------|-----|---|---|---|---|----|---------|
| 4078 | <b>DOX 76543210</b> | N/A | R | 0 | 0 | - | DP | V-F-S-B |
|------|---------------------|-----|---|---|---|---|----|---------|

The digital output logical state (of expansion board) is displayed under each number.


| IPA  | Description                             | [Unit]     | Access     | Default  | Min      | Max      | Format    | Reg. Mode      |
|--|---|------------|------------|----------|----------|----------|-----------|----------------|
| <b>I/O CONFIG / Digital outputs / Exp dig out en</b> |   |            |            |          |          |          |           |                |
| <b>3903</b>  | <b>Exp dig out en</b>                   | <b>N/A</b> | <b>RWS</b> | <b>0</b> | <b>0</b> | <b>1</b> | <b>DV</b> | <b>V-F-S-B</b> |
|  | 0                                       | Disabled   |            |          |          |          |           |                |
|  | 1                                       | Enabled    |            |          |          |          |           |                |
|  | It enables the expanded digital outputs |            |            |          |          |          |           |                |

**I/O CONFIG / Bits->Word**

The Word Composing Block, “Bits->Word”, is useful to communicate, for example, between Drive and APC card: it is possible to compose a word made of *Drive ready, Drive ok, Ref is zero, Speed is zero*, by communicating on a single word.

The Bits->Wordn Block has 16 inputs, where each of them can be connected to a signal; the output of the *Word compn* Block contains the packed input bits.

Two “Bits->Word” blocks are available.



**I/O CONFIG / Bits->Word / Bits->Word0 src**

|             |   |            |            |                 |               |            |                |
|-------------|---|------------|------------|-----------------|---------------|------------|----------------|
| <b>2100</b> | <b>Word0 B0 src</b>   | <b>N/A</b> | <b>RWS</b> | <b>IPA 4000</b> | <b>List 1</b> | <b>PIN</b> | <b>V-F-S-B</b> |
|             | IPA 4000 NULL = Default<br>It allows to connect the Bit 0 signal selected to the Word 0 (refer to signals List 1 of Pick List manual) |            |            |                 |               |            |                |
| <b>2101</b> | <b>Word0 B1 src</b>   | <b>N/A</b> | <b>RWS</b> | <b>IPA 4000</b> | <b>List 1</b> | <b>PIN</b> | <b>V-F-S-B</b> |
|             | IPA 4000 NULL = Default<br>It allows to connect the Bit 1 signal selected to the Word 0 (refer to signals List 1 of Pick List manual) |            |            |                 |               |            |                |
| <b>2102</b> | <b>Word0 B2 src</b>   | <b>N/A</b> | <b>RWS</b> | <b>IPA 4000</b> | <b>List 1</b> | <b>PIN</b> | <b>V-F-S-B</b> |
|             | IPA 4000 NULL = Default<br>It allows to connect the Bit 2 signal selected to the Word 0 (refer to signals List 1 of Pick List manual) |            |            |                 |               |            |                |
| <b>2103</b> | <b>Word0 B3 src</b>   | <b>N/A</b> | <b>RWS</b> | <b>IPA 4000</b> | <b>List 1</b> | <b>PIN</b> | <b>V-F-S-B</b> |
|             | IPA 4000 NULL = Default<br>It allows to connect the Bit 3 signal selected to the Word 0 (refer to signals List 1 of Pick List manual) |            |            |                 |               |            |                |
| <b>2104</b> | <b>Word0 B4 src</b>   | <b>N/A</b> | <b>RWS</b> | <b>IPA 4000</b> | <b>List 1</b> | <b>PIN</b> | <b>V-F-S-B</b> |
|             | IPA 4000 NULL = Default<br>It allows to connect the Bit 4 signal selected to the Word 0 (refer to signals List 1 of Pick List manual) |            |            |                 |               |            |                |
| <b>2105</b> | <b>Word0 B5 src</b>   | <b>N/A</b> | <b>RWS</b> | <b>IPA 4000</b> | <b>List 1</b> | <b>PIN</b> | <b>V-F-S-B</b> |
|             | IPA 4000 NULL = Default<br>It allows to connect the Bit 5 signal selected to the Word 0 (refer to signals List 1 of Pick List manual) |            |            |                 |               |            |                |
| <b>2106</b> | <b>Word0 B6 src</b>   | <b>N/A</b> | <b>RWS</b> | <b>IPA 4000</b> | <b>List 1</b> | <b>PIN</b> | <b>V-F-S-B</b> |
|             | IPA 4000 NULL = Default<br>It allows to connect the Bit 6 signal selected to the Word 0 (refer to signals List 1 of Pick List manual) |            |            |                 |               |            |                |



| IPA  | Description   | [Unit] | Access | Default  | Min | Max    | Format | Reg. Mode |
|--|---|--------|--------|----------|-----|--------|--------|-----------|
| 2107   | <b>Word0 B7 src</b><br>IPA 4000 NULL = Default<br>It allows to connect the Bit 7 signal selected to the Word 0<br>(refer to signals List 1 of Pick List manual)   | N/A    | RWS    | IPA 4000 |     | List 1 | PIN    | V-F-S-B   |
| 2108   | <b>Word0 B8 src</b><br>IPA 4000 NULL = Default<br>It allows to connect the Bit 8 signal selected to the Word 0<br>(refer to signals List 1 of Pick List manual)   | N/A    | RWS    | IPA 4000 |     | List 1 | PIN    | V-F-S-B   |
| 2109   | <b>Word0 B9 src</b><br>IPA 4000 NULL = Default<br>It allows to connect the Bit 9 signal selected to the Word 0<br>(refer to signals List 1 of Pick List manual)   | N/A    | RWS    | IPA 4000 |     | List 1 | PIN    | V-F-S-B   |
| 2110   | <b>Word0 B10 src</b><br>IPA 4000 NULL = Default<br>It allows to connect the Bit 10 signal selected to the Word 0<br>(refer to signals List 1 of Pick List manual) | N/A    | RWS    | IPA 4000 |     | List 1 | PIN    | V-F-S-B   |
| 2111   | <b>Word0 B11 src</b><br>IPA 4000 NULL = Default<br>It allows to connect the Bit 11 signal selected to the Word 0<br>(refer to signals List 1 of Pick List manual) | N/A    | RWS    | IPA 4000 |     | List 1 | PIN    | V-F-S-B   |
| 2112   | <b>Word0 B12 src</b><br>IPA 4000 NULL = Default<br>It allows to connect the Bit 12 signal selected to the Word 0<br>(refer to signals List 1 of Pick List manual) | N/A    | RWS    | IPA 4000 |     | List 1 | PIN    | V-F-S-B   |
| 2113   | <b>Word0 B13 src</b><br>IPA 4000 NULL = Default<br>It allows to connect the Bit 13 signal selected to the Word 0<br>(refer to signals List 1 of Pick List manual) | N/A    | RWS    | IPA 4000 |     | List 1 | PIN    | V-F-S-B   |
| 2114   | <b>Word0 B14 src</b><br>IPA 4000 NULL = Default<br>It allows to connect the Bit 14 signal selected to the Word 0<br>(refer to signals List 1 of Pick List manual) | N/A    | RWS    | IPA 4000 |     | List 1 | PIN    | V-F-S-B   |
| 2115   | <b>Word0 B15 src</b><br>IPA 4000 NULL = Default<br>It allows to connect the Bit 15 signal selected to the Word 0<br>(refer to signals List 1 of Pick List manual) | N/A    | RWS    | IPA 4000 |     | List 1 | PIN    | V-F-S-B   |
| <b>I/O CONFIG / Bits-&gt;Word / Bits-&gt;Word0 mon</b> |   |        |        |          |     |        |        |           |
| 2116   | <b>W0 comp out</b><br>Monitor for the hexadecimal output value of "Word 0"  | N/A    | R      | 0        | 0   | -      | DV     | V-F-S-B   |
| <b>I/O CONFIG / Bits-&gt;Word / Bits-&gt;Word1 src</b> |   |        |        |          |     |        |        |           |
| 9340   | <b>Word1 B0 src</b><br>IPA 4000 NULL = Default<br>It allows to connect the Bit 0 signal selected to the Word 1<br>(refer to signals List 1 of Pick List manual)   | N/A    | RWS    | IPA 4000 |     | List 1 | PIN    | V-F-S-B   |
| 9341   | <b>Word1 B1 src</b><br>IPA 4000 NULL = Default<br>It allows to connect the Bit 1 signal selected to the Word 1<br>(refer to signals List 1 of Pick List manual)   | N/A    | RWS    | IPA 4000 |     | List 1 | PIN    | V-F-S-B   |

| IPA  | Description   | [Unit] | Access | Default  | Min | Max    | Format | Reg. Mode |
|------|---|--------|--------|----------|-----|--------|--------|-----------|
| 9342 | <b>Word1 B2 src</b><br>IPA 4000 NULL = Default<br>It allows to connect the Bit 2 signal selected to the Word 1<br>(refer to signals List 1 of Pick List manual)   | N/A    | RWS    | IPA 4000 |     | List 1 | PIN    | V-F-S-B   |
| 9343 | <b>Word1 B3 src</b><br>IPA 4000 NULL = Default<br>It allows to connect the Bit 3 signal selected to the Word 1<br>(refer to signals List 1 of Pick List manual)   | N/A    | RWS    | IPA 4000 |     | List 1 | PIN    | V-F-S-B   |
| 9344 | <b>Word1 B4 src</b><br>IPA 4000 NULL = Default<br>It allows to connect the Bit 4 signal selected to the Word 1<br>(refer to signals List 1 of Pick List manual)   | N/A    | RWS    | IPA 4000 |     | List 1 | PIN    | V-F-S-B   |
| 9345 | <b>Word1 B5 src</b><br>IPA 4000 NULL = Default<br>It allows to connect the Bit 5 signal selected to the Word 1<br>(refer to signals List 1 of Pick List manual)   | N/A    | RWS    | IPA 4000 |     | List 1 | PIN    | V-F-S-B   |
| 9346 | <b>Word1 B6 src</b><br>IPA 4000 NULL = Default<br>It allows to connect the Bit 6 signal selected to the Word 1<br>(refer to signals List 1 of Pick List manual)   | N/A    | RWS    | IPA 4000 |     | List 1 | PIN    | V-F-S-B   |
| 9347 | <b>Word1 B7 src</b><br>IPA 4000 NULL = Default<br>It allows to connect the Bit 7 signal selected to the Word 1<br>(refer to signals List 1 of Pick List manual)   | N/A    | RWS    | IPA 4000 |     | List 1 | PIN    | V-F-S-B   |
| 9348 | <b>Word1 B8 src</b><br>IPA 4000 NULL = Default<br>It allows to connect the Bit 8 signal selected to the Word 1<br>(refer to signals List 1 of Pick List manual)   | N/A    | RWS    | IPA 4000 |     | List 1 | PIN    | V-F-S-B   |
| 9349 | <b>Word1 B9 src</b><br>IPA 4000 NULL = Default<br>It allows to connect the Bit 9 signal selected to the Word 1<br>(refer to signals List 1 of Pick List manual)   | N/A    | RWS    | IPA 4000 |     | List 1 | PIN    | V-F-S-B   |
| 9350 | <b>Word1 B10 src</b><br>IPA 4000 NULL = Default<br>It allows to connect the Bit 10 signal selected to the Word 1<br>(refer to signals List 1 of Pick List manual) | N/A    | RWS    | IPA 4000 |     | List 1 | PIN    | V-F-S-B   |
| 9351 | <b>Word1 B11 src</b><br>IPA 4000 NULL = Default<br>It allows to connect the Bit 11 signal selected to the Word 1<br>(refer to signals List 1 of Pick List manual) | N/A    | RWS    | IPA 4000 |     | List 1 | PIN    | V-F-S-B   |
| 9352 | <b>Word1 B12 src</b><br>IPA 4000 NULL = Default<br>It allows to connect the Bit 12 signal selected to the Word 1<br>(refer to signals List 1 of Pick List manual) | N/A    | RWS    | IPA 4000 |     | List 1 | PIN    | V-F-S-B   |
| 9353 | <b>Word1 B13 src</b><br>IPA 4000 NULL = Default<br>It allows to connect the Bit 13 signal selected to the Word 1<br>(refer to signals List 1 of Pick List manual) | N/A    | RWS    | IPA 4000 |     | List 1 | PIN    | V-F-S-B   |

| IPA  | Description   | [Unit] | Access | Default  | Min | Max    | Format | Reg. Mode |
|------|---|--------|--------|----------|-----|--------|--------|-----------|
| 9354 | <b>Word1 B14 src</b><br>IPA 4000 NULL = Default<br>It allows to connect the Bit 14 signal selected to the Word 1<br>(refer to signals List 1 of Pick List manual) | N/A    | RWS    | IPA 4000 |     | List 1 | PIN    | V-F-S-B   |
| 9355 | <b>Word1 B15 src</b><br>IPA 4000 NULL = Default<br>It allows to connect the Bit 15 signal selected to the Word 1<br>(refer to signals List 1 of Pick List manual) | N/A    | RWS    | IPA 4000 |     | List 1 | PIN    | V-F-S-B   |

### I/O CONFIG / Bits->Word / Bits->Word1 mon


|      |  |     |   |   |   |   |    |         |
|------|--|-----|---|---|---|---|----|---------|
| 9356 | <b>W1 comp out</b><br>Monitor for the hexadecimal output value of "Word 1" | N/A | R | 0 | 0 | - | DV | V-F-S-B |
|------|--|-----|---|---|---|---|----|---------|

### I/O CONFIG / Word->Bits

The Word Decomposing Block, "Word->Bits", allows to set some signals on a digital word; each signal composing the word, on the Block input, can be combined with an output channel. It is useful to communicate, for example, between APC card and Drive.

The "Wordn->Bits" block has an input word and 16 Bx Wn decomp output bits.

Two "Word->Bits" blocks are available.



### I/O CONFIG / Word->Bits / Word0->Bits src

|      |   |     |     |          |  |         |     |         |
|------|---|-----|-----|----------|--|---------|-----|---------|
| 2120 | <b>W0 decomp src</b><br>IPA 2121 W0 decomp inp = Default<br>It allows to connect the word that will be input to decomposing block<br>(refer to signals List 26 of Pick List manual) | N/A | RWS | IPA 2121 |  | List 26 | PIN | V-F-S-B |
|------|---|-----|-----|----------|--|---------|-----|---------|

### I/O CONFIG / Word->Bits / Word0->Bits cfg

|      |  |     |     |        |   |   |    |         |
|------|--|-----|-----|--------|---|---|----|---------|
| 2121 | <b>W0 decomp inp</b><br>It allows to set the "W0 decomp inp" value | N/A | RWS | 0X0000 | - | - | DV | V-F-S-B |
|------|--|-----|-----|--------|---|---|----|---------|

### I/O CONFIG / Word->Bits / Word0->Bits mon

|      |   |     |   |   |   |   |    |         |
|------|---|-----|---|---|---|---|----|---------|
| 2122 | <b>W0 decomp mon</b><br>Monitor of the hexadecimal input value of the Word 0 decomposed | N/A | R | 0 | 0 | - | DP | V-F-S-B |
| 2123 | <b>B0 W0 decomp</b><br>Bit 0 of Word 0 decomposed displaying                            | N/A | R | 0 | 0 | 1 | DV | V-F-S-B |
| 2124 | <b>B1 W0 decomp</b><br>Bit 1 of Word 0 decomposed displaying                            | N/A | R | 0 | 0 | 1 | DV | V-F-S-B |
| 2125 | <b>B2 W0 decomp</b><br>Bit 2 of Word 0 decomposed displaying                            | N/A | R | 0 | 0 | 1 | DV | V-F-S-B |

| IPA  | Description  | [Unit] | Access | Default | Min | Max | Format | Reg. Mode |
|------|--|--------|--------|---------|-----|-----|--------|-----------|
| 2126 | <b>B3 W0 decomp</b><br>Bit 3 of Word 0 decomposed displaying   | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |
| 2127 | <b>B4 W0 decomp</b><br>Bit 4 of Word 0 decomposed displaying   | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |
| 2128 | <b>B5 W0 decomp</b><br>Bit 5 of Word 0 decomposed displaying   | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |
| 2129 | <b>B6 W0 decomp</b><br>Bit 6 of Word 0 decomposed displaying   | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |
| 2130 | <b>B7 W0 decomp</b><br>Bit 7 of Word 0 decomposed displaying   | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |
| 2131 | <b>B8 W0 decomp</b><br>Bit 8 of Word 0 decomposed displaying   | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |
| 2132 | <b>B9 W0 decomp</b><br>Bit 9 of Word 0 decomposed displaying   | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |
| 2133 | <b>B10 W0 decomp</b><br>Bit 10 of Word 0 decomposed displaying | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |
| 2134 | <b>B11 W0 decomp</b><br>Bit 11 of Word 0 decomposed displaying | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |
| 2135 | <b>B12 W0 decomp</b><br>Bit 12 of Word 0 decomposed displaying | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |
| 2136 | <b>B13 W0 decomp</b><br>Bit 13 of Word 0 decomposed displaying | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |
| 2137 | <b>B14 W0 decomp</b><br>Bit 14 of Word 0 decomposed displaying | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |
| 2138 | <b>B15 W0 decomp</b><br>Bit 15 of Word 0 decomposed displaying | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |

#### I/O CONFIG / Word->Bits / Word1->Bits src

|      |   |     |     |          |         |     |         |
|------|---|-----|-----|----------|---------|-----|---------|
| 9361 | <b>W1 decomp src</b><br>IPA 9360 W1 decomp inp = Default<br>It allows to connect the word that will be input to decomposing block<br>(refer to signals List 27 of Pick List manual) | N/A | RWS | IPA 9360 | List 27 | PIN | V-F-S-B |
|------|---|-----|-----|----------|---------|-----|---------|

#### I/O CONFIG / Word->Bits / Word1->Bits cfg

|      |  |     |     |        |   |   |    |         |
|------|--|-----|-----|--------|---|---|----|---------|
| 9360 | <b>W1 decomp inp</b><br>It allows to set the "W1 decomp inp" value | N/A | RWS | 0X0000 | - | - | DV | V-F-S-B |
|------|--|-----|-----|--------|---|---|----|---------|

#### I/O CONFIG / Word->Bits / Word1->Bits mon

|      |   |     |   |   |   |   |    |         |
|------|---|-----|---|---|---|---|----|---------|
| 9362 | <b>W1 decomp mon</b><br>Monitor of the hexadecimal input value of the Word 1 decomposed | N/A | R | 0 | 0 | - | DP | V-F-S-B |
| 9363 | <b>B0 W1 decomp</b><br>Bit 0 of Word 1 decomposed displaying                            | N/A | R | 0 | 0 | 1 | DV | V-F-S-B |
| 9364 | <b>B1 W1 decomp</b><br>Bit 1 of Word 1 decomposed displaying                            | N/A | R | 0 | 0 | 1 | DV | V-F-S-B |
| 9365 | <b>B2 W1 decomp</b><br>Bit 2 of Word 1 decomposed displaying                            | N/A | R | 0 | 0 | 1 | DV | V-F-S-B |
| 9366 | <b>B3 W1 decomp</b><br>Bit 3 of Word 1 decomposed displaying                            | N/A | R | 0 | 0 | 1 | DV | V-F-S-B |

| IPA  | Description  | [Unit] | Access | Default | Min | Max | Format | Reg. Mode |
|------|--|--------|--------|---------|-----|-----|--------|-----------|
| 9367 | <b>B4 W1 decomp</b><br>Bit 4 of Word 1 decomposed displaying   | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |
| 9368 | <b>B5 W1 decomp</b><br>Bit 5 of Word 1 decomposed displaying   | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |
| 9369 | <b>B6 W1 decomp</b><br>Bit 6 of Word 1 decomposed displaying   | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |
| 9370 | <b>B7 W1 decomp</b><br>Bit 7 of Word 1 decomposed displaying   | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |
| 9371 | <b>B8 W1 decomp</b><br>Bit 8 of Word 1 decomposed displaying   | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |
| 9372 | <b>B9 W1 decomp</b><br>Bit 9 of Word 1 decomposed displaying   | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |
| 9373 | <b>B10 W1 decomp</b><br>Bit 10 of Word 1 decomposed displaying | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |
| 9374 | <b>B11 W1 decomp</b><br>Bit 11 of Word 1 decomposed displaying | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |
| 9375 | <b>B12 W1 decomp</b><br>Bit 12 of Word 1 decomposed displaying | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |
| 9376 | <b>B13 W1 decomp</b><br>Bit 13 of Word 1 decomposed displaying | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |
| 9377 | <b>B14 W1 decomp</b><br>Bit 14 of Word 1 decomposed displaying | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |
| 9378 | <b>B15 W1 decomp</b><br>Bit 15 of Word 1 decomposed displaying | N/A    | R      | 0       | 0   | 1   | DV     | V-F-S-B   |

## SAVE PARAMETERS

AVyL drive allows two different commands to save the parameters modified in the regulation mode selected:

- by STARTUP menu, “Save Config?” command
- by all other menus, “SAVE PARAMETERS” command

Any changes made in STARTUP menu require “Save Config?” command, which saves all entire regulation mode selected. It is recommended every time the user made any changes into STARTUP menu.

“SAVE PARAMETERS” command saves all the changes made out of STARTUP menu only.

When on the keypad display appears blinking message “Use Save Config”, use “Save Config?” command

| IPA | Description | [Unit] | Access | Default | Min | Max | Format | Reg. Mode |
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|

## ALARM CONFIG

The access to ALARM CONFIG menu is allowed by Level 1 password: 12345. It must be set in the SERVICE menu. In the ALARM CONFIG menu it is possible to configure Drive alarms behavior through the following functions:

- Activity It allows to set the action to be performed after the alarm intervention as:
 

|   |                 |   |
|---|-----------------|---|
| 0 | Only msg alarmq | Actions: Message                            |
| 1 | Ignore          | Actions: none                               |
| 2 | Warning         | Actions: Message – Status                   |
| 3 | Disable drive   | Actions: Message – Commands for SM – Status |
| 4 | Stop            | Actions: Message – Commands for SM – Status |
| 5 | Fast stop       | Actions: Message – Commands for SM – Status |
| 6 | Curr limstop    | Actions: Message – Commands for SM – Status |

Actions meaning:

|                 |  |
|-----------------|--|
| Message         | It means that the message has been sent to the “Alarm List” and to the “Alarm log list”.   |
| Commands for SM | State Machine commands : A change in the drive state has been forced (alarm intervention).   |
| Status          | The active alarm signal is immediately set; it is reset when the alarm is not more present and the state machine is not in an alarm condition. |
- Restart It allows to enable the automatic start after the alarm cause has been removed.
 

|   |     |
|---|-----|
| 0 | Off |
| 1 | On  |
- Restart Time It allows to set a period of time, within which the alarm state has to be removed, in order to perform an automatic start.
- Hold Off Time It allows to set a period of time, in which a specific alarm condition has to remain active (it has to persist) in order to be considered an alarm situation. It is possible to set a millisecond period of time, in which the Drive does not recognize the alarm state. Therefore, the alarm is recognized only if it persists for a period longer than the set “Hold off time”

### ALARM CONFIG / Fault reset

|  |                        |     |     |          |        |     |         |
|--|------------------------|-----|-----|----------|--------|-----|---------|
| <b>9076</b>  | <b>Fault reset src</b> | N/A | RWS | IPA 4027 | List 3 | PIN | V-F-S-B |
| IPA 4027 DI 7 monitor = Default  |                        |     |     |          |        |     |         |
| By using the “Fault reset src” source, it is possible to select the origin of the “reset” command signal, for example a command via the terminal strip through a digital Input (refer to signals List 3 of Pick List manual) |                        |     |     |          |        |     |         |

### ALARM CONFIG / Undervoltage

It trips when the voltage on the drive DC link is lower than the minimum threshold according to the Mains voltage setting

|   |                        |      |      |          |        |       |         |         |
|---|------------------------|------|------|----------|--------|-------|---------|---------|
| <b>9050</b>   | <b>UV restart</b>      | N/A  | RWS  | 1        | 0      | 1     | DP      | V-F-S-B |
| 0 off   |                        |      |      |          |        |       |         |         |
| 1 on  |                        |      |      |          |        |       |         |         |
| Undervoltage restart  |                        |      |      |          |        |       |         |         |
| <b>9051</b>   | <b>UV restart time</b> | [ms] | RWS  | 1000     | 0      | 30000 | PP      | V-F-S-B |
| Undervoltage restart time   |                        |      |      |          |        |       |         |         |
| <b>396</b>  | <b>UV select src</b>   | N/A  | RWSZ | IPA 4001 | List 3 | PIN   | V-F-S-B |         |
| Source to disable Undervoltage alarm through digital input.                                 |                        |      |      |          |        |       |         |         |
| <b>To be used exclusively with Emergency Module Supply.</b> Main power supply must be off ! |                        |      |      |          |        |       |         |         |

| IPA  | Description  | [Unit] | Access | Default  | Min  | Max    | Format | Reg. Mode |
|--|--|--------|--------|----------|------|--------|--------|-----------|
| <b>ALARM CONFIG / Overvoltage</b>  |  |        |        |          |      |        |        |           |
| It trips when the voltage on the drive DC link is higher than the maximum threshold according to the Mains voltage setting |  |        |        |          |      |        |        |           |
| 9052   | <b>OV restart</b><br>0 off<br>1 on<br>Overvoltage restart  | N/A    | RWS    | 0        | 0    | 1      | DP     | V-F-S-B   |
| 9053   | <b>OV restart time</b><br>Overvoltage restart time   | [ms]   | RWS    | 1000     | 0    | 30000  | PP     | V-F-S-B   |
| <b>ALARM CONFIG / IGBT desaturat</b>   |  |        |        |          |      |        |        |           |
| It trips when the IGBT instantaneous overcurrent is detected by gate desaturation sensing circuit                          |  |        |        |          |      |        |        |           |
| 9046   | <b>DS restart</b><br>0 off<br>1 on<br>IGBT desaturation restart  | N/A    | RWS    | 0        | 0    | 1      | DP     | V-F-S-B   |
| 9047   | <b>DS restart time</b><br>IGBT desaturation restart time   | [ms]   | RWS    | 1000     | 0    | 30000  | PP     | V-F-S-B   |
| <b>ALARM CONFIG / Inst overcurrent</b>   |  |        |        |          |      |        |        |           |
| It trips when the IGBT instantaneous overcurrent is detected by output current sensor                                      |  |        |        |          |      |        |        |           |
| 9063   | <b>IOC restart</b><br>0 off<br>1 on<br>Instantaneous overcurrent restart   | N/A    | RWS    | 0        | 0    | 1      | DP     | V-F-S-B   |
| 9064   | <b>IOC restart time</b><br>Instantaneous overcurrent restart time  | [ms]   | RWS    | 1000     | 0    | 30000  | PP     | V-F-S-B   |
| <b>ALARM CONFIG / Ground fault</b>   |  |        |        |          |      |        |        |           |
| It trips when the output phase discharge to ground   |  |        |        |          |      |        |        |           |
| 9640   | <b>GF activity</b><br>1 Ignore<br>2 Warning<br>3 Disable drive<br>4 Stop<br>5 Fast stop<br>6 Curr limstp<br>Ground fault activity                      | N/A    | RWS    | 2        | 1    | 6      | DP     | V-F-S-B   |
| 9641   | <b>GF threshold</b><br>Ground fault threshold  | [A]    | RWS    | D.Size   | Calc | D.Size | PP     | V-F-S-B   |
| <b>ALARM CONFIG / External fault</b>   |  |        |        |          |      |        |        |           |
| It trips when the External fault input is active   |  |        |        |          |      |        |        |           |
| 9075   | <b>EF src</b><br>IPA 4000 NULL = Default<br>It allows to connect the External fault input terminal strip (refer to signals List 3 of Pick List manual) | N/A    | RWS    | IPA 4023 |      | List 3 | PIN    | V-F-S-B   |
| 9060   | <b>EF activity</b><br>1 Ignore<br>2 Warning  | N/A    | RWS    | 3        | 2    | 6      | DP     | V-F-S-B   |

| IPA         | Description                 | [Unit]        | Access     | Default     | Min      | Max          | Format    | Reg. Mode      |
|-------------|-----------------------------|---------------|------------|-------------|----------|--------------|-----------|----------------|
|             | 3                           | Disable drive |            |             |          |              |           |                |
|             | 4                           | Stop          |            |             |          |              |           |                |
|             | 5                           | Fast stop     |            |             |          |              |           |                |
|             | 6                           | Curr limstp   |            |             |          |              |           |                |
|             | External fault activity     |               |            |             |          |              |           |                |
| <b>9061</b> | <b>EF restart</b>           | <b>N/A</b>    | <b>RWS</b> | <b>0</b>    | <b>0</b> | <b>1</b>     | <b>DP</b> | <b>V-F-S-B</b> |
|             | 0                           | off           |            |             |          |              |           |                |
|             | 1                           | on            |            |             |          |              |           |                |
|             | External fault restart      |               |            |             |          |              |           |                |
| <b>9062</b> | <b>EF restart time</b>      | <b>[ms]</b>   | <b>RWS</b> | <b>1000</b> | <b>0</b> | <b>30000</b> | <b>PP</b> | <b>V-F-S-B</b> |
|             | External fault restart time |               |            |             |          |              |           |                |
| <b>9600</b> | <b>EF hold off</b>          | <b>[ms]</b>   | <b>RWS</b> | <b>0</b>    | <b>0</b> | <b>30000</b> | <b>PP</b> | <b>V-F-S-B</b> |
|             | External fault hold off     |               |            |             |          |              |           |                |

### ALARM CONFIG / Motor OT

Motor Over-Temperature indicated via thermal contact or PTC thermistor on 78-79 drive regulation board terminals

|             |                                     |               |            |             |          |              |           |                |
|-------------|-------------------------------------|---------------|------------|-------------|----------|--------------|-----------|----------------|
| <b>9065</b> | <b>MOT activity</b>                 | <b>N/A</b>    | <b>RWS</b> | <b>2</b>    | <b>2</b> | <b>6</b>     | <b>DP</b> | <b>V-F-S-B</b> |
|             | 2                                   | Warning       |            |             |          |              |           |                |
|             | 3                                   | Disable drive |            |             |          |              |           |                |
|             | 4                                   | Stop          |            |             |          |              |           |                |
|             | 5                                   | Fast stop     |            |             |          |              |           |                |
|             | 6                                   | Curr limstp   |            |             |          |              |           |                |
|             | Motor Over-Temperature activity     |               |            |             |          |              |           |                |
| <b>9066</b> | <b>MOT restart</b>                  | <b>N/A</b>    | <b>RWS</b> | <b>0</b>    | <b>0</b> | <b>1</b>     | <b>DP</b> | <b>V-F-S-B</b> |
|             | 0                                   | off           |            |             |          |              |           |                |
|             | 1                                   | on            |            |             |          |              |           |                |
|             | Motor Over-Temperature restart      |               |            |             |          |              |           |                |
| <b>9067</b> | <b>MOT restart time</b>             | <b>[ms]</b>   | <b>RWS</b> | <b>1000</b> | <b>0</b> | <b>30000</b> | <b>PP</b> | <b>V-F-S-B</b> |
|             | Motor Over-Temperature restart time |               |            |             |          |              |           |                |
| <b>9603</b> | <b>MOT hold off</b>                 | <b>[ms]</b>   | <b>RWS</b> | <b>1000</b> | <b>0</b> | <b>30000</b> | <b>PP</b> | <b>V-F-S-B</b> |
|             | Motor Over-Temperature hold off     |               |            |             |          |              |           |                |

### ALARM CONFIG / Heatsink S OT

Heatsink Sensor Over-Temperature (detected by a sensor)


|             |   |               |            |             |          |              |           |                |
|-------------|---|---------------|------------|-------------|----------|--------------|-----------|----------------|
| <b>9054</b> | <b>HTS activity</b>                           | <b>N/A</b>    | <b>RWS</b> | <b>3</b>    | <b>2</b> | <b>6</b>     | <b>DP</b> | <b>V-F-S-B</b> |
|             | 2   | Warning       |            |             |          |              |           |                |
|             | 3   | Disable drive |            |             |          |              |           |                |
|             | 4   | Stop          |            |             |          |              |           |                |
|             | 5   | Fast stop     |            |             |          |              |           |                |
|             | 6   | Curr limstp   |            |             |          |              |           |                |
|             | Heatsink Sensor Over-Temperature activity     |               |            |             |          |              |           |                |
| <b>9055</b> | <b>HTS restart</b>                            | <b>N/A</b>    | <b>RWS</b> | <b>0</b>    | <b>0</b> | <b>1</b>     | <b>DP</b> | <b>V-F-S-B</b> |
|             | 0   | off           |            |             |          |              |           |                |
|             | 1   | on            |            |             |          |              |           |                |
|             | Heatsink Sensor Over-Temperature restart      |               |            |             |          |              |           |                |
| <b>9056</b> | <b>HTS restart time</b>                       | <b>[ms]</b>   | <b>RWS</b> | <b>1000</b> | <b>0</b> | <b>30000</b> | <b>PP</b> | <b>V-F-S-B</b> |
|             | Heatsink Sensor Over-Temperature restart time |               |            |             |          |              |           |                |
| <b>9604</b> | <b>HTS hold off</b>                           | <b>[ms]</b>   | <b>RWS</b> | <b>1000</b> | <b>0</b> | <b>30000</b> | <b>PP</b> | <b>V-F-S-B</b> |
|             | Heatsink Sensor Over-Temperature hold off     |               |            |             |          |              |           |                |



| IPA   | Description             | [Unit]        | Access     | Default         | Min           | Max          | Format         | Reg. Mode      |
|---|-------------------------|---------------|------------|-----------------|---------------|--------------|----------------|----------------|
| <b>ALARM CONFIG / Regulation S OT</b>   |                         |               |            |                 |               |              |                |                |
| Regulation card Sensor Over-Temperature   |                         |               |            |                 |               |              |                |                |
| <b>9057</b>   | <b>RGS activity</b>     | <b>N/A</b>    | <b>RWS</b> | <b>3</b>        | <b>2</b>      | <b>6</b>     | <b>DP</b>      | <b>V-F-S-B</b> |
|   | 2                       | Warning       |            |                 |               |              |                |                |
|   | 3                       | Disable drive |            |                 |               |              |                |                |
|   | 4                       | Stop          |            |                 |               |              |                |                |
|   | 5                       | Fast stop     |            |                 |               |              |                |                |
|   | 6                       | Curr limstp   |            |                 |               |              |                |                |
| Regulation card Sensor Over-Temperature activity  |                         |               |            |                 |               |              |                |                |
| <b>9058</b>   | <b>RGS restart</b>      | <b>N/A</b>    | <b>RWS</b> | <b>0</b>        | <b>0</b>      | <b>1</b>     | <b>DP</b>      | <b>V-F-S-B</b> |
|   | 0                       | off           |            |                 |               |              |                |                |
|   | 1                       | on            |            |                 |               |              |                |                |
| Regulation card Sensor Over-Temperature restart   |                         |               |            |                 |               |              |                |                |
| <b>9059</b>   | <b>RGS restart time</b> | <b>[ms]</b>   | <b>RWS</b> | <b>1000</b>     | <b>0</b>      | <b>30000</b> | <b>PP</b>      | <b>V-F-S-B</b> |
| Regulation card Sensor Over-Temperature restart time  |                         |               |            |                 |               |              |                |                |
| <b>9605</b>   | <b>RGS hold off</b>     | <b>[ms]</b>   | <b>RWS</b> | <b>10000</b>    | <b>0</b>      | <b>30000</b> | <b>PP</b>      | <b>V-F-S-B</b> |
| Regulation card Sensor Over-Temperature hold off  |                         |               |            |                 |               |              |                |                |
| <b>ALARM CONFIG / Intake air S OT</b>   |                         |               |            |                 |               |              |                |                |
| Intake air Sensor Over-Temperature (only for model AVyL 4185 and over)                                    |                         |               |            |                 |               |              |                |                |
| <b>9087</b>   | <b>IAS activity</b>     | <b>N/A</b>    | <b>RWS</b> | <b>3</b>        | <b>2</b>      | <b>6</b>     | <b>DP</b>      | <b>V-F-S-B</b> |
|   | 2                       | Warning       |            |                 |               |              |                |                |
|   | 3                       | Disable drive |            |                 |               |              |                |                |
|   | 4                       | Stop          |            |                 |               |              |                |                |
|   | 5                       | Fast stop     |            |                 |               |              |                |                |
|   | 6                       | Curr limstp   |            |                 |               |              |                |                |
| Intake air Sensor Over-Temperature activity   |                         |               |            |                 |               |              |                |                |
| <b>9088</b>   | <b>IAS restart</b>      | <b>N/A</b>    | <b>RWS</b> | <b>0</b>        | <b>0</b>      | <b>1</b>     | <b>DP</b>      | <b>V-F-S-B</b> |
|   | 0                       | off           |            |                 |               |              |                |                |
|   | 1                       | on            |            |                 |               |              |                |                |
| Intake air Sensor Over-Temperature restart  |                         |               |            |                 |               |              |                |                |
| <b>9089</b>   | <b>IAS restart time</b> | <b>[ms]</b>   | <b>RWS</b> | <b>1000</b>     | <b>0</b>      | <b>30000</b> | <b>PP</b>      | <b>V-F-S-B</b> |
| Intake air Sensor Over-Temperature restart time   |                         |               |            |                 |               |              |                |                |
| <b>9606</b>   | <b>IAS hold off</b>     | <b>[ms]</b>   | <b>RWS</b> | <b>10000</b>    | <b>0</b>      | <b>30000</b> | <b>PP</b>      | <b>V-F-S-B</b> |
| Intake air Sensor Over-Temperature hold off   |                         |               |            |                 |               |              |                |                |
| <b>ALARM CONFIG / Contact feedback</b>  |                         |               |            |                 |               |              |                |                |
| It trips when the contact feedback signal is not detected .   |                         |               |            |                 |               |              |                |                |
| Can be used to monitor the status of output contactor and give alarm if command and feedback don't match. |                         |               |            |                 |               |              |                |                |
|   |                         |               |            |                 |               |              |                |                |
| <b>7141</b>   | <b>CNT feedback src</b> | <b>N/A</b>    | <b>RWS</b> | <b>IPA 7122</b> | <b>List 3</b> | <b>PIN</b>   | <b>V-F-S-B</b> |                |
| IPA 7122 RUN cont mon = Default   |                         |               |            |                 |               |              |                |                |
| It allows to select the origin of Contact feedback signal (refer to signals List 3 of Pick List manual)   |                         |               |            |                 |               |              |                |                |

| IPA  | Description                     | [Unit]        | Access | Default | Min | Max | Format | Reg. Mode |
|------|---------------------------------|---------------|--------|---------|-----|-----|--------|-----------|
| 9068 | <b>CNT activity</b>             | N/A           | RWS    | 3       | 1   | 6   | DP     | V-F-S-B   |
|      | 1                               | Ignore        |        |         |     |     |        |           |
|      | 2                               | Warning       |        |         |     |     |        |           |
|      | 3                               | Disable drive |        |         |     |     |        |           |
|      | 4                               | Stop          |        |         |     |     |        |           |
|      | 5                               | Fast stop     |        |         |     |     |        |           |
|      | 6                               | Curr limstp   |        |         |     |     |        |           |
|      | Contact feedback alarm activity |               |        |         |     |     |        |           |

|      |                           |      |     |      |   |       |    |         |
|------|---------------------------|------|-----|------|---|-------|----|---------|
| 7135 | <b>CNT hold off</b>       | [ms] | RWS | 1000 | 0 | 30000 | PP | V-F-S-B |
|      | Contact feedback hold off |      |     |      |   |       |    |         |




### ALARM CONFIG / Brake feedback

It trips when the brake feedback signal is not detected

|      |   |     |     |          |        |     |         |  |
|------|---|-----|-----|----------|--------|-----|---------|--|
| 7142 | <b>BRK feedback src</b>   | N/A | RWS | IPA 7123 | List 3 | PIN | V-F-S-B |  |
|      | IPA 7123 BRAKE cont mon = Default   |     |     |          |        |     |         |  |
|      | It allows to select the origin of Brake feedback signal (refer to signals List 3 of Pick List manual) |     |     |          |        |     |         |  |

|      |                               |               |     |   |   |   |    |         |
|------|-------------------------------|---------------|-----|---|---|---|----|---------|
| 9086 | <b>BRK activity</b>           | N/A           | RWS | 3 | 1 | 6 | DP | V-F-S-B |
|      | 1                             | Ignore        |     |   |   |   |    |         |
|      | 2                             | Warning       |     |   |   |   |    |         |
|      | 3                             | Disable drive |     |   |   |   |    |         |
|      | 4                             | Stop          |     |   |   |   |    |         |
|      | 5                             | Fast stop     |     |   |   |   |    |         |
|      | 6                             | Curr limstp   |     |   |   |   |    |         |
|      | Brake feedback alarm activity |               |     |   |   |   |    |         |

|      |                         |      |     |      |   |       |    |         |
|------|-------------------------|------|-----|------|---|-------|----|---------|
| 7136 | <b>BRK hold off</b>     | [ms] | RWS | 1000 | 0 | 30000 | PP | V-F-S-B |
|      | Brake feedback hold off |      |     |      |   |       |    |         |



**Note!** During brake active state eventual alarms are latched and are reported only in brake idle state, see IPA 7145.

|      |                                       |     |   |   |   |   |    |         |
|------|---------------------------------------|-----|---|---|---|---|----|---------|
| 7145 | <b>BRK RUN hold off</b>               | N/A | RNS   | 1 | 0 | 1 | DP | V-F-S-B |
|      | Brake feedback holdoff configuration. |     |   |   |   |   |    |         |
|      | 0                                     | Off | brake feedback trip is reported immediately   |   |   |   |    |         |
|      | 1                                     | On  | eventual brake feedback trip is reported at the end of run. This allows the car to arrive at floor in case of faulty brake status switch. |   |   |   |    |         |

| IPA   | Description   | [Unit] | Access | Default  | Min    | Max   | Format  | Reg. Mode |
|---|---|--------|--------|----------|--------|-------|---------|-----------|
| <b>ALARM CONFIG / Brake feedback / Door feedback</b>  |   |        |        |          |        |       |         |           |
| 7144  | <b>Door fbk src</b><br>IPA 7139 Door open mon = Default. (Refer to signals List 3 of Pick List manual)<br>Source to provide Feedback to check status of the command provided through the input. | N/A    | RWS    | IPA 7139 | List 3 | PIN   | V-F-S-B |           |
| 9099  | <b>Door activity</b><br>1 Ignore<br>2 Warning<br>3 Disable drive<br>4 Stop<br>5 Fast stop<br>6 Curr limstp<br>Door feedback alarm activity. (from software rel. 3.300)                          | N/A    | RWS    | 3        | 1      | 6     | DP      | V-F-S-B   |
| 7137  | <b>Door hold off</b><br>Alarm hold off time; during this time mismatch in command and feedback is ignored.  | [ms]   | RWS    | 200      | 0.00   | 65535 | PP      | V-F-S-B   |
|   |   |        |        |          |        |       |         |           |
| <b>ALARM CONFIG / Comm card fault</b>   |   |        |        |          |        |       |         |           |
| It trips when LAN communication is interrupted (LAN communication between drive and Field Bus optional card)                        |   |        |        |          |        |       |         |           |
| 9074  | <b>CCF activity</b><br>2 Warning<br>3 Disable drive<br>4 Stop<br>5 Fast stop<br>6 Curr limstp<br>Comm card fault activity   | N/A    | RWS    | 3        | 2      | 6     | DP      | V-F-S-B   |
| 4200  | <b>CCF restart</b><br>0 off<br>1 on<br>Comm card fault restart  | N/A    | RWS    | 0        | 0      | 1     | DP      | V-F-S-B   |
| 4201  | <b>CCF restart time</b><br>Comm card fault restart time   | [ms]   | RWS    | 1000     | 0      | 30000 | PP      | V-F-S-B   |
| <b>ALARM CONFIG / Appl card fault</b>   |   |        |        |          |        |       |         |           |
| It trips when optional coprocessor communication is interrupted (coprocessor communication between drive and APC 100 optional card) |   |        |        |          |        |       |         |           |
| 9049  | <b>ACF activity</b><br>2 Warning<br>3 Disable drive<br>4 Stop<br>5 Fast stop<br>6 Curr limstp<br>Appl card fault activity   | N/A    | RWS    | 3        | 2      | 6     | DP      | V-F-S-B   |

| IPA   | Description                    | [Unit]       | Access     | Default     | Min         | Max          | Format    | Reg. Mode      |
|---|--------------------------------|--------------|------------|-------------|-------------|--------------|-----------|----------------|
| <b>ALARM CONFIG / Drive overload</b>                                      |                                |              |            |             |             |              |           |                |
| It trips when Drive overload accumulator exceeded trip threshold          |                                |              |            |             |             |              |           |                |
| <b>9040</b>   | <b>DOL activity</b>            | <b>N/A</b>   | <b>RWS</b> | <b>1</b>    | <b>1</b>    | <b>6</b>     | <b>DP</b> | <b>V-F-S-B</b> |
|   | 1                              |              |            |             |             |              |           | Ignore         |
|   | 2                              |              |            |             |             |              |           | Warning        |
|   | 3                              |              |            |             |             |              |           | Disable drive  |
|   | 4                              |              |            |             |             |              |           | Stop           |
|   | 5                              |              |            |             |             |              |           | Fast stop      |
|   | 6                              |              |            |             |             |              |           | Curr limstp    |
|   | Drive overload activity        |              |            |             |             |              |           |                |
| <b>ALARM CONFIG / Motor overload</b>                                      |                                |              |            |             |             |              |           |                |
| It trips when Motor overload accumulator exceeded trip threshold          |                                |              |            |             |             |              |           |                |
| <b>9041</b>   | <b>MOL activity</b>            | <b>N/A</b>   | <b>RWS</b> | <b>2</b>    | <b>1</b>    | <b>6</b>     | <b>DP</b> | <b>V-F-S-B</b> |
|   | 1                              |              |            |             |             |              |           | Ignore         |
|   | 2                              |              |            |             |             |              |           | Warning        |
|   | 3                              |              |            |             |             |              |           | Disable drive  |
|   | 4                              |              |            |             |             |              |           | Stop           |
|   | 5                              |              |            |             |             |              |           | Fast stop      |
|   | 6                              |              |            |             |             |              |           | Curr limstp    |
|   | Motor overload activity        |              |            |             |             |              |           |                |
| <b>ALARM CONFIG / BU overload</b>   |                                |              |            |             |             |              |           |                |
| It trips when Brake resistor overload accumulator exceeded trip threshold |                                |              |            |             |             |              |           |                |
| <b>9071</b>   | <b>BUOL activity</b>           | <b>N/A</b>   | <b>RWS</b> | <b>3</b>    | <b>1</b>    | <b>6</b>     | <b>DP</b> | <b>V-F-S-B</b> |
|   | 2                              |              |            |             |             |              |           | Warning        |
|   | 3                              |              |            |             |             |              |           | Disable drive  |
|   | 4                              |              |            |             |             |              |           | Stop           |
|   | 5                              |              |            |             |             |              |           | Fast stop      |
|   | 6                              |              |            |             |             |              |           | Curr limstp    |
|   | Braking Unit overload activity |              |            |             |             |              |           |                |
| <b>ALARM CONFIG / Overspeed</b>   |                                |              |            |             |             |              |           |                |
| It trips when the speed of the motor exceeded speed limit threshold       |                                |              |            |             |             |              |           |                |
| <b>9220</b>   | <b>OS activity</b>             | <b>N/A</b>   | <b>RWS</b> | <b>3</b>    | <b>1</b>    | <b>6</b>     | <b>DP</b> | <b>V-F-S-B</b> |
|   | 2                              |              |            |             |             |              |           | Warning        |
|   | 3                              |              |            |             |             |              |           | Disable drive  |
|   | 4                              |              |            |             |             |              |           | Stop           |
|   | 5                              |              |            |             |             |              |           | Fast stop      |
|   | 6                              |              |            |             |             |              |           | Curr limstp    |
|   | Overspeed activity             |              |            |             |             |              |           |                |
| <b>9221</b>   | <b>OS threshold</b>            | <b>[rpm]</b> | <b>RWS</b> | <b>Calc</b> | <b>0.00</b> | <b>8192</b>  | <b>PP</b> | <b>V-F-S-B</b> |
|   | Overspeed threshold            |              |            |             |             |              |           |                |
| <b>9608</b>   | <b>OS hold off</b>             | <b>[ms]</b>  | <b>RWS</b> | <b>0</b>    | <b>0</b>    | <b>30000</b> | <b>PP</b> | <b>V-F-S-B</b> |
|   | Overspeed hold off             |              |            |             |             |              |           |                |
| <b>ALARM CONFIG / Spd fbk loss</b>  |                                |              |            |             |             |              |           |                |
| It trips when the speed feedback is not detected or encoder supply failed |                                |              |            |             |             |              |           |                |
| <b>9042</b>   | <b>SFL activity</b>            | <b>N/A</b>   | <b>RWS</b> | <b>3</b>    | <b>1</b>    | <b>6</b>     | <b>DP</b> | <b>V-F-S-B</b> |
|   | 1                              |              |            |             |             |              |           | Ignore         |
|   | 2                              |              |            |             |             |              |           | Warning        |
|   | 3                              |              |            |             |             |              |           | Disable drive  |
|   | 4                              |              |            |             |             |              |           | Stop           |
|   | 5                              |              |            |             |             |              |           | Fast stop      |
|   | 6                              |              |            |             |             |              |           | Curr limstp    |
|   | Spd fbk loss activity          |              |            |             |             |              |           |                |

| IPA   | Description         | [Unit] | Access | Default | Min | Max    | Format | Reg. Mode |
|---|---------------------|--------|--------|---------|-----|--------|--------|-----------|
| <b>ALARM CONFIG / UV repetitive</b>   |                     |        |        |         |     |        |        |           |
| It trips when more than a programmable number, with "UVR attempts" parameter, of Undervoltage faults are detected in 4 minutes (time programmable with "UVR delay" parameter) |                     |        |        |         |     |        |        |           |
| 9043  | <b>UVR attempts</b> | N/A    | RWS    | 5       | 1   | 1000   | PP     | V-F-S-B   |
| It determines the number of Undervoltage faults accepted  |                     |        |        |         |     |        |        |           |
| 9044  | <b>UVR delay</b>    | [sec]  | RWS    | 240     | 1   | 262.14 | PP     | V-F-S-B   |
| It determines the time window of "UVR attempts" parameter   |                     |        |        |         |     |        |        |           |

### ALARM CONFIG / Hw fault

It trips when the communication between drive regulation card and one of its option cards is not detected

|                        |                     |     |   |   |   |   |    |         |
|------------------------|---------------------|-----|---|---|---|---|----|---------|
| 4202                   | <b>Hw fault mon</b> | N/A | R | 0 | 0 | 0 | DP | V-F-S-B |
| 0 communication OK     |                     |     |   |   |   |   |    |         |
| 1 communication failed |                     |     |   |   |   |   |    |         |

### ALARM CONFIG / Alarm status

The alarm state can be reported via three Words. Each bit determines an alarm state. It is therefore possible to determine the state of 48 alarms. Each single bit can be controlled if the corresponding bit of a specific mask is set with 1, otherwise their setting is always 0.

When an alarm becomes active, the word corresponding bit is set with 1. Its setting remains equal to 1 till the alarm becomes inactive and the "State Machine or Sequencer" is not in an alarm condition (see the previous paragraphs). If the state of a single alarm has to be controlled via an output, then only the mask needed bit has to be set with 1. If the state of several alarms has to be controlled via an output, then the mask corresponding bits have to be set with 1. The alarms have to be controlled by the Word itself.

Ex: the state of the External fault alarm has to be read.  
 Mask W1 S1 = 0x0100 => 0000 0001 0000 0000  
 Mask W2 S1 = 0x0000 => 0000 0000 0000 0000  
 Mask W3 S1 = 0x0000 => 0000 0000 0000 0000  
 DO 0 src = Select ipa Alm W1 S1.

The state of the Undervoltage and Overvoltage alarm has to be read.  
 Mask W1 S1 = 0x0100 => 0000 0000 0000 0110  
 Mask W2 S1 = 0x0000 => 0000 0000 0000 0000  
 Mask W3 S1 = 0x0000 => 0000 0000 0000 0000  
 DO 0 src = Select ipa Alm W1 S1.

The state of the External fault and F\_R\_C alarm has to be read.  
 Mask W1 S1 = 0x0100 => 0000 0001 0000 0000  
 Mask W2 S1 = 0x0000 => 0000 0000 1000 0000  
 DO 0 src = Select ipa Alm W1 S1  
 DO 1 src = Select ipa Alm W2 S1

### Alarm status / Alm status cfg

|      |                   |     |     |       |   |    |    |         |
|------|-------------------|-----|-----|-------|---|----|----|---------|
| 9610 | <b>Mask W1 S1</b> | N/A | RWS | 0XFFF | 0 | -1 | DP | V-F-S-B |
| 9611 | <b>Mask W2 S1</b> | N/A | RWS | 0XFFF | 0 | -1 | DP | V-F-S-B |
| 9612 | <b>Mask W3 S1</b> | N/A | RWS | 0XFFF | 0 | -1 | DP | V-F-S-B |
| 9614 | <b>Mask W1 S2</b> | N/A | RWS | 0XFFF | 0 | -1 | DP | V-F-S-B |
| 9615 | <b>Mask W2 S2</b> | N/A | RWS | 0XFFF | 0 | -1 | DP | V-F-S-B |
| 9616 | <b>Mask W3 S2</b> | N/A | RWS | 0XFFF | 0 | -1 | DP | V-F-S-B |

### Alarm status / Alm status mon

|      |                  |     |   |   |   |      |    |         |
|------|------------------|-----|---|---|---|------|----|---------|
| 9630 | <b>Alm W1 S1</b> | N/A | R | 0 | 0 | Calc | DP | V-F-S-B |
| 9631 | <b>Alm W2 S1</b> | N/A | R | 0 | 0 | Calc | DP | V-F-S-B |
| 9632 | <b>Alm W3 S1</b> | N/A | R | 0 | 0 | Calc | DP | V-F-S-B |
| 9634 | <b>Alm W1 S2</b> | N/A | R | 0 | 0 | Calc | DP | V-F-S-B |

| IPA  | Description | [Unit] | Access | Default | Min | Max  | Format | Reg. Mode |
|------|-------------|--------|--------|---------|-----|------|--------|-----------|
| 9635 | Alm W2 S2   | N/A    | R      | 0       | 0   | Calc | DP     | V-F-S-B   |
| 9636 | Alm W3 S2   | N/A    | R      | 0       | 0   | Calc | DP     | V-F-S-B   |

| ALARM NAME       | BIT position in the alarm Word | Code in the alarm LIST | Drive activity after Alarm | HOLD OFF            | Restart                             | Restart time | Acknowledgment request | Msg ad alarm | DigOut |
|------------------|--------------------------------|------------------------|----------------------------|---------------------|-------------------------------------|--------------|------------------------|--------------|--------|
| Failure supply   | 1                              | 21                     | Dis. drive                 | No                  | No                                  | No           | Yes                    | Yes          | Yes    |
| Undervoltage     | 2                              | 22                     | Dis. drive                 | No                  | Yes. logic on n° times              | Yes          | Yes                    | Yes          | Yes    |
| Overvoltage      | 3                              | 23                     | Dis. drive                 | No                  | Yes                                 | Yes          | Yes                    | Yes          | Yes    |
| IGBT desaturat   | 4                              | 24                     | Dis. drive                 | No                  | Yes. logic on 2 alarms in 30 second | Yes          | Yes                    | Yes          | Yes    |
| Inst overcurrent | 5                              | 25                     | Dis. drive                 | No                  | Yes. logic on 2 alarms in 30 second | Yes          | Yes                    | Yes          | Yes    |
| Ground fault     | 6                              | 26                     | Prog.                      | No                  | No                                  | No           | Yes                    | Yes          | Yes    |
| Curr fbk loss    | 7                              | 27                     | Dis. drive                 | No                  | No                                  | No           | Yes                    | Yes          | Yes    |
| External fault   | 8                              | 28                     | Prog.                      | Yes. Prog.          | Yes                                 | Yes. Prog.   | Yes                    | Yes          | Yes    |
| Spd fbk loss     | 9                              | 29                     | Prog.                      | No                  | No                                  | No           | Yes                    | Yes          | Yes    |
| Module OT        | 10                             | 30                     | Dis. drive                 | Yes Fixed 10 msec   | No                                  | No           | Yes                    | Yes          | Yes    |
| Heatsink OT      | 11                             | 31                     | Dis. drive                 | Yes Fixed 1000 msec |                                     |              | Yes                    | Yes          | Yes    |
| Motor OT         | 12                             | 32                     | Prog.                      | Yes. Prog.          | Yes                                 | Yes. Prog.   | Yes                    | Yes          | Yes    |
| Heatsink S OT    | 13                             | 33                     | Prog.                      | Yes. Prog.          | Yes                                 | Yes. Prog.   | Yes                    | Yes          | Yes    |
| Regulation S OT  | 14                             | 34                     | Prog.                      | Yes. Prog.          | Yes                                 | Yes. Prog.   | Yes                    | Yes          | Yes    |
| Intake air S OT  | 15                             | 35                     | Prog.                      | Yes. Prog.          | Yes                                 | Yes. Prog.   | Yes                    | Yes          | Yes    |
| Cont fbk fail    | 16                             | 36                     | Prog.                      | No                  | Yes                                 | No           | Yes                    | Yes          | Yes    |
| Comm card fault  | 17                             | 37                     | Prog.                      | No                  | Yes                                 | Yes. Prog.   | Yes                    | Yes          | Yes    |
| Appl card fault  | 18                             | 38                     | Dis. drive                 | No                  | No                                  | No           | Yes                    | Yes          | Yes    |
| Drive overload   | 19                             | 39                     | Prog.                      | No                  | No                                  | No           | Yes                    | Yes          | Yes    |
| Motor overload   | 20                             | 40                     | Prog.                      | No                  | No                                  | No           | Yes                    | Yes          | Yes    |
| BU overload      | 21                             | 41                     | Prog.                      | No                  | No                                  | No           | Yes                    | Yes          | Yes    |
| Data lost        | 22                             | 42                     | Dis. drive                 | No                  | No                                  | No           | Yes                    | Yes          | Yes    |
| Brake fbk fail   | 23                             | 43                     | Prog.                      | No                  | No                                  | No           | Yes                    | Yes          | Yes    |
| Max time         | 24                             | 44                     | Dis. drive                 | No                  | No                                  | No           | Yes                    | Yes          | Yes    |
| Sequencer        | 25                             | 45                     | Dis. drive                 | No                  | No                                  | No           | Yes                    | Yes          | No     |
| Door fbk fail    | 26                             | 46                     | Prog.                      | Yes                 | No                                  | No           | Yes                    | Yes          | Yes    |
| Overspeed        | 27                             | 47                     | Prog.                      | Yes. Prog.          | No                                  | No           | Yes                    | Yes          | Yes    |
| UV repetitive    | 28                             | 48                     | Dis. drive                 | No                  | No                                  | No           | Yes                    | Yes          | Yes    |
| IOC repetitive   | 29                             | 49                     | Dis. drive                 | No                  | No                                  | No           | Yes                    | Yes          | Yes    |
| IGBTdesat repet  | 30                             | 50                     | Dis. drive                 | No                  | No                                  | No           | Yes                    | Yes          | Yes    |
| WatchDog user    | 31                             | 51                     | Dis. drive                 | No                  | No                                  | No           | Yes                    | Yes          | Yes    |
| Hw fail          | 32                             | 52                     | Dis. drive                 | No                  | No                                  | No           | Yes                    | Yes          | Yes    |

Alarms status

| IPA | Description | [Unit] | Access | Default | Min | Max | Format | Reg. Mode |
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|

## COMMUNICATION

The access to COMMUNICATION menu is allowed by Level 1 password: 12345. It must be set in the SERVICE menu.

**RS485:** The communication protocol can be chosen between Slink4, Modbus, Jbus or ISO 1745 through the "Protocol type" parameter. Each of these protocols allow a multipoint network. See the specific protocol manual for further details.

The Drive address can be defined via the "Slave address" parameter. Editing parameter 105, "Slave address", and saving the new value perform the address change. The new address becomes active after the Drive has been switched off and then back on. A temporary address change is also possible when using the Slink4 protocol with an Slink4 command.

When using the Slink4 protocol, the RS485 serial line operates in half-duplex, where the data cannot be transmitted and received simultaneously. It is sometimes possible during the transition from transmission to reception modes, the Master (PC or PLC) reaches the reception condition after the Drive has already started to send its data package. As a consequence, the package received by the master is not correct. In order to avoid such occurrences, the "Slave res time" parameter can be adjusted to delay the drive response so the Master has sample mode switching time. This situation does not occur with the Modbus and Jbus protocols as the synchronization pause between messages is specified by the protocol and is guaranteed.

**SBI:** The communication with the SBI Field Bus option cards (Serial Bus Interface) is performed via two channels:

- Synchronous or Process channel (PDC Process Data Channel) for a cyclical value interchange.
- Asynchronous or Configuration channel for a low priority access to all the Drive parameters.

As for the data exchange modes between the SBI card and the Network see the SBI card documentation.

The process data exchange between the Drive and the SBI has the following structure:

- the interface is made of six writing Words and six reading Words.
- the source Drive parameter has to be defined for the six Words: "Drv -> SBI word" transmitting the data from the Drive to the SBI.
- Six Words move the data from the SBI to the Drive: "SBI -> Drv word"

For more information to see the following documents for related information on SBI:

|            |  |
|------------|--|
| SBI-PDP 33 | Interface card Profibus- DP instruction manual |
| SBI-DN 33  | DeviceNet card instruction manual              |
| SBI-COP    | CANopen card instruction manual                |

### COMMUNICATION / RS485

|            |   |     |     |   |   |     |    |         |
|------------|---|-----|-----|---|---|-----|----|---------|
| <b>105</b> | <b>Slave address</b><br>It define the drive slave address   | N/A | RWS | 1 | 0 | 255 | DK | V-F-S-B |
| <b>106</b> | <b>Slave res time</b><br>It define the drive slave address time   | N/A | RWS | 1 | 0 | 255 | DK | V-F-S-B |
| <b>104</b> | <b>Protocol type</b><br>0 Slink 4<br>1 Modbus<br>2 Jbus<br>3 ISO 1745<br>4 Hiperface protocol (Used to communicate with Stegmann absolute encoders)<br>It defines the drive communication protocol type | N/A | RWS | 0 | 0 | 2   | DK | V-F-S-B |

### COMMUNICATION / SBI config

|             |  |     |     |   |   |   |    |         |
|-------------|--|-----|-----|---|---|---|----|---------|
| <b>8999</b> | <b>SBI enable</b><br>0 Disabled<br>1 Enabled<br>It allows to enable SBI Field Bus option cards<br>(SAVE PARAMETERS command and drive recycle power are required) | N/A | RWS | 0 | 0 | 1 | DK | V-F-S-B |
|-------------|--|-----|-----|---|---|---|----|---------|

| IPA   | Description   | [Unit] | Access | Default  | Min | Max     | Format | Reg. Mode |
|---|---|--------|--------|----------|-----|---------|--------|-----------|
| <b>COMMUNICATION / SBI monitor</b>                          |   |        |        |          |     |         |        |           |
| 8998  | <b>Last SBI error</b><br>It defines the last found error:<br>0 = OK (no error)<br>1 = Hardware fault<br>2 = Bus Loss  | N/A    | R      | 0        | 0   | 2       | DP     | V-F-S-B   |
| <b>COMMUNICATION / Drv-&gt;SBI word</b>                     |   |        |        |          |     |         |        |           |
| <b>COMMUNICATION / Drv-&gt;SBI word / Drv-&gt;SBI W src</b> |   |        |        |          |     |         |        |           |
| 9010  | <b>Drv SBI W0 src</b><br>IPA 9020 Int Drv SBI W0 = Default<br>It allows to select the origin of Word 0 to be transmitted from Drive to SBI card<br>(refer to signals List 40 of Pick List manual) | N/A    | RWS    | IPA 9020 |     | List 40 | PIN    | V-F-S-B   |
| 9011  | <b>Drv SBI W1 src</b><br>IPA 9021 Int Drv SBI W1 = Default<br>It allows to select the origin of Word 1 to be transmitted from Drive to SBI card<br>(refer to signals List 40 of Pick List manual) | N/A    | RWS    | IPA 9021 |     | List 40 | PIN    | V-F-S-B   |
| 9012  | <b>Drv SBI W2 src</b><br>IPA 9022 Int Drv SBI W2 = Default<br>It allows to select the origin of Word 2 to be transmitted from Drive to SBI card<br>(refer to signals List 40 of Pick List manual) | N/A    | RWS    | IPA 9022 |     | List 40 | PIN    | V-F-S-B   |
| 9013  | <b>Drv SBI W3 src</b><br>IPA 9023 Int Drv SBI W3 = Default<br>It allows to select the origin of Word 3 to be transmitted from Drive to SBI card<br>(refer to signals List 40 of Pick List manual) | N/A    | RWS    | IPA 9023 |     | List 40 | PIN    | V-F-S-B   |
| 9014  | <b>Drv SBI W4 src</b><br>IPA 9024 Int Drv SBI W4 = Default<br>It allows to select the origin of Word 4 to be transmitted from Drive to SBI card<br>(refer to signals List 40 of Pick List manual) | N/A    | RWS    | IPA 9024 |     | List 40 | PIN    | V-F-S-B   |
| 9015  | <b>Drv SBI W5 src</b><br>IPA 9025 Int Drv SBI W5 = Default<br>It allows to select the origin of Word 5 to be transmitted from Drive to SBI card<br>(refer to signals List 40 of Pick List manual) | N/A    | RWS    | IPA 9025 |     | List 40 | PIN    | V-F-S-B   |
| <b>COMMUNICATION / Drv-&gt;SBI word / Drv-&gt;SBI W cfg</b> |   |        |        |          |     |         |        |           |
| 9020  | <b>Int Drv SBI W0</b><br>Internal Word 0 value configuration (default connected to Drv SBI W0 src)  | N/A    | RWS    | 0.00     | -   | -       | PV     | V-F-S-B   |
| 9021  | <b>Int Drv SBI W1</b><br>Internal Word 1 value configuration (default connected to Drv SBI W1 src)  | N/A    | RWS    | 0.00     | -   | -       | PV     | V-F-S-B   |
| 9022  | <b>Int Drv SBI W2</b><br>Internal Word 2 value configuration (default connected to Drv SBI W2 src)  | N/A    | RWS    | 0.00     | -   | -       | PV     | V-F-S-B   |
| 9023  | <b>Int Drv SBI W3</b><br>Internal Word 3 value configuration (default connected to Drv SBI W3 src)  | N/A    | RWS    | 0.00     | -   | -       | PV     | V-F-S-B   |
| 9024  | <b>Int Drv SBI W4</b><br>Internal Word 4 value configuration (default connected to Drv SBI W4 src)  | N/A    | RWS    | 0.00     | -   | -       | PV     | V-F-S-B   |
| 9025  | <b>Int Drv SBI W5</b><br>Internal Word 5 value configuration (default connected to Drv SBI W5 src)  | N/A    | RWS    | 0.00     | -   | -       | PV     | V-F-S-B   |



| IPA   | Description  | [Unit] | Access | Default | Min | Max | Format | Reg. Mode |
|---|--|--------|--------|---------|-----|-----|--------|-----------|
| <b>COMMUNICATION / Drv-&gt;SBI word / Drv-&gt;SBI W mon</b> |  |        |        |         |     |     |        |           |
| 9030  | <b>Drv SBI W0 mon</b><br>Word 0 monitor of the PDC channel on the Drive output | N/A    | R      | 0.00    | -   | -   | PP     | V-F-S-B   |
| 9031  | <b>Drv SBI W1 mon</b><br>Word 1 monitor of the PDC channel on the Drive output | N/A    | R      | 0.00    | -   | -   | PP     | V-F-S-B   |
| 9032  | <b>Drv SBI W2 mon</b><br>Word 2 monitor of the PDC channel on the Drive output | N/A    | R      | 0.00    | -   | -   | PP     | V-F-S-B   |
| 9033  | <b>Drv SBI W3 mon</b><br>Word 3 monitor of the PDC channel on the Drive output | N/A    | R      | 0.00    | -   | -   | PP     | V-F-S-B   |
| 9034  | <b>Drv SBI W4 mon</b><br>Word 4 monitor of the PDC channel on the Drive output | N/A    | R      | 0.00    | -   | -   | PP     | V-F-S-B   |
| 9035  | <b>Drv SBI W5 mon</b><br>Word 5 monitor of the PDC channel on the Drive output | N/A    | R      | 0.00    | -   | -   | PP     | V-F-S-B   |

### COMMUNICATION / SBI->Drv word

#### COMMUNICATION / SBI->Drv word / SBI->Drv W mon

|      |   |     |   |      |   |   |    |         |
|------|---|-----|---|------|---|---|----|---------|
| 9000 | <b>SBI Drv W0 mon</b><br>Word 0 monitor of the PDC channel on the Drive input | N/A | R | 0.00 | - | - | PP | V-F-S-B |
| 9001 | <b>SBI Drv W1 mon</b><br>Word 1 monitor of the PDC channel on the Drive input | N/A | R | 0.00 | - | - | PP | V-F-S-B |
| 9002 | <b>SBI Drv W2 mon</b><br>Word 2 monitor of the PDC channel on the Drive input | N/A | R | 0.00 | - | - | PP | V-F-S-B |
| 9003 | <b>SBI Drv W3 mon</b><br>Word 3 monitor of the PDC channel on the Drive input | N/A | R | 0.00 | - | - | PP | V-F-S-B |
| 9004 | <b>SBI Drv W4 mon</b><br>Word 4 monitor of the PDC channel on the Drive input | N/A | R | 0.00 | - | - | PP | V-F-S-B |
| 9005 | <b>SBI Drv W5 mon</b><br>Word 5 monitor of the PDC channel on the Drive input | N/A | R | 0.00 | - | - | PP | V-F-S-B |

### SAVE PARAMETERS

AVyL drive allows two different commands to save the parameters modified in the regulation mode selected:

- by STARTUP menu, "Save Config?" command
- by all other menus, "SAVE PARAMETERS" command

Any changes made in STARTUP menu require "Save Config?" command, which saves all entire regulation mode selected.

It is recommended every time the user made any changes into STARTUP menu.

"SAVE PARAMETERS" command saves all the changes made out of STARTUP menu only.

When on the keypad display appears blinking message "Use Save Config", use "Save Config?" command

| IPA | Description | [Unit] | Access | Default | Min | Max | Format | Reg. Mode |
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|

## APPL CARD CONFIG

The access to APPL CARD CONFIG menu is allowed by Level 1 password: 12345. It must be set in the SERVICE menu.

APC option card is used for advanced lift applications.

The communication between the Drive and the APC is performed via two channels for each direction.

- from drive to APC: "Drv->DGFCs" writing to drive 5 Synchronous words  
"Drv->DGFCa" writing to drive 10 Asynchronous words
- from APC to drive: "DGFCs->Drv" reading from APC 5 Synchronous words  
"DGFCa->Drv" reading from APC 10 Asynchronous words

The Words move the data from the APC to the Drive can be found in the source selecting lists.

For more information following the instructions on DGFC-386y-1 card (APC100 card) manual

### APPL CARD CONFIG / DGFC / DGFC config

|             |  |            |            |          |          |          |           |                |
|-------------|--|------------|------------|----------|----------|----------|-----------|----------------|
| <b>4129</b> | <b>DGFC enable</b>   | <b>N/A</b> | <b>RWS</b> | <b>0</b> | <b>0</b> | <b>1</b> | <b>DK</b> | <b>V-F-S-B</b> |
|             | 0 Disabled   |            |            |          |          |          |           |                |
|             | 1 Enabled  |            |            |          |          |          |           |                |
|             | It allows to enable APC option cards<br>(SAVE PARAMETERS command and drive recycle power are required) |            |            |          |          |          |           |                |

### APPL CARD CONFIG / DGFC / DGFC sync Ch

#### APPL CARD CONFIG / DGFC / Drv->DGFCs W src

|             |  |            |            |                 |                |            |                |  |
|-------------|--|------------|------------|-----------------|----------------|------------|----------------|--|
| <b>4100</b> | <b>Drv DGFC-S W0src</b>  | <b>N/A</b> | <b>RWS</b> | <b>IPA 4105</b> | <b>List 29</b> | <b>PIN</b> | <b>V-F-S-B</b> |  |
|             | IPA 4105 Int DrvDGFC-S W0 = Default<br>It allows to select the origin of Synchronous Word 0 to be transmitted from Drive to APC card<br>(refer to signals List 29 of Pick List manual) |            |            |                 |                |            |                |  |
| <b>4101</b> | <b>Drv DGFC-S W1src</b>  | <b>N/A</b> | <b>RWS</b> | <b>IPA 4106</b> | <b>List 29</b> | <b>PIN</b> | <b>V-F-S-B</b> |  |
|             | IPA 4106 Int DrvDGFC-S W1 = Default<br>It allows to select the origin of Synchronous Word 1 to be transmitted from Drive to APC card<br>(refer to signals List 29 of Pick List manual) |            |            |                 |                |            |                |  |
| <b>4102</b> | <b>Drv DGFC-S W2src</b>  | <b>N/A</b> | <b>RWS</b> | <b>IPA 4107</b> | <b>List 29</b> | <b>PIN</b> | <b>V-F-S-B</b> |  |
|             | IPA 4107 Int DrvDGFC-S W2 = Default<br>It allows to select the origin of Synchronous Word 2 to be transmitted from Drive to APC card<br>(refer to signals List 29 of Pick List manual) |            |            |                 |                |            |                |  |
| <b>4103</b> | <b>Drv DGFC-S W3src</b>  | <b>N/A</b> | <b>RWS</b> | <b>IPA 4108</b> | <b>List 29</b> | <b>PIN</b> | <b>V-F-S-B</b> |  |
|             | IPA 4108 Int DrvDGFC-S W3 = Default<br>It allows to select the origin of Synchronous Word 3 to be transmitted from Drive to APC card<br>(refer to signals List 29 of Pick List manual) |            |            |                 |                |            |                |  |
| <b>4104</b> | <b>Drv DGFC-S W4src</b>  | <b>N/A</b> | <b>RWS</b> | <b>IPA 4109</b> | <b>List 29</b> | <b>PIN</b> | <b>V-F-S-B</b> |  |
|             | IPA 4109 Int DrvDGFC-S W4 = Default<br>It allows to select the origin of Synchronous Word 4 to be transmitted from Drive to APC card<br>(refer to signals List 29 of Pick List manual) |            |            |                 |                |            |                |  |

#### APPL CARD CONFIG / DGFC / Drv->DGFCs W cfg

|             |   |            |            |             |          |          |           |                |
|-------------|---|------------|------------|-------------|----------|----------|-----------|----------------|
| <b>4105</b> | <b>Int DrvDGFC-S W0</b>   | <b>N/A</b> | <b>RWS</b> | <b>0.00</b> | <b>-</b> | <b>-</b> | <b>PV</b> | <b>V-F-S-B</b> |
|             | Internal Synchronous Word 0 value configuration (default connected to Drv DGFC-S W0src) |            |            |             |          |          |           |                |
| <b>4106</b> | <b>Int DrvDGFC-S W1</b>   | <b>N/A</b> | <b>RWS</b> | <b>0.00</b> | <b>-</b> | <b>-</b> | <b>PV</b> | <b>V-F-S-B</b> |
|             | Internal Synchronous Word 1 value configuration (default connected to Drv DGFC-S W1src) |            |            |             |          |          |           |                |
| <b>4107</b> | <b>Int DrvDGFC-S W2</b>   | <b>N/A</b> | <b>RWS</b> | <b>0.00</b> | <b>-</b> | <b>-</b> | <b>PV</b> | <b>V-F-S-B</b> |
|             | Internal Synchronous Word 2 value configuration (default connected to Drv DGFC-S W2src) |            |            |             |          |          |           |                |

| IPA   | Description  | [Unit] | Access | Default  | Min | Max     | Format | Reg. Mode |
|---|--|--------|--------|----------|-----|---------|--------|-----------|
| 4108  | <b>Int DrvDGFC-S W3</b><br>Internal Synchronous Word 3 value configuration (default connected to Drv DGFC-S W3src)   | N/A    | RWS    | 0.00     | -   | -       | PV     | V-F-S-B   |
| 4109  | <b>Int DrvDGFC-S W4</b><br>Internal Synchronous Word 4 value configuration (default connected to Drv DGFC-S W4src)   | N/A    | RWS    | 0.00     | -   | -       | PV     | V-F-S-B   |
| <b>APPL CARD CONFIG / DGFC / Drv-&gt;DGFC S W mon</b> |  |        |        |          |     |         |        |           |
| 4110  | <b>Drv DGFC-S W0mon</b><br>Synchronous Word 0 monitor (from Drive to DGFC)   | N/A    | R      | 0.00     | -   | -       | PP     | V-F-S-B   |
| 4111  | <b>Drv DGFC-S W1mon</b><br>Synchronous Word 1 monitor (from Drive to DGFC)   | N/A    | R      | 0.00     | -   | -       | PP     | V-F-S-B   |
| 4112  | <b>Drv DGFC-S W2mon</b><br>Synchronous Word 2 monitor (from Drive to DGFC)   | N/A    | R      | 0.00     | -   | -       | PP     | V-F-S-B   |
| 4113  | <b>Drv DGFC-S W3mon</b><br>Synchronous Word 3 monitor (from Drive to DGFC)   | N/A    | R      | 0.00     | -   | -       | PP     | V-F-S-B   |
| 4114  | <b>Drv DGFC-S W4mon</b><br>Synchronous Word 4 monitor (from Drive to DGFC)   | N/A    | R      | 0.00     | -   | -       | PP     | V-F-S-B   |
| <b>APPL CARD CONFIG / DGFC / DGFC S-&gt;Drv W mon</b> |  |        |        |          |     |         |        |           |
| 4120  | <b>DGFC-S Drv W0mon</b><br>Synchronous Word 0 monitor (from DGFC to Drive)   | N/A    | R      | 0.00     | -   | -       | PV     | V-F-S-B   |
| 4121  | <b>DGFC-S Drv W1mon</b><br>Synchronous Word 1 monitor (from DGFC to Drive)   | N/A    | R      | 0.00     | -   | -       | PV     | V-F-S-B   |
| 4122  | <b>DGFC-S Drv W2mon</b><br>Synchronous Word 2 monitor (from DGFC to Drive)   | N/A    | R      | 0.00     | -   | -       | PV     | V-F-S-B   |
| 4123  | <b>DGFC-S Drv W3mon</b><br>Synchronous Word 3 monitor (from DGFC to Drive)   | N/A    | R      | 0.00     | -   | -       | PV     | V-F-S-B   |
| 4124  | <b>DGFC-S Drv W4mon</b><br>Synchronous Word 4 monitor (from DGFC to Drive)   | N/A    | R      | 0.00     | -   | -       | PV     | V-F-S-B   |
| <b>APPL CARD CONFIG / DGFC / DGFC async Ch</b>        |  |        |        |          |     |         |        |           |
| <b>APPL CARD CONFIG / DGFC / Drv-&gt;DGFC A W src</b> |  |        |        |          |     |         |        |           |
| 4130  | <b>Drv DGFC-A W0src</b><br>IPA 4140 Int DrvDGFC-A W0 = Default<br>It allows to select the origin of Asynchronous Word 0 to be transmitted from Drive to DGFC card (refer to signals List 30 of Pick List manual) | N/A    | RWS    | IPA 4140 |     | List 30 | PIN    | V-F-S-B   |
| 4131  | <b>Drv DGFC-A W1src</b><br>IPA 4141 Int DrvDGFC-A W1 = Default<br>It allows to select the origin of Asynchronous Word 1 to be transmitted from Drive to DGFC card (refer to signals List 30 of Pick List manual) | N/A    | RWS    | IPA 4141 |     | List 30 | PIN    | V-F-S-B   |
| 4132  | <b>Drv DGFC-A W2src</b><br>IPA 4142 Int DrvDGFC-A W2 = Default<br>It allows to select the origin of Asynchronous Word 2 to be transmitted from Drive to DGFC card (refer to signals List 30 of Pick List manual) | N/A    | RWS    | IPA 4142 |     | List 30 | PIN    | V-F-S-B   |
| 4133  | <b>Drv DGFC-A W3src</b><br>IPA 4143 Int DrvDGFC-A W3 = Default<br>It allows to select the origin of Asynchronous Word 3 to be transmitted from Drive to DGFC card (refer to signals List 30 of Pick List manual) | N/A    | RWS    | IPA 4143 |     | List 30 | PIN    | V-F-S-B   |

| IPA  | Description  | [Unit] | Access | Default  | Min | Max     | Format | Reg. Mode |
|------|--|--------|--------|----------|-----|---------|--------|-----------|
| 4134 | <b>Drv DGFC-A W4src</b><br>IPA 4144 Int DrvDGFC-A W4 = Default<br>It allows to select the origin of Asynchronous Word 4 to be transmitted from Drive to DGFC card (refer to signals List 30 of Pick List manual) | N/A    | RWS    | IPA 4144 |     | List 30 | PIN    | V-F-S-B   |
| 4135 | <b>Drv DGFC-A W5src</b><br>IPA 4145 Int DrvDGFC-A W5 = Default. It allows to select the origin of Asynchronous Word 5 to be transmitted from Drive to DGFC card (refer to signals List 30 of Pick List manual)   | N/A    | RWS    | IPA 4145 |     | List 30 | PIN    | V-F-S-B   |
| 4136 | <b>Drv DGFC-A W6src</b><br>IPA 4146 Int DrvDGFC-A W6 = Default<br>It allows to select the origin of Asynchronous Word 6 to be transmitted from Drive to DGFC card (refer to signals List 30 of Pick List manual) | N/A    | RWS    | IPA 4146 |     | List 30 | PIN    | V-F-S-B   |
| 4137 | <b>Drv DGFC-A W7src</b><br>IPA 4147 Int DrvDGFC-A W7 = Default<br>It allows to select the origin of Asynchronous Word 7 to be transmitted from Drive to DGFC card (refer to signals List 30 of Pick List manual) | N/A    | RWS    | IPA 4147 |     | List 30 | PIN    | V-F-S-B   |
| 4138 | <b>Drv DGFC-A W8src</b><br>IPA 4148 Int DrvDGFC-A W8 = Default<br>It allows to select the origin of Asynchronous Word 8 to be transmitted from Drive to DGFC card (refer to signals List 30 of Pick List manual) | N/A    | RWS    | IPA 4148 |     | List 30 | PIN    | V-F-S-B   |
| 4139 | <b>Drv DGFC-A W9src</b><br>IPA 4149 Int DrvDGFC-A W9 = Default<br>It allows to select the origin of Asynchronous Word 9 to be transmitted from Drive to DGFC card (refer to signals List 30 of Pick List manual) | N/A    | RWS    | IPA 4149 |     | List 30 | PIN    | V-F-S-B   |

#### APPL CARD CONFIG / DGFC / Drv->DGFC-A W cfg

|      |   |     |     |      |   |   |    |         |
|------|---|-----|-----|------|---|---|----|---------|
| 4140 | <b>Int DrvDGFC-A W0</b><br>Internal Asynchronous Word 0 value configuration (default connected to Drv DGFC-A W0src) | N/A | RWS | 0.00 | - | - | PV | V-F-S-B |
| 4141 | <b>Int DrvDGFC-A W1</b><br>Internal Asynchronous Word 1 value configuration (default connected to Drv DGFC-A W0src) | N/A | RWS | 0.00 | - | - | PV | V-F-S-B |
| 4142 | <b>Int DrvDGFC-A W2</b><br>Internal Asynchronous Word 2 value configuration (default connected to Drv DGFC-A W0src) | N/A | RWS | 0.00 | - | - | PV | V-F-S-B |
| 4143 | <b>Int DrvDGFC-A W3</b><br>Internal Asynchronous Word 3 value configuration (default connected to Drv DGFC-A W0src) | N/A | RWS | 0.00 | - | - | PV | V-F-S-B |
| 4144 | <b>Int DrvDGFC-A W4</b><br>Internal Asynchronous Word 4 value configuration (default connected to Drv DGFC-A W0src) | N/A | RWS | 0.00 | - | - | PV | V-F-S-B |
| 4145 | <b>Int DrvDGFC-A W5</b><br>Internal Asynchronous Word 5 value configuration (default connected to Drv DGFC-A W0src) | N/A | RWS | 0.00 | - | - | PV | V-F-S-B |
| 4146 | <b>Int DrvDGFC-A W6</b><br>Internal Asynchronous Word 6 value configuration (default connected to Drv DGFC-A W0src) | N/A | RWS | 0.00 | - | - | PV | V-F-S-B |
| 4147 | <b>Int DrvDGFC-A W7</b><br>Internal Asynchronous Word 7 value configuration (default connected to Drv DGFC-A W0src) | N/A | RWS | 0.00 | - | - | PV | V-F-S-B |
| 4148 | <b>Int DrvDGFC-A W8</b><br>Internal Asynchronous Word 8 value configuration (default connected to Drv DGFC-A W0src) | N/A | RWS | 0.00 | - | - | PV | V-F-S-B |
| 4149 | <b>Int DrvDGFC-A W9</b><br>Internal Asynchronous Word 9 value configuration (default connected to Drv DGFC-A W0src) | N/A | RWS | 0.00 | - | - | PV | V-F-S-B |

| IPA   | Description   | [Unit] | Access | Default | Min | Max | Format | Reg. Mode |
|---|---|--------|--------|---------|-----|-----|--------|-----------|
| <b>APPL CARD CONFIG / DGFC / Drv-&gt;DGFC A W mon</b> |   |        |        |         |     |     |        |           |
| 4150  | <b>Drv DGFC-A W0mon</b><br>Asynchronous Word 0 monitor (from Drive to DGFC) | N/A    | R      | 0.00    | -   | -   | PP     | V-F-S-B   |
| 4151  | <b>Drv DGFC-A W1mon</b><br>Asynchronous Word 1 monitor (from Drive to DGFC) | N/A    | R      | 0.00    | -   | -   | PP     | V-F-S-B   |
| 4152  | <b>Drv DGFC-A W2mon</b><br>Asynchronous Word 2 monitor (from Drive to DGFC) | N/A    | R      | 0.00    | -   | -   | PP     | V-F-S-B   |
| 4153  | <b>Drv DGFC-A W3mon</b><br>Asynchronous Word 3 monitor (from Drive to DGFC) | N/A    | R      | 0.00    | -   | -   | PP     | V-F-S-B   |
| 4154  | <b>Drv DGFC-A W4mon</b><br>Asynchronous Word 4 monitor (from Drive to DGFC) | N/A    | R      | 0.00    | -   | -   | PP     | V-F-S-B   |
| 4155  | <b>Drv DGFC-A W5mon</b><br>Asynchronous Word 5 monitor (from Drive to DGFC) | N/A    | R      | 0.00    | -   | -   | PP     | V-F-S-B   |
| 4156  | <b>Drv DGFC-A W6mon</b><br>Asynchronous Word 6 monitor (from Drive to DGFC) | N/A    | R      | 0.00    | -   | -   | PP     | V-F-S-B   |
| 4157  | <b>Drv DGFC-A W7mon</b><br>Asynchronous Word 7 monitor (from Drive to DGFC) | N/A    | R      | 0.00    | -   | -   | PP     | V-F-S-B   |
| 4158  | <b>Drv DGFC-A W8mon</b><br>Asynchronous Word 8 monitor (from Drive to DGFC) | N/A    | R      | 0.00    | -   | -   | PP     | V-F-S-B   |
| 4159  | <b>Drv DGFC-A W9mon</b><br>Asynchronous Word 9 monitor (from Drive to DGFC) | N/A    | R      | 0.00    | -   | -   | PP     | V-F-S-B   |
| <b>APPL CARD CONFIG / DGFC / DGFC-&gt;Drv W mon</b>   |   |        |        |         |     |     |        |           |
| 4160  | <b>DGFC-A Drv W0mon</b><br>Asynchronous Word 0 monitor (from DGFC to Drive) | N/A    | R      | 0.00    | -   | -   | PV     | V-F-S-B   |
| 4161  | <b>DGFC-A Drv W1mon</b><br>Asynchronous Word 1 monitor (from DGFC to Drive) | N/A    | R      | 0.00    | -   | -   | PV     | V-F-S-B   |
| 4162  | <b>DGFC-A Drv W2mon</b><br>Asynchronous Word 2 monitor (from DGFC to Drive) | N/A    | R      | 0.00    | -   | -   | PV     | V-F-S-B   |
| 4163  | <b>DGFC-A Drv W3mon</b><br>Asynchronous Word 3 monitor (from DGFC to Drive) | N/A    | R      | 0.00    | -   | -   | PV     | V-F-S-B   |
| 4164  | <b>DGFC-A Drv W4mon</b><br>Asynchronous Word 4 monitor (from DGFC to Drive) | N/A    | R      | 0.00    | -   | -   | PV     | V-F-S-B   |
| 4165  | <b>DGFC-A Drv W5mon</b><br>Asynchronous Word 5 monitor (from DGFC to Drive) | N/A    | R      | 0.00    | -   | -   | PV     | V-F-S-B   |
| 4166  | <b>DGFC-A Drv W6mon</b><br>Asynchronous Word 6 monitor (from DGFC to Drive) | N/A    | R      | 0.00    | -   | -   | PV     | V-F-S-B   |
| 4167  | <b>DGFC-A Drv W7mon</b><br>Asynchronous Word 7 monitor (from DGFC to Drive) | N/A    | R      | 0.00    | -   | -   | PV     | V-F-S-B   |
| 4168  | <b>DGFC-A Drv W8mon</b><br>Asynchronous Word 8 monitor (from DGFC to Drive) | N/A    | R      | 0.00    | -   | -   | PV     | V-F-S-B   |
| 4169  | <b>DGFC-A Drv W9mon</b><br>Asynchronous Word 9 monitor (from DGFC to Drive) | N/A    | R      | 0.00    | -   | -   | PV     | V-F-S-B   |

| IPA | Description | [Unit] | Access | Default | Min | Max | Format | Reg. Mode |
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|

## SAVE PARAMETERS

AVyL drive allows two different commands to save the parameters modified in the regulation mode selected:

- by STARTUP menu, "Save Config?" command
- by all other menus, "SAVE PARAMETERS" command

Any changes made in STARTUP menu require "Save Config?" command, which saves all entire regulation mode selected.

It is recommended every time the user made any changes into STARTUP menu.

"SAVE PARAMETERS" command saves all the changes made out of STARTUP menu only.

When on the keypad display appears blinking message "Use Save Config", use "Save Config?" command

| IPA | Description | [Unit] | Access | Default | Min | Max | Format | Reg. Mode |
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|
|-----|-------------|--------|--------|---------|-----|-----|--------|-----------|

## CUSTOM FUNCTIONS

The access to CUSTOM FUNCTIONS menu is allowed by Level 1 password: 12345. It must be set in the SERVICE menu.

**COMPARE:** The Block supplies two signal Comparators, Compare 1 and Compare 2, with the same features. Each Comparator is in a position to compare two or three input signals (INP0, INP1, INP2).

Some comparisons allow to set via Cmp x window a window, in count, stating an acceptable range among the signals. Example:

-INP0 and INP1 have to be compared as "INP0 = INP1"

INP0 = +1000count

INP1 = +1000count

Window = 100count

In this case the equality is true for a maximum overall variation of INP1 between 1100 and 900 counts.

Possible variations:

None none

I0 = = I1

INP0-window ≤ INP1 ≤ INP0+window

I0 != I1

INP1 lower INP0-window or INP1 higher INP0+window

I0 < I1

INP0 lower INP1

I0 > I1

INP0 higher INP1

I0 < I1 > I2

INP0 < INP1 < INP2 (INP1 included between..)

|I0| == |I1|

INP0| -window ≤ |INP1| ≤ |INP0| +window

|I0| != |I1|

INP1| lower |INP0| -window, or |INP1| higher |INP0| +window

|I0| < |I1|

INP0| lower |INP1|

|I0| > |I1|

INP0| higher |INP1|

|I0| < |I1| < |I2|

INP0| < |INP1| < |INP2| (|INP1|

I0 AND I1 AND I2

AND logic between I0, I1 and I2

I0 OR I1 OR I2

OR logic between I0, I1 and I2

I0 XOR I1

XOR logic between I0 and I1

### CUSTOM FUNCTIONS / Compare / Compare 1

#### CUSTOM FUNCTIONS / Compare / Compare 1 / Compare 1 src

|      |                 |     |     |          |        |     |         |
|------|-----------------|-----|-----|----------|--------|-----|---------|
| 6049 | Cmp 1 inp 0 src | N/A | RWS | IPA 6041 | List 5 | PIN | V-F-S-B |
|------|-----------------|-----|-----|----------|--------|-----|---------|

IPA 6041 Cmp 1 inp 0 = Default

It allows to select the origin of the input signal 0 to be compared of the Compare 1 block (refer to signals List 5 of Pick List manual)

|      |                 |     |     |          |        |     |         |
|------|-----------------|-----|-----|----------|--------|-----|---------|
| 6050 | Cmp 1 inp 1 src | N/A | RWS | IPA 6042 | List 5 | PIN | V-F-S-B |
|------|-----------------|-----|-----|----------|--------|-----|---------|

IPA 6042 Cmp 1 inp 1 = Default

It allows to select the origin of the input signal 1 to be compared of the Compare 1 block (refer to signals List 5 of Pick List manual)

|      |                 |     |     |          |        |     |         |
|------|-----------------|-----|-----|----------|--------|-----|---------|
| 6051 | Cmp 1 inp 2 src | N/A | RWS | IPA 6043 | List 5 | PIN | V-F-S-B |
|------|-----------------|-----|-----|----------|--------|-----|---------|

IPA 6043 Cmp 1 inp 2 = Default

It allows to select the origin of the input signal 2 to be compared of the Compare 1 block (refer to signals List 5 of Pick List manual)

#### CUSTOM FUNCTIONS / Compare / Compare 1 / Compare 1 cfg

|      |             |     |     |      |   |   |    |         |
|------|-------------|-----|-----|------|---|---|----|---------|
| 6041 | Cmp 1 inp 0 | N/A | RWS | 0.00 | - | - | PV | V-F-S-B |
|------|-------------|-----|-----|------|---|---|----|---------|

Value of the internal input signal 0, default connected to Cmp 1 inp 0 src

| IPA   | Description  | [Unit] | Access | Default  | Min  | Max    | Format | Reg. Mode |
|---|--|--------|--------|----------|------|--------|--------|-----------|
| <b>6042</b>   | <b>Cmp 1 inp 1</b><br>Value of the internal input signal 1, default connected to Cmp 1 inp 1 src   | N/A    | RWS    | 0.00     | -    | -      | PV     | V-F-S-B   |
| <b>6043</b>   | <b>Cmp 1 inp 2</b><br>Value of the internal input signal 2, default connected to Cmp 1 inp 2 src   | N/A    | RWS    | 0.00     | -    | -      | PV     | V-F-S-B   |
| <b>6044</b>   | <b>Cmp 1 function</b><br>0 None<br>1 $I0 == I1$<br>2 $I0 != I1$<br>3 $I0 < I1$<br>4 $I0 > I1$<br>5 $I0 < I1 < I2$<br>6 $ I0  ==  I1 $<br>7 $ I0  !=  I1 $<br>8 $ I0  <  I1 $<br>9 $ I0  >  I1 $<br>10 $ I0  <  I1  <  I2 $<br>11 $I0 \text{ AND } I1 \text{ AND } I2$<br>12 $I0 \text{ OR } I1 \text{ AND } I2$<br>13 $I0 \text{ XOR } I1$ | N/A    | RWS    | 0        | 0    | 10     | DP     | V-F-S-B   |
| <b>6045</b>   | <b>Cmp 1 window</b><br>It allows to set a window stating an acceptable range among the signals of the Compare 1 block  | [cnt]  | RWS    | 0.00     | 0.00 | -      | PP     | V-F-S-B   |
| <b>6046</b>   | <b>Cmp 1 delay</b><br>It allows to set a delay in seconds on the comparison transition in the Compare 1 block  | [sec]  | RWS    | 0.00     | 0.00 | 30     | PP     | V-F-S-B   |
| <b>6047</b>   | <b>Cmp 1 inversion</b><br>0 Not inverted<br>1 Inverted<br>It allows to invert the Compare 1 block output signal  | N/A    | RWS    | 0        | 0    | 1      | DP     | V-F-S-B   |
| <b>CUSTOM FUNCTIONS / Compare / Compare 1 / Compare 1 mon</b> |  |        |        |          |      |        |        |           |
| <b>6048</b>   | <b>Compare 1 output</b><br>It allows to monitor the state of Compare 1 block output signal<br>0 = FALSE<br>1 = TRUE  | N/A    | R      | 0        | 0    | 1      | DV     | V-F-S-B   |
| <b>CUSTOM FUNCTIONS / Compare / Compare 2</b>                 |  |        |        |          |      |        |        |           |
| <b>CUSTOM FUNCTIONS / Compare / Compare 2 / Compare 2 src</b> |  |        |        |          |      |        |        |           |
| <b>6064</b>   | <b>Cmp 2 inp 0 src</b><br>IPA 6056 Cmp 2 inp 0 = Default<br>It allows to select the origin of the input signal 0 to be compared of the Compare 2 block (refer to signals List 6 of Pick List manual)   | N/A    | RWS    | IPA 6056 |      | List 6 | PIN    | V-F-S-B   |
| <b>6065</b>   | <b>Cmp 2 inp 1 src</b><br>IPA 6057 Cmp 2 inp 1 = Default<br>It allows to select the origin of the input signal 1 to be compared of the Compare 2 block (refer to signals List 6 of Pick List manual)   | N/A    | RWS    | IPA 6057 |      | List 6 | PIN    | V-F-S-B   |
| <b>6066</b>   | <b>Cmp 2 inp 2 src</b><br>IPA 6058 Cmp 2 inp 2 = Default<br>It allows to select the origin of the input signal 2 to be compared of the Compare 2 block (refer to signals List 6 of Pick List manual)   | N/A    | RWS    | IPA 6058 |      | List 6 | PIN    | V-F-S-B   |



| IPA   | Description   | [Unit] | Access | Default | Min  | Max | Format | Reg. Mode |
|---|---|--------|--------|---------|------|-----|--------|-----------|
| <b>CUSTOM FUNCTIONS / Compare / Compare 2 / Compare 2 cfg</b>                   |   |        |        |         |      |     |        |           |
| 6056  | <b>Cmp 2 inp 0</b><br>Value of the internal input signal 0, default connected to Cmp 2 inp 0 src  | N/A    | RWS    | 0.00    | -    | -   | PV     | V-F-S-B   |
| 6057  | <b>Cmp 2 inp 1</b><br>Value of the internal input signal 1, default connected to Cmp 2 inp 1 src  | N/A    | RWS    | 0.00    | -    | -   | PV     | V-F-S-B   |
| 6058  | <b>Cmp 2 inp 2</b><br>Value of the internal input signal 2, default connected to Cmp 2 inp 2 src  | N/A    | RWS    | 0.00    | -    | -   | PV     | V-F-S-B   |
| 6059  | <b>Cmp 2 function</b><br>0 None<br>1 IO == I1<br>2 IO != I1<br>3 IO < I1<br>4 IO > I1<br>5 IO < I1 < I2<br>6  IO  ==  I1 <br>7  IO  !=  I1 <br>8  IO  <  I1 <br>9  IO  >  I1 <br>10  IO  <  I1  <  I2 <br>11 IO AND I1 AND I2<br>12 IO OR I1 AND I2<br>13 IO XOR I1 | N/A    | RWS    | 0       | 0    | 10  | DP     | V-F-S-B   |
| 6060  | <b>Cmp 2 window</b><br>It allows to set a window stating an acceptable range among the signals of the Compare 2 block   | [cnt]  | RWS    | 0.00    | 0.00 | -   | PP     | V-F-S-B   |
| 6061  | <b>Cmp 2 delay</b><br>It allows to set a delay in seconds on the comparison transition in the Compare 2 block   | [sec]  | RWS    | 0.00    | 0.00 | 30  | PP     | V-F-S-B   |
| 6062  | <b>Cmp 2 inversion</b><br>0 Not inverted<br>1 Inverted<br>It allows to invert the Compare 2 block output signal   | N/A    | RWS    | 0       | 0    | 1   | DP     | V-F-S-B   |
| <b>CUSTOM FUNCTIONS / Compare / Compare 2 / Compare 2 mon</b>                   |   |        |        |         |      |     |        |           |
| 6063  | <b>Compare 2 output</b><br>It allows to monitor the state of Compare 2 block output signal<br>0 = FALSE<br>1 = TRUE   | N/A    | R      | 0       | 0    | 1   | DV     | V-F-S-B   |
| <b>CUSTOM FUNCTIONS / Pad parameters</b>  |   |        |        |         |      |     |        |           |
| The use variables, "Pads", are used for the data exchange with the option cards |   |        |        |         |      |     |        |           |
| <b>CUSTOM FUNCTIONS / Pad parameters / Pad param word</b>                       |   |        |        |         |      |     |        |           |
| 9100  | <b>Pad 0</b><br>Analog Pad 0  | N/A    | RWS    | 0       | -    | -   | PV     | V-F-S-B   |
| 9101  | <b>Pad 1</b><br>Analog Pad 1  | N/A    | RWS    | 0       | -    | -   | PV     | V-F-S-B   |
| 9102  | <b>Pad 2</b><br>Analog Pad 2  | N/A    | RWS    | 0       | -    | -   | PV     | V-F-S-B   |
| 9103  | <b>Pad 3</b><br>Analog Pad 3  | N/A    | RWS    | 0       | -    | -   | PV     | V-F-S-B   |

| IPA  | Description                    | [Unit] | Access | Default | Min | Max | Format | Reg. Mode |
|------|--------------------------------|--------|--------|---------|-----|-----|--------|-----------|
| 9104 | <b>Pad 4</b><br>Analog Pad 4   | N/A    | RWS    | 0       | -   | -   | PV     | V-F-S-B   |
| 9105 | <b>Pad 5</b><br>Analog Pad 5   | N/A    | RWS    | 0       | -   | -   | PV     | V-F-S-B   |
| 9106 | <b>Pad 6</b><br>Analog Pad 6   | N/A    | RWS    | 0       | -   | -   | PV     | V-F-S-B   |
| 9107 | <b>Pad 7</b><br>Analog Pad 7   | N/A    | RWS    | 0       | -   | -   | PV     | V-F-S-B   |
| 9108 | <b>Pad 8</b><br>Analog Pad 8   | N/A    | RWS    | 0       | -   | -   | PV     | V-F-S-B   |
| 9109 | <b>Pad 9</b><br>Analog Pad 9   | N/A    | RWS    | 0       | -   | -   | PV     | V-F-S-B   |
| 9110 | <b>Pad 10</b><br>Analog Pad 10 | N/A    | RWS    | 0       | -   | -   | PV     | V-F-S-B   |
| 9111 | <b>Pad 11</b><br>Analog Pad 11 | N/A    | RWS    | 0       | -   | -   | PV     | V-F-S-B   |
| 9112 | <b>Pad 12</b><br>Analog Pad 12 | N/A    | RWS    | 0       | -   | -   | PV     | V-F-S-B   |
| 9113 | <b>Pad 13</b><br>Analog Pad 13 | N/A    | RWS    | 0       | -   | -   | PV     | V-F-S-B   |
| 9114 | <b>Pad 14</b><br>Analog Pad 14 | N/A    | RWS    | 0       | -   | -   | PV     | V-F-S-B   |
| 9115 | <b>Pad 15</b><br>Analog Pad 15 | N/A    | RWS    | 0       | -   | -   | PV     | V-F-S-B   |

#### CUSTOM FUNCTIONS / Pad parameters / Pad param bit

|      |                                   |     |     |   |   |   |    |         |
|------|-----------------------------------|-----|-----|---|---|---|----|---------|
| 9116 | <b>Dig pad 0</b><br>Digital Pad 1 | N/A | RWS | 0 | 0 | 1 | DV | V-F-S-B |
| 9117 | <b>Dig pad 1</b><br>Digital Pad 2 | N/A | RWS | 0 | 0 | 1 | DV | V-F-S-B |
| 9118 | <b>Dig pad 2</b><br>Digital Pad 3 | N/A | RWS | 0 | 0 | 1 | DV | V-F-S-B |
| 9119 | <b>Dig pad 3</b><br>Digital Pad 3 | N/A | RWS | 0 | 0 | 1 | DV | V-F-S-B |
| 9120 | <b>Dig pad 4</b><br>Digital Pad 4 | N/A | RWS | 0 | 0 | 1 | DV | V-F-S-B |
| 9121 | <b>Dig pad 5</b><br>Digital Pad 5 | N/A | RWS | 0 | 0 | 1 | DV | V-F-S-B |
| 9122 | <b>Dig pad 6</b><br>Digital Pad 6 | N/A | RWS | 0 | 0 | 1 | DV | V-F-S-B |
| 9123 | <b>Dig pad 7</b><br>Digital Pad 7 | N/A | RWS | 0 | 0 | 1 | DV | V-F-S-B |
| 9124 | <b>Dig pad 8</b><br>Digital Pad 8 | N/A | RWS | 0 | 0 | 1 | DV | V-F-S-B |
| 9125 | <b>Dig pad 9</b><br>Digital Pad 9 | N/A | RWS | 0 | 0 | 1 | DV | V-F-S-B |

| IPA  | Description                         | [Unit] | Access | Default | Min | Max | Format | Reg. Mode |
|------|-------------------------------------|--------|--------|---------|-----|-----|--------|-----------|
| 9126 | <b>Dig pad 10</b><br>Digital Pad 10 | N/A    | RWS    | 0       | 0   | 1   | DV     | V-F-S-B   |
| 9127 | <b>Dig pad 11</b><br>Digital Pad 11 | N/A    | RWS    | 0       | 0   | 1   | DV     | V-F-S-B   |
| 9128 | <b>Dig pad 12</b><br>Digital Pad 12 | N/A    | RWS    | 0       | 0   | 1   | DV     | V-F-S-B   |
| 9129 | <b>Dig pad 13</b><br>Digital Pad 13 | N/A    | RWS    | 0       | 0   | 1   | DV     | V-F-S-B   |
| 9130 | <b>Dig pad 14</b><br>Digital Pad 14 | N/A    | RWS    | 0       | 0   | 1   | DV     | V-F-S-B   |
| 9131 | <b>Dig pad 15</b><br>Digital Pad 15 | N/A    | RWS    | 0       | 0   | 1   | DV     | V-F-S-B   |

### CUSTOM FUNCTIONS / Connect

This block function connects signals to programmable block area, using drive parameters that are accessible through the “Conf99” PC program or drive keypad menu.

Connect A, connects up to 7 analog input signals

Connect B, connects up to 7 digital signals inputs

### CUSTOM FUNCTIONS / Connect/ Connect A

|      |  |     |     |          |        |     |         |
|------|--|-----|-----|----------|--------|-----|---------|
| 6070 | <b>ConnectA inp 0 src</b><br>IPA 4000 NULL = Default | N/A | RWS | IPA 4000 | List 2 | PIN | V-F-S-B |
| 6071 | <b>ConnectA inp 1 src</b><br>IPA 4000 NULL = Default | N/A | RWS | IPA 4000 | List 2 | PIN | V-F-S-B |
| 6072 | <b>ConnectA inp 2 src</b><br>IPA 4000 NULL = Default | N/A | RWS | IPA 4000 | List 2 | PIN | V-F-S-B |
| 6073 | <b>ConnectA inp 3 src</b><br>IPA 4000 NULL = Default | N/A | RWS | IPA 4000 | List 2 | PIN | V-F-S-B |
| 6074 | <b>ConnectA inp 4 src</b><br>IPA 4000 NULL = Default | N/A | RWS | IPA 4000 | List 2 | PIN | V-F-S-B |
| 6075 | <b>ConnectA inp 5 src</b><br>IPA 4000 NULL = Default | N/A | RWS | IPA 4000 | List 2 | PIN | V-F-S-B |
| 6076 | <b>ConnectA inp 6 src</b><br>IPA 4000 NULL = Default | N/A | RWS | IPA 4000 | List 2 | PIN | V-F-S-B |
| 6077 | <b>ConnectA inp 7 src</b><br>IPA 4000 NULL = Default | N/A | RWS | IPA 4000 | List 2 | PIN | V-F-S-B |

### CUSTOM FUNCTIONS / Connect/ Connect B

|      |  |     |     |          |        |     |         |
|------|--|-----|-----|----------|--------|-----|---------|
| 6078 | <b>ConnectB inp 0 src</b><br>IPA 4000 NULL = Default | N/A | RWS | IPA 4000 | List 1 | PIN | V-F-S-B |
| 6079 | <b>ConnectB inp 1 src</b><br>IPA 4000 NULL = Default | N/A | RWS | IPA 4000 | List 1 | PIN | V-F-S-B |
| 6080 | <b>ConnectB inp 2 src</b><br>IPA 4000 NULL = Default | N/A | RWS | IPA 4000 | List 1 | PIN | V-F-S-B |
| 6081 | <b>ConnectB inp 3 src</b><br>IPA 4000 NULL = Default | N/A | RWS | IPA 4000 | List 1 | PIN | V-F-S-B |

| IPA  | Description  | [Unit] | Access | Default  | Min | Max    | Format | Reg. Mode |
|------|--|--------|--------|----------|-----|--------|--------|-----------|
| 6082 | <b>ConnectB inp 4 src</b><br>IPA 4000 NULL = Default | N/A    | RWS    | IPA 4000 |     | List 1 | PIN    | V-F-S-B   |
| 6083 | <b>ConnectB inp 5 src</b><br>IPA 4000 NULL = Default | N/A    | RWS    | IPA 4000 |     | List 1 | PIN    | V-F-S-B   |
| 6084 | <b>ConnectB inp 6 src</b><br>IPA 4000 NULL = Default | N/A    | RWS    | IPA 4000 |     | List 1 | PIN    | V-F-S-B   |
| 6085 | <b>ConnectB inp 7 src</b><br>IPA 4000 NULL = Default | N/A    | RWS    | IPA 4000 |     | List 1 | PIN    | V-F-S-B   |

## SAVE PARAMETERS

AVyL drive allows two different commands to save the parameters modified in the regulation mode selected:

- by STARTUP menu, “Save Config?” command
- by all other menus, “SAVE PARAMETERS” command

Any changes made in STARTUP menu require “Save Config?” command, which saves all entire regulation mode selected. It is recommended every time the user made any changes into STARTUP menu.

“SAVE PARAMETERS” command saves all the changes made out of STARTUP menu only.

When on the keypad display appears blinking message “Use Save Config”, use “Save Config?” command

## **SERVICE**

SERVICE menu allows the setting of the password to enable Level 1 drive menus: 12345.

To have the access of Level 1 drive menus, edit 12345 password into "Insert Password" parameter and confirm it using "Enter" button.

NOTE! Level 1 password must be edit every recycle drive supply

SERVICE menu allows also the setting of the password to enable Level 2 drive menu: ask Level 2 password to the technical support.

To have the access of Level 2 drive menus:

1\_ edit 12345 password into "Insert Password" parameter and confirm it using "Enter" button

2\_ check the password through "Check password" parameter using "Enter" button

---

# Chapter 10 - Troubleshooting

When the red “Alarm” LED blinks, it is indicating one (or more) alarm conditions.


Figure 10.1: Led Status and Keypad



**Alarm led is lighted**

In case an alarm occurs, this led is lighted up with an intermittent red colour.

See following steps to view alarm and reset it:



1) Press **Shift + Alarm** . The “Alarm list” will be displayed.

2) Press **Enter** one or more times until “Sequencer” message appears, to acknowledge the alarms.

**NOTE!**

If the alarm is still active, red LED will blink again. If it not active, red LED will stop.

3) Press **[0]** key to reset the Sequencer. The Alarm List shows all the occurred alarms, both if they are due to protections and to errors when limit values are exceeded. In order to disappear from the alarm list, alarm have to be acknowledged. The acknowledgement is possible only if the alarm is no longer active. The alarms are automatically acknowledged after two minutes.

**NOTE!**

Pressing **Enter** will acknowledge the alarm. Acknowledging the alarm


will only remove it from the active alarm list. If the alarm condition also resulted in a drive trip, the sequence will also need to be reset. This can be done by pressing the [O] key. The drive cannot be re-enabled or started after a trip condition unless the drive sequencer is reset. The drive State Machine, controls the drive running and starting, accounting for protection & alarming, command sequence, and reset status.

The table below displays various operation states by Sequencer status number:

| Sequencer status | State   |
|------------------|---|
| 1                | Magnetization running                                   |
| 2                | Magnetization completed, Stop                           |
| 3                | Start   |
| 4                | Fast stop, Stop   |
| 5                | Fast stop, Start  |
| 9                | No alarm, drive is ready to accept all commands         |
| 10               | Magnetization running and Start command already present |
| 12               | Alarm active  |
| 16               | Alarm not active, waiting for reset                     |

TAV3i020

To read the sequencer status of the State Machine, go to menu:



### 10.1 List of Regulation Alarm Events

Table 10.1.1 provides a description of regulation alarm events and information on how to configure the intended drive behaviour on their occurrence (where applicable).

Table 10.1.1 Regulation Alarm Events

| Alarm name<br>Description  | Drive activity<br>after alarm | Hold off            | Restart   | Restart time | Code in<br>theAlarm list | Bit position in<br>Alarm list |
|--|-------------------------------|---------------------|---|--------------|--------------------------|-------------------------------|
| <b>Failure supply</b><br>One or more of the power supply circuits in the control section failed                                  | Disable drive                 | No                  | No  | NA           | 21                       | 1                             |
| <b>Undervoltage</b><br>Voltage on the drive DC link is lower than the minimum threshold for the given Mains voltage setting.     | Disable drive                 | No                  | Yes<br>Logic is based on the number of attempts | Yes          | 22                       | 2                             |
| <b>Overvoltage</b><br>Voltage on the drive DC link is higher than the maximum threshold for the given Mains voltage setting      | Disable drive                 | No                  | Yes   | Yes          | 23                       | 3                             |
| <b>IGBT desat flt</b><br>IGBT instantaneous overcurrent was detected by gate desaturation sensing circuit                        | Disable drive                 | No                  | Yes<br>No more than 2 attempts in 30 seconds    | Yes          | 24                       | 4                             |
| <b>Inst Overcurrent</b><br>IGBT instantaneous overcurrent was detected by output current sensor                                  | Disable drive                 | No                  | Yes<br>No more than 2 attempts /30sec.          | Yes          | 25                       | 5                             |
| <b>Ground fault</b><br>Output phase discharge to ground  | Programmable                  | No                  | No  | Yes          | 26                       | 6                             |
| <b>Curr fbk loss</b><br>A failure of current sensor feedback or power supply was detected  | Disable drive                 | No                  | No  | No           | 27                       | 7                             |
| <b>External fault</b><br>External fault input is active  | Programmable                  | Programmable        | Yes   | Programm.    | 28                       | 8                             |
| <b>Spd fbk loss</b><br>A failure of the speed feedback sensor or power supply was detected                                       | Programmable                  | No                  | No  | No           | 29                       | 9                             |
| <b>Module OT</b><br>IGBT overtemperature was detected by internal sensor (models 0.75 to 20 Hp only)                             | Disable drive                 | Constant, 10 msec   | No  | No           | 30                       | 10                            |
| <b>Heatsink OT</b><br>Heatsink overtemperature was detected by thermal contact (only for models 18.5 kW and over)                | Disable drive                 | Constant, 1000 msec | No  | No           | 31                       | 11                            |
| <b>Motor OT</b><br>Motor overtemperature was detected by thermal contact or PTC thermistor                                       | Programmable                  | Programmable        | Yes   | Programm.    | 32                       | 12                            |
| <b>Heatsink S OT</b><br>Heatsink linear temperature sensor threshold was exceeded  | Programmable                  | Programmable        | Yes   | Programm.    | 33                       | 13                            |
| <b>Regulat S OT</b><br>Regulation board linear temperature sensor threshold was exceeded   | Programmable                  | Programmable        | Yes   | Programm.    | 34                       | 14                            |
| <b>Intake Air S OT</b><br>Cooling air intake linear temperature sensor threshold was exceeded (only for models 18.5 kW and over) | Programmable                  | Programmable        | Yes   | Programm.    | 35                       | 15                            |
| <b>Cont fbk fail</b><br>It trips when the contact feedback signal is not detected  | Programmable                  | No                  | Yes   | No           | 36                       | 16                            |
| <b>Comm card fault</b><br>Fault of optional LAN communication board  | Programmable                  | No                  | Yes   | Programm.    | 37                       | 17                            |
| <b>Appl card fault</b><br>Fault of optional application coprocessor board  | Disable drive                 | No                  | No  | No           | 38                       | 18                            |
| <b>Drv overload</b><br>Drive overload accumulator exceeded trip threshold  | Programmable                  | No                  | No  | No           | 39                       | 19                            |



| Alarm name<br>Description  | Drive activity<br>after alarm | Hold off | Restart | Restart time | Code in<br>the Alarm list | Bit position in<br>Alarm list |
|--|-------------------------------|----------|---------|--------------|---------------------------|-------------------------------|
| <b>Mot overload</b><br>Motor overload accumulator exceeded trip threshold  | Programmable                  | No       | No      | No           | 40                        | 20                            |
| <b>BU overload</b><br>Braking resistor overload accumulator exceeded trip threshold  | Programmable                  | No       | No      | No           | 41                        | 21                            |
| <b>Data lost</b><br>Data corrupted in non-volatile memory  | Disable drive                 | No       | No      | No           | 42                        | 22                            |
| <b>Brake fbk fail</b><br>It trips when the brake feedback signal is not detected   | Programmable                  | No       | No      | No           | 43                        | 23                            |
| <b>Max time</b><br>Software task time overrun was detected   | Disable drive                 | No       | No      | No           | 44                        | 24                            |
| <b>Sequencer</b><br>Alarm event caused drive disable   | Disable drive                 | No       | No      | No           | 45                        | 25                            |
| <b>Door fbk fail</b><br>It trips when the door feedback signal is not detected   | Disable drive                 | Yes      | No      | No           | 46                        | 26                            |
| <b>Overspeed</b><br>Maximum speed threshold was exceeded while drive in RUN state  | No                            | Yes      | No      | No           | 47                        | 27                            |
| <b>UV repetitive</b><br>If n. of faults is set to max the Alarm is disabled.<br>More than a programmable number of UV fault were detected in 5 minutes | Disable drive                 | No       | No      | No           | 48                        | 28                            |
| <b>IOC repetitive</b><br>More than 2 OC faults were detected in 30 sec.  | Disable drive                 | No       | No      | No           | 49                        | 29                            |
| <b>IGBTdesat repet</b><br>More than 2 IGBT desat faults were detected in 30 sec.   | Disable drive                 | No       | No      | No           | 50                        | 30                            |
| <b>WatchDog user</b><br>The drive failed to retrigger the communication watchdog within the specified time   | Disable drive                 | No       | No      | No           | 51                        | 31                            |
| <b>Hw fail</b><br>Communication failure between Drive Regulation board and one of its options or I/O expansions.                                       | Disable drive                 | No       | No      | No           | 52                        | 32                            |

## 10.2 List of Configuration and DataBase Error Alarm Events

Entering bad data or conflicting data into the drive configuration will cause user errors to be displayed.

These type of errors can be:

- Configuration errors
- Database errors (DB errors)

Refer to the following paragraphs for descriptions.

### Drive size setting

#### **NOTE!**

If the User changes the Drive size, the drive will display: Drv size: new size - old size. For example: ***Drive size: 0 - 1***

### 10.2.1 Configuration Errors

Configuration errors can occur by entering incompatible or invalid parameter data.

The drive reports configuration error by the following example description:

***Calc error: Calc error number***

***Param: Param error number***

The Calc error number denotes the cause of invalid calculation. The Calc error number is composed as follows:

Calc error number = Offset + Error code

The Offset denotes the type of error:

- 0 for specific errors
- 100 for errors originated by the database calculation (see DB error paragraph)
- 500 for errors due to floating point calculation (exception, divide by zero etc..)
- 600 for errors originated by the configuration calculations (range and so on).

The Error code denotes the origin cause of the error, see values list below.

### Error code values lists

Error code values for Offset 0:

- 0 no error
- 1 signal not managed in current configurator state
- 2 cannot stop regulation
- 3 recipe export error
- 4 recipe import error
- 5 error while loading selftune data
- 6 error while loading motor data
- 7 reserved

- 8 error while loading customer specific data
- 9 error while loading drive size data
- 10 error while writing file size.ini
- 11 error while apply database. The operation is refused because errors arised during group calculation.To reset the errors it is necessary re-enter the data, and confirm correctness
- 12 error while saving too changes

Error code values for Offset 100: See DB errors, section 10.2.3

Error code values for Offset 500 (500 + error code):

- 3 Integer overflow
- 4 Floating overflow
- 5 Floating underflow
- 7 Divide by zero
- 9 Undefined float
- 10 Conversion error
- 11 Floating point stack underflow
- 12 Floating point stack overflow

Error code values for Offset 600 (600 + error code):

- 0 no error
- 1 switching freq. error
- 2 mains voltage error
- 3 ambient temperature error
- 4 regulation mode error
- 5 take selection error
- 6 base speed error
- 7 drive size error

For example, Calc error number **606** is a configuration error (600) caused by speed base value (6) out of range.

The Param error number is not meaningful.

### 10.2.2 Database Errors (DB Errors)

DB errors are caused by a incorrect setting in a single parameter. This problem is originated in the database calculation. For example the most common are:

- DB error Limit HIGH
- DB error Limit LOW

The message DB error is displayed by the drive in this format:

*DB ERR IPA: error code*

#### Note !

See chapter 12  
Parameter index

The IPA denotes the parameter number which caused the DB error calculation. The error code denotes the type error.

Example of message DB error displayed: **DB ERR 3420: 5**

This means that the DB error is caused by IPA **3420** (V/f voltage) which is below the low limit; Error code 5 denotes the type error (for the DB error code values list see below). To find the low limit, which depends on drive configuration, it is possible to go to the V/f voltage parameter

on the keypad. Press the Shift key and then the Help key, the following will be displayed:

Max Value  
Min Value  
Def(ault) Value  
Unit  
Raw value  
IPA  
Description  
(Access) mode

In most cases it is enough to set a new value which is within the limits.

#### DB error code list

|    |                             |
|----|-----------------------------|
| 0  | No error                    |
| 1  | SBI PROBLEM 0x01            |
| 2  | Generic error               |
| 3  | Attribute not exist         |
| 4  | Limit High                  |
| 5  | Limit Low                   |
| 11 | Division by zero            |
| 12 | Int Overflow                |
| 13 | Int Underflow               |
| 14 | Long Overflow               |
| 15 | Long Underflow              |
| 16 | Domain Error                |
| 17 | Indirection Error           |
| 18 | Reached wrong eof           |
| 19 | Dbase not configured        |
| 20 | Value not valid             |
| 21 | Process doesn't reply       |
| 22 | Wrong record size           |
| 23 | Attribute read only         |
| 24 | SBI PROBLEM 0x18            |
| 25 | Command not yet implemented |
| 26 | Command wrong               |
| 27 | Read file error             |
| 28 | Header wrong                |
| 29 | Reserved for internal use   |
| 30 | Parameter not exist         |
| 31 | Parameter read only         |
| 32 | Parameter "z" only          |
| 48 | SBI PROBLEM 0x30            |

### 10.2.3 List of Error Codes for All Autotune Procedures

The different autotune procedures for Current regulator, Flux regulator, Speed regulator or Analog input calibration may generate error messages that are described in section 10.2.2 .

*Table 10.2.3.1: Error Messages from Autotune Procedures*

| <b>Error text</b>     | <b>Description</b>   |
|-----------------------|--|
| No error              |  |
| Abort                 | The user entered Escape or O key, or removed enable permissive (term 12 low)                   |
| DB access <IPA>       | An attempt to access the database at the specified index occurred during autotune procedure    |
| No break point        | Failure in measuring inverter voltage distortion   |
| Rs high lim           | Failure in measuring motor stator Resistance   |
| Rs low lim            | Failure in measuring motor stator Resistance   |
| DTL high lim          | Failure in computing compensation for the inverter voltage distortion                          |
| DTL low lim           | Failure in computing compensation for the inverter voltage distortion                          |
| DTS high lim          | Failure in computing compensation for the inverter voltage distortion                          |
| DTS low lim           | Failure in computing compensation for the inverter voltage distortion                          |
| LsS high lim          | Failure in calculating motor leakage inductance  |
| LsS low lim           | Failure in calculating motor leakage inductance  |
| ImNom not found       | Identification of rated magnetizing current failed   |
| ImNom not found       | Identification of maximum magnetizing current failed   |
| RrV low lim           | Voltage limit exceeded during measurement for the calculation of motor rotor resistance        |
| RrV high lim          | Voltage limit exceeded during measurement for the calculation of motor rotor resistance        |
| Rr high lim           | Failure in calculating motor rotor resistance  |
| Rr low lim            | Failure in calculating motor rotor resistance  |
| AI too high           | Value of analog input is too high for full scale autocalibration                               |
| AI too low            | Value of analog input is too low for full scale autocalibration                                |
| Rr2 high lim          | Failure in calculating motor rotor resistance  |
| Rr2 low lim           | Failure in calculating motor rotor resistance  |
| Drive disabled        | Enable permissive (term 12) was found low when attempting to start autotune procedure          |
| Rr timeout            | Timeout occurred during measurement for the calculation of motor rotor resistance              |
| Rr2 timeout           | Timeout occurred during measurement for the calculation of motor rotor resistance              |
| LsS timeout           | Timeout occurred during measurement for the calculation of motor leakage inductance            |
| Drive enabled         | Drive was found to be already enabled when attempting to initiate autotune procedure           |
| Calc error            | An error occurred when processing measurement data   |
| Config error<errcode> | The specified Configurator error occurred during database configuration based on autotune data |
| Cmd not supported     | Command not supported in the current state   |

# Chapter 11 - EMC Directive - Declaration of Conformity

## EMC Directive

**The possible Validity Fields of the EMC Directive (89/336) applied to PDS “CE marking”** summarises the presumption of compliance with the Essential Requirements of the EMC Directive, which is formulated in the EC Declaration of Conformity Clauses numbers [.]

refer to European Commission document “Guide to the Application of Directive 89/336/EEC” 1997 edition. ISBN 92-828-0762-2

|   | Validity Field  | Description  |
|---|---|--|
| Relates to PDS or CDM or BDM directly       | <p><b>-1- Finished Product/ Complex component available to general public</b><br/>[Clauses: 3.7, 6.2.1, 6.2.3.1 &amp; 6.3.1]</p> <p>A PDS (or CDM/BDM) of the Unrestricted Distribution class</p>   | <p>Placed on the market as a single commercial unit for distribution and final use. Free movement based on compliance with the EMC Directive</p> <p><b>- EC Declaration of conformity required - CE marking required</b><br/><b>- PDS or CDM/BDM should comply with IEC 1800-3/EN 61800-3</b></p> <p>The manufacturer of the PDS (or CDM/BDM) is responsible for the EMC behaviour of the PDS (or CDM/BDM), under specified conditions. EMC measures outside the item are described in an easy to understand fashion and could actually be implemented by a layman in the field of EMC.</p> <p>The EMC responsibility of the assembler of the final product is to follow the manufacturer’s recommendations and guidelines.</p> <p>Note: The manufacturer of the PDS (or CDM/BDM) is not responsible for the resulting behaviour of any system or installation which includes the PDS, see Validity Fields 3 or 4.</p> |
|   | <p><b>-2- Finished Product/Complex component only for professional assemblers</b><br/>[Clauses: 3.7, 6.2.1, 6.2.3.2 &amp; 6.3.2]</p> <p>A PDS (or CDM/BDM) of the Restricted Distribution class sold to be included as part of a system or installation</p> | <p>Not placed on the market as a single commercial unit for distribution and final use. Intended only for professional assemblers who have a level of technical competence to correctly install.</p> <p><b>- No EC Declaration of conformity - No CE marking</b><br/><b>- PDS or CDM/BDM should comply with IEC 1800-3/EN 61800-3</b></p> <p>The manufacturer of the PDS (or CDM/BDM) is responsible for the provision of installation guidelines that will assist the manufacturer of the apparatus, system or installation to achieve compliance.</p> <p>The resulting EMC behaviour is the responsibility of the manufacturer of the apparatus, system, or installation, for which its own standards may apply.</p>   |
| Relates to application of PDS or CDM or BDM | <p><b>-3- Installation</b><br/>[Clause: 6.5]</p> <p>Several combined items of system, finished product or other components brought together at a given place. May include PDSs (CDM or BDM), possibly of different classes -Restricted or Unrestricted</p>  | <p>Not intended to be placed on the market as a single functional unit (no free movement). Each system included is subject to the provisions of the EMC Directive.</p> <p><b>- No EC Declaration of conformity - No CE marking</b><br/><b>- For the PDSs or CDM/BDMs themselves see Validity Fields 1 or 2</b><br/><b>- Responsibility of the manufacturer of the PDS may include commissioning</b></p> <p>The resulting EMC behaviour is the responsibility of the manufacturer of the installation in co-operation with the user (e.g. by following an appropriate EMC plan). Essential protection requirements of EMC Directive apply regarding the neighbourhood of the installation.</p>  |
|   | <p><b>-4- System</b><br/>[Clause: 6.4]</p> <p>Ready to use finished item(s). May include PDSs (CDM or BDM), possibly of different classes - Restricted or Unrestricted</p>  | <p>Has a direct function for the final user. Placed on the market for distribution as a single functional unit, or as units intended to be easily connected together.</p> <p><b>- EC Declaration of conformity required - CE marking required for the system</b><br/><b>- For the PDSs or CDM/BDMs themselves see Validity Fields 1 or 2</b></p> <p>The resulting EMC behaviour, under specified conditions is the responsibility of the manufacturer of the system by using a modular or system approach as appropriate.</p> <p>Note: The manufacturer of the system is not responsible for the resulting behaviour of any installation which includes the PDS, see Validity Field 3.</p>   |

### Examples of application in the different Validity Fields:

- BDM to be used anywhere:** (example in domestic premises, or BDM available from commercial distributors), sold without any knowledge of the purchaser or the application. The manufacturer is responsible that sufficient EMC can be achieved even by any unknown customer or layman (snap-in, switch-on).
- CDM/BDM or PDS for general purpose:** to be incorporated in a machine or for industrial application This is sold as a subassembly to a professional assembler who incorporates it in a machine, system or installation. Conditions of use are specified in the manufacturer’s documentation. Exchange of technical data allows optimization of the EMC solution.. (See restricted distribution definition).
- Installation:** It can consist of different commercial units (PDS, mechanics, process control etc.). The conditions of incorporation for the PDS (CDM or BDM) are specified at the time of the order, consequently an exchange of technical data between supplier and client is possible. The combination of the various items in the installation should be considered in order to ensure EMC. Harmonic compensation is an evident example of this, for both technical and economical reasons. (E.g. rolling mill, paper machine, crane, etc.)
- System:** Ready to use finished item which includes one or more PDSs (or CDMs/BDMs); e.g. household equipment, air conditioners, standard machine tools, standard pumping systems, etc.



SIEI SpA

## Declaration of EC-Conformity

Document No. ECC/SR/02005

The product(s)...

Type reference: **AVy2040÷5550-AC4**

Manufacturer: **SIEI SpA  
(Regolazione e Controllo)  
I - 21040 Gerenzano (VA)**

Description: **Adjustable speed vector controlled ac drive(s)**

... to which this declaration relates is in conformity with the following standard(s) or normative document(s)

Standard, Document: **- EN 60529  
- EN 50178  
- IEC 664, IEC 664-1**

and complies with the provisions of the following EC-Directive(s):

**- 73/23/EEC modified by 93/68/EEC and named Low Voltage Directive.**

CE marking from\*: 2002. (\* For Low Voltage Directive only)

Date of issue SIEI SpA

05-03-2002

General manager

Engineering manager

This declaration confirms compliance with the named directives but is not a guarantee of any performances. The safety related recommendations of the delivered product documentation have to be observed.

AVy-AC4-W01\_dec



SIEI SpA

## Declaration of EC-Conformity

Document No. ECC/SR/02006

The product(s)...

Type reference: **AVy2040-5550-BR4**

Manufacturer: **SIEI SpA  
(Regolazione e Controllo)  
I - 21040 Gerenzano (VA)**

Description: **Adjustable speed vector controlled ac drive(s)**

... to which this declaration relates is in conformity with the following standard(s) or normative document(s)

Standard, Document: **- EN 60529  
- EN 50178  
- IEC 664, IEC 664-1**

and complies with the provisions of the following EC-Directive(s):

**- 73/23/EEC modified by 93/68/EEC and named Low Voltage Directive.**

CE marking from\*: 2002. (\* For Low Voltage Directive only)

Date of issue SIEI SpA

05-03-2002

General manager

Engineering manager

This declaration confirms compliance with the named directives but is not a guarantee of any performances. The safety related recommendations of the delivered product documentation have to be observed.

AVy-BR4-W01\_dec



## Chapter 12 - Parameters Index

### IPAs

|            |            |            |            |                 |
|------------|------------|------------|------------|-----------------|
| 100 p.137  | 1250 p.155 | 2005 p.153 | 2137 p.180 | 3240 p.124      |
| 1002 p.129 | 1260 p.155 | 2007 p.153 | 2138 p.180 | 3400 p.152      |
| 1003 p.129 | 1300 p.132 | 2013 p.153 | 2380 p.145 | 3411 p.152      |
| 1004 p.129 | 1301 p.133 | 2015 p.153 | 2440 p.154 | 3412 p.152      |
| 1005 p.129 | 1350 p.126 | 2021 p.153 | 2441 p.154 | 3413 p.152      |
| 1006 p.129 | 1460 p.124 | 2022 p.153 | 2442 p.154 | 3420 p.135      |
| 1007 p.129 | 150 p.160  | 2031 p.153 | 2445 p.155 | 3430 p.135      |
| 1011 p.129 | 151 p.160  | 2033 p.153 | 2450 p.154 | 3520 p.152      |
| 1012 p.130 | 152 p.160  | 2039 p.154 | 2530 p.144 | 3530 p.152      |
| 1015 p.129 | 153 p.159  | 2041 p.154 | 2540 p.145 | 3531 p.152      |
| 104 p.191  | 154 p.159  | 2048 p.134 | 2550 p.145 | 3541 p.152      |
| 105 p.191  | 1540 p.123 | 2049 p.135 | 2560 p.145 | 3570 p.166      |
| 106 p.191  | 156 p.159  | 2054 p.147 | 2580 p.147 | 3575 p.166      |
| 107 p.125  | 157 p.159  | 2063 p.153 | 2590 p.147 | 3576 p.166      |
| 1085 p.157 | 1610 p.135 | 2065 p.153 | 2610 p.135 | 3580 p.166      |
| 1086 p.157 | 1611 p.135 | 2075 p.152 | 2625 p.147 | 3585 p.152      |
| 1090 p.156 | 1612 p.135 | 2077 p.152 | 2745 p.158 | 3700 p.144, 152 |
| 1091 p.156 | 162 p.122  | 2100 p.176 | 2750 p.158 | 3701 p.144, 152 |
| 1092 p.156 | 163 p.122  | 2101 p.176 | 2755 p.158 | 3702 p.144      |
| 1093 p.156 | 164 p.122  | 2102 p.176 | 2756 p.158 | 3703 p.144      |
| 1094 p.156 | 1650 p.135 | 2103 p.176 | 2760 p.158 | 3704 p.144      |
| 1095 p.157 | 1670 p.123 | 2104 p.176 | 2780 p.128 | 3705 p.144      |
| 1096 p.157 | 170 p.126  | 2105 p.176 | 2790 p.128 | 3706 p.146      |
| 1097 p.157 | 1700 p.136 | 2106 p.176 | 2800 p.128 | 3707 p.146      |
| 1098 p.157 | 1710 p.136 | 2107 p.177 | 2810 p.128 | 3708 p.146      |
| 1099 p.157 | 1720 p.136 | 2108 p.177 | 2820 p.128 | 3709 p.146      |
| 110 p.125  | 1730 p.136 | 2109 p.177 | 2830 p.128 | 3720 p.144      |
| 1101 p.157 | 1740 p.136 | 2110 p.177 | 2840 p.128 | 3722 p.144      |
| 1102 p.157 | 1781 p.123 | 2111 p.177 | 2850 p.128 | 3723 p.144      |
| 1103 p.157 | 1810 p.155 | 2112 p.177 | 2860 p.128 | 3724 p.145      |
| 1104 p.157 | 1815 p.155 | 2113 p.177 | 2870 p.128 | 3725 p.145      |
| 1105 p.157 | 1833 p.148 | 2114 p.177 | 2880 p.129 | 3726 p.145      |
| 1106 p.157 | 1834 p.148 | 2115 p.177 | 2890 p.129 | 3727 p.145      |
| 1107 p.157 | 1835 p.148 | 2116 p.177 | 2900 p.129 | 380 p.126       |
| 111 p.125  | 1836 p.148 | 2120 p.179 | 300 p.124  | 3900 p.165      |
| 1111 p.157 | 1837 p.148 | 2121 p.179 | 3060 p.122 | 3901 p.168      |
| 1112 p.157 | 1880 p.126 | 2122 p.179 | 3070 p.122 | 3902 p.172      |
| 1120 p.156 | 1885 p.129 | 2123 p.179 | 3080 p.122 | 3903 p.176      |
| 1121 p.155 | 1890 p.132 | 2124 p.179 | 3090 p.122 | 396 p.182       |
| 1130 p.156 | 1900 p.133 | 2125 p.179 | 3100 p.123 | 4002 p.159      |
| 114 p.124  | 1902 p.132 | 2126 p.180 | 3110 p.123 | 4004 p.159      |
| 1140 p.156 | 1925 p.131 | 2127 p.180 | 3120 p.123 | 4006 p.160      |
| 1141 p.156 | 1926 p.132 | 2128 p.180 | 3130 p.123 | 4011 p.169      |
| 115 p.125  | 1927 p.132 | 2129 p.180 | 3140 p.123 | 4012 p.169      |
| 1150 p.156 | 1931 p.132 | 2130 p.180 | 3180 p.123 | 4013 p.169      |
| 1170 p.156 | 1936 p.134 | 2131 p.180 | 3190 p.123 | 4014 p.169      |
| 1180 p.156 | 1940 p.131 | 2132 p.180 | 3200 p.122 | 4015 p.169      |
| 1190 p.154 | 1952 p.133 | 2133 p.180 | 3210 p.122 | 4016 p.169      |
| 1210 p.154 | 1962 p.133 | 2134 p.180 | 3222 p.123 | 4017 p.170      |
| 1220 p.155 | 1999 p.153 | 2135 p.180 | 3223 p.123 | 4020 p.170      |
|            | 2000 p.153 | 2136 p.180 | 3230 p.124 | 4021 p.170      |

|                 |            |            |            |            |
|-----------------|------------|------------|------------|------------|
| 4022 p.170      | 4084 p.175 | 4155 p.197 | 5011 p.160 | 6015 p.166 |
| 4023 p.170      | 4085 p.175 | 4156 p.197 | 5012 p.160 | 6016 p.166 |
| 4024 p.170      | 4086 p.175 | 4157 p.197 | 5020 p.162 | 6017 p.166 |
| 4025 p.170      | 4087 p.175 | 4158 p.197 | 5021 p.162 | 6018 p.167 |
| 4026 p.170      | 4090 p.167 | 4159 p.197 | 5022 p.162 | 6020 p.167 |
| 4027 p.170      | 4091 p.167 | 4160 p.197 | 5023 p.162 | 6021 p.167 |
| 4028 p.122, 170 | 4092 p.167 | 4161 p.197 | 5024 p.162 | 6022 p.167 |
| 4030 p.170      | 4093 p.168 | 4162 p.197 | 5025 p.162 | 6023 p.167 |
| 4031 p.170      | 4100 p.194 | 4163 p.197 | 5026 p.162 | 6025 p.167 |
| 4032 p.170      | 4101 p.194 | 4164 p.197 | 5027 p.162 | 6026 p.167 |
| 4033 p.170      | 4102 p.194 | 4165 p.197 | 5028 p.162 | 6027 p.167 |
| 4034 p.170      | 4103 p.194 | 4166 p.197 | 5029 p.162 | 6028 p.167 |
| 4035 p.170      | 4104 p.194 | 4167 p.197 | 5030 p.162 | 6030 p.168 |
| 4036 p.170      | 4105 p.194 | 4168 p.197 | 5031 p.161 | 6031 p.168 |
| 4037 p.171      | 4106 p.194 | 4169 p.197 | 5032 p.162 | 6032 p.168 |
| 4038 p.171      | 4107 p.194 | 4200 p.187 | 5040 p.163 | 6033 p.168 |
| 4039 p.171      | 4108 p.195 | 4201 p.187 | 5041 p.163 | 6034 p.167 |
| 4040 p.171      | 4109 p.195 | 4202 p.189 | 5042 p.163 | 6035 p.168 |
| 4041 p.171      | 4110 p.195 | 4500 p.165 | 5043 p.163 | 6036 p.168 |
| 4045 p.171      | 4111 p.195 | 4501 p.165 | 5044 p.163 | 6037 p.168 |
| 4046 p.171      | 4112 p.195 | 4502 p.165 | 5045 p.163 | 6038 p.168 |
| 4047 p.171      | 4113 p.195 | 4503 p.165 | 5046 p.163 | 6039 p.168 |
| 4048 p.171      | 4114 p.195 | 4504 p.165 | 5047 p.163 | 6041 p.199 |
| 4049 p.171      | 4120 p.195 | 4505 p.172 | 5048 p.163 | 6042 p.200 |
| 4050 p.171      | 4121 p.195 | 4506 p.172 | 5049 p.163 | 6043 p.200 |
| 4051 p.171      | 4122 p.195 | 4507 p.172 | 5050 p.163 | 6044 p.200 |
| 4052 p.171      | 4123 p.195 | 4508 p.172 | 5051 p.162 | 6045 p.200 |
| 4053 p.171      | 4124 p.195 | 4509 p.172 | 5052 p.162 | 6046 p.200 |
| 4054 p.171      | 4129 p.194 | 4510 p.172 | 5060 p.163 | 6047 p.200 |
| 4055 p.171      | 4130 p.195 | 4511 p.172 | 5061 p.164 | 6048 p.200 |
| 4056 p.171      | 4131 p.195 | 4512 p.172 | 5062 p.164 | 6049 p.199 |
| 4057 p.122, 171 | 4132 p.195 | 4513 p.172 | 5063 p.164 | 6050 p.199 |
| 4060 p.174      | 4133 p.195 | 4514 p.172 | 5064 p.164 | 6051 p.199 |
| 4061 p.174      | 4134 p.196 | 4515 p.172 | 5065 p.164 | 6056 p.201 |
| 4062 p.174      | 4135 p.196 | 4516 p.172 | 5066 p.164 | 6057 p.201 |
| 4063 p.174      | 4136 p.196 | 4517 p.172 | 5067 p.164 | 6058 p.201 |
| 4064 p.122, 174 | 4137 p.196 | 4518 p.172 | 5068 p.164 | 6059 p.201 |
| 4065 p.173      | 4138 p.196 | 4519 p.172 | 5069 p.163 | 6060 p.201 |
| 4066 p.174      | 4139 p.196 | 4520 p.172 | 5080 p.164 | 6061 p.201 |
| 4067 p.174      | 4140 p.196 | 4521 p.172 | 5081 p.165 | 6062 p.201 |
| 4068 p.174      | 4141 p.196 | 4522 p.172 | 5082 p.164 | 6063 p.201 |
| 4070 p.175      | 4142 p.196 | 4523 p.172 | 5083 p.164 | 6064 p.200 |
| 4071 p.175      | 4143 p.196 | 4524 p.172 | 5084 p.165 | 6065 p.200 |
| 4072 p.175      | 4144 p.196 | 5000 p.160 | 5085 p.164 | 6066 p.200 |
| 4073 p.175      | 4145 p.196 | 5001 p.161 | 5086 p.164 | 6070 p.203 |
| 4074 p.175      | 4146 p.196 | 5002 p.161 | 5087 p.165 | 6071 p.203 |
| 4075 p.175      | 4147 p.196 | 5003 p.161 | 5088 p.165 | 6072 p.203 |
| 4076 p.175      | 4148 p.196 | 5004 p.161 | 5089 p.164 | 6073 p.203 |
| 4077 p.175      | 4149 p.196 | 5005 p.161 | 530 p.153  | 6074 p.203 |
| 4078 p.122, 175 | 4150 p.197 | 5006 p.161 | 540 p.153  | 6075 p.203 |
| 4080 p.174      | 4151 p.197 | 5007 p.161 | 6010 p.166 | 6076 p.203 |
| 4081 p.174      | 4152 p.197 | 5008 p.161 | 6011 p.166 | 6077 p.203 |
| 4082 p.174      | 4153 p.197 | 5009 p.161 | 6012 p.166 | 6078 p.203 |
| 4083 p.174      | 4154 p.197 | 5010 p.161 | 6013 p.166 | 6079 p.203 |

|                |            |            |            |            |
|----------------|------------|------------|------------|------------|
| 6080 p.203     | 7134 p.138 | 9031 p.193 | 9109 p.202 | 9369 p.181 |
| 6081 p.203     | 7135 p.186 | 9032 p.193 | 9110 p.202 | 9370 p.181 |
| 6082 p.204     | 7136 p.186 | 9033 p.193 | 9111 p.202 | 9371 p.181 |
| 6083 p.204     | 7137 p.187 | 9034 p.193 | 9112 p.202 | 9372 p.181 |
| 6084 p.204     | 7138 p.141 | 9035 p.193 | 9113 p.202 | 9373 p.181 |
| 6085 p.204     | 7141 p.185 | 9040 p.188 | 9114 p.202 | 9374 p.181 |
| 670 p.126, 127 | 7142 p.186 | 9041 p.188 | 9115 p.202 | 9375 p.181 |
| 680 p.126      | 7143 p.141 | 9042 p.188 | 9116 p.202 | 9376 p.181 |
| 690 p.126, 127 | 7144 p.187 | 9043 p.189 | 9117 p.202 | 9377 p.181 |
| 700 p.127      | 7145 p.186 | 9044 p.189 | 9118 p.202 | 9378 p.181 |
| 7029 p.149     | 720 p.127  | 9046 p.183 | 9119 p.202 | 9405 p.122 |
| 7030 p.149     | 730 p.127  | 9047 p.183 | 9120 p.202 | 9410 p.131 |
| 7031 p.149     | 775 p.127  | 9049 p.187 | 9121 p.202 | 9411 p.130 |
| 7032 p.149     | 8021 p.149 | 9050 p.182 | 9122 p.202 | 9412 p.130 |
| 7033 p.149     | 8022 p.150 | 9051 p.182 | 9123 p.202 | 9417 p.130 |
| 7034 p.149     | 8031 p.149 | 9052 p.183 | 9124 p.202 | 9419 p.130 |
| 7035 p.149     | 8040 p.139 | 9053 p.183 | 9125 p.202 | 9420 p.130 |
| 7036 p.149     | 8041 p.139 | 9054 p.184 | 9126 p.203 | 9421 p.140 |
| 7037 p.149     | 8042 p.139 | 9055 p.184 | 9127 p.203 | 9431 p.146 |
| 7038 p.149     | 8043 p.139 | 9056 p.184 | 9128 p.203 | 9432 p.146 |
| 7039 p.149     | 8044 p.139 | 9057 p.185 | 9129 p.203 | 9434 p.147 |
| 7040 p.150     | 8046 p.139 | 9058 p.185 | 9130 p.203 | 9435 p.147 |
| 7041 p.150     | 8047 p.139 | 9059 p.185 | 9131 p.203 | 9438 p.147 |
| 7045 p.150     | 8050 p.139 | 9060 p.183 | 9210 p.159 | 9439 p.147 |
| 7046 p.151     | 8051 p.139 | 9061 p.184 | 9211 p.159 | 9550 p.133 |
| 7050 p.150     | 8052 p.140 | 9062 p.184 | 9220 p.188 | 9551 p.133 |
| 7051 p.150     | 8053 p.140 | 9063 p.183 | 9221 p.188 | 9553 p.123 |
| 7053 p.150     | 8054 p.140 | 9064 p.183 | 930 p.127  | 9554 p.123 |
| 7060 p.138     | 8056 p.139 | 9065 p.184 | 9340 p.177 | 9555 p.123 |
| 7061 p.138     | 8057 p.140 | 9066 p.184 | 9341 p.177 | 9557 p.133 |
| 7062 p.138     | 8078 p.141 | 9067 p.184 | 9342 p.178 | 9600 p.184 |
| 7063 p.138     | 8090 p.141 | 9068 p.186 | 9343 p.178 | 9603 p.184 |
| 7064 p.138     | 810 p.125  | 9071 p.188 | 9344 p.178 | 9604 p.184 |
| 7065 p.138     | 8998 p.192 | 9072 p.123 | 9345 p.178 | 9605 p.185 |
| 7066 p.138     | 8999 p.191 | 9073 p.123 | 9346 p.178 | 9606 p.185 |
| 7067 p.138     | 9000 p.193 | 9074 p.187 | 9347 p.178 | 9608 p.188 |
| 7069 p.141     | 9001 p.193 | 9075 p.183 | 9348 p.178 | 9610 p.189 |
| 7070 p.141     | 9002 p.193 | 9076 p.182 | 9349 p.178 | 9611 p.189 |
| 7072 p.140     | 9003 p.193 | 9086 p.186 | 9350 p.178 | 9612 p.189 |
| 7073 p.141     | 9004 p.193 | 9087 p.185 | 9351 p.178 | 9614 p.189 |
| 7074 p.141     | 9005 p.193 | 9088 p.185 | 9352 p.178 | 9615 p.189 |
| 710 p.127      | 9010 p.192 | 9089 p.185 | 9353 p.178 | 9616 p.189 |
| 7100 p.140     | 9011 p.192 | 9090 p.123 | 9354 p.179 | 9630 p.189 |
| 7101 p.140     | 9012 p.192 | 9095 p.123 | 9355 p.179 | 9631 p.189 |
| 7102 p.140     | 9013 p.192 | 9099 p.187 | 9356 p.179 | 9632 p.189 |
| 7103 p.140     | 9014 p.192 | 9100 p.201 | 9360 p.180 | 9634 p.189 |
| 7104 p.140     | 9015 p.192 | 9101 p.201 | 9361 p.180 | 9635 p.190 |
| 7105 p.140     | 9020 p.192 | 9102 p.201 | 9362 p.180 | 9636 p.190 |
| 7106 p.140     | 9021 p.192 | 9103 p.201 | 9363 p.180 | 9640 p.183 |
| 7110 p.138     | 9022 p.192 | 9104 p.202 | 9364 p.180 | 9641 p.183 |
| 7115 p.140     | 9023 p.192 | 9105 p.202 | 9365 p.180 | 970 p.127  |
| 7116 p.140     | 9024 p.192 | 9106 p.202 | 9366 p.180 | 98 p.125   |
| 7117 p.140     | 9025 p.192 | 9107 p.202 | 9367 p.181 | 980 p.127  |
| 7118 p.142     | 9030 p.193 | 9108 p.202 | 9368 p.181 | 99 p.125   |

990 p.127

## A

Abort ? p.137

ACF activity p.187

Actual setup p.125

Advanced Status p.123

AI 1 alt sel src p.160

AI 1 alt value p.161

AI 1 gain tune p.161

AI 1 offs tune p.161

AI 1 sgn src p.160

AI 1X gain tune p.164

AI 1X offs tune p.164

AI 1X sgn src p.163

AI 2 alt sel src p.162

AI 2 alt value p.162

AI 2 gain tune p.162

AI 2 offs tune p.162

AI 2 sgn src p.161

AI 2X gain tune p.164

AI 2X offs tune p.164

AI 2X sgn src p.164

AI 3 alt sel src p.162

AI 3 alt value p.163

AI 3 gain tune p.163

AI 3 offs tune p.163

AI 3 sgn src p.162

ALARM CONFIG p.182

Alarm log p.125

Alarm log clear? p.125

Alarm status p.189

Alm status cfg p.189

Alm status mon p.189

Alm W1 S1 p.189

Alm W1 S2 p.189

Alm W2 S1 p.189

Alm W2 S2 p.190

Alm W3 S1 p.189

Alm W3 S2 p.190

Ambient temp p.126

An inp 1 < thr p.161

An inp 1 cfg p.160

An inp 1 dst p.165

An inp 1 filter p.161

An inp 1 gain p.161

An inp 1 hi lim p.161

An inp 1 low lim p.161

An inp 1 mon p.161

An inp 1 offset p.161

An inp 1 output p.161

An inp 1 scale p.161

An inp 1 src p.160

An inp 1 thr p.161

An inp 1 type p.160

An inp 1X < thr p.164

An inp 1X cfg p.163

An inp 1X dst p.165

An inp 1X gain p.164

An inp 1X hi lim p.164

An inp 1X lo lim p.164

An inp 1X mon p.164

An inp 1X offset p.164

An inp 1X output p.164

An inp 1X scale p.164

An inp 1X src p.163

An inp 1X thr p.164

An inp 1X type p.163

An inp 2 < thr p.162

An inp 2 cfg p.162

An inp 2 dst p.165

An inp 2 filter p.162

An inp 2 gain p.162

An inp 2 hi lim p.162

An inp 2 lo lim p.162

An inp 2 mon p.162

An inp 2 offset p.162

An inp 2 output p.162

An inp 2 scale p.162

An inp 2 src p.161

An inp 2 thr p.162

An inp 2 type p.162

An inp 2X < thr p.165

An inp 2X cfg p.164

An inp 2X dst p.165

An inp 2X gain p.165

An inp 2X hi lim p.164

An inp 2X lo lim p.164

An inp 2X mon p.165

An inp 2X offset p.165

An inp 2X output p.165

An inp 2X scale p.164

An inp 2X src p.164

An inp 2X thr p.164

An inp 2X type p.164

An inp 3 < thr p.163

An inp 3 cfg p.163

An inp 3 dst p.165

An inp 3 filter p.163

An inp 3 gain p.163

An inp 3 hi lim p.163

An inp 3 lo lim p.163

An inp 3 mon p.163

An inp 3 offset p.163

An inp 3 output p.163

An inp 3 scale p.163

An inp 3 src p.162

An inp 3 thr p.163

An inp 3 type p.163

An out 1 cfg p.166

An out 1 hi lim p.166

An out 1 lo lim p.166

An out 1 mon p.166

An out 1 scale p.166

An out 1 sgn src p.166

An out 1 src p.166

An out 1X cfg p.167

An out 1X hi lim p.167

An out 1X lo lim p.167

An out 1X mon p.167

An out 1X scale p.167

An out 1X src p.167

An out 2 cfg p.166

An out 2 hi lim p.166

An out 2 lo lim p.166

An out 2 mon p.167

An out 2 scale p.166

An out 2 sgn src p.166

An out 2 src p.166

An out 2X cfg p.167

An out 2X hi lim p.167

An out 2X lo lim p.167

An out 2X mon p.167

An out 2X scale p.167

An out 2X src p.167

An out 3X cfg p.167

An out 3X hi lim p.168

An out 3X lo lim p.168

An out 3X mon p.168

An out 3X scale p.168

An out 3X src p.167

An out 3X type p.167

An out 4X cfg p.168

An out 4X hi lim p.168

An out 4X lo lim p.168

An out 4X mon p.168

An out 4X scale p.168

An out 4X src p.168

An out 4X type p.168

Analog inputs p.160

Analog outputs p.165

Antioscill gain p.152

APPL CARD CONFIG

p.194

Appl card fault p.187

Autotune p.128

Available Outvlt p.156

## B

B0 W0 decomp p.179

B0 W1 decomp p.180

B1 W0 decomp p.179

B1 W1 decomp p.180

B10 W0 decomp p.180

B10 W1 decomp p.181

B11 W0 decomp p.180

B11 W1 decomp p.181

B12 W0 decomp p.180

B12 W1 decomp p.181

B13 W0 decomp p.180

B13 W1 decomp p.181

B14 W0 decomp p.180

B14 W1 decomp p.181

B15 W0 decomp p.180

B15 W1 decomp p.181

B2 W0 decomp p.179

B2 W1 decomp p.180

B3 W0 decomp p.180

B3 W1 decomp p.180

B4 W0 decomp p.180

B4 W1 decomp p.181

B5 W0 decomp p.180

B5 W1 decomp p.181

B6 W0 decomp p.180

B6 W1 decomp p.181

B7 W0 decomp p.180

B7 W1 decomp p.181

B8 W0 decomp p.180

B8 W1 decomp p.181

B9 W0 decomp p.180

B9 W1 decomp p.181

Bandwidth p.135

Base values p.152, 153,

154

Bits->Word p.176

Bits->Word / Bits-  
>Word0 mon  
p.177

Bits->Word / Bits-  
>Word0 src p.176

Bits->Word / Bits-  
>Word1 mon  
p.179

Brake close dly p.140

Brake feedback p.186

Brake open delay p.140

Brake open src p.142

BRK activity p.186

BRK feedback src p.186

BRK hold off p.186

BRK RUN hold off p.186

BU control p.136

BU OL accum % p.123

BU overload p.188

BU protection p.136

BU res cont pwr p.136  
BU res OL factor p.136  
BU res OL time p.136  
BU resistance p.136  
BUOL activity p.188

## C

Cabin weight p.129  
Calc Inertia p.135  
Calc method p.134  
CCF activity p.187  
CCF restart p.187  
CCF restart time p.187  
Cmp 1 delay p.200  
Cmp 1 function p.200  
Cmp 1 inp 0 p.199  
Cmp 1 inp 0 src p.199  
Cmp 1 inp 1 p.200  
Cmp 1 inp 1 src p.199  
Cmp 1 inp 2 p.200  
Cmp 1 inp 2 src p.199  
Cmp 1 inversion p.200  
Cmp 1 window p.200  
Cmp 2 delay p.201  
Cmp 2 function p.201  
Cmp 2 inp 0 p.201  
Cmp 2 inp 0 src p.200  
Cmp 2 inp 1 p.201  
Cmp 2 inp 1 src p.200  
Cmp 2 inp 2 p.201  
Cmp 2 inp 2 src p.200  
Cmp 2 inversion p.201  
Cmp 2 window p.201  
CNT activity p.186  
CNT feedback src p.185  
CNT hold off p.186  
Comm card fault p.187  
Commands p.159  
Commands cfg p.159  
Commands mon p.160  
Commands select p.159  
Commands src p.159  
COMMUNICATION p.191  
Compare 1 p.199  
Compare 1 cfg p.199  
Compare 1 mon p.200  
Compare 1 output p.200  
Compare 1 src p.199  
Compare 2 p.200  
Compare 2 cfg p.201  
Compare 2 mon p.201  
Compare 2 output p.201  
Compare 2 src p.200

Complete rot p.128  
Complete still p.128  
Connect p.203  
Connect A p.203  
Connect B p.203  
ConnectA inp 0 src p.203  
ConnectA inp 1 src p.203  
ConnectA inp 2 src p.203  
ConnectA inp 3 src p.203  
ConnectA inp 4 src p.203  
ConnectA inp 5 src p.203  
ConnectA inp 6 src p.203  
ConnectA inp 7 src p.203  
ConnectB inp 0 src p.203  
ConnectB inp 1 src p.203  
ConnectB inp 2 src p.203  
ConnectB inp 3 src p.203  
ConnectB inp 4 src p.204  
ConnectB inp 5 src p.204  
ConnectB inp 6 src p.204  
ConnectB inp 7 src p.204  
Cont close delay p.140  
Cont open delay p.140  
Contact feedback p.185  
Cosfi p.127  
Counter weight p.129  
CPU1 runtime p.124  
CPU2 runtime p.124  
Curr regulato p.153  
Currl base value p.153  
Currl gain % p.153  
CurrP base value p.153  
CurrP gain % p.153  
CurrReg p.128  
CUSTOM FUNCTIONS  
p.199

## D

DC braking p.148  
DC link voltage p.123  
DCbrake cmd src p.121,  
148  
DCbrake current p.148  
DCbrake delay p.148  
DCbrake duration p.148  
DCBrake state p.148  
Dead time limit p.153  
Dead time slope p.153  
Destinations p.172  
DGFC async Ch p.195  
DGFC config p.194  
DGFC enable p.194  
DGFC sync Ch p.194,  
195, 196, 197  
DGFC-A Drv W0mon  
p.197  
DGFC-A Drv W1mon  
p.197  
DGFC-A Drv W2mon  
p.197  
DGFC-A Drv W3mon  
p.197  
DGFC-A Drv W4mon  
p.197  
DGFC-A Drv W5mon  
p.197  
DGFC-A Drv W6mon  
p.197  
DGFC-A Drv W7mon  
p.197  
DGFC-A Drv W8mon  
p.197  
DGFC-A Drv W9mon  
p.197  
DGFC-S Drv W0mon  
p.195  
DGFC-S Drv W1mon  
p.195  
DGFC-S Drv W2mon  
p.195  
DGFC-S Drv W3mon  
p.195  
DGFC-S Drv W4mon  
p.195  
DI 0X inversion p.170  
DI 0X monitor p.171  
DI 1X inversion p.170  
DI 1X monitor p.171  
DI 2X inversion p.170  
DI 2X monitor p.171  
DI 3X inversion p.170  
DI 3X monitor p.171  
DI 4X inversion p.170  
DI 4X monitor p.171  
DI 5X inversion p.170  
DI 5X monitor p.171  
DI 6X inversion p.171  
DI 6X monitor p.171  
DI 7X inversion p.171  
DI 7X monitor p.171  
DI 8X inversion p.171  
DI 8X monitor p.171  
DI 9X inversion p.171  
DI 9X monitor p.171  
DI 0 Enable dst p.172  
DI 0 Enable mon p.170  
DI 0X dst p.172

DI 1 dst p.172  
DI 1 inversion p.169  
DI 1 monitor p.170  
DI 10X dst p.172  
DI 10X inversion p.171  
DI 10X monitor p.171  
DI 11X dst p.172  
DI 11X inversion p.171  
DI 11X monitor p.171  
DI 1X dst p.172  
DI 2 dst p.172  
DI 2 inversion p.169  
DI 2 monitor p.170  
DI 2X dst p.172  
DI 3 dst p.172  
DI 3 inversion p.169  
DI 3 monitor p.170  
DI 3X dst p.172  
DI 4 dst p.172  
DI 4 inversion p.169  
DI 4 monitor p.170  
DI 4X dst p.172  
DI 5 dst p.172  
DI 5 inversion p.169  
DI 5 monitor p.170  
DI 5X dst p.172  
DI 6 dst p.172  
DI 6 inversion p.169  
DI 6 monitor p.170  
DI 6X dst p.172  
DI 7 dst p.172  
DI 7 inversion p.170  
DI 7 monitor p.170  
DI 7654321E p.122, 170  
DI 7X dst p.172  
DI 8X dst p.172  
DI 9X dst p.172  
Dig Enable src p.159  
Dig pad 0 p.202  
Dig pad 1 p.202  
Dig pad 10 p.203  
Dig pad 11 p.203  
Dig pad 12 p.203  
Dig pad 13 p.203  
Dig pad 14 p.203  
Dig pad 15 p.203  
Dig pad 2 p.202  
Dig pad 3 p.202  
Dig pad 4 p.202  
Dig pad 5 p.202  
Dig pad 6 p.202  
Dig pad 7 p.202  
Dig pad 8 p.202  
Dig pad 9 p.202

Dig StrStp src p.159  
 Digital inputs p.169  
 Digital outputs p.173  
 DIX BA9876543210 p.122, 171  
 DO p.174  
 DO 0 inversion p.174  
 DO 0 src p.173  
 DO 0X inversion p.175  
 DO 0X src p.174  
 DO 1 inversion p.174  
 DO 1 src p.174  
 DO 1X inversion p.175  
 DO 1X src p.174  
 DO 2 inversion p.174  
 DO 2 src p.174  
 DO 2X inversion p.175  
 DO 2X src p.174  
 DO 3 inversion p.174  
 DO 3 src p.174  
 DO 3210 p.122  
 DO 3X inversion p.175  
 DO 3X src p.174  
 DO 4X inversion p.175  
 DO 4X src p.175  
 DO 5X inversion p.175  
 DO 5X src p.175  
 DO 6X inversion p.175  
 DO 6X src p.175  
 DO 7X inversion p.175  
 DO 7X src p.175  
 DOL activity p.188  
 Door activity p.187  
 Door fbk src p.187  
 Door feedback p.187  
 Door hold off p.187  
 Door open speed p.141  
 Door open src p.141  
 DOX 76543210 p.122, 175  
 Drive cont curr p.124  
 Drive data p.126  
 Drive ID Status p.124  
 Drive name p.125  
 Drive overload p.188  
 Drive size p.124  
 Drive type p.124  
 Drv DGFC-A W0mon p.197  
 Drv DGFC-A W0src p.195  
 Drv DGFC-A W1mon p.197  
 Drv DGFC-A W1src p.195  
 Drv DGFC-A W2mon p.197  
 Drv DGFC-A W2src p.195  
 Drv DGFC-A W3mon p.197  
 Drv DGFC-A W3src p.195  
 Drv DGFC-A W4mon p.197  
 Drv DGFC-A W4src p.196  
 Drv DGFC-A W5mon p.197  
 Drv DGFC-A W5src p.196  
 Drv DGFC-A W6mon p.197  
 Drv DGFC-A W6src p.196  
 Drv DGFC-A W7mon p.197  
 Drv DGFC-A W7src p.196  
 Drv DGFC-A W8mon p.197  
 Drv DGFC-A W8src p.196  
 Drv DGFC-A W9mon p.197  
 Drv DGFC-A W9src p.196  
 Drv DGFC-S W0mon p.195  
 Drv DGFC-S W0src p.194  
 Drv DGFC-S W1mon p.195  
 Drv DGFC-S W1src p.194  
 Drv DGFC-S W2mon p.195  
 Drv DGFC-S W2src p.194  
 Drv DGFC-S W3mon p.195  
 Drv DGFC-S W3src p.194  
 Drv DGFC-S W4mon p.195  
 Drv DGFC-S W4src p.194  
 Drv OL accur % p.123  
 Drv SBI W0 mon p.193  
 Drv SBI W0 src p.192  
 Drv SBI W1 mon p.193  
 Drv SBI W1 src p.192  
 Drv SBI W2 mon p.193  
 Drv SBI W2 src p.192  
 Drv SBI W3 mon p.193  
 Drv SBI W3 src p.192  
 Drv SBI W4 mon p.193  
 Drv SBI W4 src p.192  
 Drv SBI W5 mon p.193  
 Drv SBI W5 src p.192  
 Drv->SBI W cfg p.192  
 Drv->SBI W mon p.193  
 Drv->SBI W src p.192  
 Drv->SBI word p.192  
 DS restart p.183  
 DS restart time p.183  
 Dyn vlt margin p.156  
**E**  
 EF activity p.183  
 EF hold off p.184  
 EF restart p.184  
 EF restart time p.184  
 EF src p.183  
 Efficiency p.127  
 EMF constant p.127  
 En/Disable mode p.159  
 Enable cmd mon p.160  
 Enable SM mon p.122  
 Encoders config p.131  
 Enter setup mode p.126  
 Exp ana inp en p.165  
 Exp ana out en p.168  
 Exp dig inp cfg p.170  
 Exp dig inp en p.172  
 Exp dig inp mon p.171  
 Exp dig out cfg p.175  
 Exp dig out en p.176  
 Exp dig out mon p.175  
 Exp dig out src p.174  
 Exp enc cnt dir p.133  
 Exp enc position p.123  
 Exp enc pulses p.133  
 Exp enc type p.132  
 External fault p.183  
**F**  
 FastStop cmd mon p.160  
 FastStop SM mon p.122  
 FastStop src p.159  
 Fault rese p.182  
 Fault reset src p.182  
 Flux p.123  
 Flux config p.155  
 Flux level src p.155  
 Flux max lim cfg p.156  
 Flux max lim mon p.156  
 Flux max lim src p.155  
 Flux ref p.123  
 Flux regulator p.153  
 FluxReg rot p.128  
 FluxReg still p.128  
 FlxI base value p.153  
 FlxI gain % p.153  
 FlxP base value p.153  
 FlxP gain % p.153  
 Frequency p.122  
 Full scale speed p.129  
**G**  
 Gain monitor p.157  
 Gain transitions p.157  
 Gearbox inertia p.130  
 Gearbox ratio p.129  
 Gen Hi ref p.158  
 Gen Low ref p.158  
 Gen output p.158  
 Gen Period p.158  
 GF activity p.183  
 GF threshold p.183  
 Ground fault p.183  
**H**  
 Heatsink S OT p.184  
 HT sensor temp p.123  
 HTS activity p.184  
 HTS hold off p.184  
 HTS restart p.184  
 HTS restart time p.184  
 Hw fault p.189  
 Hw fault mon p.189  
**I**  
 I/O CONFIG p.159  
 I/O status p.122  
 IA sensor temp p.123  
 IAS activity p.185  
 IAS hold off p.185  
 IAS restart p.185  
 IAS restart time p.185  
 IGBT desaturat p.183  
 Import recipe p.137  
 In use values p.153  
 Index storing p.133  
 Index storing en p.133  
 Inertia comp p.147  
 Inertia comp en p.147  
 Inertia comp fit p.147  
 Inertia comp mon p.147  
 Inst overcurrent p.183  
 Int Drv SBI W0 p.192  
 Int Drv SBI W1 p.192  
 Int Drv SBI W2 p.192  
 Int Drv SBI W3 p.192  
 Int Drv SBI W4 p.192  
 Int Drv SBI W5 p.192  
 Int DrvDGFC-A W0 p.196  
 Int DrvDGFC-A W1 p.196

Int DrvDGFC-A W2 p.196  
 Int DrvDGFC-A W3 p.196  
 Int DrvDGFC-A W4 p.196  
 Int DrvDGFC-A W5 p.196  
 Int DrvDGFC-A W6 p.196  
 Int DrvDGFC-A W7 p.196  
 Int DrvDGFC-A W8 p.196  
 Int DrvDGFC-A W9 p.196  
 Int DrvDGFC-S W0 p.194  
 Int DrvDGFC-S W1 p.194  
 Int DrvDGFC-S W2 p.194  
 Int DrvDGFC-S W3 p.195  
 Int DrvDGFC-S W4 p.195  
 Int flx maxlim p.156  
 Int Inertia p.147  
 Int IS ctrl p.133  
 Int Outvlt lim p.156  
 Int Pre-torque p.146  
 Int ramp ref 1 p.149  
 Int ramp ref 2 p.149  
 Int ramp ref 3 p.149  
 Int speed ref 1 p.150  
 Int speed ref 2 p.150  
 Int torque ref 2 p.154  
 Intake air S OT p.185  
 Inuse flx maxlim p.156  
 Inuse Outvlt ref p.156  
 Inuse S I gain p.157  
 Inuse S P gain p.157  
 InUse Spdl gain% p.153  
 InUse SpdP gain% p.153  
 Inuse Tcurr lim+ p.155  
 Inuse Tcurr lim- p.155  
 IOC restart p.183  
 IOC restart time p.183  
 IS ctrl src p.133

## L

Landing control p.130  
 Landing distance p.130  
 Landing init src p.130  
 Landing ratio p.130  
 Landing zone p.130  
 Last SBI error p.192  
 Life time p.125  
 Lift sequence p.140  
 Load default ? p.137  
 Load setup p.129  
 Load weight p.129  
 Lock flux pos p.155  
 LS inductance p.127

## M

Magn curr ref p.123  
 Magn ramp time p.155  
 Magnetiz config p.155  
 Magnetizing curr p.123  
 Mains voltage p.126  
 Mask W1 S1 p.189  
 Mask W1 S2 p.189  
 Mask W2 S1 p.189  
 Mask W2 S2 p.189  
 Mask W3 S1 p.189  
 Mask W3 S2 p.189  
 Max linear speed p.138  
 Measured DTL p.128  
 Measured DTS p.128, 129  
 Measured LsSigma p.128, 129  
 Measured Rs p.128  
 Mechanical data p.129  
 Mlt ramp s0 src p.141  
 Mlt ramp sel mon p.141  
 Mlt spd out mon p.141  
 Mlt spd s 0 src p.140  
 Mlt spd s 1 src p.141  
 Mlt spd s 2 src p.141  
 Mlt spd sel mon p.141  
 MOL activity p.188  
 MONITOR p.122  
 MOT activity p.184  
 MOT hold off p.184  
 Mot OL accum p.135  
 Mot OL accum % p.123  
 Mot OL trip p.135  
 MOT restart p.184  
 MOT restart time p.184  
 Motor data p.126, 127  
 Motor inertia p.129  
 Motor OL control p.135  
 Motor OL factor p.135  
 Motor OL time p.135  
 Motor OT p.184  
 Motor overload p.188  
 Motor pp/sens pp p.134  
 Motor protection p.135  
 Motoring gains p.156  
 MRO acc end jerk p.139  
 MRO acc ini jerk p.139  
 MRO acceleration p.139  
 MRO dec end jerk p.139  
 MRO dec ini jerk p.139  
 MRO deceleration p.139  
 MRO end decel p.139  
 MR1 acc end jerk p.139

MR1 acc ini jerk p.139  
 MR1 acceleration p.139  
 MR1 dec end jerk p.140  
 MR1 dec ini jerk p.140  
 MR1 deceleration p.140  
 MR1 end decel p.140  
 Multi speed 0 p.138  
 Multi speed 1 p.138  
 Multi speed 2 p.138  
 Multi speed 3 p.138  
 Multi speed 4 p.138  
 Multi speed 5 p.138  
 Multi speed 6 p.138  
 Multi speed 7 p.138

## N

Norm Exp enc spd p.123  
 Norm Speed p.122  
 Norm Std enc spd p.123

## O

Observer filter p.157  
 Observer ref mon p.157  
 OS activity p.188  
 OS hold off p.188  
 OS threshold p.188  
 Out vlt ref cfg p.156  
 Out vlt ref mon p.156  
 Out vlt ref src p.156  
 Output current p.122  
 Output power p.122  
 Output vlt ref p.156  
 Output voltage p.122  
 Outvlt lim src p.156  
 OV restart p.183  
 OV restart time p.183  
 Overspeed p.188  
 Overvoltage p.183

## P

Pad 0 p.201  
 Pad 1 p.201  
 Pad 10 p.202  
 Pad 11 p.202  
 Pad 12 p.202  
 Pad 13 p.202  
 Pad 14 p.202  
 Pad 15 p.202  
 Pad 2 p.201  
 Pad 3 p.201  
 Pad 4 p.202  
 Pad 5 p.202

Pad 6 p.202  
 Pad 7 p.202  
 Pad 8 p.202  
 Pad 9 p.202  
 Pad param bit p.202  
 Pad param word p.201  
 Pad parameters p.201  
 Percent values p.152, 153  
 Pole pairs p.127  
 Pos P gain p.130  
 Pos speed limit p.131  
 Pre-torque p.146  
 Pre-torque gain p.147  
 Pre-torque src p.147  
 Pre-torque time p.146  
 Pre-torque type p.147  
 Pre-trq sign src p.147  
 Prop filter p.145  
 Protocol type p.191  
 Pulley diameter p.129

## R

Ramp function p.149  
 Ramp out enable p.149  
 Ramp out mon p.150  
 Ramp profile p.138  
 Ramp ref p.122  
 Ramp ref 1 mon p.149  
 Ramp ref 1 src p.149  
 Ramp ref 2 mon p.149  
 Ramp ref 2 src p.149  
 Ramp ref 3 mon p.149  
 Ramp ref 3 src p.149  
 Ramp ref cfg p.149  
 Ramp ref inv src p.149  
 Ramp ref mon p.149  
 Ramp ref src p.149  
 Ramp setpoint p.149  
 Ramp shape p.149  
 Rated current p.126, 127  
 Rated frequency p.126  
 Rated power p.127  
 Rated speed p.127  
 Rated voltage p.126, 127  
 Regen gains p.157  
 Regulation mode p.137  
 REGULATION PARAM p.152  
 Regulation S OT p.185  
 Rep/Sim enc sel p.133  
 Rep/Sim encoder p.133  
 Results p.128  
 RG sensor temp p.123

RGS activity p.185  
RGS hold off p.185  
RGS restart p.185  
RGS restart time p.185  
Rope weight p.129  
RS485 p.191

## S

S mot HPgain p.156, 157  
Save config ? p.137  
SAVE PARAMETERS  
    p.151, 158, 181,  
    193, 198, 204  
SBI config p.191  
SBI Drv W0 mon p.193  
SBI Drv W1 mon p.193  
SBI Drv W2 mon p.193  
SBI Drv W3 mon p.193  
SBI Drv W4 mon p.193  
SBI Drv W5 mon p.193  
SBI enable p.191  
SBI monitor p.192  
SBI->Drv W mon p.193  
SBI->Drv word p.193  
Seq start mode p.140  
Seq start sel p.140  
Sequencer status p.123  
SERVICE p.205  
Service factor p.135  
Sfbk der base p.145  
Sfbk der enable p.144  
Sfbk der filter p.145  
Sfbk der gain p.145  
SFL activity p.188  
SGP tran21 band p.146  
SGP tran21 h thr p.146  
SGP tran32 band p.146  
SGP tran32 l thr p.146  
Slave address p.191  
Slave res time p.191  
Slip comp p.152  
Slip comp filter p.152  
Slip comp mode p.152  
Slip l gain p.152  
Slip P gain p.152  
SlowDown dist p.140  
Sls SpdFbk gains p.156  
Smooth start spd p.138  
Smooth str time p.140  
Software status p.125  
Software type p.125  
Software version V .  
    p.125  
Spd 0 dis dly p.160

Spd 0 enable p.144  
Spd 0 l gain % p.144  
Spd 0 P gain % p.144  
Spd 0 ref delay p.145  
Spd 0 ref thr p.145  
Spd 0 spd delay p.145  
Spd 0 speed thr p.145  
Spd fbk loss p.188  
Spd ref/fbk res p.126  
Spd regulator p.152  
Spdl base value p.152  
Spdl1 gain % p.144, 152  
Spdl2 gain % p.144  
Spdl3 gain % p.144  
SpdP base value p.152  
SpdP1 gain % p.144, 152  
SpdP2 gain % p.144  
SpdP3 gain % p.144  
SpdReg gain calc p.134  
Speed fbk sel p.131  
Speed profile p.138  
Speed ref p.122  
Speed ref 1 mon p.150  
Speed ref 1 src p.150  
Speed ref 2 mon p.151  
Speed ref 2 src p.150  
Speed ref cfg p.150  
Speed ref mon p.150  
Speed reg gains p.142  
Speed setpoint p.150  
Speed threshold p.145  
Speedref inv src p.150  
Start alt src p.140  
Start cmd mon p.160  
Start fwd src p.140  
Start rev src p.140  
Start SM mon p.122  
STARTUP p.126  
Stator resistance p.127  
Std dig enc mode p.132  
Std dig inp cfg p.169  
Std dig inp mon p.170  
Std dig out cfg p.174  
Std dig out mon p.174  
Std dig out src p.173  
Std enc cnt dir p.132  
Std enc position p.123  
Std enc pulses p.132  
Std enc supply p.132  
Std enc type p.131  
Std sin enc mod p.123  
Std sin enc Vp p.132  
Switching freq p.126  
Sys time-ddmmyy p.125

## T

T setpoint cfg p.154  
T setpoint mon p.154  
T setpoint src p.154  
Tcurr lim + p.154  
Tcurr lim - p.155  
Tcurr lim sel p.154  
Tcurr lim state p.155  
Term Start src p.159  
Term Stop src p.159  
Term StrStp src p.159  
Test gen cfg p.158  
Test gen mode p.158  
Test gen mon p.158  
Test generator p.157  
Torque config p.154  
Torque constant p.127  
Torque curr p.123  
Torque curr ref p.123  
Torque ref p.154  
Torque ref 2 mon p.154  
Torque ref 2 src p.154  
TRAVEL p.138  
Travel units sel p.129  
Trq curr lim cfg p.154  
Trq curr lim mon p.155  
Trq curr lim src p.154

## U

Undervoltage p.182  
UV repetitive p.189  
UV restart p.182  
UV restart time p.182  
UV select src p.182  
UVR attempts p.189  
UVR delay p.189

## V

V lLim l gain p.152  
V lLim P gain p.152  
V reg param p.152  
V/f config p.135  
V/f frequency p.135  
V/f voltage p.135  
Vlt regulator p.153  
Vltl base value p.154  
Vltl gain % p.153  
VltP base value p.154  
VltP gain % p.153  
Voltage boost p.152

## W

W0 comp out p.177  
W0 decomp inp p.179  
W0 decomp mon p.179  
W0 decomp src p.179  
W1 comp out p.179  
W1 decomp inp p.180  
W1 decomp mon p.180  
W1 decomp src p.180  
Weights p.129  
Term->Bits p.179  
Word0 B0 src p.176  
Word0 B1 src p.176  
Word0 B10 src p.177  
Word0 B11 src p.177  
Word0 B12 src p.177  
Word0 B13 src p.177  
Word0 B14 src p.177  
Word0 B15 src p.177  
Word0 B2 src p.176  
Word0 B3 src p.176  
Word0 B4 src p.176  
Word0 B5 src p.176  
Word0 B6 src p.176  
Word0 B7 src p.177  
Word0 B8 src p.177  
Word0 B9 src p.177  
Word0->Bits cfg p.179  
Word0->Bits mon p.179  
Word0->Bits src p.179  
Word1 B0 src p.177  
Word1 B1 src p.177  
Word1 B10 src p.178  
Word1 B11 src p.178  
Word1 B12 src p.178  
Word1 B13 src p.178  
Word1 B14 src p.179  
Word1 B15 src p.179  
Word1 B2 src p.178  
Word1 B3 src p.178  
Word1 B4 src p.178  
Word1 B5 src p.178  
Word1 B6 src p.178  
Word1 B7 src p.178  
Word1 B8 src p.178  
Word1 B9 src p.178  
Word1->Bits cfg p.180  
Word1->Bits mon p.180  
Word1->Bits src p.180



**SIEI**

Via Carducci 24  
21040 Gerenzano VA – Italia  
Tel. +39 – 02.967.601  
Fax +39 – 02.968.26.53

Information:  
E-mail [info@siei.it](mailto:info@siei.it)

Technical Assistance:  
E-mail [technohelp@siei.it](mailto:technohelp@siei.it)

Internet  
[www.sieigroup.com](http://www.sieigroup.com)

**SIEI worldwide****Germany:**

SIEI-AREG – Gemmrigheim  
Tel. +49 – 7143 – 9730  
E-mail [info@sieiareg.de](mailto:info@sieiareg.de)

**France:**

SIEI FRANCE – Saverne  
Tel. +33 – 3 – 88 02 14 14  
E-mail [sieispa.fr@wanadoo.fr](mailto:sieispa.fr@wanadoo.fr)

**England:**

SIEI UK – Telford  
Tel. +44 – 1952 – 604555  
E-mail [sales@sieiuk.co.uk](mailto:sales@sieiuk.co.uk)

**Slovenia:**

SIEI EST – Ljubljana  
Tel. +386 – 611 614 940  
E-mail [ljubljana@sieiest.com](mailto:ljubljana@sieiest.com)

**Asia:**

GEFRAN SIEI ASIA – Singapore  
Tel. +65 – 6 – 8418.300  
E-mail [info@gefransiei.com.sg](mailto:info@gefransiei.com.sg)

**SIEI ASIA – Shanghai**

Tel. +86 – 21 – 6916.9898  
E-mail [info@sieiasia.com.cn](mailto:info@sieiasia.com.cn)

**USA:**

SIEI AMERICA – Charlotte, NC 28208  
Tel. +1 – 704 – 329.0200  
E-mail [salescontact@sieiamerica.com](mailto:salescontact@sieiamerica.com)

**SIEI Customer Service**

E-mail [customer@siei.it](mailto:customer@siei.it)  
Tel. +39 – 02.967.60.500  
Fax +39 – 02.967.60.278

**GEFRAN**

**SIEI** – A member of the GEFTRAN Group.

**GEFRAN S.p.A.**

Via Sebina 74  
25050 Provaglio d'Iseo (BS) – Italia  
Tel. +39 – 030.9888.1  
Fax +39 – 030.9839063  
E-mail [info@gefran.com](mailto:info@gefran.com)  
Internet [www.gefran.com](http://www.gefran.com)



Manuale AVy\_L AC/BR 3.5 -HGB  
0.2 - 22.5.2006



1S9H16