

ACCU ELECTRIC MOTORS INC

USA: (888) 932-9183

CANADA: (905) 829-2505

- ✓ Over 100 years cumulative experience
- ✓ 24 hour rush turnaround / technical support service
- ✓ Established in 1993



The leading independent repairer of servo motors and drives in North America.

Visit us on the web:

www.servo-repair.com

www.servorepair.ca

www.ferrocontrol.com

www.sandvikrepair.com

www.accuelectric.com

Scroll down to view your document!

For 24/7 repair services :

USA: 1 (888) 932 - 9183

Canada: 1 (905) 829 -2505

Emergency After hours: 1 (416) 624 0386

Servicing USA and Canada

Tips for using this handbook

Dear reader,

this screen-guided document is provided with jump labels so that individual items of information can be found easily.

All jump labels are highlighted in colour:

Passages marked in red
refer to information within this document.

Passages marked in blue
refer to information not in this document.

By clicking on the marked passage with the mouse you go directly to the page in the reference.

Please note!
The passages marked blue are not active in this document at present.

CUSTOMER SERVICES ADDRESS

ferrocontrol

Steuerungssysteme GmbH & Co.

Postfach 1653

D-32006 Herford

Bodelschwinghstraße 20

D-32049 Herford

Fon +49(0)5221 | 966-0

Fax +49(0)5221 | 66347

E-Mail Info@ferrocontrol.de

Internet <http://www.ferrocontrol.de>

Trouble-shooting and Spare parts

Fon +49(0)5221 | 966-200

Fax +49(0)5221 | 966-173

E-Mail service@ferrocontrol.de

Document-no. 96-032 000

Please state when ordering.

Quick-reference manual

for the ferrocontrol Fieldbus system

1st edition, October 98
Document no.: 96-032 000 / English

Target group:

Service technicians, commissioning personnel, skilled workers familiar with the basic functions of automation equipment.

Range of application of this documentation:

This document should serve as a practical guide for the service technician on location when locating and remedying faults.

Complementary documentation:

You can find a current list of our documentation in the [appendix](#) of this manual.

© October 98 by ferrocontrol Steuerungssysteme GmbH & Co.

Subject to alterations and errors. This document may not be duplicated or made available to third parties, in particular to our competitors, without our permission.

1 What you definitely need to know

- 1.1 **Safety information** Page 1-1
Instructions you must follow when doing repairs!
- 1.2 **Password information** 1-2
Structure of the password system
Assigning passwords
Entering a password

2 Functional overview: Service menu

- 2.1 **Information for the user** 2-1
Switching from one language to another
Direct access for test and diagnostic purposes / ATEST
- 2.2 **The service menu**, all functions at a glance 2-2
Overview of all functional levels

3 Where are system and error messages displayed?

Message overview

- 3.1 PLC: Messages from the Programmable Logic Controller (FPS) 3-1
- 3.2 PC: Messages from the industrial PC 3-1
- 3.3 SYSTEM / messages from the fieldbus system 3-1
 - 3.3.1 Messages from the axis controller 3-2
display: operating status
display: error status
 - 3.3.2 Messages from the motor controller 3-3
display: operating status
display: error status

4 What do the individual messages mean?

Meaning of the messages / Tips for trouble-shooting

4.1 Messages from the Fieldbus system	
Message no. 1 to 6	Page 4-1
Message no. 7 to 25	4-2
Message no. 26 to 51	4-3
Message no. 52 to 58	4-4
Message no. 59 to 64	4-5
4.2 Messages from the axis controller	
4.2.1 Operating status - axis	4-6
4.2.2 Error status - axis	4-12
4.3 Messages from the motor controller	
4.3.1 Error status - motor controller	4-14
4.3.2 Operating status - motor controller	4-16
4.4 Messages from the Programmable Logic Controller (FPS)	
See PLC Programming Manual	
Document no. 97-551000 / English	

5 Operating the screen masks

5.1 Mask: Inputs / binary	5-1
5.2 Mask: Outputs / binary	5-2
5.3 Mask: Module addressing	5-3
5.4 Mask: Selecting axis	5-4
5.5 Mask: Axis equipment and parameters	5-5
5.5.1 Selection: Equipment	5-5
5.5.2 Selection: Resolver	5-6
5.5.3 Selection: Motion profile	5-7
5.5.4 Selection: Position control	5-8
5.5.5 Selection: Speed control	5-9
5.5.6 Selection: External absolute position encoder	5-10
5.5.7 Selection: Referencing	5-11
5.5.8 Selection: Current limiting	5-12
5.5.9 Selection: Analog input	5-13
5.5.10 Selection: Gantry axis	5-14
5.5.11 Selection: Quick-stop	5-15
5.5.12 Selection: Synchronous motion	5-16
5.6 Mask: Move axis	5-17
5.6.1 Selection: Mode of operation	5-18
5.6.2 Operating functions	5-19



6 Functional modules in the CNC Fieldbus system

Board images, pin configurations, technical data, address settings, DIP switches

6.1 FBI-PC	
Fieldbus interface card	Page 6-1
6.2 FBK	
Fieldbus nodes	6-2
6.3 FBUR / FBRR	
Fieldbus universal controller	6-4
FBRR	
Fieldbus directional controller	6-4
6.4 FB-IN-16	
Input module with 16 inputs (binary)	6-5
6.5 FB-OUT-16	
Output module with 16 inputs (binary)	6-6
6.6 FB-IOT-8	
Combi module, 8 in- and 8 outputs	6-7
6.7 FB-INOUT	
Combi module, 8 in- and 8 outputs	6-8
6.8 FB-ANI	
Module for 4 analog inputs	6-9
6.9 FB-ANO	
Module for 3 analog outputs	6-10
6.10 FB-SAE	
Module for serial absolute encoders (SSI)	6-11
6.11 FB-INC-1	
Module for reading an incremental encoder	6-12
6.12 FBIR	
Fieldbus interpolator	6-13
6.13 FTRG	
Fieldbus interface with 3 temperature control systems	6-14
6.14 FVI	
Activation of Festo valve units with a fieldbus connection	6-15
6.15 MPLI	
Interface for the Festo Multipol valve unit	6-16
6.16 FB-REP	
Fieldbus repeater	6-17
6.17 Short diagram	
Fieldbus system bus topology with repeater	6-18
6.18 FBK-DP	
Fieldbus bridge: CNC Fieldbus - Profibus	6-19
6.19 Short diagram	
Bus topology with a bridge to the Profibus	6-21
6.20 DARC axis regulation controller	
Connection configuration	6-22
6.21 DARC supply module V15	
Connection configuration	6-23
Operating display LED: Fieldbus	6-24



7 Cable and connector configuration

Illustrations:

7.1	Encoder signal: Resolver - DARC input	Page 7-1
7.2	Encoder signal: Absolute position encoder - DARC input	7-2
7.3	Encoder signal: Incremental encoder - DARC input	7-3
	Encoder signal: Incremental encoder - FB-INC input	7-3
7.4	Encoder signal: Incremental encoder distributor - DARC supply module	7-4
7.5	Pin configuration: CNC fieldbus, fieldbus cable	7-5
7.6	Pin configuration: interface cable RS 232 PC - DARC supply module	7-6
7.7	Connection wiring: Override potentiometer Service cable V-24 for DARC supply module	7-7

8 Cable length and baud rate in the CNC Fieldbus system

Method of measuring the installed cable length

8.1	Cable length and baud rate	8-1
	Connector configuration: CNC fieldbus cable Connector configuration: CNC fieldbus plug	
8.2	Determining the installed cable length via the DC resistance	8-2
	Specific DC resistance of the ferrocontrol fieldbus cable	8-2

9 The ferrocontrol industrial PC

9.1 Model range 1.4 (3.4) and 1.3 (3.3)

9.1.1	Device view	9-1
9.1.2	External connector configuration	9-2
9.1.3	PC plug-in unit, installation and removal	9-3
9.1.4	PC opened, interior view	9-4
	Component identification Position of the buffer battery	
9.1.5	Illustration: CPU board / version 1.3 (3.3)	9-4
	Floppy connection IDE hard disk connection Interfaces: COM1 / COM 2 / LPT 1-Printer Battery connection	

9 The ferrocontrol industrial PC / continued

9.1 PC / Model range 1.4 (3.4)

- 9.1.6 Illustration: CPU board / version 1.4 (3.4) Page 9-5
Floppy connection
IDE hard disk connection
Graphic, TFT screen connection
Interfaces: COM 1 / COM 2 / LPT 1-Printer etc.

9.2 PC / Model range 1.2

- 9.2.1 Device view 9-6
9.2.2 External connector configuration 9-7
9.2.3 PC plug-in unit, installation and removal 9-7
9.2.4 PC opened, interior view 9-8
Operating voltage connection - mainboard
Component identification
Position of the puffer battery
9.2.5 Tips for removing the PC chassis 9-9
9.2.6 Illustration mainboard 9-9
Battery, soldered

9.3 PC / Model range 1.1

- 9.3.1 Device view 9-10
9.3.2 External connector configuration 9-11
9.3.3 PC plug-in unit, installation and removal 9-11
9.3.4 PC opened, interior view 9-12
Component identification
Battery connection
Switching: battery / accumulator
9.3.5 Tips for removing the PC chassis 9-12
9.3.6 Changing the battery 9-13
9.3.7 Changing the bulbs in the display unit 9-14

Appendix

- A.1 Index A-1
A.2 Overview of ferrocontrol documentation A-4
A.3 Connection diagram: DARC system A-5
Circuit diagram A3 / leaflet

1 What you definitely need to know

1.1 Safety information Instructions you must follow when doing repairs!



Must read!

1. **Interference and repairs carried out improperly can impair the integrated safety and protection functions of an automation system and can, in certain circumstances, cause risk to life and health of persons as well as damage to machinery and plant parts!**
2. **For this reason repairs to our automation systems may only be carried out by suitably qualified skilled workers!**
3. The qualified skilled worker is familiar with the risks and the appropriate safety measures to be taken when dealing with electrical currents.
4. The qualified skilled worker is familiar with the safety and protective measures common to all automation equipment - and in particular with the measures of the relevant machine (plant).
5. The qualified skilled worker can evaluate the damage and risks (caused by incorrect operation or by failure of a protective function) properly.
6. **Only use original spare parts specified by ferrocontrol**
Alterations and conversions to our components are not permitted. To do this you need our express permission.
7. **Please observe the valid accident prevention regulations!**
See VBG 4 and DIN VDE 015.
8. **After servicing or repairs:**
Before returning the machine to the production process, make absolutely certain that all integrated safety and protective devices are ready to function again. You are obliged to do this. See VBG 4.
9. **Please observe the safety conditions of the machine manufacturer!**

1 What you definitely need to know

1.2 Password information

Important input masks are protected by a password system against unauthorized access. Our password system permits a classification into a maximum of 9 access levels.

A password status is assigned to every access level. Status 9 has the highest priority. Status 9 gives you access to all levels, status 8 to the levels 1 to 8 and status 7 to the levels 1 to 7 and so on.

In agreement with the machine manufacturer, ferrocontrol allocates the input masks to a certain access level.

If you wish to obtain access entitlement to a particular level, as a user or service technician, you have to have the required status. You receive the status assignment by entering the appropriate password.

**The assignment of passwords for the status 1 to 8 is carried out in the mask: Passwords / assigning (see [Quick overview 2.2](#))
Access to this mask is only possible with status 9!
The password for status 9 is assigned by ferrocontrol.**




Notice!

If you wish to alter the configuration data or the controller parameters in the Service menu, you need the password for status 8.



Enter password:



Password entry takes place in the mask: Password / enter
You can call this entry mask from all menu levels using the key combination [ALT] + [F10].


The entry mask appears on the screen.

Enter the appropriate password.

Confirm your entry with the key [F10].

If you have entered a valid password, the status assigned to you is displayed.
If the password is invalid, an appropriate message is displayed.

Switching languages:




Using the key combination [ALT] + [S] you can switch between two national languages for the menu functions, e.g.:

German <-> English
German <-> French etc.

You can activate this function from every menu level. A prerequisite is, however, that a second language has been integrated for menu functions.

Direct access for test and diagnostic purposes (ATEST)




Direct access to the ATEST function is achieved by pressing the [ALT] + [F1] key combination. **This function enables you to inquire current actual values from the controller.**

**You can activate this function from every menu level!
With this function you cannot alter configuration data or parameter settings!**

2 Functional overview: Service menu

2.2 All functions at a glance

ferrocontrol - V 2.16




Notice!
Direct access with the key combination [ALT] + [F1]
Possible from every menu level!

Only password access

2 Functional overview: Service menu

2.2 All functions at a glance



2 Functional overview: Service menu

Space for your own notes

3 Where are system and error messages displayed?


Message overview

The ferrocontrol automation system is equipped with a powerful information and message unit. This aid shows you the current operating status of the plant on the screen.

This effective diagnostic tool is especially useful in determining the cause of a malfunction.

On the following pages you will be shown how this aid can be used effectively.

This display field appears on every screen mask.



3.1 FPS

This line shows the messages from the Programmable Logic Control section. (PLC)

3.2 PC

This line shows the messages from the industrial PC section

3.3 SYS


This line shows the complete messages from the Fieldbus SYSTEM section, including DARC.

The meaning of these messages along with tips for trouble-shooting can be found in this manual in **Pos. 4.1**

3 Where are system and error messages displayed?

3.3.1 Messages from the axis controller

Screen mask: "Move axis"



Selection of the relevant axis

C 8 4 2
 lower byte (1st group)
 upper byte (2nd group)

Example:
 upper byte
 C 8 = Interpolation active

lower byte
 4 x = Axis is referenced
 x 2 = Temperature monitoring
 (x = any status)

Access to this screen mask:

1. Press the key combination [ALT] + [F1] -> ATEST
2. Select Position 4 -SET VALUES-
3. Select the required axis
4. Press the [F4] key for details

Further information about this screen mask
 See Pos. 5.6

Display: operating status - axis
 In older software versions this entry is also called **Axis status** or **Operating status 1**.
These labels are identical!

This display is shown in a hexadecimal numerical system. The four-digit display is divided into two groups (lower and upper byte). In 4.2.1 you can see in plain text which operating status lies concealed behind the character combination displayed.

Display: Error status - axis
 In older software versions this entry is also called **Error profile generator** or **Error status 1**.
These labels are identical!

This display is shown in a hexadecimal numerical system. In 4.2.2 the plain text shows you which operating status lies concealed behind the character combination displayed.

3 Where are system and error messages displayed?

3.3.2 Messages from the motor controller

Screen mask: "Move axis"

The screenshot shows the 'ferrocontrol' software interface. At the top left is the 'ferrocontrol' logo. To its right is a document icon labeled 'Moveax_1.tif'. On the top right, there is a status bar showing 'Version 1.01 28.09.1998 14:12' and system information: 'SYS 47 Controller 2 not responding', 'PC', and 'FPS'. Below this is a 'Move axis' window with a title bar 'U 1.54 / 09.09.98'. The window is divided into several sections:

- Axis selection:** 'Axis 1.1 DARC axis' and 'X-Achse'.
- Operating mode:** 'Change Pos.1 (<) Pos.2'.
- Position data:** 'Position 1 1998.000 mm', 'Position 2 2000.000 mm', and 'Dwell time 0.000 s'.
- Speeds:** 'Traversing speed 1 %' and 'Jogging speed 1 %'.
- Test parameters:** 'Test amplitude 0' and 'Test pulse width 0'.
- Error status table:** A table with 10 rows and 2 columns. The first column lists error types, and the second column shows their status in hexadecimal.

Following error	0.000
Actual speed (rpm)	0
Actual torque	0
Act. posit. 2.encoder	0.000
Operational status axis	0000
Error status axis	0000
Hardware configuration	0000
Job counter axis	00
Error status MotCont	0000
Operational status MotCo.	0000
Heat sink temperature	0
Resolver offset	0
Status 2. encoder	00
Position pos. flank	0.000
Position neg. flank	0.000
Motor controller vers.	0000
Boot EPROM vers.	0000
Encoder interface version	0000
- Status bar:** A bar labeled 'Status' with a large empty space.
- Position displays:** Two large digital displays: 'Set position value 0.000' and 'Actual position 0.000'.
- Control buttons:** A row of 10 buttons: 1 Help, 2 Axis -1, 3 Axis +1, 4 Clear error, 5 Referen, 6 ON, 7 OFF, 8 << smaller, 9 >> greater, 10 OK.

Selection of the relevant axis

0 0 0 2
 Bit - 0...3
 Bit - 4...7
 Bit - 8...11
 Bit - 12...15

Display: Operating status - motor controller

In older software versions this entry is called **Status motor controller** or **Operating status 2**. These labels are identical!

Example: 0002
 5-volt voltage error

This display is shown in a hexadecimal numerical system. In 4.3.2 you can see in plain text which operating status lies concealed behind the character combination displayed.

Example 0200
 Stack error

Access to this screen mask:

1. Press the key combination [ALT] + [F1] -> ATEST
2. Select position 4 -ACTUAL VALUES-
3. Select the required axis
4. Press the [F4] key for details

Display: Error status - motor controller

In older software versions this entry is called **Error motor controller** or **error status 2**. These labels are identical!

This display is shown in a hexadecimal numerical system. In 4.3.1 the plain text shows you which operating status lies concealed behind the character combination displayed.

Further information about this screen mask:
 See Pos. 5.6


3 Where are system and error messages displayed?

Space for your own notes

4 What the system and error messages mean

4.1 System messages from the fieldbus system

Message no. 1 to 6



No.:	Message text / English	Tips for fault clearance	Additional information
1	No encoder value axis no.	<p>The axis listed is not receiving any actual position value (encoder value). This axis is not started but is stopped immediately!</p> <p>Check the encoder signal for this axis! For fault clearance aid see also: 4.2.1 Operating status axis Message: D8xx; No encoder value Check encoder cables!</p>	<p>This message also appears in the mask:</p> <p>Move axis Operating status axis Display: D8xx</p> <p>The pin configuration of the encoder cables can be found in Chapter 7</p>
2	Sluggish axis	<p>Following error During positioning the given set value is constantly compared with the encoder signal (position ACTUAL value). If an inadmissible deviation occurs, the axis is stopped immediately.</p> <p>For fault remedy see also: 4.2.1 Operating status axis Message: D9xx Axis sluggish</p>	<p>This message also appears in the mask:</p> <p>Move axis Operating status axis Display: D9xx (Hex)</p> <p>Error status axis Display: 4000</p>
4	Set value error axis no.:	<p>Error in given set value / measuring unit Your current set value is not within the permitted limits for axis positioning. The axis won't start. Check your set value setting / measuring unit</p>	<p>This message also appears in the mask:</p> <p>Move axis Operating status axis Display: DCxx Error status axis Display: 0080</p>
5	Axis no.: not initialized	<p>There are no valid axis parameters for this axis. Remedy: Reset the the fieldbus system! See also Pos. 2.2 Quick overview service menu: Initializing the system</p>	
6	Profile error axis no.:	<p>Message from the interpolator. The given contour can't be traversed with these parameters.</p> <p>Check your set speed value</p> <p>Entering the speed is performed in the user program</p>	<p>See also Position: 4.2.1 Operating status axis Display: DDxx (hex) 4.2.2 Error status axis Display: 0800 (hex)</p> <p>Mask: Move axis</p>

4 What the system and error messages mean

4.1 System messages from the fieldbus system

Message no. 7 to 25


U 2.20h	10.06.1997	9 49
SYS	47 Controller 2 is not responding	
PC		
FPS		

No.:	Message text / English	Tips for fault clearance	Additional information
7	Argument error axis no.:	<p>Incorrect interpolation data (e.g. radius = 0). The axis switches off immediately! The interpolation could not be performed because the speed at non-constant transitions was too high (negative circle radii). Remedy: 1. Check the interpolation data! 2. Exchange the interpolator board!</p>	<p>This message also appears in the mask: Move axis</p> <p>4.2.2 Error status axis Display: 2000</p>
8	System error FBIR axis no.:	<p>Axis switches off immediately! Remedy: Exchange interpolator for DARC or FBIR</p>	
9	Error current controller axis no.:	<p>Message from DARC controller (Current control processor) Remedy on location: exchange DARC</p>	
11	Quick-stop, positive axis no.:	<p>The quick-stop (+) input is set at zero. (Limit switch in positive direction) -> clockwise rotation</p>	<p>See Pos. 6.20 Pin configuration Axis regulation controller (X 1) See also circuit diagram in the appendix (last page) Pos. 22 / KL. X1 / 2 Pos. 23 / KL. X1 / 3</p>
12	Quick-stop, negative axis no.:	<p>The quick-stop (-) input is set at zero. (Limit switch in negative direction) -> anticlockwise rotation</p>	
13	Interpolation error group no.:	<p>Interpolation error message. You will find information about the cause of the error in the status message of the relevant interpolation group.</p>	
25	Axis no. inadmissible	<p>Check the axis number entry Your entry exceeds the max. permissible value. Maximum 63 axes!</p>	

4 What the system and error messages mean

4.1 System messages from the fieldbus system

Message no. 26 to 51



No.:	Message text / English	Tips for error clearance	Additional information
26	Error in axis parameter transmission	Configuration error, axis number possibly not entered.	
27	PLC start refused	PLC (Programmable Logic Control) has not been loaded. Possibly a file cannot be found when starting the PC program.	
28	Interpolation error controller	Erroneous transmission of the interpolation data from the PC to the FBIR board.	
34	PC; error not defined	Not defined	
47	Controller (x) is not responding	Proceed as follows: 1. Check the power supply to the controller. Check the fuse (F) on the controller board. If the green LED is on = OK. 2. Check the cable connection to the fieldbus system. If the red LED is not on = OK.	See Pos. 6.2 ... Fieldbus controller
48	Input does not exist	The input address does not exist in the system.	
49	Output does not exist	The output address does not exist in the system.	
50	Axis no.: does not exist	This axis does not exist in this configuration. The configuration data have not been loaded yet.	
51	No transmission enabling	Possible error causes: 1. Fieldbus not connected 2. Terminating resistor (terminator) is missing 3. No supply voltage at the fieldbus end 4. Fieldbus cable defective	Check supply voltage: See Pos. 6.1 ... Connector configuration Fieldbus cable: See Pos. 7.5

4 What the system and error messages mean

4.1 System messages from the fieldbus system

Message no. 52 to 58


U 2.20h	10.06.1997	9 49
SYS	47 Controller 2 is not responding	
PC		
FPS		

No.:	Message text / English	Tips for error clearance	Additional information
52	Status error	<p>Possible causes of error:</p> <ol style="list-style-type: none"> 1. Fieldbus not connected 2. Terminator is missing 3. No power voltage at the fieldbus end 4. Fieldbus cable defective 	<p>Check supply voltage: See Pos. 6.2 ... etc. Connector configuration Fieldbus cables: See Pos. 7.5</p>
54	Handshake error	<p>Software versions controller - FBI do not match.</p>	
55	Configuration error controller	<p>Error on Parallel bus Possible causes of error:</p> <ol style="list-style-type: none"> 1. The controller has not received any configuration data yet. 2. The voltage supply to the controller was briefly interrupted. 3. Error in the parallel connector 	<p>Info: Pos. 6.2 ... etc.</p>
56	Controller not ready to receive	<p>Check the configuration in the mask: Module addressing. Which DARC has not been entered? (Key F2 = Read configuration)</p>	<p>Mask: Module addressing See Pos. 5.3</p>
57	No acknowledge controller	<p>Check your configuration! Which controller has not been entered? No confirmation received for axis command. Error on the fieldbus, poss. incorrect software version.</p>	
58	Fieldbus error on controller	<p>Erroneous protocols, too many errors during data transfer!</p> <ol style="list-style-type: none"> 1. Make sure that the cable lengths in the fieldbus system have not been exceeded. Max. cable length = See Pos. 8.1 and 8.2 2. Make sure that the fieldbus cables are not damaged. Pay special attention to earthing and screen cables. 3. Hardware error controller board Exchange the controller board. 	<p>Notice! EMC If earthing and screen cables are defective or improperly connected, it can lead to EMC irradiation (and thus to defective data transfer)!</p> <p>Info EMC: See Manual CNC-Fieldbus Section: Commissioning</p>

4 What the system and error messages mean

4.1 System messages from the fieldbus system

Message no. 59 to 64



No.:	Message text / English	Tips for error clearance	Additional information
59	No interpolator	Your axis controller module does not have an interpolating function	
60	Timeout on controller	Erroneous data transfer on the fieldbus: 1. Check the cable and plug connectors. 2. Exchange the FBI board.	Connector configuratiuon fieldbus cable See Pos. 8.1 and 8.2
61	No digital controller	A special command for the digital axis controller was sent to another controller.	
62	Axis still has a job	The axis is still occupied and so no new job can be taken on at the moment. Notice! If necessary correct the positioning window in the parameter "Position control"	Info: Position control mask See Pos. 5.5.4 and manual DARC System Commissioning and Service Chapter 6.3.5.6
63	Incorrect interpolation group	This message appears: 1. if an incorrect interpolation group has been defined in the PLC. 2. if there is no interpolator.	
64	Watchdog elapsed	This message appears if the watchdog function has elapsed and the contact on the FBI board is open. Notice! Problems with the mains connection can also cause this message to be sent. If necessary exchange the FBI board.	Info: See Pos. 6.1

4 What the system and error messages mean

4.2 Messages from the axis controller

Mask: Select Move axis

The screenshot shows the 'ferrocontrol' software interface. At the top, it displays 'Version 1.01', '28.09.1998 14:12', and 'SYS 47 Controller 2 not responding'. The main window is titled 'Move axis' and shows parameters for 'Axis 1.1 DARC axis'. The 'Operating mod' is set to 'Change Pos.1 <> Pos.2'. The 'Set position value' and 'Actual position' are both displayed as '0.000'. A 'Following error' table is visible on the right side of the interface.

Following error	Value
Actual speed (rpm)	0
Actual torque	0
Act. posit. 2.encoder	0.000
Operational status axis	0000
Error status axis	0000
Hardware configuration	0000
Job counter axis	00
Error status MotCont	0000
Operational status MotCont	0000
Heat sink temperature	0
Resolver offset	0
Status 2. encoder	00
Position pos. flank	0.000
Position neg. flank	0.000
Motor controller vers.	0000
Boot EPROM vers.	0000
Encoder interface version	0000

At the bottom, there is a control bar with buttons: 1 Help, 2 Axis -1, 3 Axis +1, 4 Clear error, 5 Referen, 6 ON, 7 OFF, 8 << smaller, 9 >> greater, 10 OK.

Display: Operating status axis

In older software versions this entry is also called

Axis status or Operating status 1. These labels are identical!

This display is shown in a hexadecimal numerical system.

The four-digit display is divided into two groups (lower and upper byte).

Please note!

The four-digit display allows 2 to a maximum of 3 independent items of information to be displayed simultaneously

Example:

C 8 4 2
 └───┬───┬───┬───
 lower byte (1st group)
 upper byte (2nd group)

The display C 8 4 2 contains the following information:

C 8 X X = 1. Interpolation active
 X X 4 X = 2. Axis has been referenced
 X X X 2 = 3. Temperature monitoring / excess temperature

(X = any status)

4 What the system and error messages mean

4.2 Messages from the axis controller

4.2.1 Operating status axis

Error display	Description of error	Tips for error clearance	Additional information
xxx2	<p>TM (Temperature Monitoring) responds after 20 seconds</p> <p>Temperature monitoring is carried out in the power output of the power supply. This message is sent if the temperature measured is > 100 °C.</p>	<p>Possible causes of error</p> <p>a) Dimensional error, power requirement of the axis drive is too high. b) Ambient temperature too high. c) Current flow too high, possible short circuit, fine fault, earth fault</p> <p>Also check the messages:</p> <p>0004 Error status motor controller Short circuit, earth fault, excess current in the power circuit 0001 Error status axis Heat sink temperature too high</p>	<p>Manual DARC System Pos. 4-7.14</p>
xxx4 xxx8	<p>Axis is interpolating Axis stopped</p>	<p>Axis is interpolating Axis has been stopped (e.g. PLC).</p>	
xx1x xx2x xx4x	<p>Referencing is performed in this cycle Master referencing complete Axis referenced</p>	<p>Information about master referencing see -></p>	<p>Manual DARC System Pos. 6-3.5.1</p>
xx8x	<p>Automatic resolver adjustment complete</p>		
BBxx	<p>Positioning is active</p>		
C7xx	<p>Gearing active This axis is being led by a master axis. You can find the allocation to a master axis in the mask: Equipment and parameters Selection: Equipment</p>		
C8xx	<p>Interpolation active</p>		
C9xx	<p>Test mode active</p>		
CAxx	<p>Automatic resolver adjustment active</p>		
CBxx	<p>Torque control is active</p>		
CCxx	<p>Position control is active</p>	<p>You can switch on or off position control Mask: Move axis Softkeys: ON / OFF</p>	<p>Pos. 5.6.2 Mask: Move axis</p>
CDxx	<p>Axis is in defined window</p>		

4 What the system and error messages mean

4.2.1 Operating status axis

Error display	Description of error	Tips for error clearance	Additional information
CExx	Synchronous start has been prepared	only message	
CFxx	Position control inactive (disabled) (See also Message CCxx)	only message	
D1xx	Transmission error on DARC parallel bus		
D2xx	Temperature switch-off controller-		
D3xx	Temperature switch-off motor-		
D4xx	Motor controller error This message basically appears if an error message has been sent by the motor controller. You can find more detailed information about the state of the motor controller in: Error status - motor controller Operating status - motor controller	Notice! <i>In older software versions you will find the expression Error profile generator or Error status 1 instead of Error status axis. These messages are identical!</i>	
D5xx D6xx	Quick-stop positive Quick-stop negative		Pos. A.3 Circuit diagram in the appendix Pos. 6.20 X1 / Peripheral devices and holding brake
D7xx	Inadmissible nominal speed		
D8xx	No encoder value	Proceed as follows to remedy the cause: 1. Determine the encoder type in operation with this axis. You will find the allocation in the mask: Equipment and parameters Selection: Equipment a/ Resolver b/ Absolute position encoder DARC c/ Absolute position encoder Fieldbus SAE-IN d/ Incremental encoder DARC e/ Incremental encoder Fieldbus-INC 2. Proceed as follows depending on the encoder type: a/ Resolver Check the power connection between the DARC module and the resolver. Check that the plug-in connections are fixed firmly. -> Continued on next page...	Pos. 7.1 Pin configuration Resolver connection

4 What the system and error messages mean

4.2 Messages from the axis controller


4.2.1 Operating status axis

Error display	Description of error	Tips for error clearance	Additional information
D8xx	No encoder value /continued	<p>If it is possible, take a second resolver signal and plug it into the "faulty" DARC input. If you now get an encoder signal, the cause of the error can be found in the resolver or in its line terminal. Check the line connection to the "faulty" resolver with a resistance meter (ohmmeter).</p> <p>b/ Absolute position encoder / DARC system Check the line connection between the DARC module and the absolute position encoder. Make sure the plug-in connections are firmly fixed. If it is possible, take a second encoder signal (of the same type) and plug it into the "faulty" DARC input. If there now is an encoder signal, the error is to be found in the first encoder or its line terminal. Check the line connection to the "faulty" absolute position encoder with a resistance meter (ohmmeter).</p> <p>c/ Absolute position encoder Fieldbus system Check the following on the FB-SAE-IN module: 1. The operating voltage display LED 4 / green / $U_{OP} = 24\text{ V}$ 2. The fusible cutout = 1 A (time-lag) 3. Check LED 1, 2 and 3 for the encoder signal. If the line connection to the encoder = OK, the relevant LED glows a weak red. 4. Exchange the SAE-IN module</p> <p>d/ Incremental encoder / DARC system Check the line connection between the DARC module and the incremental encoder. Check that the pin connections are properly fixed. If it is possible, take a second encoder signal (of the same type) and plug it into the "faulty" DARC input. If there now is an encoder signal, the error is to be found in the first encoder or its line terminal. Check the line connection to the "faulty" incremental encoder with a resistance meter (ohmmeter).</p>	<p>Pos. 7.2 Pin configuration Absolute position encoder DARC input</p> <p>Pos. 6.10 Card diagram FB-SAE-IN</p> <p>Pos. 7.3 Pin configuration Incremental encoder -> DARC input</p>

4 What the system and error messages mean

4.2 Messages from the axis controller

4.2.1 Operating status axis

Error display	Description of error	Tips for error clearance	Additional information
D8xx	<p>No encoder value /continued</p>	<p>e/ Incremental encoder / Fieldbus system</p> <p>Check: The operating voltage display on the FB-INC-1 module = LED 3 (green), $U_{Op} = 24\text{ V}$. The fuse for operating voltage = 1 A (time-lag).</p> <p>If possible, take a second encoder signal (of the same type) and plug it into the "faulty" input of the INC-1 module. If you now have an encoder signal, the cause of the error can be found in the first encoder or in its line terminal. Check the line connection to the "faulty" incremental encoder with a resistance meter (ohmmeter).</p>	<p>Pos. 6.11 Card diagram FB-INC-1 Modul</p> <p>Pos. 7.3 Pin configuration Incremental encoder -> fieldbus system</p>
D9xx	<p>Sluggish axis During positioning the given set value is constantly compared with the encoder signal (actual position value). If an inadmissible deviation occurs here, it leads to this error message.</p> <p> Important notice</p> <p>This error message only appears if the monitoring function of the appropriate axis is switched on! Info: see preceding column</p> <p>Possible causes of this error are:</p> <ol style="list-style-type: none"> 1. Incorrect commissioning Incorrect setting-up of the controller Axis regulator parameters not correctly adjusted. 2. Interface connection to actual value encoder not O.K. Ageing / wear and tear of gears / slip Bearing play/ friction Servo-motor running with too great a load Servo-motor running with too small a load 	<p>Proceed as follows to determine the cause:</p> <p>Move the axis by hand in Service mode</p> <ol style="list-style-type: none"> 1. Select the Service mode 2. Select the mask: Move axis <p>Assistance: See also Menu overview, Pos. 2.2 See also Mask display, Pos. 5.6.1</p>	<p>Switch ON or OFF monitoring function</p> <ol style="list-style-type: none"> 1. Select mask: Equipment and parameters 2. Select: Position controller 3. Select position: Axis monitoring <p>See also Pos. 5.5.4</p>

4 What the system and error messages mean

4.2 Messages from the axis controller

4.2.1 Operating status axis

Error display	Description of error	Tips for error clearance	Additional information
DAxx	No axis parameters loaded		
DBxx	Axis not referenced		
DCxx	Set value limits exceeded Your set value input is outside the permissible limits for axis positioning.	Check your set value input	
DDxx	Axis profile error The stated contour can't be executed with these parameters This message also appears under Error status : 0800	See Error status axis: Message 0800 Notice! <i>In older software versions you will find the expression Error profile generator or also Error status 1 instead of the message line Error status axis. These messages are identical!</i>	
DExx	Internal error in the interpolator		
DFxx	Incorrect interpolation data		
E0xx	Error message from the supply controller (No enabling from the supply module)	Cause: D.c. link voltage not available! 1. Check the LED display: Uz on the DARC supply module. 2. Check the voltage supply L1 / L2 / L3 from the supply module Check the fuse!	Pos. 6.21 Diagram DARC supply module Pos. A.3 Circuit diagram in the appendix
E1xx	External enabling signal is missing	Check the (+ 24 volts) power supply for the enabling signal! Measuring point: DARC supply module Terminal X6 / No. 3	Pos. 6.21 Diagram DARC supply module

4 What the system and error messages mean

4.2 Messages from the axis controller

4.2.2 Error status: axis / Error profile generator / Error status 1

Screen mask:
Move axis

The screenshot shows the 'ferrocontrol' software interface for 'Move axis'. It includes a top status bar with version and date information, and a main control area with fields for axis selection, position, speed, and error status. A table on the right lists various error codes and their values, with 'Error status axis' highlighted.

Following error	Value
Actual speed (rpm)	0
Actual torque	0
Act. posit. 2.encoder	0.000
Operational status axis	0000
Error status axis	0000
Hardware configuration	0000
Job counter axis	00
Error status MotCont	0000
Operational status MotCont	0000
Heat sink temperature	0
Resolver offset	0
Status 2. encoder	00
Position pos. flank	0.000
Position neg. flank	0.000
Motor controller vers.	0000
Boot EPROM vers.	0000
Encoder interface version	0000

Status

Set position value: 0.000

Actual position: 0.000

1 Help 2 Axis -1 3 Axis +1 4 Clear error 5 Referen 6 ON 7 OFF 8 << smaller 9 >> greater 10 OK

Display: Error status - axis
In older software versions this entry is also called:
Error profile generator or Error status 1. These labels are identical!


This display is represented in a hexadecimal numerical system.

Error display	Description of error	Tips for error clearance	Additional information
0001	Heat sink temperature too high	Power output (in the power supply) too hot.	
0002	Motor temperature too high Axis is switched off after 30 seconds due to too high motor temperature. (Bimetallic contact -> motor)	Bimetallic contact, see Circuit diagram in the appendix (last page) Position 18. See also axis regulation controller diagram Pos. 6.20 (Terminal X1-1).	Pos. 6.20
0004	Error motor controller Causes the axis to be switched off immediately! This message also appears under Error status axis: 0800	You can find a detailed error description under Error status motor controller Notice! In older software versions you will find the expression Error profile generator or also Error status 1 instead of Error status axis . These messages are identical!	

4 What the system and error messages mean

4.2 Messages from the axis controller

4.2.2 Error status: axis / Error profile generator / Error status 1

Error display	Description of error	Tips for error clearance	Additional information
0008 0010	Quick-stop, negative Quick-stop, positive Causes immediate halt Can only be moved on in enabled direction.	See circuit diagram in the appendix (last page)	Pos. 6.20 DARC. X1 (Terminal 2 and 3)
0020	No parameters exist in axis module Effect: axis cannot be switched on.		
0040	Axis not referenced Thus only jogging, referencing and gearing are possible.		
0080	Set value error Axis switches off immediately.		
0200	Data error on the Parallel bus		
0400	No enabling from supply module		
0800	Profile error Axis switches off immediately. The stated contour can't be executed with these parameters.	Cause: 1. The speed selected for this profile is not possible. Check your speed setting. 2. Incorrect interpolation data. Exchange the axis controller card.	
1000	Internal error Axis switches off immediately.	Remedy: Exchange axis regulation controller.	Pos. 6.20
2000	Argument error Axis switches off immediately. Error in the interpolator.	Remedy: Exchange card with interpolator.	
4000	Following error (sluggish axis) Axis switches off immediately if the preset following error value has been exceeded.  Important notice This error message only appears if following error monitoring for this axis is turned on. Info: see preceding column.	See also Operating status - axis Message: D9xx Sluggish axis	Switch on and off following error monitoring: See Pos. 4.2.1 Operating status - axis Error message Sluggish axis
8000	Encoder error Axis switches off immediately. If an error "external encoder" occurs, only jogging is possible! See also Operating status - axis: D8xx No encoder value		

4 What the system and error messages mean


4.3 Messages from the motor controller

4.3.1 Error status motor controller

Screen mask:
Move axis

Display:
Error status
motor controller

This display is shown in
a hexadecimal numerical
system



Error display	Description of error	Tips for error clearance	Additional information
0001	Run-time / interrupt error If the program structure is disturbed, the axis is switched off.		
0002	5 Volt voltage error This causes immediate switch-off if the 5 volts operating voltage is not within the nominal range.	On location: exchange motor controller	
0004	Short circuit / earth contact / overcurrent in the power circuit Causes immediate switch-off to protect the power outputs.	If this error message occurs very frequently, the cause can also be an incorrect parameter input (gain-current controller). In this case reduce the gain by 10 %. 1. Select the mask: Equipment and parameters (see 2.2). 2. Press the key combination [Contr.] + [F4] (motor data). This mask appears: Motor / controller combination 3. Reduce the parameter: Current regulator: gain	
0008	Resolver error The axis module does not switch on if e.g. the resolver feedback is missing. The resolver feedback is checked after every first-time axis enabling (after reset).	Check: Cable and plug connections	Pos. 7.1 Pin configuration Resolver cable

4 What the system and error messages mean

4.3 Messages from the motor controller

4.3.1 Error status motor controller

Error display	Description of error	Tips for error clearance	Additional information
0010	Heat sink temperature in the controller exceeded	<ol style="list-style-type: none"> 1. Axis drive dimensioning correct? 2. Switching cabinet ventilation OK? Fan filter dirty? 3. Ambient temperature too high? 	
0020	Motor temperature exceeded Bimetallic contact in the motor has triggered.	x-1 terminal (motor temperature)	Pos. A.3 / Circuit diagram in the appendix: (18)
0080	Current measuring adjustment error Causes immediate switch-off.	Diagnostic aid for ferrocontrol testing station	
0100	IGBT - Output switch-off Causes immediate switch-off.	IGBT excess current, e.g. due to incorrect motor parameters Remedy on location: Exchange motor controller module	
0200	Stack error Causes immediate switch-off.	Stack overflow in the motor controller Remedy on location: Exchange motor controller module	
0400	The permissible speed deviation has been exceeded Causes immediate switch-off.	Correct the preset value for the permitted speed deviation. In the axis parameters select the mask: Equipment and parameters . Press the key combination [Ctrl] + [F4] = Motor data. This mask appears on the screen: Motor controller combination . Set the parameter: Switch-off threshold - speed monitoring to the value = 0.	
0800	Run-time error in the speed controller		
1000	RAM test error After every reset the communication RAM in the axis module is checked. If the result is negative, the axis controller cannot be switched on.	Remedy on location: Exchange motor controller module	
2000	Error in digital transformer -> resolver After every reset the digital converter in the resolver is checked. If the result is negative, the axis controller cannot be switched on.		
4000	Bit checking error in the resolver After every reset the microcontroller databus is checked by the resolver in the axis module. If the result is negative, the axis controller cannot be switched on.	The digital transformer can be found on the motor controller module Remedy on location: Exchange motor controller module	
8000	Synchronous error Causes immediate switch-off. Signal transmission error on the internal Parallel bus.	Check the plug-in connector (X30) on the top side of the DARC.	Pos. 6.20 Pos. 6.21 DARC diagram

4 What the system and error messages mean

4.3 Messages from the motor controller

4.3.2 Operating status motor controller / *Status Motor controller / Operating status 2*

Screen mask:
Move axis

ferrocontrol		Version 1.01 28.09.1998 14:12
Moveax_1.tif		SYS 47 Controller 2 not responding
		PC
		FPS

Move axis		U 1.54 / 09.09.98
Axis	1.1 DARC axis	
X-Achse		
Operating mod	Change Pos.1 <> Pos.2	
Position 1	1998.000 mm	
Position 2	2000.000 mm	
Dwell time	0.000 s	
Traversing speed	1 %	
Jogging speed	1 %	
Test amplitude	0	
Test pulse width	0	

Following error	0.000
Actual speed (rpm)	0
Actual torque	0
Act. posit. 2.encoder	0.000
Operational status axis	0000
Error status axis	0000
Hardware configuration	0000
Job counter axis	00
Error status MotCont	0000
Operational status MotCont	0000
Heat sink temperature	0
Resolver offset	0
Status 2. encoder	00
Position pos. flank	0.000
Position neg. flank	0.000
Motor controller vers.	0000
Boot EPROM vers.	0000
Encoder interface version	0000

Status	

Set position value	Actual position
0.000	0.000

1 Help	2 Axis -1	3 Axis +1	4 Clear error	5 Referen	6 ON	7 OFF	8 << smaller	9 >> greater	10 OK
--------	-----------	-----------	---------------	-----------	------	-------	--------------	--------------	-------

Display: Operating status - motor controller

In older software versions this entry is called

Status motor controller or **Operating status 2**.

These labels are identical!

This display is shown in a hexadecimal numerical system

4 What the system and error messages mean

4.3 Messages from the motor controller

4.3.2 Operating status motor controller

Error display	Description of error	Tips for error clearance	Additional information
▶ 0000	Output is switched off (disabled) See also Message 0040 = Output is switched on.		
0001	In the last position control cycle a negative measuring edge was detected.	You can find more information in the DARC system manual Pos. 4.4.15 Control in- and outputs	DARC System Manual Pos. 4.4.15
0002	In the last position control cycle a positive measuring edge was detected.		
0008	Level at measuring input Diagnostic aid for ferrocontrol testing station		
0010	Warning! Heat sink temperature exceeded	Power supply temperature too high	
0020	Warning! Motor temperature exceeded	Check motor bimetallic contact	See circuit diagram in the appendix: A.3
0040	Output is switched on (enabled) See also message 0000 = Output is switched off		
0080	Only for ferrocontrol testing station Causes immediate switch-off		
0100	Peak current limiting is active (only status message)		
0200	Nominal current limiting is active (only status message)		
1000	Enable-PIN input is set	Contact X6 (Terminal 3) is set. DARC power supply See Pos. 6.21	DARC system manual Pos. 4.4.15
2000	Only for ferrocontrol testing station		
8000	Automatic resolver adjustment (only status message)	Enable software in the communication RAM is set.	

4 What the system and error messages mean

Space for your own notes

Access to this mask:

See under 2.2
Overview service menu

ferrocontrol | inputs_1.tif | Version 1.01 18.09.1998 12 25
SYS 47 Controller 2 not responding
PC
FPS

Inputs | Bank 0

00h	0 1 2 3 4 5 6 7	8 9 A B C D E F	10h	0 1 2 3 4 5 6 7	8 9 A B C D E F
20h	0 1 2 3 4 5 6 7	8 9 A B C D E F	30h	0 1 2 3 4 5 6 7	8 9 A B C D E F
40h	0 1 2 3 4 5 6 7	8 9 A B C D E F	50h	0 1 2 3 4 5 6 7	8 9 A B C D E F
60h	0 1 2 3 4 5 6 7	8 9 A B C D E F	70h	0 1 2 3 4 5 6 7	8 9 A B C D E F
80h	0 1 2 3 4 5 6 7	8 9 A B C D E F	90h	0 1 2 3 4 5 6 7	8 9 A B C D E F
A0h	0 1 2 3 4 5 6 7	8 9 A B C D E F	B0h	0 1 2 3 4 5 6 7	8 9 A B C D E F
C0h	0 1 2 3 4 5 6 7	8 9 A B C D E F	D0h	0 1 2 3 4 5 6 7	8 9 A B C D E F
E0h	0 1 2 3 4 5 6 7	8 9 A B C D E F	F0h	0 1 2 3 4 5 6 7	8 9 A B C D E F

1 He 1p | 2 | 3 | 4 | 5 TEXT | 6 Bank - 1 | 7 Bank + 1 | 8 | 9 | 10 OK

Text
Filed application-related commentary (allocation in plain text) for this input

Status display - input
Green = logical ON
Grey = logical OFF

Hardware:



Input module / 16 inputs / binary
see Pos. 6.4

5 Screen masks

5.2 Binary outputs

Access to this mask:

See under [2.2](#)
Overview service menu



Hardware:

Output module / 16 outputs / binary
see [Pos. 6.5](#)

Access to this mask:

See under 2.2
Overview service menu

ferrocontrol Modad_1.tif Version 1.01 18.09.1998 12 27
SYS 47 Controller 1 not responding
PC
FPS

Module address

FBI board 1 Segment SDA00 Version 04.39
Fieldbus baud rate 500 kbit/s

Controller No. Type
1 DARC IP
2 DARC IP
3
4
5
6
7
8
9
10
11
12
13
14
15
16

DARC with INTERPOLATOR UMDR 62.21

Name	Mark	Adresses			
		1	2	3	4
16 Outputs	OUT 16	0	0	0	0
DARC axis		1	0	0	0
DARC axis		9	0	0	0
DARC axis		11	0	0	0
DARC axis		16	0	0	0
DARC axis		2	0	0	0
DARC axis		5	0	0	0
		0	0	0	0
		0	0	0	0
		0	0	0	0

1 Help 2 Read config. 3 Reset error 4 Load all 5 6 7 8 Select 9 10 OK



Attention!
Do not activate the function "LOAD ALL" (Key F4) rashly then ...

Select

Here you can enter your configuration data manually.

Load all

The displayed configuration data are taken over as valid. **The previously valid data record (on the hard disk) is overwritten!!**

Reset - error

Resets the error display.

Read configuration (key F2)

A) Key not yet pressed:

The device configuration displayed is based on a filed data record (hard disk)

B) Press key:

The **current operating status** is read again and updated on the screen. **A possible functionally disturbed bus participant (controller) will no longer be listed in the updated display!**

Proceed as follows when looking for the malfunction:

1. Before you press [F2] make a note of the device configuration displayed.
2. Press [F2]. Compare the updated display with your notes.
3. A defective bus participant **does not appear** in the current display.

5 Screen masks

5.4 Select axis

Access to this mask:

See under [2.2](#)
Overview service menu

The screenshot shows a terminal window with the following information:

- Header: ferrocontrol selax_1.tif Version 1.01 18.09.1998 12 29
- Status: SYS 47 Controller 2 not responding
- PC: [blank]
- FPS: [blank]

The main area is titled "Select axis" and contains a table:

Axis		Axis type	Axis name	Gantry axes
1.1	<input checked="" type="checkbox"/>	DARC axis	X-Achse	
1.3	<input checked="" type="checkbox"/>	Direction axis	X-Achse	
1.9	<input checked="" type="checkbox"/>	DARC axis	X-Achse	
2.1	<input checked="" type="checkbox"/>	Servo axis	Y-Achse	
2.2	<input type="checkbox"/>	DARC axis	Y-Achse	
3.1	<input type="checkbox"/>	DARC axis	Z-Achse	
4.1	<input type="checkbox"/>	Servo axis	Kommentartext aus FPS-Ac	
5.1	<input checked="" type="checkbox"/>	DARC axis	Kommentartext aus FPS-Ac	
9.1	<input checked="" type="checkbox"/>	DARC axis		
16.1	<input checked="" type="checkbox"/>	DARC axis		
18.1	<input type="checkbox"/>	UMDR master axis		
	<input type="checkbox"/>			
	<input type="checkbox"/>			
	<input type="checkbox"/>			
	<input type="checkbox"/>			

Below the table is an "Input:" field.

The bottom navigation bar contains 10 buttons:

- 1 Help
- 2 Increment search
- 3
- 4
- 5
- 6 Abort
- 7
- 8
- 9
- 10 OK


Select axis

If you want to alter the configuration of a particular axis, you receive access via this mask.

Use the cursor to select the desired mask.

Access to this mask:

See under [2.2](#)
Overview service menu



Select: Equipment

Allocation between the axis regulation controller and a motor type is made in this mask.

Notice!

Configuration parameters for determining the control characteristics for the individual motor types are filed by ferrocontrol. These configuration data are adopted and applied by the axis regulation controller.

You can find more information in the ferrocontrol manual:

DARC System - Commissioning and Service / [Chapter 6.3.5](#)

Brake holding time:

The brake holding time is the time between the brake contact opening and the switch-off moment of the motor current. It must correspond to the switch-off delay time of the brake release coil. This ensures that hanging axes do not sag.

Enter **0 ms** without a holding brake, and with a holding brake enter **50 ms** as the application time of standard holding brakes is about 50 ms.

5 Screen masks

5.5 Axis equipment and parameters

5.5.2 Select: Resolver

Access to this mask:

See under [2.2](#)
Overview service menu

The screenshot displays the 'ferrocontrol' software interface. At the top, there is a status bar with the logo 'ferrocontrol', a file icon labeled 'Epres_1.tif', and system information: 'Version 1.01 18.09.1998 12:31'. Below this, a table shows 'SYS 47 Controller 2 not responding', 'PC', and 'FPS'. The main interface is titled 'Equipment and parameters' and includes a 'Select' menu with options like 'Equipment', 'Resolver', 'Motion profile', 'Position control', 'Speed control', '2. encoder: absolute value', 'Referencing', 'Current limitation', 'Analog input', 'Gantry axis', 'Quick-stop', and 'Synchronous motion'. An arrow points to the 'Resolver' option. The 'Resolver' section shows parameters: 'Distance/motor revolution' (16.0000 mm), 'Counting direction' (neg.), 'Encoder offset' (0.000 mm), 'Modulo axis' (NO), 'Minimum modulo value' (0.000), and 'Maximum modulo value' (0.000). The 'Actual position' is shown as 0.000. A bottom navigation bar contains keys: 1 Help, 2 Axis -1, 3 Axis +1, 4 Clear error, 5 Load axis, 6 Check record, 7, 8, 9, 10 OK.

Select: Resolver

The selection of the resolver settings is made in this mask

Notice!

You can find more information in the ferrocontrol manual:
DARC System - Commissioning and Service / [Chapter 6.3.5.4](#)

Encoder offset:

In this input field you are able to set a new absolute value (desired actual value).

Proceed as follows:

1. Place the cursor on the field: **Encoder offset**.
2. Press the **Enter key**.
This mask appears: **Input absolute value**
3. Enter your desired value.

When the [F10] key is pressed, the value entered is adopted and stored as the new absolute actual value.

Access to this mask:

See under [2.2](#)
Overview service menu

The screenshot shows the 'ferrocontrol' software interface. At the top, there is a title bar with the logo and a file icon labeled 'Epmot_1.tif'. To the right, a status bar displays 'Version 1.01 18.09.1998 12 32' and system status: 'SYS 47 Controller 2 not responding', 'PC', and 'FPS'. The main window is titled 'Equipment and parameters' and 'Version 2.46 / 09.09.98'. It is divided into several sections:

- Equipment and parameters:**
 - Axis: 1.1 (Axis active)
 - Type: DARC axis
 - Encode: 2. encoder: absolute v
- Select:** A list of menu items with 'Motion profile' highlighted and indicated by a black arrow.
 - Equipment
 - Resolver
 - Motion profile**
 - Position control
 - Speed control
 - 2. encoder: absolute value
 - Referencing
 - Current limitation
 - Analog input
 - Gantry axis
 - Quick-stop
 - Synchronous motion
- Motion profile:** A table of parameters:

Minimum nominal position	0.000 mm
Maximum nominal position	1000.000 mm
Motion profile	linear
Starting-up time	340 ms
Braking time	600 ms
Maximum speed	800.000 mm/s
Limited speed	0.000 mm/s
User window	10.000 mm
Loop value	3.000 mm
Override pot. active	NO
Short distance jolt limiting	NO
Return outside limits	NO
- Actual position:** A display showing '0.000'.

At the bottom, a navigation bar contains 10 buttons: 1 Help, 2 Axis -1, 3 Axis +1, 4 Clear error, 5 Load axis, 6 Check record, 7, 8, 9, and 10 OK.

Select: Motion profile

Notice!

You can find more information in the ferrocontrol manual:

DARC System - Commissioning and Service / [Chapter 6.3.5.5](#)

5 Screen masks

5.5 Axis equipment and parameters

5.5.4 Select: Position control

Access to this
mask:

See under [2.2](#)
Overview service menu

The screenshot displays the 'ferrocontrol' software interface. At the top, there is a status bar with 'Version 1.01 18.09.1998 12 32' and 'SYS 47 Controller 2 not responding'. Below this, the 'Equipment and parameters' screen is active, showing 'Axis 1.1' and 'Type DARC axis'. The 'Select' menu on the left has 'Position control' highlighted, indicated by an arrow. The 'Position control' parameters are as follows:

Parameter	Value	Unit
Servo-gain factor	1.200	m/min
Without following error	NO	
Distance correction	NO	
Distance correction value	300.000	
Completed message	Meas. val.	
Positioning window	0.000	mm
Axis monitoring	ON	
Deactivate when maximum following error is exceeded	YES	
Error reaction	Quick-stop	
Maximum following error	4.000	mm
Pos. control after crawling	NO	
IPL resonance filter	OFF	

The bottom of the screen features a navigation bar with buttons: 1 Help, 2 Axis -1, 3 Axis +1, 4 Clear error, 5 Load axis, 6 Check record, 7, 8, 9, and 10 OK.

Select: Position control


Notice!

You can find more information in the ferrocontrol manual:
DARC System - Commissioning and Service / [Chapter 6.3.5.6](#)

5.5 Axis equipment and parameters 5.5.5 Select: Speed control

Access to this mask:

See under [2.2](#)
Overview service menu



Select: Speed control

Notice!

You can find more information in the ferrocontrol manual:
DARC System - Commissioning and Service / [Chapter 6.3.5.7](#)

5 Screen masks

5.5 Axis equipment and parameters

5.5.6 Select: External absolute position encoder

Access to this mask:

See under [2.2](#)
Overview service menu

The screenshot displays the 'ferrocontrol' software interface. At the top, there is a header bar with the logo, a file icon labeled '2enc_1.tif', and system information including 'Version 1.01', '18.09.1998', '12:35', and status messages for 'SYS', 'PC', and 'FPS'. The main window is titled 'Equipment and parameters' and is divided into several sections. On the left, a 'Select' menu lists various options, with '2. encoder: absolute value' highlighted and an arrow pointing to it. Below this menu is a field for 'Actual position' showing '0.000'. The right side of the screen shows parameters for the selected encoder, including 'Encoder resolution' (4096x 1), 'Distance/encoder revolution' (421.426 mm), 'Counting direction' (neg.), 'Encoder offset' (0.000 mm), 'Zero offset' (200.000 mm), and 'Position control from 2. enc' (NO). A bottom toolbar contains numbered buttons: 1 Help, 2 Axis -1, 3 Axis +1, 4 Clear error, 5 Load axis, 6 Check record, 7, 8 Select, 9, and 10 OK.


Select: External absolute position encoder

Notice!

You can find more information in the ferrocontrol manual:
DARC System - Commissioning and Service / [Chapter 6.3.5.8](#)

Access to this mask:

See under [2.2](#)
Overview service menu



Select: Referencing

Notice!

You can find more information in the ferrocontrol manual:

DARC System - Commissioning and Service / [Chapter 6.3.5.9](#)

5 Screen masks

5.5 Axis equipment and parameters

5.5.8 Select: Current limitation

Access to this mask:

See under [2.2](#)
Overview service menu

The screenshot displays the 'ferrocontrol' software interface. At the top left, the logo 'ferrocontrol' is visible. The top right corner shows system information: 'Version 1.01 18.09.1998 12:37', 'SYS 47 Controller 2 not responding', 'PC', and 'FPS'. Below this, a file icon labeled 'Epcurr_1.tif' is shown. The main window is titled 'Equipment and parameters' and contains several sections:

- Axis information:** Axis 1.1, Axis active, Type DARC axis, Encode 2. encoder: absolute v.
- Select menu:** A list of options including Equipment, Resolver, Motion profile, Position control, Speed control, 2. encoder: absolute value, Referencing, **Current limitation** (highlighted with a black arrow), Analog input, Gantry axis, Quick-stop, and Synchronous motion.
- Actual position:** A display showing '0.000'.
- Current limitation parameters:** Peak current limit set to 100 % and Noninal current limit set to 50 %.
- X-Achse details:** Last changer 18.09.1998 / 12:12, Fieldbus controller: DARC IP, Encoder mod.: DARC, Output mod.:

At the bottom, a navigation bar contains 10 buttons: 1 Help, 2 Axis -1, 3 Axis +1, 4 Clear error, 5 Load axis, 6 Check record, 7, 8, 9, and 10 OK.

Select: Current limitation

Notice!


You can find more information in the ferrocontrol manual:

DARC System - Commissioning and Service / [Chapter 6.3.5.10](#)

5.5 Axis equipment and parameters 5.5.9 Select: Analog input

Access to this mask:

See under [2.2](#)
Overview service menu



Select: Analog input

Notice!

You can find more information in the ferrocontrol manual:

DARC System - Commissioning and Service / [Chapter 6.3.5.11](#)

5 Screen masks

5.5 Axis equipment and parameters

5.5.10 Select: Gantry axis

Access to this
mask:

See under [2.2](#)
Overview service menu

The screenshot displays the 'ferrocontrol' software interface. At the top, there is a header bar with the logo, a file icon labeled 'Epgaax_1.tif', and system information: 'Version 1.01 18.09.1998 12:39'. Below this, a status bar shows 'SYS 47 Controller 2 not responding', 'PC', and 'FPS'. The main window is titled 'Equipment and parameters' and contains several sections:

- Equipment and parameters:** A sub-header for the main configuration area.
- Axis:** '1.1' with a status 'Axis active'.
- Type:** 'DARC axis'.
- Encode:** '2. encoder: absolute v'.
- Select:** A list of menu items including 'Equipment', 'Resolver', 'Motion profile', 'Position control', 'Speed control', '2. encoder: absolute value', 'Referencing', 'Current limitation', 'Analog input', 'Gantry axis' (highlighted with a black arrow), 'Quick-stop', and 'Synchronous motion'.
- Actual position:** A display showing '0.000'.
- X-Achse:** A section with 'Last changer: 18.09.1998 / 12:12', 'Fieldbus controller: DARC IP', 'Encoder mod.: DARC', and 'Output mod.:'. Below this is a 'Gantry axis' section with a 'Gantry axis' field containing './.', a 'Master axis' field containing '0', and an 'Allowed offset in act.vals' field containing '0.000 mm'. A 'Gantry mode with' field is also present.

At the bottom, there is a navigation bar with 10 buttons: 1 Help, 2 Axis -1, 3 Axis +1, 4 Clear error, 5 Load axis, 6 Check record, 7, 8, 9, and 10 OK.

Select: Gantry axis


Notice!

You can find more information in the ferrocontrol manual:

DARC System - Commissioning and Service / [Chapter 6.3.5.12](#)

Access to this mask:

See under [2.2](#)
Overview service menu



Select: Quick-stop

Notice!

You can find more information in the ferrocontrol manual:

DARC System - Commissioning and Service / [Chapter 6.3.5.13](#)

5 Screen masks

5.5 Axis equipment and parameters

5.5.12 Select: Synchronous motion

Access to this
mask:

See under [2.2](#)
Overview service menu

The screenshot displays the 'ferrocontrol' software interface. At the top, there is a header bar with the logo, a file icon labeled 'Epsynm_1.tif', and system information: 'Version 1.01 18.09.1998 12:41'. Below this, a status bar shows 'SYS 47 Controller 2 not responding', 'PC', and 'FPS'. The main window is titled 'Equipment and parameters' and contains several sections:

- Axis information:** Axis 1.1, Axis active, Type DARC axis, Encode 2, encoder: absolute v.
- Select menu:** A list of options including Equipment, Resolver, Motion profile, Position control, Speed control, 2. encoder: absolute value, Referencing, Current limitation, Analog input, Gantry axis, Quick-stop, and Synchronous motion (highlighted with a black arrow).
- Actual position:** A display showing 0.000.
- X-Achse parameters:** Last changer: 18.09.1998 / 12:12, Fieldbus controller: DARC IP, Encoder mod.: DARC, Output mod.:
- Synchronous motion parameters:** Window position (0.000 mm), (reserved) (100.000), (reserved) (100), (reserved) (0.000), Distance to rendezvous (0.000 mm), End position monitoring (OFF), End position (0.000 mm), Synchronous motion factor (1.00000000).

At the bottom, there is a navigation bar with 10 buttons: 1 Help, 2 Axis -1, 3 Axis +1, 4 Clear error, 5 Load axis, 6 Check record, 7, 8, 9, and 10 OK.

Select: Synchronous motion

Notice!

You can find more information in the ferrocontrol manual:

DARC System - Commissioning and Service / [Chapter 6.3.5.14](#)

Access to this mask:

See under 2.2
Overview service menu

Moveax_1.tif

Version 1.01 28.09.1998 14:12
 SYS 47 Controller 2 not responding
 PC
 FPS

Move axis

Axis DARC axis

X-Achse

Operating mod Pos.1 <> Pos.2

Position 1 mm

Position 2 mm

Dwell time s

Traversing speed %

Jogging speed %

Test amplitude

Test pulse width

Following error	0.000
Actual speed (rpm)	0
Actual torque	0
Act. posit. 2.encoder	0.000
Operational status axis	0000
Error status axis	0000
Hardware configuration	0000
Job counter axis	00
Error status MotCont	0000
Operational status MotCont	0000
Heat sink temperature	0
Resolver offset	0
Status 2. encoder	00
Position pos. flank	0.000
Position neg. flank	0.000
Motor controller vers.	0000
Boot EPROM vers.	0000
Encoder interface version	0000

Status

Set position value

0.000

Actual position

0.000

1 Help

2 Axis -1

3 Axis +1

4 Clear error

5 Referen

6 ON

7 OFF

8 << smaller

9 >> greater

10 OK

In older software versions you will come across variant names for the following data fields:

<table style="width: 100%; border-collapse: collapse;"> <tr><td>Following error</td><td style="text-align: right;">0.000</td></tr> <tr><td>Actual speed (rpm)</td><td style="text-align: right;">0</td></tr> <tr><td>Actual torque</td><td style="text-align: right;">0</td></tr> <tr><td>Act. posit. 2.encoder</td><td style="text-align: right;">0.000</td></tr> <tr><td>Operational status axis</td><td style="text-align: right;">0000</td></tr> <tr><td>Error status axis</td><td style="text-align: right;">0000</td></tr> <tr><td>Hardware configuration</td><td style="text-align: right;">0000</td></tr> <tr><td>Job counter axis</td><td style="text-align: right;">00</td></tr> <tr><td>Error status MotCont</td><td style="text-align: right;">0000</td></tr> <tr><td>Operational status MotCont</td><td style="text-align: right;">0000</td></tr> <tr><td>Heat sink temperature</td><td style="text-align: right;">0</td></tr> <tr><td>Resolver offset</td><td style="text-align: right;">0</td></tr> <tr><td>Status 2. encoder</td><td style="text-align: right;">00</td></tr> <tr><td>Position pos. flank</td><td style="text-align: right;">0.000</td></tr> <tr><td>Position neg. flank</td><td style="text-align: right;">0.000</td></tr> <tr><td>Motor controller vers.</td><td style="text-align: right;">0000</td></tr> <tr><td>Boot EPROM vers.</td><td style="text-align: right;">0000</td></tr> <tr><td>Encoder interface version</td><td style="text-align: right;">0000</td></tr> </table>	Following error	0.000	Actual speed (rpm)	0	Actual torque	0	Act. posit. 2.encoder	0.000	Operational status axis	0000	Error status axis	0000	Hardware configuration	0000	Job counter axis	00	Error status MotCont	0000	Operational status MotCont	0000	Heat sink temperature	0	Resolver offset	0	Status 2. encoder	00	Position pos. flank	0.000	Position neg. flank	0.000	Motor controller vers.	0000	Boot EPROM vers.	0000	Encoder interface version	0000	<p>Old name</p> <div style="border: 1px solid gray; padding: 5px; margin-bottom: 10px; width: fit-content;"> Axis status Operating status 1 </div> <div style="border: 1px solid gray; padding: 5px; margin-bottom: 10px; width: fit-content;"> Profile generator Error status 1 </div> <div style="border: 1px solid gray; padding: 5px; margin-bottom: 10px; width: fit-content;"> INIT status </div> <div style="border: 1px solid gray; padding: 5px; margin-bottom: 10px; width: fit-content;"> Error motor controller Error status 2 </div> <div style="border: 1px solid gray; padding: 5px; width: fit-content;"> Status motor controller Operating status 2 </div>
Following error	0.000																																				
Actual speed (rpm)	0																																				
Actual torque	0																																				
Act. posit. 2.encoder	0.000																																				
Operational status axis	0000																																				
Error status axis	0000																																				
Hardware configuration	0000																																				
Job counter axis	00																																				
Error status MotCont	0000																																				
Operational status MotCont	0000																																				
Heat sink temperature	0																																				
Resolver offset	0																																				
Status 2. encoder	00																																				
Position pos. flank	0.000																																				
Position neg. flank	0.000																																				
Motor controller vers.	0000																																				
Boot EPROM vers.	0000																																				
Encoder interface version	0000																																				

5 Screen masks

5.6 Move axis

5.6.1 Select: Mode of operation

Access to this mask:

See under [2.2](#)
Overview service menu

The screenshot shows the 'ferrocontrol' interface for 'Move axis'. At the top, it displays 'Version 1.01', '28.09.1998 14:12', and system status 'SYS 47 Controller 2 not responding'. The main screen is divided into several sections:

- Move axis:** Shows 'Axis 1.1 DARC axis' and 'X-Achse'.
- Operating mod:** Includes 'Change Pos.1 <> Pos.2', 'Position 1: 1998.000 mm', 'Position 2: 2000.000 mm', and 'Dwell time: 0.000 s'.
- Speeds:** 'Traversing speed' and 'Jogging speed' are both set to 1%.
- Test parameters:** 'Test amplitude' and 'Test pulse width' are both set to 0.
- Status:** A field for displaying the current status.
- Set position value:** A large display showing '0.000'.
- Actual position:** A large display showing '0.000'.
- Mode of operation menu:** A list of 10 options:
 - 0 Start at Position 1
 - 1 ChangePos. 1 <> Pos. 2
 - 2 Start Pos.1 / G86
 - 3 Change 1 <-> 2 / G68
 - 4 Follow analog input
 - 5 Torque control
 - 6 Jump function
 - 7 Reversing
 - 8 Resolver adjustment
 - 9 Start Pos. 1 / G91
- Control Panel:** A row of 10 buttons: 1 Help, 2 Axis -1, 3 Axis +1, 4 Clear error, 5 Referen, 6 ON, 7 OFF, 8 Select, 9 >> greater, 10 OK.

An arrow points from the 'Select' button (8) to a box labeled 'Select - Mode of operation', which in turn points to the 'Mode of operation' menu.

Select: Mode of operation

Start auf Position 1

If the **START** key is pressed, the axis moves at the preset traversing speed to the set value in the input window of Position 1.

Change Pos 1 <> Pos 2

If the **START** key is pressed, the axis moves at the preset traversing speed between the set values in the input window of Position 1 and Position 2.

Resolver adjustment

See ferrocontrol manual:

DARC System - Commissioning and Service / [Chapter 6.4.7](#)

Access to this mask:

See under [2.2](#)
Overview service menu

The screenshot shows the 'ferrocontrol' interface for 'Move axis'. The top bar includes the logo, a file icon labeled 'Moveax_1.tif', and system information: 'Version 1.01 28.09.1998 14:12'. Below this, a status table shows 'SYS 47 Controller 2 not responding', 'PC', and 'FPS'. The main area is titled 'Move axis' and contains several sections:

- Axis selection:** 'Axis 1.1 DARC axis' and 'X-Achse'.
- Operating mode:** 'Change Pos.1 (<) Pos.2'.
- Position settings:** 'Position 1 1998.000 mm', 'Position 2 2000.000 mm', and 'Dwell time 0.000 s'.
- Speed settings:** 'Traversing speed 1 %' and 'Jogging speed 1 %'.
- Test parameters:** 'Test amplitude 0' and 'Test pulse width 0'.
- Following error table:**

Following error	0.000
Actual speed (rpm)	0
Actual torque	0
Act. posit. 2.encoder	0.000
Operational status axis	0000
Error status axis	0000
Hardware configuration	0000
Job counter axis	00
Error status MotCont	0000
Operational status MotCont	0000
Heat sink temperature	0
Resolver offset	0
Status 2. encoder	00
Position pos. flank	0.000
Position neg. flank	0.000
Motor controller vers.	0000
Boot EPROM vers.	0000
Encoder interface version	0000
- Status:** A large empty box.
- Set position value:** A large display showing '0.000'.
- Actual position:** A large display showing '0.000'.
- Control buttons:** A row of 10 buttons: 1 Help, 2 Axis -1, 3 Axis +1, 4 Clear error, 5 Referen, 6 ON, 7 OFF, 8 << smaller, 9 >> greater, 10 OK.

Callouts from the buttons:

- Axis -1:** Select axis
- Axis +1:** Select axis
- Referen:** Perform referencing
- ON:** Position control (ON - enable, OFF - disable). INFO: Position control DARC - System Commissioning and Service 6.3.5.6
- OFF:** Position control (ON - enable, OFF - disable). INFO: Position control DARC - System Commissioning and Service 6.3.5.6
- << smaller:** Inching mode, only in jogging mode
- >> greater:** Inching mode, only in jogging mode
- STOP:** The function can be aborted with STOP.

Traversing speed in inching mode



The axis traverses at the preset reduced (by percentage) speed shown in the **Jogging speed** window.

5 Screen masks

Space for your own notes

6 Functional modules in the Fieldbus system

6.1 FBI-PC, Fieldbus interface card for IBM computers



Addressing:

Possible segment addresses in PC: C000 h - EF00 h
Settable via jumper field: address

Address	Jumper:	9	8	7	6	5	4	3	2	
0C000 h	=	0	0	X	X	X	X	X	X	X = Jumper plugged in 0 = Jumper open
0C100 h	=	0	0	X	X	X	X	X	0	Jumper 8 and 9 remain open!
0C200 h	=	0	0	X	X	X	X	0	X	
0C300 h	=	0	0	X	X	X	X	0	0	
0C400 h	=	0	0	X	X	X	0	X	X	
... ..										
FD00 h	=	0	0	0	0	0	0	X	0	
FE00 h	=	0	0	0	0	0	0	0	X	
FF00 h	=	0	0	0	0	0	0	0	0	
DA00 h	=	0	0	X	0	0	X	0	X	/ Factory setting



Select Interrupt (IRQ) :

Settable via jumper field: IRQ

IRQ	Jumper:	2	3	4	5	6	7	
IRQ-2	=	X	0	0	0	0	0	X = Jumper plugged in 0 = Jumper open
IRQ-3	=	0	X	0	0	0	0	Only max. one jumper may be plugged in!
IRQ-4	=	0	0	X	0	0	0	
IRQ-5	=	0	0	0	X	0	0	
IRQ-6	=	0	0	0	0	X	0	
IRQ-7	=	0	0	0	0	0	X	


6 Functional modules in the Fieldbus system

6.2 FBK / Fieldbus nodes




**Pin configuration ST1 (9-pole)
RS 232/20 mA**

- 1 RX-
- 2 RXD
- 3 TXD
- 4 TX-
- 5 0 V / Screening
- 6 RX+
- 7 not in use
- 8 not in use
- 9 TX+



**Setting baud rate
Serial interface ST1**




6 Functional modules in the Fieldbus system

6.2 Fieldbus nodes Technical data

What the LED display means: Fieldbus errors	
Display:	possible causes of error:
off	- No error
on with short pauses	- Short circuit on the fieldbus - Driver board not available or faulty
regular blinking	- Operating system on the fieldbus interface card in the PC not started yet. - No connection via fieldbus cable - No terminating resistor connectors
4 x blinking	- Configuration does not match the connected modules. - Parallel bus cable not connected or faulty. - Parallel bus cable too long (malfunctions)

Addressing:		
Setting the node addresses via DIP switches / address 0 - 63		
Address	DIP switch no.	
	1 2 3 4 5 6	
0	0 0 0 0 0 0	X = DIP switch closed
1	X 0 0 0 0 0	0 = DIP switch open
2	0 X 0 0 0 0	
3	X X 0 0 0 0	
4	0 0 X 0 0 0	
5	X 0 X 0 0 0	
6	0 X X 0 0 0	
7	X X X 0 0 0	
...		
60	0 0 X X X X	
61	X 0 X X X X	
62	0 X X X X X	
63	X X X X X X	




Please note!

If only one fieldbus cable is connected to the fieldbus node, the terminating resistor connector (Art. no. 70-042 500) must be plugged into the free connection.

6 Functional modules in the Fieldbus system

6.3 FBUR / FBRR

Fieldbus universal controller / Fieldbus directional controller



FBUR:

With this version a maximum of 3 servo-drive or controlled fixed-speed axes can be traversed. (See Label EPROM)

FBRR:


With this version a maximum of 6 controlled fixed-speed axes can be traversed. (See Label EPROM)

Addressing:
Setting the node address via DIP switches / address 0 - 63

Address	DIP switch no.						X = DIP switch closed 0 = DIP switch open
	1	2	3	4	5	6	
0	0	0	0	0	0	0	
1	X	0	0	0	0	0	
2	0	X	0	0	0	0	
3	X	X	0	0	0	0	
4	0	0	X	0	0	0	
5	X	0	X	0	0	0	
6	0	X	X	0	0	0	
7	X	X	X	0	0	0	
...							
60	0	0	X	X	X	X	
61	X	0	X	X	X	X	
62	0	X	X	X	X	X	
63	X	X	X	X	X	X	

6 Functional modules in the Fieldbus system

6.4 FB-IN 16-2 Input module with 16 inputs (binary)



Technical data

Inputs:

All inputs metallically separated
 Maximum input voltage 30 V DC
 Current consumption per input c. 18 mA / 24 V

Input level:

High level > 19 V
 Low level < 3 V
 Time until input signal valid 100 µs


**If the input voltage is between 3 and 19 volts,
 the value read is not defined.**

AC voltage may not be connected!

6 Functional modules in the Fieldbus system

6.5 FBOUT-16

Output module with 16 outputs (binary)




Notice!

Every output is fitted with protection against short circuit and excess temperature. After a short circuit the control of the appropriate output must be reset. Only then is the output ready for operation again.

Technical data

Outputs:

Maximum switching voltage:	30 V DC
Minimum switching voltage:	19 V DC
Constant load per output:	1 A
Total constant load of board:	8 A
Peak load per output:	3 A / 10 sec. / 45° C ambient temperature



Description

The FB-IOT8 is a combined input/output module. The module has 8 inputs and 8 outputs at its disposal. All in- and outputs are metallurgically separated by optical isolators.

The outputs are short-circuit proof and protected against excess temperature.

After remedying a short circuit the output can only work normally again once the control has been reset.

The LEDs 1 ... 8

signal the status of the inputs.

The LEDs 9 ... 16

signal the status of the outputs.

ON = in-/outputs active

Technical data


Outputs:

Maximum switching voltage:	30 V DC
Minimum switching voltage:	19 V DC
Constant load per output:	1 A
Total constant load of card	8 A
Peak load per output:	3 A / 10 sec. / 45° C ambient temperature

Input level:

High level	> 19 V
Low level	< 3 V
Time until input signal is valid	100 µs

**If the input voltage is between 3 and 19 volts, the value read is not defined.
AC voltage may not be connected!**



Input 1

- Ter. 11 + 10 V / Output
- Ter. 12 Analog input 1 / - 10 V ... + 10 V
- Ter. 13 - 10 V / output
- Ter. 14 0 V / earth for input 1
- Ter. PE Screening for input 1

Input 2

- Ter. 21 + 10 V / output
- Ter. 22 Analog input 2 / - 10 V ... + 10 V
- Ter. 23 - 10 V / output
- Ter. 24 0 V / Earth for input 2
- Ter. PE Screening for input 2

Input 3

...

Input 4

...

Technical data


- | | |
|-----------------------|---|
| Analog inputs: | 4 channels |
| Input voltage range: | (- 10 V) to (+ 10 V) |
| Input resistance: | 20 KOhm |
| Analog converter: | 12 bit resolution / 4096 values = c. 5 mV |

The inputs are protected against overvoltage!

6 Functional modules in the Fieldbus system

6.9 FB-ANO

Module for 3 analog outputs



Technical data

The analog output module FB-ANO has 3 analog outputs at its disposal for controlling servo-controllers. The set values determined by the axis controller are output as analog voltages (-10 V to +10 V). In addition, one potential-free relay contact (controller enabling) is available for every channel.

Analog outputs

Output voltage range:	(- 10 V) to (+ 10 V)
D/A converter:	12 bit resolution / 4096 values = c. 5 mV
Output current:	5 mA
Short-circuit current:	40 mA


Relay contact

Switching power:	max. 10 Watt
Switching voltage:	max. 30 V
Switching current:	max. 0.5 A

6 Functional modules in the Fieldbus system

6.10 FB-SAE


Module for serial absolute encoders (SSI interface)



Description

The FB-SAE module is responsible for reading a maximum of 3 serial absolute encoders with SSI interface simultaneously.


- 1 Data input -
- 2 Data input +
- 3 Screening
- 4 Clock output -
- 5 Clock output +
- 6 + 24 V - Operating voltage for encoder
- 7 + 24 V - Operating voltage for encoder
- 8 0 V / GND
- 9 0 V / GND



6 Functional modules in the Fieldbus system


6.11 FB-INC-1

Module for reading an incremental encoder



ST 1: Incremental encoder

- 1 UA 2 / K2
- 2 UA 1 / K1
- 3 UA 0 / K0
- 4 0 V / GND
- 5 Screening
- 6 UA 2 / K2 / negative
- 7 UA 1 / K1 / negative
- 8 UA 0 / K0 / negative
- 9 +5 V



LED 1 (green) signals: Speed reduction for referencing switched on.
LED 2 (green) signals: Referencing = active


Jumper zero impulse

The zero impulse of the encoder can be interrupted by the two jumpers.
Both jumpers must always be opened or closed!

Both jumpers open: The counter is reset for every negative edge of the referencing input.

6 Functional modules in the Fieldbus system

6.12 FBIR / Interpolator for the CNC-Fieldbus system Module for connecting max. 6 controlled servo-axes



- Terminal 17: Earth GND
- Terminal 19: GND for sensors
- Terminal 3: Trigger input 0 (for distance measurement)
- Terminal 4: Trigger input 1 (for distance measurement)

- Terminal 16: + 24 V / Operating voltage lead
- Terminal 18: + 24 V / supply for sensors

- LED 1 (red) Display fieldbus errors (see page 6-15)
- LED 2 (green) Operating voltage
- LED 3 Trigger input 0 / Terminal 3
- LED 4 Trigger input 1 / Terminal 4

Addressing:
Setting of node address via DIP switch / address 0 - 63


Address	DIP switch no.	1	2	3	4	5	6
0		0	0	0	0	0	0
1		X	0	0	0	0	0
2		0	X	0	0	0	0
3		X	X	0	0	0	0
4		0	0	X	0	0	0
5		X	0	X	0	0	0
6		0	X	X	0	0	0
7		X	X	X	0	0	0
...							
60		0	0	X	X	X	X
61		X	0	X	X	X	X
62		0	X	X	X	X	X
63		X	X	X	X	X	X

X = DIP switch closed
0 = DIP switch open

6 Functional modules in the Fieldbus system

6.13 FBTRG

CNC-Fieldbus interface with 3 temperature control systems



Technical data

3 control systems for FeCuNi - Thermal elements

Effective range: 0 to 409.6° C
 Correcting variable outputs: 24V / DC / 500 mA
 Signal resolution: 12 Bit / 0.1°C / 10 mV for each °C

Card power consumption max. 600 mA

Terminal configuration

Terminal 3:	+ 24 V	Input temperature increase
Terminal 4:	+ 24 V	Input temperature decrease
Terminal 16:	+ 24 V	Operating voltage module
Terminal 17:	GND	Operating voltage
Terminal 18:	+ 24 V	Operating voltage pick-off for sensors
Terminal 19:	GND	For sensors

Connection FeCuNi - Thermal elements:

Terminal 20	PE bar connection / PE	
Terminal 21 / 22	Thermal element 1	Terminal 21 (-)
Terminal 31 / 32	Thermal element 2	Terminal 31 (-)
Terminal 41 / 42	Thermal element 3	Terminal 41 (-)
Terminal 45	Input controller enabling	
Terminal 46	+ 24 V for controller enabling	
Terminal 23 / 24	Corr. variable Th-1	Terminal 23 (+)
Terminal 33 / 34	Corr. variable Th-2	Terminal 33 (+)
Terminal 43 / 44	Corr. variable Th-3	Terminal 43 (+)
Terminal 48	+ 24 V / Operating voltage pick-off for controller enabling	
Terminal 49	GND	

LED 1 (red)
 Display fieldbus errors
 (see page 6-15)

LED 2 (green)
 Operating voltage

LED 3
 Enable, temperature increase
 Terminal 3


LED 4
 Enable, temperature decrease
 Terminal 4

LED 5
 Operating voltage for controller enabling

6 Functional modules in the Fieldbus system

6.14 FVI

Activation of Festo valve units with fieldbus connection



Addressing:
Setting the node address via DIP switch / address 0 - 63

Address	DIP switch no.						X = DIP switch closed 0 = DIP switch open
	1	2	3	4	5	6	
0	0	0	0	0	0	0	
1	X	0	0	0	0	0	
2	0	X	0	0	0	0	
3	X	X	0	0	0	0	
4	0	0	X	0	0	0	
5	X	0	X	0	0	0	
6	0	X	X	0	0	0	
7	X	X	X	0	0	0	
...							
60	0	0	X	X	X	X	
61	X	0	X	X	X	X	

Notice!
DIP switch 7 and DIP switch 8 are always set to 0!


What the fieldbus error display means (LED 1 red)

Display:	Possible causes of error:
Off	- No error
Steady flashing	- Operating system on the fieldbus interface card in the PC has not been started yet. - No connection via fieldbus cable - No terminator
flashes 4 x	- Configuration does not match the connected modules. - Parallel bus not connected or faulty. - Parallel bus cable too long (malfunctions)
flashes 7 x	- Error in initializing valve units type 03.
flashes 9 x	- Error in initializing valve units type 02.

6 Functional modules in the Fieldbus system

6.15 MPLI

Interface for connecting the Festo Multipol valve unit



Description

This module makes 24 switching outputs available.

These outputs are reserved especially as drivers for the Festo valve units.

These outputs do not have any internal protection against short circuit, excess temperature, overvoltage or switching peaks.

Special feature

In the fieldbus configuration this module is registered **twice with the ID number 6** (as FB-OUT 16). This module has two logical addresses in the fieldbus configuration. Exception: the module is in operation as the last parallel bus participant.


Please note!

If all 24 outputs are in operation, this module may only be connected to the Parallel bus as the 7th participant at the highest!

Technical data:

Max. switching voltage	30 V / DC
Min. switching voltage:	5 V / DC
Constant load per output:	120 mA
Peak load per output:	200 mA / 10 sec / 45° C ambient temperature
Total constant load of module:	2.4 A

The total constant load of 2.4 A may not be exceeded!
20 Outputs at 120 mA each = 2.4 A.



Description

With the repeater it is possible to realize a tree-shaped fieldbus topology. (see figure on the [next page](#)). The purpose of the fieldbus repeater is to branch and enlarge the maximum permitted cable lengths.

Max. cable lengths (for each fieldbus phase)

Baud rate:	
500 Kbit/sec.	70 Meter
250 Kbit/sec.	170 Meter
125 Kbit/sec.	350 Meter
62,5 Kbit/sec.	650 Meter


LED 1 ... 5	Error status display
LED 1 is on	Error on fieldbus connection 1
LED 2 is on	Error on fieldbus connection 2


The following table is valid only if LED 1 or LED 2 is on:

LED 3	LED 4	LED 5	
off	off	off	— Short circuit in the fieldbus cables after 5 V
off	off	on	— More than 32 telegrams with transmission error
off	on	off	— More than 32 telegrams with transmission error
off	on	on	— Short circuit in the fieldbus cables after 0 V
on	off	on	— ABUS not synchronized

6 Functional modules in the Fieldbus system

6.17 Diagram: Fieldbus system
Bus topology with repeater





LED 1 / green

LED 2 / red

LED 3 / red

Operating voltage available

Error diagnosis / CNC-Fieldbus
see Table **card FVI** = LED 1 (red)

Error diagnosis / is on if a profibus error
occurs

Description

The fieldbus bridge FBK_DP allows the exchange of information between the CNC-Fieldbus and the Profibus (Process-Field-Bus).


The configuration of this module is carried out via the Profibus-Master.

The address allocation for the CNC-Fieldbus is carried out via DIP switch S1.

The address allocation for the CNC-Fieldbus is carried out via DIP switch S2.

Pin configuration Profibus connection cable

- 1 NC / not connected
- 2 NC / not connected
- 3 RS 485 -B**
- 4 RTS (TTL level)
- 5 GND (metallically separated)
- 6 + 5 V (metallically separated)
- 7 NC / not connected
- 8 RS 485 -A**
- 9 NC / not connected



6 Functional modules in the Fieldbus system

6.18 FBK-DP

Fieldbus bridge: continued

Setting the address via DIP switches

DIP switch S1						
Addresses in the CNC-Fieldbus system / settable address range: 0 - 63						
Address	DIP switch no.					
	1	2	3	4	5	6
0	0	0	0	0	0	0
1	X	0	0	0	0	0
2	0	X	0	0	0	0
3	X	X	0	0	0	0
4	0	0	X	0	0	0
5	X	0	X	0	0	0
6	0	X	X	0	0	0
7	X	X	X	0	0	0
...						
60	0	0	X	X	X	X
61	X	0	X	X	X	X

X = DIP switch closed
0 = DIP switch open


DIP switch S2								
Addresses in the Profibus system / settable address range: 0 - 127								
Address	DIP switch no.							
	1	2	3	4	5	6	7	8
0	0	0	0	0	0	0	0	0
1	X	0	0	0	0	0	0	0
2	0	X	0	0	0	0	0	0
3	X	X	0	0	0	0	0	0
4	0	0	X	0	0	0	0	0
5	X	0	X	0	0	0	0	0
6	0	X	X	0	0	0	0	0
7	X	X	X	0	0	0	0	0
...								
124	0	0	X	X	X	X	X	0
125	0	X	X	X	X	X	X	0
126	X	0	X	X	X	X	X	0
127	X	X	X	X	X	X	X	0

X = DIP switch closed
0 = DIP switch open

Notice!
DIP switch 8 is
always set to 0!

6 Functional modules in the Fieldbus system

6.19 Bus topology with a bridge to the Profibus




FSTSTR30

6 Functional modules in the Fieldbus system

6.20 Connection configuration: DARC axis regulation controller

- 1 **X 20**
24 V power supply
- 2 **X 30**
Parallel bus
- 3 **X 1**
Peripheral devices and holding brake
 - 1 Temperature contact - motor
 - 2 Quick-stop - right
 - 3 Quick-stop - left
 - 4 Input - reference switch
 - 5 Input - trigger
 - 6 0 V - potential (24 V)
 - 7 + 24 V / line entry
 - 8 Holding brake - motor
 Protective circuit see [Appendix A.3](#)
- 4 **X 2**
Input resolver
Input protective circuit
see [Appendix A.3](#)
- 5 **X 3**
Input - OPTIONAL
for absolute position encoders
or incremental encoders
- 6 **X 4**
Test and diagnosis measuring point
- 7 **BTB: Operational display**
LED = ON
Axis reg. controller ready for operation
LED = OFF
Axis reg. controller not ready for operation


Enabling: Operational display
 LED = ON
 Pulse-controlled inverter = ON
 Axis enabled
 LED = OFF / axis disabled
- 8 **D.c. link**
PE / L+ / L-
Connection diagram see [Appendix A.3](#)
- 9 **X 5**
Motor connection
Connection diagram see [Appendix A.3](#)



6 Functional modules in the Fieldbus system

6.21 Connection configuration: DARC supply module

- 1 **X 20**
24 V power supply / DC
1 + 24 V
2 0 V
- 2 **X 30**
Parallel bus
- 3 **X 6**
Control in- and outputs
1 + 24 V / input
2 Ready for operation (BTB)
BTB output
3 External enabling signal (+ 24 V)
4 Trigger signal (+ 24 V)
5 0 V / earth
Protetive circuit see [Appendix A.3](#)
- 4 **Fieldbus LED**
Info about LED display
see [next page](#)
- 5 **X 7**
Service-interface
RS-232
Override potentiometer
- 6 **X 8 / OPTIONAL**
Input for absolute position encoder
or incremental encoder
- 7 **X 9 Measuring points**
Only for ferrocontrol service
- 8 **BTB; operational display**
LED - ON = ready for operation
LED - OFF = not ready
Uz; operational display
LED - ON =
D.c. link voltage im
set range
LED - OFF =
Over- or undervoltage
- 9 **D.c. link**
PE / L+ / L-
Connection diagram see [Appendix A.3](#)
- 10 **X 11**
Power connection
R1 - R2 = Braking resistance
D1 - D2 = D.c. link choke
Connection diagram see [Appendix A.3](#)
- 11 **X 10.1 / X 10.2**
CNC - Fieldbus connection
- 12 **S1- Module address**
DIP switch for setting
the module address



Notice! Altered marking sequence!

6 Functional modules in the Fieldbus system


6.21 DARC supply module

Operating display F-Bus (LED)

Operational display: Fieldbus LED	Status	Cause / Meaning
	ON	The operating software is being transferred to the axis regulation controller. If the LED doesn't go out, possibly a download error.
	OFF	No error, everything OK.
	ON (with short pauses)	a) Fieldbus transfer error b) Short circuit in the fieldbus c) Terminating resistor connector is missing
	Steady flashing	Fieldbus system not started yet. no connection via fieldbus cable
	4 x flashing, 1 x pause	Error in the parallel bus connector

7 Pin configuration


7.1 Encoder signal resolver - DARC input




Resolver

DARC input


View = solder side




Jack insert 12-pin
Type: IN92



View = crimp side




Jack insert sub-D 9-pin



Metallic casing
Screws = UNC thread

7 Pin configuration


7.2 Absolute position encoder - DARC input




Absolute position encoder

DARC input


View = solder side




Jack contact unit
7-pin



View = solder side




Pin contact unit
sub-D 9-pin



Metallic casing
Screws = UNC thread


7 Pin configuration

7.3 Incremental encoder -> DARC input Incremental encoder -> FB-INC




Incremental encoder

View = solder side




Jack contact unit 12-pin
Type: IN 101




DARC input and FB - INC

View = solder side




Pin contact unit
sub-D 9-pin



Metallic casing
Screws = UNC thread


7 Pin configuration

7.4 Incremental encoder distribution board -> DARC supply module




View = crimp side

View = crimp side




Sub-D 9-pin socket


View = solder side



Male connector




Metallic casing
Screws = UNC thread



Metallic casing
Screws = UNC thread


7 Pin configuration

7.5 Fieldbus cable ferrocontrol - CNC Fieldbus





8.0121.00.0


View of solder side



View of solder side




Male connector 5-pin



Pin contact unit sub-D 9-pin


7 Pin configuration

7.6 RS-232 interface cable / PC -> DARC supply module




PC

View = crimp side




Sub-D 9-pin socket




Metallic casing
 Screws = UNC thread

DARC supply module

View = crimp side








Sub-D 9-pin socket



Metallic casing
 Screws = UNC thread

7 Pin configuration

7.7 Connection: Override potentiometer Service cable: V24 for DARC supply module



7 Pin configuration


Space for your own notes

8 Cable lengths and transmission rate in the CNC-Fieldbus

8.1 Max. cable lengths


Baud rate:	Cable length (for each fieldbus phase)
500 Kbit/sec.	70 metres
250 Kbit/sec.	170 metres
125 Kbit/sec.	350 metres
62.5 Kbit/sec.	650 metres

By using an amplifier (repeater) you can increase the cable lengths!





8.0121.00.0


View of solder side




View of solder side



Male connector 5-pin



Male connector 5-pin



Pinconfiguration: CNC-Fieldbus connection

- 1 Rt + / terminator
Differential signal - positive
- 2 Fieldbus signal
Differential signal - negative
- 3 Screening
- 4 Fieldbus signal
Differential signal - positive
- 5 Rt - / terminator
Differential signal - negative

8 Cable lengths and transmission rate in the CNC-Fieldbus

8.2 Determining the length of the installed cables via the d.c. link resistance



Warning!

Only carry out this measurement when the power current (+ 24 V) is switched off!

If the error message

"58 fieldbus error in controller"

occurs very frequently in your system or transmission errors occur very often, you should definitely check the reliability performance of the fieldbus cables.

Frequent causes of malfunction are e.g.:

Line interruptions or short circuits on mobile (incorporated) cable routes, whereby the error can only appear briefly (according to the cable position)

"Cold junction", e.g. at plug-in connectors

Transmission rate too high for the appropriate cable length (see [Table 8.1](#)).


In many cases determining the d.c. link resistance to a restriction of the cause of the fault.

The following figures refer to the fieldbus with the ferrocontrol article no.: 70-041 000. The specific d.c. link resistance of this cable is 0.077 ohms/metre.

Cable length	D.c. link resistance
70 metres	c. 11 ohms / pin 2 - 4
170 metres	c. 26 ohms / pin 2 - 4
350 metres	c. 54 ohms / pin 2 - 4

These figures refer to the return journey. Between pin 2 and 3 or pin 4 and 3 check the connections to the screen conductor.


This measurement can be made between the two ends of the complete fieldbus phase.




9 The industrial PC

9.1 Model range 1.4 (3.4) and 1.3 (3.3) 9.1.1 Device view

Model: 1.4 (1.3)



Model: 3.4 (3.3)




9 The industrial PC

9.1 Model range 1.4 (3.4) and 1.3 (3.3)

9.1.2 External pin configuration


Version 1.3 / 3.3



If only one fieldbus channel is in use, a terminating resistor connector (Art. no. 70-042500) must be plugged into the free channel!

- 1 LPT 1**
Parallel interface for printer connection
- 2 Com 2 / RS 232**
Serial interface for e.g. modem
- 3 External monitor (VGA)**
- 4 Com 1 / RS 232**
for e.g. mouse
- 5 2 free plug-in stations** for additional functions
e.g. interface RS 485
- 6 OPTION / not in use**
- 7 Fieldbus connection / channel 1**
- 8 Fieldbus connection / channel 2**
(with terminating resistor connector)
- 9 Watchdog output**
potential-free contact,
max. contact load: 30 Volt/0.5 A/ 10 W

Version 1.4 / 3.4




If only one fieldbus channel is in use, a terminating resistor connector (Art. no. 70-042500) must be plugged into the free channel!

- 1 COM 1 / RS 232**
Serial interface
- 2 COM 2 / RS 232**
Serial interface for e.g. modem
- 3 PS/2 Mouse**
- 4 External monitor (VGA)**
- 5 2 free plug-in stations** for additional functions
e.g. interface RS 485
- 6 OPTION / not in use**
- 7 Fieldbus connection / channel 1**
- 8 Fieldbus connection / channel 2**
(with terminating resistor connector)
- 9 Watchdog output**
potential-free contact,
max. contact load: 30 Volt/0.5 A/ 10 W
- 10 LPT 1**
Parallel interface for printer connection

9.1 Model range 1.4 (1.3) / 3.4 (3.3)
9.1.3 PC plug-in unit, installation and removal

The model range 1.4 (1.3) / 3.4 (3.3) is based on a particularly service-friendly concept.




For servicing the computer chassis can be easily removed from the faceplate.

The faceplate does not have to be dismantled.

Dismantling the computer chassis:

- 1. Unsrew the 4 knurled screws (A)
- 2. Carefully remove the chassis from its locking element with both hands.




 **Notice!**

In case of malfunctions in the input keyboard or in the display, the complete faceplate is exchanged!


9 The industrial PC

9.1 Model range 1.4 (1.3) / 3.4 (3.3)

9.1.4 Interior view




9.1.5 CPU card PC version: 1.3 / 3.3




9 The industrial PC

9.1 Model range 1.4 (1.3) / 3.4 (3.3)

9.1.6 CPU card / Intel-Pentium / PC version: 1.4 (3.4)



CPU card rear view



9 The industrial PC

9.2 Model range 1.2


9.2.1 Device view

Model: 1.2
Front view


Mounting depth: 180 mm

Nameplate
Serial no.

Disk drive
3.5" (1.44 MB)



Connection for additional
keyboard
PC - AT / plug = DIN




Model: 1.2
rear view

Fan

Nameplate
Serial no.

Disk drive
3.5" (1.44 MB)




When making service enquiries or ordering spare parts please state the full type designation and serial number.

9.2.2 External pin configuration

Device view from below:

- 1 Keyboard connection (external)**
PC-AT / DIN plug
- 2 Connection for internal keyboard**
DIN plug
- 3 COM 2**
Serial interface / RS-232
Plug depending on version
SUB-D 25-pin or SUB-D 9-pin
Application:
e.g.: modem or printer (serial)
- 4 COM 1**
Serial interface / RS-232
Plug depending on version
SUB-D 25-pin or SUB-D 9-pin
Application:
mouse or printer (serial)
- 5 LPT1**
Parallel interface
Standard printer connection
- 6 OPTION / not in use**
- 7 Fieldbus connection / channel 1**
- 8 Fieldbus connection / channel 2**
- 9 Watchdog output**
potential-free contact




9.2.3 Industrial PC: removing

When repairing the industrial PC (version 1.2), the complete device must be removed from the mounting frame.

Proceed as follows:


1. Switch the device off.
2. Disconnect all connecting cables:
 - mains power supply
 - interface cables
 - fieldbus connection
 - protective conductor terminal
3. Unscrew the 10 fixing screws.
4. Pull the device carefully out of the mounting frame to the front.



9 The industrial PC

9.2 Model range 1.2

9.2.4 Interior view



Notice!

If malfunctions in the industrial PC occur, always check the operating voltage first! To do this you only need to remove the housing rear panel (12). You now have access to the terminal block.

1 Operational voltage connection
for the mother board

2 Display:
if malfunctions occur the complete unit is exchanged

2a Voltage transformer for display

3 Controller unit
for the internal keyboard

4 Disk drive
3.5" / 1.44 MByte

5 Accumulator 3.6 V / soldered in

6 I/O card
IDE hard disk controller
Controller for disk drive
RS 232: COM 1/Com 2
Parallel interface: LPT 1

7 Fieldbus interface card / FBI_PC

8 Graphic card
Connection for LCD / TFT screen
Connection VGA monitor (external)

9 Hard disk drive / IDE

10 Power supply unit module
+/- 5 Volt; +/- 12 Volt
see also **Pos. 1**
Operational voltage connection


11 Mains power supply

12 Housing rear panel
(can be removed separately)


9.2.5 Dismantling PC chassis

If you want to exchange components in the PC, proceed as follows:

- 1. Place the PC unit (with the front panel) carefully on a fixed base (table-top). In order to avoid scratches on the front of the device, use a piece of cardboard or a woollen blanket as a mat.
- 2. Carefully remove the PC chassis and place it on the device frame (as shown in the diagram opposite).



9.2.6 PC main board




View: Mylex board

9 The industrial PC


9.3 Model range 1.1

9.3.1 Device view

Model: 1.1
Front view



Model: 1.1
rear view




When making service enquiries or ordering spare parts please state the full type designation and serial number.

9.3.2 External pin configuration

Device view from below:

- 1 **VGA monitor** / external
- 2 **LPT1**
Parallel interface
Standard printer connection
- 3 **COM 2**
Serial interface RS-232
Plug: SUB-D 9-pin
Application:
modem or printer (serial)
- 4 **COM 1**
Serial interface RS-232
Plug SUB-D 9-pin
Application:
mouse or printer (serial)
- 5 **Connection for the internal keyboard**
Mini-DIN plug (6-pin)
- 6 **Fan**
- 7 **Mains power supply**
- 8 **Free plug-in station/ ISA-AT**
- 9 **Fieldbus controller**
- 9a **OPTION / not in use**
- 9b **Fieldbus connection** / channel 2
- 9c **Fieldbus connection**/ channel 1
- 9d **Watchdog output**
potential-free contact




9.3.3 Industrial PC: removing

When repairing the industrial PC (version 1.2), the complete device must be removed from the mounting frame.

Proceed as follows:

1. Switch the device off.
2. Disconnect all connecting cables:
 - mains power supply
 - interface cables
 - fieldbus connection
 - protective conductor terminal
3. Unscrew the 10 fixing screws.
4. Pull the device carefully out of the mounting frame to the front.




9 The industrial PC

9.3 Model range 1.1

9.3.4 Interior view

Fig. 1: Battery connection



- | | |
|--|--|
| 1 Display unit / complete | 6 Hard disk (IDE)
including mounting bracket |
| 2 Coupling rod
switching - power supply unit | 7 Main board / Compac |
| 3 Electronics for internal key set | 8 Power supply unit / Compac |
| 4 Casing shell | 9 Battery / or accumulator
soldered to main board
(see also 9.3.6 Battery change) |
| 5 Mounting location / new
for spare battery
(see also 9.3.6 Battery change) | 10 Mounting location for the battery
(first fitting) |
| | 11 PC chassis / complete |

9.3.5 Opening the device, dismantling the PC chassis:

If you want to exchange components in the PC, proceed as follows:

1. Place the whole PC unit on a suitable pad.
2. Unscrew the screws on the rear side of the PC chassis (11).
3. Carefully rotate the chassis out to the rear (see diagram).
Be careful of cable connections!

9.3.6 Battery change

Notice!

The PC version 1.1 was delivered with different main boards. Some of these boards are fitted with an NC accumulator (soldered in). If an error occurs the soldered-in accumulator can be switched off via a plug-in jumper (see Fig. 1). Switching to battery or accumulator mode. **The appropriate spare battery (3.6 V) is plugged in via a lead.**

When carrying out repairs (on location) never do any soldering on the main board! Consult our customer services!

Access to the battery is blocked by the hard disk mounting bracket.

When changing the battery proceed in the following way:

1. Remove the coupling rod from its locking element (**Pos. 2**).
2. Unscrew the **two** screws holding the hard disk mounting bracket (**Pos. 6**).
3. Before removing the hard disk, disconnect the two plug-in connectors for the data line and the power supply from the hard disk.
4. Remove the hard disk together with the mounting bracket. The main board is now accessible.

5. Before connecting the new battery:

Check ...

whether the main board is switched to battery or accumulator mode.

Correct, if necessary...

the plug-in jumper on the contact bank **P9** (only main board with 386-CPU) or the plug-in jumper **J 52** (only for the main board with 486-CPU).

Info: see [Fig. 1 / Battery connection](#).

6. Connect the battery connector to the contact bank (**P-10**) (**red = +**).
7. Fix the new battery (with a Velcro fastening) to the hard disk mounting bracket (**Pos. 5**).

After changing the battery, check:

- the entries in the BIOS-Setup (configuration - hard disk etc.)
- the system time




Only use lithium batteries with 3.6 V nominal voltage.

9 The industrial PC

9.3 Model range 1.1

9.3.7 Replacing bulbs in the display unit



- 1 Display unit / complete
- 2 Lead strips covering the fluorescent tube
- 3 Bulb / fluorescent tube
- 4 Casing shell

Proceed as follows:

- A Undo the screws of the casing shell.
Pull the casing shell a few centimetres to the front.
Be careful of the cable connections!
- B Open the locking element of the lead strip with a screwdriver (Pos. 2).
- C Pull the lead strip (Pos. 2) sideways out of its guides.
- D Carefully remove the bulb (fluorescent tube).
Carefully disconnect the electrical connection.

Insert the new bulb in reverse order.



When making service enquiries or ordering spare parts please state the full type designation and serial number.

A

Axis equipment a. parameters 5-5

Axis status

Operating status 1 5-17

B

Battery <--> accumulator mode

PC-Model 1.1 9-12

Battery change

PC-Model range 1.1 9-13

Baudrate -> cable length 8-1

Brake holding time 5-5

Bulb (fluorescent tube) for Display:

replacing / PC-Model 1.1 9-14

C

CNC-fieldbus connection 6-1

Computer chassis, dismantling

PC model 1.4 (3.4) 9-3

Connection configuration

DARC axis regulation controller 6-22

DARC supply module 6-23

Connection FeCuNi - Thermal elements: 6-14

Connection for additional keyboard 9-1

Connection: Override-potentiometer 7-7

D

Disc drive 9-1

Display:

Error status axis 3-2, 4-12

Operating status axis 3-2, 4-6

E

Encoder offset,

enter 5-6

Error status 1 5-17

Error status 2 5-17

Error status:

Axis 4-12

Motor controller 4-14, 4-15

F

Festo Multipol valve unit 6-16

Fieldbus connection:

Channel 1 6-1

Channel 2 6-1

Fieldbus nodes
 Addressing
 Fieldbus-errors (LED) 6-3
Fieldbus:
 Differential signal -negative 6-1, 8-1
 Differential signal -positive 6-1, 8-1
 Interface card 6-1
 Repeater 6-17

I

Inching mode 5-19
Incremental encoder:
 Connector configuration 6-12
 Jumper zero impulse 6-12
INIT-status,
 Hardware configuration 5-17
Interface:
 for connecting the Festo Multipol valve 6-16

M

Max. cable lengths
 (for each fieldbus phase) 6-17
Messages from the axis controller 4-6
Module addressing 5-3

N

Nameplate 9-1

O

Operating status 1 5-17
Operating status 2 5-17
Operating status:
 Axis 4-8
 Motor controller 4-16
Operating voltage connection
 PC-Model 1.2 9-8
Override potentiometer 6-13

P

Password, enter 1-2
Position control:
 ON / OFF 5-19
Profi-Bus
 Pin configuration connection cable 6-19
Profi-Bus:
 Bridge: CNC-Fiedbus -> Profibus 6-19
Profile generator 5-17

R

Referencing, perform 5-19

Resolver adjustment 5-18

S

Select axis 5-4

Serial no. 9-1

SSI interface 6-11

 Absolut encoder 6-11

 connector (pin configuration) 6-11

Status display:

 Input 5-1

 Output 5-2

Status motor controller 5-17

T

Terminator Differential signal - positive 6-1

Terminator Differential signal- negative 6-1

Test & Diagnostic (ATEST)

 direct access 2-1

TOGGLE 5-2

Traversing speed in inching mode 5-19

V

Variant names

 ... in older software versions 5-17

W

Watchdog output 6-1

Appendix


A.2 Overview of ferrocontrol documentation

Curr. no	Document no.	Description	Language	Status
1	96-050 500	CNC-Feldbus: Gerätebeschreibung	German	3/95
2	96-100 500	DARC Handbuch: Inbetriebnahme / Service	German	9/97
3	96-101 000	DARC Service Manual	English	9/97
4	96-102 000	RS-232-Schnittstellenbeschreibung / DARC Protokoll RS 232	German	
5	96-100 501	DARC Produktdokumentation	German	
6	96-401 000	DARC-System, Inbetriebnahme- Hardware	German	
7	96-510 000	ferrocontrol CNC-Feldbus / Teil: Gerätebeschreibung	German	
8	96-511 000	ferrocontrol CNC-Feldbus / Appliance Description	English	
9	96-520 500	ferrocontrol CNC-Feldbus / Teil: Inbetriebnahme/ Service	German	3/95
10	96-521 000	ferrocontrol CNC-Feldbus: Commissioning / Service	English	3/95
11	96-600 500	ferrocontrol Industrie-PC 1.2 (FIPC-1.2)	German	10/94
12	96-601 000	The ferrocontrol Industrial PC 1.2 (FIPC-1.2)	English	
13	96-700 500	Bedienfeld mit Anzeige TSED-RS485	German	
14	97-400 500	Einführung ferrocontrol-Bedienoberflächen	German	
15	97-400 600	Description of PC-Software (ferrocontrol User Interfaces)	English	
16	97-400 700	Introduction: InterfacesUtilisateur ferrocontrol	French	
17	97-500 500	Benutzer- u. Referenzhandbuch / Applikationsgenerator	German	
18	97-501 000	User and Reference Manual / Application Generator	English	
19	97-550 500	Programmierhandbuch FPS	German	
20	97-551 000	Programming Manual PLC	English	
21	97-880 500	Doppeldiagonalsäge mit DARC	German	
22	97-881 000	Tandem Diagonal Saw with DARC	English	
23		DARC mit Verbundachsen	German	
24	96-051 000	ferrocontrol MAS: Systemhandbuch-Hardware	German	
25	97-053 500	ferrocontrol MAS: Systemhandbuch-Software	German	
26	96-800 500	MAG-System: Inbetriebnahme/Service	German	
27	96-801 000	MAG-System: Gerätebeschreibung	German	
28	97-051 000	DARC-System: Software SeleCAN	German	
29	97-051 500	DARC-System: Software CANopen	German	
30	97-052 000	DARC-System: Software Profibus-DP	German	
31	97-052 500	DARC-System: Programmierung	German	
32	97-053 000	DARC-System: Inbetriebnahme DARCTOOL	German	
33	96-031 000	Quick-Referenzhandbuch für das ferrocontrol Feldbussystem (Hilfestellung zur Störungsbeseitigung)	German	8/98
34	96-032 000	Quick-reference Manual for the ferrocontrol Fieldbus System (Tips for Trouble-shooting)	English	9/98

A.3 Connection diagram: DARC system

①	Fieldbus connection	Terminal 10
②	PE terminal power supply	Terminal X 11
③	Mains supply / fusing	Terminal X 11
④	Mains contactor	Terminal X 11
⑤	Braking resistor	Terminal X 11
⑥	D.c. link filter choke	Terminal X 11
⑦	Service connector, 9-pin sub-D socket	Terminal X 7
⑧	24 V / DC power supply for internal signal processing	Terminal X 20
⑨	Parallel bus connector	Terminal X 30
⑩	Terminating resistor connector, bus connector	Terminal X 30
⑪	D.C. link bridges	Terminal L+, L-, PE
⑫	Control in- and outputs	Terminal X 6
⑬	Auxiliary relay, power BTB (ready for operation)	Terminal X 6
⑭	Enabling	Terminal X 6
⑮	24 V DC (trigger signal)	Terminal X 6
⑯	Resolver	Terminal X 2
⑰	Resolver connector, resolver cable	Terminal X 2
⑱	Servo-motor temperature monitoring	Terminal X 1 /1
⑲	Holding brake	Terminal X 1 /8
⑳	Peripheral devices and holding brake	Terminal X 1
㉑	Motor cable screening	Terminal X 1
㉒	Quick-stop switch - clockwise rotation	Terminal X 1 /2
㉓	Quick-stop switch - anticlockwise rotation	Terminal X 1 /3
㉔	Reference point switch	Terminal X 1 /4
㉕	Trigger switch	Terminal X 1 /5

A.3 Connection diagram: DARC system



Attention!
 For brake release current > 1A use coupling- or contactor relay!
 Connect a medium time-lag fuse = 1 A in series.

8.0011.00.1

hier abtrennen